



Junos[®] OS

Flow-Based and Packet-Based Processing Feature Guide for Security Devices

Release

15.1X49-D30



Modified: 2016-06-12

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Junos[®] OS Flow-Based and Packet-Based Processing Feature Guide for Security Devices
15.1X49-D30
Copyright © 2016, Juniper Networks, Inc.
All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

About the Documentation	xvii
Documentation and Release Notes	xvii
Supported Platforms	xvii
Using the Examples in This Manual	xvii
Merging a Full Example	xviii
Merging a Snippet	xviii
Documentation Conventions	xix
Documentation Feedback	xxi
Requesting Technical Support	xxi
Self-Help Online Tools and Resources	xxi
Opening a Case with JTAC	xxii

Part 1

Overview

Chapter 1

Introduction to Processing on Security Devices 3

Juniper Networks Devices Processing Overview	3
Understanding Flow-Based Processing	4
Zones and Policies	5
Flows and Sessions	5
Understanding Packet-Based Processing	5
Configuring Packet-Based Processing	6
Stateless Firewall Filters	6
Class-of-Service Features	6
Screens	7
Understanding SRX Series Services Gateways Central Point Architecture	7
Load Distribution in Combo Mode	8
Sharing Processing Power and Memory in Combo Mode	8
Understanding Enhancements to Central Point Architecture for the SRX5000 Line	9
SRX5000 Line Devices Processing Overview	10
Understanding First-Packet Processing	11
Understanding Fast-Path Processing	12
Understanding the Data Path for Unicast Sessions	13
Session Lookup and Packet-Match Criteria	13
Understanding Session Creation: First-Packet Processing	13
Understanding Fast-Path Processing	16
Understanding Services Processing Units	19
Understanding Scheduler Characteristics	19
Understanding Network Processor Bundling	19
Network Processor Bundling Limitations	19

	SRX3000 Line and SRX1400 Devices Processing Overview	20
	Components Involved in Setting Up a Session	21
	Understanding the Data Path for Unicast Sessions	21
	Session Lookup and Packet Match Criteria	22
	Understanding Session Creation: First Packet Processing	22
	Understanding Fast-Path Processing	24
	SRX210 Services Gateway Processing Overview	24
	Understanding Flow Processing and Session Management	24
	Understanding First-Packet Processing	25
	Understanding Session Creation	25
	Understanding Fast-Path Processing	25
Part 2	Configuring Flow-Based Sessions	
Chapter 2	Configuring Security Flow Sessions	29
	Understanding Session Characteristics for SRX Series Services Gateways	29
	Understanding Aggressive Session Aging	30
	Example: Controlling Session Termination for SRX Series Services Gateways	30
	Understanding TCP Session Checks per Policy	32
	Example: Disabling TCP Packet Security Checks for SRX Series Services Gateways	33
	Example: Setting the Maximum Segment Size for All TCP Sessions for SRX Series Services Gateways	34
	Example: Configuring TCP Packet Security Checks Per Policy	36
	Configuring the Timeout Value for Multicast Flow Sessions	37
	Clearing Sessions for SRX Series Services Gateways	39
	Terminating Sessions for SRX Series Services Gateways	39
	Terminating a Specific Session for SRX Series Services Gateways	39
	Using Filters to Specify the Sessions to Be Terminated for SRX Series Services Gateways	39
Part 3	Improving Flow-Based Performance	
Chapter 3	Expanding Session Capacity by Device	43
	Expanding Session Capacity by Device	43
	Expanding Session Capacity on an SRX3400 or SRX3600 Device	44
	Reverting to Default Session Capacity on an SRX5800 Device	44
	Verifying the Current Session Capacity	44
Chapter 4	Managing Sessions and Flow Distribution	47
	Understanding Load Distribution in High-End SRX Series Devices	47
	Hash-Based Forwarding on the SRX5K-MPC, SRX5K-MPC3-40G10G (IOC3), and the SRX5K-MPC3-100G10G (IOC3)	47
	Understanding Load Distribution on SRX5000 Line Devices Using the Packet-Ordering Function	49
	Disabling Packet-Ordering Mode on SRX5000 Line Devices	50

Chapter 5	Reducing Long Packet-Processing Latency by Express Path	53
	Understanding Session Cache	53
	Overview	53
	Selective Session Cache Installation	55
	IPsec VPN Session Affinity Enhancement Using Session Cache	56
	Fragmentation Packet Ordering Using NP Session Cache	56
	Express Path Overview	57
	Understanding Express Path Functionality	57
	Understanding Express Path Support on SRX Series Devices	58
	Express Path Support on NP-IOC Card	59
	Express Path Support on SRX5K Modular Port Concentrator	60
	Express Path Support on SRX5K-MPC3-100G10G (IOC3) and SRX5K-MPC3-40G10G (IOC3)	61
	Understanding Express Path Features	63
	Wing Statistics Counter	63
	Cross-Network Traffic	64
	LAG Support in Express Path Mode	65
	End-to-End Debugging	66
	Per-Session Statistics CLI	67
	Disabling TCP Packet Security Checks	68
	Express Path Limitations	68
	Understanding the Express Path Solution	69
	Enabling and Disabling Express Path	70
	Example: Enabling Express Path in Security Policies	72
	Example: Configuring an NPC on SRX3000 Line Devices or SRX1400 Devices to Support Express Path	74
	Example: Configuring an IOC on SRX5000 Line Devices to Support Express Path	75
	Example: Configuring an NP-IOC on SRX3000 Line Devices or SRX1400 Devices to Support Express Path	77
	Example: Configuring an SRX5K-MPC on an SRX5000 Line Device to Support Express Path	78
	Example: Configuring SRX5K-MPC3-100G10G (IOC3) and SRX5K-MPC3-40G10G (IOC3) on an SRX5000 Line Device to Support Express Path	81
	Example: Configuring Low Latency	83
Part 4	Managing Flow-Based Processing for IPv6	
Chapter 6	Enabling IPv6 Flow-Based Processing	89
	IPv6 Advanced Flow	89
	Understanding Sessions for IPv6 Flows	90
	Understanding IPv6 Flow Processing on High-End SRX Series Devices	91
	Enabling Flow-Based Processing for IPv6 Traffic	94
	Using Filters to Display IPv6 Session and Flow Information for SRX Series Services Gateways	95
Chapter 7	Managing IPv6 Packets	101
	The IPv6 Packet Header and SRX Series Overview	101
	About the IPv6 Basic Packet Header	102

	Understanding IPv6 Packet Header Extensions	103
	About IPv6 Packet Header Verification Performed by the Flow Module for SRX Series Devices	105
	Understanding Path MTU Messages for IPv6 Packets	105
	Understanding How SRX Series Devices Handle Packet Fragmentation for IPv6 Flows	107
	Understanding How SRX Series Devices Handle ICMPv6 Packets	107
Chapter 8	Configuring IPv6 Dual-Stack	109
	Understanding IPv6 Dual-Stack Lite	109
	Example: Configuring IPv6 Dual-Stack Lite	112
Part 5	Monitoring Flow-Based Sessions	
Chapter 9	Monitoring Security Flow Sessions	117
	Monitoring Security Flow Sessions Overview	117
	Understanding How to Obtain Session Information for SRX Series Services Gateways	118
	Displaying Global Session Parameters for All SRX Series Services Gateways	120
	Displaying a Summary of Sessions for SRX Series Services Gateways	121
	Displaying Session and Flow Information About Sessions for SRX Series Services Gateways	121
	Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways	122
	Using Filters to Display Session and Flow Information for SRX Series Services Gateways	123
	Information Provided in Session Log Entries for SRX Series Services Gateways	123
Chapter 10	Monitoring X2 Traffic By Configuring Mirror Filters	129
	Understanding X2 Traffic Monitoring	129
	X2 Traffic Monitoring Overview	129
	Limitations of X2 Traffic Monitoring	131
	X2 Traffic Terminology	131
	Example: Configuring Mirror Filters for X2 Traffic Monitoring	132
Part 6	Configuring Packet-Based Forwarding	
Chapter 11	Configuring Selective Stateless Packet-Based Services	139
	Understanding Packet-Based Processing	139
	Understanding Selective Stateless Packet-Based Services	140
	Selective Stateless Packet-Based Services Configuration Overview	142
	Example: Configuring Selective Stateless Packet-Based Services for End-to-End Packet-Based Forwarding	144
	Example: Configuring Selective Stateless Packet-Based Services for Packet-Based to Flow-Based Forwarding	154

Part 7	Configuration Statements and Operational Commands	
Chapter 12	Configuration Statements	165
	Chassis Configuration Statement Hierarchy	167
	Security Configuration Statement Hierarchy	170
	[edit security flow] Hierarchy Level	171
	[edit security forwarding-process] Hierarchy Level	172
	aging	173
	all-tcp	174
	allow-dns-reply	174
	allow-embedded-icmp	175
	application-services (Security Forwarding Process)	176
	apply-to-half-close-state	177
	ethernet-switching	178
	destination-header	179
	destination-port (Security Forwarding Options)	180
	destination-prefix (Security Forwarding Options)	184
	early-ageout	184
	fin-invalidate-session	185
	force-ip-reassembly	185
	forwarding-process	186
	fru-poweron-sequence	187
	gre-in	188
	gre-out	189
	high-watermark	189
	hop-by-hop-header	190
	icmpv6-malformed	191
	inline-tap	191
	interface-in (Security Forwarding Options)	192
	interface-out (Security Forwarding Options)	192
	ipv4-template (Services)	192
	ipv6-extension-header	193
	ipv6-extension-header-limit	194
	ipv6-malformed-header	194
	ipv6-template (Services)	195
	low-latency	195
	low-watermark	196
	maximize-idp-sessions	196
	mirror-filter (Security Forwarding Options)	197
	mode (Security Forwarding Options)	198
	no-sequence-check	199
	no-tcp-reset	199
	output (Security Forwarding Options)	200
	packet-filter	201
	packet-ordering-mode (Application Services)	202
	pending-sess-queue-length	203
	propagate-settings	203
	protocol (Security Forwarding Options)	204
	resource-manager	205

	route-change-timeout	205
	rst-invalidate-session	206
	rst-sequence-check	206
	sampling	207
	services-offload	208
	np-cache (Flexible PIC Concentrator)	209
	source-port (Security Forwarding Options)	210
	source-prefix (Security Forwarding Options)	214
	syn-flood-protection-mode	214
	tcp-initial-timeout	215
	tcp-mss (Security Flow)	216
	tcp-session	217
	time-wait-state	218
	traceoptions (Security)	219
	traceoptions (Security Flow)	221
	transport (Security Log)	224
	weight (Security)	225
Chapter 13	Operational Commands	227
	clear firewall	230
	clear monitor security flow filter	231
	clear security flow ip-action	232
	clear security flow session all	234
	clear security flow session application	235
	clear security flow session destination-port	237
	clear security flow session family	239
	clear security flow session interface	240
	clear security flow session protocol	242
	clear security flow session resource-manager	244
	clear security flow session services-offload	245
	clear security flow session session-identifier	248
	clear security flow session source-port	249
	clear security flow session source-prefix	251
	clear security forward-options mirror filter	253
	monitor security flow file	254
	monitor security flow filter	256
	monitor security flow start	258
	monitor security flow stop	259
	show chassis environment (Security)	260
	show chassis fpc (View)	264
	show chassis hardware (View)	274
	show chassis pic (Security)	303
	show chassis power	305
	show chassis power sequence	307
	show firewall (View)	308
	show interfaces (View Aggregated Ethernet)	310
	show interfaces (SRX Series)	320
	show interfaces diagnostics optics	335
	show interfaces flow-statistics	340

show interfaces statistics (View)	345
show interfaces swfabx	346
show monitor security flow	347
show security flow cp-session	349
show security flow cp-session destination-port	353
show security flow cp-session destination-prefix	355
show security flow cp-session family	357
show security flow cp-session protocol	359
show security flow cp-session source-port	362
show security flow cp-session source-prefix	364
show security flow gate	366
show security flow ip-action	370
show security flow gate brief node	378
show security flow gate destination-port	384
show security flow gate destination-prefix	387
show security flow gate protocol	390
show security flow gate summary node	393
show security flow session	398
show security flow session brief node	404
show security flow session destination-port	408
show security flow session destination-prefix	412
show security flow session extensive node	416
show security flow session family	422
show security flow session interface	427
show security flow session nat	431
show security flow session policy-id	434
show security flow session protocol	437
show security flow session resource-manager	442
show security flow session services-offload	446
show security flow session session-identifier	451
show security flow session source-port	455
show security flow session source-prefix	459
show security flow session summary family	463
show security flow session summary node	465
show security flow session summary services-offload	471
show security flow session tunnel	475
show security flow statistics	481
show security flow status	483
show security forward-options mirror-filter	486
show security monitoring	488
show security policies	490
show security policies hit-count	498
show security resource-manager group active	501
show security resource-manager resource active	504
show security resource-manager settings	507
show security resource-manager summary	509
show security screen ids-option	510
show security screen statistics	515
show security softwires	523

show security zones	524
show security zones type	527

Part 8

Index

Index	533

List of Figures

Part 1	Overview	
Chapter 1	Introduction to Processing on Security Devices	3
	Figure 1: Traffic Flow for Flow-Based Processing	4
	Figure 2: First-Packet Processing	11
	Figure 3: Fast-Path Processing	12
	Figure 4: Session Creation: First-Packet Processing	16
	Figure 5: Packet Walk for Fast-Path Processing	18
Part 3	Improving Flow-Based Performance	
Chapter 5	Reducing Long Packet-Processing Latency by Express Path	53
	Figure 6: IOC3 Intra-PFE Express Path	62
	Figure 7: IOC3 Inter-PFE Express Path	62
	Figure 8: Inter-IOC3 Express Path	63
Part 4	Managing Flow-Based Processing for IPv6	
Chapter 8	Configuring IPv6 Dual-Stack	109
	Figure 9: DS-Lite NAT (IPv4-in-IPv6)	110
Part 5	Monitoring Flow-Based Sessions	
Chapter 10	Monitoring X2 Traffic By Configuring Mirror Filters	129
	Figure 10: SRX Series Device in an LTE Mobile Network	130
	Figure 11: Monitoring X2 Traffic	130
	Figure 12: Configuring Mirror Filters for X2 Traffic Monitoring	132
Part 6	Configuring Packet-Based Forwarding	
Chapter 11	Configuring Selective Stateless Packet-Based Services	139
	Figure 13: Traffic Flow for Packet-Based Forwarding	139
	Figure 14: Traffic Flow with Selective Stateless Packet-Based Services	141
	Figure 15: Intranet Traffic Using End-to-End Packet-Based Services	145
	Figure 16: Selective Stateless Packet-Based Services for Packet-Based Forwarding	155

List of Tables

	About the Documentation	xvii
	Table 1: Notice Icons	xix
	Table 2: Text and Syntax Conventions	xix
Part 1	Overview	
Chapter 1	Introduction to Processing on Security Devices	3
	Table 3: Combo Mode Processing	8
Part 3	Improving Flow-Based Performance	
Chapter 3	Expanding Session Capacity by Device	43
	Table 4: Maximum Central Point Session Increases	43
Chapter 5	Reducing Long Packet-Processing Latency by Express Path	53
	Table 5: Session Cache Installation Bars	55
	Table 6: Session Cache Table Utilization Bits Status	56
	Table 7: Express Path Support on SRX Series Device Cards	58
	Table 8: Total Number of Sessions per Wing in Network Processor Express Path Configuration Mode	64
Part 4	Managing Flow-Based Processing for IPv6	
Chapter 6	Enabling IPv6 Flow-Based Processing	89
	Table 9: Device Status Upon Configuration Change	95
Chapter 7	Managing IPv6 Packets	101
	Table 10: IPv6 Extension Headers	104
	Table 11: ICMPv6 Packets That Junos OS Handles Differently from Other ICMPv6 Packets	108
Chapter 8	Configuring IPv6 Dual-Stack	109
	Table 12: Softwire Initiator and Softwire Concentrator Capacity	111
Part 5	Monitoring Flow-Based Sessions	
Chapter 9	Monitoring Security Flow Sessions	117
	Table 13: Session Create Log Fields	123
	Table 14: Session Close Log Fields	124
	Table 15: Session Deny Log Fields	127
Chapter 10	Monitoring X2 Traffic By Configuring Mirror Filters	129
	Table 16: X2 Traffic Terminology	131

Part 7	Configuration Statements and Operational Commands	
Chapter 12	Configuration Statements	165
	Table 17: Ports Supported by Services Interfaces	181
	Table 18: Device Status Upon Configuration Change	198
	Table 19: Ports Supported by Services Interfaces	211
	Table 20: Session Capacity and Resulting Throughput	225
Chapter 13	Operational Commands	227
	Table 21: show chassis environment Output Fields	260
	Table 22: SRX5K-MPC3-40G10G (IOC3) PIC Selection Summary	264
	Table 23: show chassis fpc Output Fields	266
	Table 24: show chassis hardware Output Fields	274
	Table 25: show chassis pic Output Fields	303
	Table 26: show chassis power Output Fields	305
	Table 27: show chassis power sequence Output Fields	307
	Table 28: show firewall Output Fields	308
	Table 29: Aggregated Ethernet show interfaces Output Fields	310
	Table 30: show interfaces Output Fields	322
	Table 31: show interfaces diagnostics optics Output Fields	335
	Table 32: show interfaces flow-statistics Output Fields	340
	Table 33: Flow Error Statistics (Packet Drop Statistics for the Flow Module)	341
	Table 34: show interfaces <swfab0 swfab1> Output Fields	346
	Table 35: show monitor security flow Output Fields	347
	Table 36: show security flow cp-session Output Fields	349
	Table 37: show security flow cp-session destination-port Output Fields	353
	Table 38: show security flow cp-session destination-prefix Output Fields	355
	Table 39: show security flow cp-session family Output Fields	357
	Table 40: show security flow cp-session protocol Output Fields	360
	Table 41: show security flow cp-session source-port Output Fields	362
	Table 42: show security flow cp-session source-prefix Output Fields	364
	Table 43: show security flow gate Output Fields	366
	Table 44: show security flow ip-action Output Fields	371
	Table 45: show security flow gate brief node Output Fields	378
	Table 46: show security flow gate destination-port Output Fields	384
	Table 47: show security flow gate destination-prefix Output Fields	387
	Table 48: show security flow gate protocol Output Fields	391
	Table 49: show security flow gate summary node Output Fields	393
	Table 50: show security flow session Output Fields	399
	Table 51: show security flow session brief node Output Fields	404
	Table 52: show security flow session destination-port Output Fields	408
	Table 53: show security flow session destination-prefix Output Fields	412
	Table 54: show security flow session extensive node Output Fields	416
	Table 55: show security flow session family Output Fields	422
	Table 56: show security flow session interface Output Fields	427
	Table 57: show security flow session nat Output Fields	431
	Table 58: show security flow session policy-id Output Fields	434
	Table 59: show security flow session protocol Output Fields	438
	Table 60: show security flow session resource-manager Output Fields	442
	Table 61: show security flow session services-offload Output Fields	447

Table 62: show security flow session session-identifier Output Fields	451
Table 63: show security flow session source-port Output Fields	455
Table 64: show security flow session source-prefix Output Fields	459
Table 65: show security flow session summary Output Fields	463
Table 66: show security flow session summary node Output Fields	465
Table 67: show security flow session summary services-offload Output Fields	472
Table 68: show security flow session tunnel Output Fields	475
Table 69: show security flow statistics Output Fields	481
Table 70: show security flow status Output Fields	483
Table 71: show security forward-options mirror-filter	486
Table 72: show security policies Output Fields	491
Table 73: show security policies hit-count Output Fields	499
Table 74: show security resource-manager group Output Fields	501
Table 75: show security resource-manager resource Output Fields	504
Table 76: show security resource-manager settings Output Fields	507
Table 77: show security resource-manager summary Output Fields	509
Table 78: show security screen ids-option Output Fields	510
Table 79: show security screen statistics Output Fields	516
Table 80: show security zones Output Fields	524
Table 81: show security zones type Output Fields	527

About the Documentation

- [Documentation and Release Notes on page xvii](#)
- [Supported Platforms on page xvii](#)
- [Using the Examples in This Manual on page xvii](#)
- [Documentation Conventions on page xix](#)
- [Documentation Feedback on page xxi](#)
- [Requesting Technical Support on page xxi](#)

Documentation and Release Notes

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <http://www.juniper.net/books>.

Supported Platforms

For the features described in this document, the following platforms are supported:

- [vSRX](#)
- [SRX Series](#)

Using the Examples in This Manual

If you want to use the examples in this manual, you can use the **load merge** or the **load merge relative** command. These commands cause the software to merge the incoming configuration into the current candidate configuration. The example does not become active until you commit the candidate configuration.

If the example configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the **load merge** command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the **load merge relative** command. These procedures are described in the following sections.

Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following configuration to a file and name the file **ex-script.conf**. Copy the **ex-script.conf** file to the **/var/tmp** directory on your routing platform.

```
system {
  scripts {
    commit {
      file ex-script.xml;
    }
  }
}
interfaces {
  fxp0 {
    disable;
    unit 0 {
      family inet {
        address 10.0.0.1/24;
      }
    }
  }
}
```

2. Merge the contents of the file into your routing platform configuration by issuing the **load merge** configuration mode command:

```
[edit]
user@host# load merge /var/tmp/ex-script.conf
load complete
```

Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following snippet to a file and name the file **ex-script-snippet.conf**. Copy the **ex-script-snippet.conf** file to the **/var/tmp** directory on your routing platform.

```
commit {
  file ex-script-snippet.xml; }
```

2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

```
[edit]
user@host# edit system scripts
[edit system scripts]
```

3. Merge the contents of the file into your routing platform configuration by issuing the **load merge relative** configuration mode command:

```
[edit system scripts]
user@host# load merge relative /var/tmp/ex-script-snippet.conf
load complete
```

For more information about the **load** command, see the *CLI User Guide*.

Documentation Conventions

Table 1 on page xix defines notice icons used in this guide.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.
	Tip	Indicates helpful information.
	Best practice	Alerts you to a recommended use or implementation.

Table 2 on page xix defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents text that you type.	To enter configuration mode, type the configure command: user@host> configure

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
Fixed-width text like this	Represents output that appears on the terminal screen.	<pre>user@host> show chassis alarms</pre> No alarms currently active
<i>Italic text like this</i>	- Introduces or emphasizes important new terms. - Identifies guide names. - Identifies RFC and Internet draft titles.	- A policy <i>term</i> is a named structure that defines match conditions and actions. <i>Junos OS CLI User Guide</i> - RFC 1997, <i>BGP Communities Attribute</i>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: <pre>[edit] root@# set system domain-name domain-name</pre>
Text like this	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	- To configure a stub area, include the stub statement at the <code>[edit protocols ospf area area-id]</code> hierarchy level. - The console port is labeled CONSOLE.
< > (angle brackets)	Encloses optional keywords or variables.	stub <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast multicast <i>(string1 string2 string3)</i>
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp { # Required for dynamic MPLS only
[] (square brackets)	Encloses a variable for which you can substitute one or more values.	community name members [community-ids]
Indentation and braces ({ })	Identifies a level in the configuration hierarchy.	<pre>[edit] routing-options { static { route default { nexthop address; retain; } } }</pre>
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
GUI Conventions		
Bold text like this	Represents graphical user interface (GUI) items you click or select.	- In the Logical Interfaces box, select All Interfaces. - To cancel the configuration, click Cancel.

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
> (bold right angle bracket)	Separates levels in a hierarchy of menu selections.	In the configuration editor hierarchy, select Protocols>Ospf .

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can provide feedback by using either of the following methods:

- Online feedback rating system—On any page of the Juniper Networks TechLibrary site at <http://www.juniper.net/techpubs/index.html>, simply click the stars to rate the content, and use the pop-up form to provide us with information about your experience. Alternately, you can use the online feedback form at <http://www.juniper.net/techpubs/feedback/>.
- E-mail—Send your comments to techpubs-comments@juniper.net. Include the document or topic name, URL or page number, and software version (if applicable).

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or Partner Support Service support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>

- Download the latest versions of software and review release notes:
<http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications:
<http://kb.juniper.net/InfoCenter/>
- Join and participate in the Juniper Networks Community Forum:
<http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html>.

PART 1

Overview

- Introduction to Processing on Security Devices on page 3

CHAPTER 1

Introduction to Processing on Security Devices

- [Juniper Networks Devices Processing Overview on page 3](#)
- [Understanding SRX Series Services Gateways Central Point Architecture on page 7](#)
- [Understanding Enhancements to Central Point Architecture for the SRX5000 Line on page 9](#)
- [SRX5000 Line Devices Processing Overview on page 10](#)
- [SRX3000 Line and SRX1400 Devices Processing Overview on page 20](#)
- [SRX210 Services Gateway Processing Overview on page 24](#)

Juniper Networks Devices Processing Overview

Junos OS for security devices integrates the world-class network security and routing capabilities of Juniper Networks. Junos OS includes a wide range of packet-based filtering, class-of-service (CoS) classifiers, and traffic-shaping features as well as a rich, extensive set of flow-based security features including policies, screens, network address translation (NAT), and other flow-based services.

Traffic that enters and exits a security device is processed according to features you configure, such as packet filters, security policies, and screens. For example, the software can determine:

- Whether the packet is allowed into the device
- Which firewall screens to apply to the packet
- The route the packet takes to reach its destination
- Which CoS to apply to the packet, if any
- Whether to apply NAT to translate the packet's IP address
- Whether the packet requires an Application Layer Gateway (ALG)

Packets that enter and exit a device undergo both packet-based and flow-based processing:

- Flow-based packet processing treats related packets, or a stream of packets, in the same way. Packet treatment depends on characteristics that were established for the first packet of the packet stream, which is referred to as a flow.

For the distributed processing architecture of the services gateway, all flow-based processing occurs on the SPU and sampling is multi-thread aware. Packet sequencing is maintained for the sampled packets.

- Packet-based, or stateless, packet processing treats packets discretely. Each packet is assessed individually for treatment.

For the distributed processing architecture of the services gateway, some packet-based processing, such as traffic shaping, occurs on the NPU. Some packet-based processing, such as application of classifiers to a packet, occurs on the SPU.

This topic includes the following sections:


- [Understanding Flow-Based Processing on page 4](#)
- [Understanding Packet-Based Processing on page 5](#)

Understanding Flow-Based Processing

A packet undergoes flow-based processing after packet-based filters and some screens have been applied to it. All flow-based processing for a single flow occurs on a single System Processing Unit (SPU). An SPU processes the packets of a flow according to the security features and other services configured for the session.

[Figure 1 on page 4](#) shows a conceptual view of how flow-based traffic processing occurs on services gateway.

Figure 1: Traffic Flow for Flow-Based Processing



A flow is a stream of related packets that meet the same matching criteria and share the same characteristics. Junos OS treats packets belonging to the same flow in the same manner.

Configuration settings that determine the fate of a packet—such as the security policy that applies to it, if it requires an Application Layer Gateway (ALG), if NAT is applied to

translate the packet's source and/or destination IP address—are assessed for the first packet of a flow.

To determine if a flow exists for a packet, the NPU attempts to match the packet's information to that of an existing session based on the following match criteria:

- Source address
- Destination address
- Source port
- Destination port
- Protocol
- Unique session token number for a given zone and virtual router

Zones and Policies

The security policy to be used for the first packet of a flow is cached in a flow table for use with the same flow and closely related flows. Security policies are associated with zones. A zone is a collection of interfaces that define a security boundary. A packet's incoming zone, as determined by the interface through which it arrived, and its outgoing zone, as determined by the forwarding lookup, together determine which policy is used for packets of the flow.

Flows and Sessions

Flow-based packet processing, which is stateful, requires the creation of sessions. A session is created for the first packet of a flow for the following purposes:

- To store most of the security measures to be applied to the packets of the flow.
- To cache information about the state of the flow.

For example, logging and counting information for a flow is cached in its session. (Some stateful firewall screens rely on threshold values that pertain to individual sessions or across all sessions.)

- To allocate required resources for the flow for features such as NAT.
- To provide a framework for features such as ALGs and firewall features.

Most packet processing occurs in the context of a flow, including:

- Management of policies, NAT, zones, and most screens.
- Management of ALGs and authentication.

Understanding Packet-Based Processing

A packet undergoes packet-based processing when it is removed from the queue from its input interface and before it is added to the queue on its output interface.

Packet-based processing applies stateless firewall filters, CoS features, and some screens to discrete packets.

- When a packet arrives at an interface, sanity checks, packet-based filters, some CoS features, and some screens are applied to it.
- Before a packet leaves the device, any packet-based filters, some CoS features, and some screens associated with the interface are applied to the packet.

Filters and CoS features are typically associated with one or more interfaces to influence which packets are allowed to transit the system and to apply special actions to packets as necessary.

The following topics describe the kinds of packet-based features that you can configure and apply to transit traffic.

Configuring Packet-Based Processing

On SRX Series devices, the default mode for processing traffic is flow mode. To configure an SRX Series device as a border router, you must change the mode from flow-based processing to packet-based processing. Use the **set security forwarding-options family mpls mode packet-based** statement to configure the SRX device to packet mode. You must reboot the device for the configuration to take effect.



NOTE: Packet-based processing is supported only on the following SRX Series devices: SRX550, and SRX1500.

Stateless Firewall Filters

Also referred to as access control lists (ACLs), stateless firewall filters control access and limit traffic rates. They statically evaluate the contents of packets transiting the device from a source to a destination, or packets originating from or destined for the Routing Engine. A stateless firewall filter evaluates every packet, including fragmented packets.

You can apply a stateless firewall filter to an input or output interface, or to both. A filter contains one or more terms, and each term consists of two components—match conditions and actions. By default, a packet that does not match a firewall filter is discarded.

You can plan and design stateless firewall filters to be used for various purposes—for example, to limit traffic to certain protocols, IP source or destination addresses, or data rates. Stateless firewall filters are executed on the SPU.

Class-of-Service Features

CoS features allow you to classify and shape traffic. CoS features are executed on the SPU.

- Behavior aggregate (BA) classifiers—These classifiers operate on packets as they enter the device. Using behavior aggregate classifiers, the device aggregates different types of traffic into a single forwarding class to receive the same forwarding treatment. BA classifiers allow you to set the forwarding class and loss priority of a packet based on the Differentiated Service (DiffServ) value.

- Traffic shaping—You can shape traffic by assigning service levels with different delay, jitter, and packet loss characteristics to particular applications served by specific traffic flows. Traffic shaping is especially useful for real-time applications, such as voice and video transmission.

Screens

Some screens, such as denial-of-service (DoS) screens, are applied to a packet outside the flow process. They are executed on the Network Processing Unit (NPU).

For details on specific stateless CoS features, see [Class of Service Feature Guide for Security Devices](#).

Related Documentation

- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)
- [SRX5000 Line Devices Processing Overview on page 10](#)
- *forwarding-options (Security)*

Understanding SRX Series Services Gateways Central Point Architecture

The central point in the architecture has two basic flow functionalities: load balancing and traffic identification (global session matching). The central point forwards a packet to its Services Processing Unit (SPU) upon session matching, or distributes traffic to an SPU for security processing if the packet does not match any existing session.

On some SRX Series devices, an entire SPU cannot be dedicated for central point functionality, but a certain percentage of the SPU is automatically allocated for central point functionality and the rest is allocated for normal flow processing. When an SPU performs the function of central point as well as normal flow processing, it is said to be in combination, or *combo*, mode.

The percentage of SPU dedicated to the central point functionality depends on the number of SPUs in the device. Based on the number of SPUs, there are three modes available on the SRX Series devices— small central point, medium central point, and large central point.

In small central point mode, a small percentage of an SPU is dedicated to central point functionality and the rest is dedicated to the normal flow processing. In medium central point mode, an SPU is almost equally shared for central point functionality and normal flow processing. In large central point mode, an entire SPU is dedicated to central point functionality. In combo mode, the central point and SPU share the same load-balancing thread (LBT) and packet-ordering thread (POT) infrastructure.

This topic includes the following sections:

- [Load Distribution in Combo Mode on page 8](#)
- [Sharing Processing Power and Memory in Combo Mode on page 8](#)

Load Distribution in Combo Mode

The central point maintains SPU mapping table (for load distribution) that lists live SPUs with the logic SPU IDs mapped to the physical Trivial Network Protocol (TNP) addresses mapping. In combo mode, the SPU that hosts the central point is included in the table. The load distribution algorithm is adjusted based on session capacity and processing power to avoid overloading of sessions.

Sharing Processing Power and Memory in Combo Mode

The CPU processing power in a combo-mode SPU is shared based on the platform and the number of SPUs in the system. Similarly, the CPU memory is also shared between the central point and SPU.

An SPU has multiple cores (CPUs) for networking processing. In "small" SPU combo mode, CPU functionality takes a small portion of the cores, whereas "medium" SPU combo mode requires a larger portion of cores. The processing power for central point functionalities and flow processing is shared, based on the number of Services Processing Cards (SPC), as shown in [Table 3 on page 8](#).

Table 3: Combo Mode Processing

SRX Series device	Central point mode with 1 SPC	Central point mode with 2 or More than 2 SPCs
SRX1400	Small	Medium
SRX3400	Small	Medium
SRX3600	Small	Medium
SRX3400 (expanded performance and capacity license)	Small	Large
SRX3600 (expanded performance and capacity license)	Small	Large
SRX5600	Medium	Large
SRX5800	Medium	Large



NOTE: The combo mode processing only exists with SPC1 on SRX1400, SRX3400, SRX3600, and SRX5000 line devices.

Related Documentation

- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)

Understanding Enhancements to Central Point Architecture for the SRX5000 Line

Previously, for the SRX5000 line of services gateways, the central point was a bottleneck in device performance and scaling. When more Services Processing Cards (SPCs) were integrated into the system, the overall processing power increased linearly, but the system connections per second (cps) remained constant and could not be improved because of the single centralized point in the system. This severely impacted the overall system utilizations in both capacity and cps.

Beginning with Junos OS Release 15.1X49-D30, on SRX5000 line devices, the central point architecture is enhanced to handle higher connections per second (cps). The new central point architecture prevents data packets from going through the central point by offloading session management functionalities to the Services Processing Unit (SPU). Therefore, data packets are directly forwarded from the network processing unit to the SPU instead of going through the central point.

The central point architecture is divided into two modules, the application central point and the distributed central point. The application central point is responsible for global resource management and load balancing, while the distributed central point is responsible for traffic identification (global session matching). The application central point functionality runs on the dedicated central point SPU, while the distributed central point functionality is distributed to the rest of the SPUs. Now the central point sessions are no longer on the dedicated central point SPU, but with distributed central point on other flow SPUs.



NOTE: The central point for SRX5000 line refers to the application central point, or the distributed central point or both, with respect to global resource management and load balancing, it refers to the application central point, whereas with respect to traffic identification and session management, it refers to the distributed central point (sometimes referred to the SPU as well).



NOTE: The SNMP log and SNMP trap were generated by the central point with rate limit. Now, the SNMP log and SNMP trap are generated by the SPU or central point. As there is more than one SPU, the number of SNMP log and traps generated are more. To verify the number of connections per second (CPS) on the device run `SNMP MIB walk nxJsNodeSessionCreationPerSecond` command. The SNMP polling mechanism calculates the CPS value based on the average number of CPS in the past 96 seconds. So, if the CPS is not constant, the number of CPS reported is inaccurate.

Related Documentation • [SRX5000 Line Devices Processing Overview on page 10](#)

SRX5000 Line Devices Processing Overview

Junos OS is a distributed, parallel processing, high-throughput and high-performance system. The distributed parallel processing architecture of the SRX5000 line of services gateways includes multiple processors to manage sessions and run security and other services processing. This architecture provides greater flexibility and allows for high throughput and fast performance.

The SRX5000 line devices include I/O cards (IOCs) and Services Processing Cards (SPCs) that each contain processing units that process a packet as it traverses the device. A Network Processing Unit (NPU) runs on an IOC. An IOC has one or more NPUs. One or more Services Processing Units (SPUs) run on an SPC.

These processing units have different responsibilities. All flow-based services for a packet are executed on a single SPU. Otherwise, however, the responsibilities of these NPUs are not clearly delineated in regard to the other kind of services that run on them. (For details on flow-based processing, see [“Juniper Networks Devices Processing Overview” on page 3.](#))

For example:

- An NPU processes packets discretely. It performs sanity checks and applies some screens that are configured for the interface, such as denial-of-service (DoS) screens, to the packet.
- An SPU manages the session for the packet flow and applies security features and other services to the packet. It also applies packet-based stateless firewall filters, classifiers, and traffic shapers to the packet.
- An NPU forwards a packet to the SPU using the hash algorithm. However, for some applications, like ALG, the system will need to query the application central point to determine on which SPU the packet should be processed.

These discrete, cooperating parts of the system, including the central point, each store the information identifying whether a session exists for a stream of packets and the information against which a packet is matched to determine if it belongs to an existing session.

This architecture allows the device to distribute processing of all sessions across multiple SPUs. It also allows an NPU to determine if a session exists for a packet, to check the packet, and to apply screens to the packet. How a packet is handled depends on whether it is the first packet in a flow.

The following sections describe the processing architecture using SRX5600 and SRX5800 devices as an example:

- [Understanding First-Packet Processing on page 11](#)
- [Understanding Fast-Path Processing on page 12](#)
- [Understanding the Data Path for Unicast Sessions on page 13](#)
- [Understanding Services Processing Units on page 19](#)


- [Understanding Scheduler Characteristics on page 19](#)
- [Understanding Network Processor Bundling on page 19](#)

Understanding First-Packet Processing

If the packet matches an existing flow, processing for the packet is assessed in the context of its flow state. The SPU maintains the state for each session, and the settings are then applied to the rest of the packets in the flow. If the packet does not match an existing flow, it is used to create a flow state and a session is allocated for it.

[Figure 2 on page 11](#) illustrates the path the first packet in a flow takes as it enters the device—the NPU determines that no session exists for the packet, and the NPU sends the packet to the distributed central point to set up a distributed central point session. The distributed central point then sends a message to the application central point to select the SPU to set up a session for the packet and to process the packet. The distributed central point then sends the packet to that SPU. The SPU processes the packet and sends it to the NPU for transmission from the device. (This high-level description does not address application of features to a packet.)

Figure 2: First-Packet Processing




For details on session creation for the first packet in a flow, see “[Understanding Session Creation: First-Packet Processing](#)” on page 13.

After the first packet in a flow has traversed the system and a session has been established for it, it undergoes fast-path processing.

Subsequent packets in the flow also undergo fast-path processing; in this case, after each packet enters the session and the NPU finds a match for it in its session table, the NPU forwards the packet to the SPU that manages its session.

[Figure 3 on page 12](#) illustrates fast-path processing. This is the path a packet takes when a flow has already been established for its related packets. (It is also the path that the first packet in a flow takes after the session for the flow that the packet initiated has been set up.) After the packet enters the device, the NPU finds a match for the packet in its session table, and it forwards the packet to the SPU that manages the packet's session. Note that the packet bypasses interaction with the central point.

Figure 3: Fast-Path Processing



The following section explains how a session is created and the process a packet undergoes as it transits the device.

Understanding Fast-Path Processing

Here is an overview of the main components involved in setting up a session for a packet and processing packets both discretely and as part of a flow as they transit the SRX5600 and SRX5800 devices:

- Network Processing Units (NPUs)—NPUs reside on IOCs. They handle packet sanity checking and application of some screens. NPUs maintain session tables that they use to determine if a session exists for an incoming packet or for reverse traffic.

The NPU session table contains an entry for a session if the session is established on an SPU for a packet that had previously entered the device via the interface and was processed by this NPU. The SPU installs the session in the NPU table when it creates the session.

An NPU determines if a session exists for a packet by checking the packet information against its session table. If the packet matches an existing session, the NPU sends the packet and the metadata for it to the SPU. If there is no session, the NPUs sends the packet to one SPU which is calculated using the hash algorithm.

- Services Processing Units (SPUs)—The main processors of the SRX5600 and SRX5800 devices reside on SPCs. SPUs establish and manage traffic flows and perform most of the packet processing on a packet as it transits the device. Each SPU maintains a hash table for fast session lookup. The SPU applies stateless firewall filters, classifiers, and traffic shapers to traffic. An SPU performs all flow-based processing for a packet and most packet-based processing. Each multicore SPU processes packets independently with minimum interaction among SPUs on the same or different SPC. All packets that belong to the same flow are processed by the same SPU.

The SPU maintains a session table with entries for all sessions that it established and whose packets it processes. When an SPU receives a packet from an NPU, it checks its session table to ensure that the packet belongs to it. It also checks its session table when it receives a packet from the distributed central point and sends a message to establish a session for that packet to verify that there is not an existing session for the packet.

- Central point—The central point architecture is divided into two modules, the application central point and the distributed central point. The application central point is responsible for global resource management and loading balancing, while the distributed central point is responsible for traffic identification (global session

matching). The application central point functionality runs on the dedicated central point SPU, while the distributed central point functionality is distributed to the rest of the SPUs. Now the central point sessions are no longer on the dedicated central point SPU, but with the distributed central point on other flow SPUs.

- Routing Engine—The Routing Engine runs the control plane.

Understanding the Data Path for Unicast Sessions

This section describes the process of establishing a session for packets belonging to a flow that transits the device.

To illustrate session establishment and the packet “walk” including the points at which services are applied to the packets in a flow, this example uses the simple case of a unicast session.

This packet “walk” brings together the packet-based processing and flow-based processing that Junos OS performs on the packet.

Session Lookup and Packet-Match Criteria

To determine if a packet belongs to an existing flow, the device attempts to match the packet’s information to that of an existing session based on the following six match criteria:

- Source address
- Destination address
- Source port
- Destination port
- Protocol
- Unique token from a given zone and virtual router

Understanding Session Creation: First-Packet Processing

This section explains how a session is set up to process the packets composing a flow. To illustrate the process, this section uses an example with a source “a” and a destination “b”. The direction from source to destination for the packets of the flow is referred to as (a -> b). The direction from destination to source is referred to as (b -> a).

Step 1. A Packet Arrives at an Interface on the Device And the NPU Processes It.

This section describes how a packet is handled when it arrives at an SRX Series device ingress IOC.

1. The packet arrives at the device’s IOC and is processed by the NPU on the IOC.
2. The NPU performs basic sanity checks on the packet and applies some screens configured for the interface to the packet.
3. The NPU checks its session table for an existing session for the packet. (It checks the packet’s tuple against those of packets for existing sessions in its session table.)

- a. If no existing session is found, the NPU forwards the packet to the hash SPU.
- b. If a session match is found, the session has already been created on an SPU that was assigned to it, so the NPU forwards the packet to the SPU for processing along with the session ID. (See [“Understanding Fast-Path Processing” on page 16.](#))

Example: Packet (a ->b) arrives at NPU1. NPU1 performs sanity checks and applies DoS screens to the packet. NPU1 checks its session table for a tuple match, and no existing session is found. NPU1 forwards the packet to an SPU.

Step 2. The Distributed Central Point Creates a Session with a "Pending" State.

When an NPU receives a packet, the NPU send it to the distributed central point, based on the hash algorithm. The distributed central point then looks up the distributed central point session table and creates an entry if needed.

This process entails the following parts:

1. The distributed central point checks its session table to determine if a session exists for the packet received from the NPU. (An NPU forwards a packet to the distributed central point because it cannot find an existing session for the packet)
2. If there is no entry that matches the packet in the distributed central point session table, the distributed central point creates a pending wing for the session. The distributed central point then sends a query message to the application central point to select an SPU to be used for the session.
3. On receiving the query message, the application central point checks its gate table to determine if a gate exists for the packet. If a gate is matched or some other session distribution algorithm is triggered, the application central point selects another SPU to process the packet; otherwise, the SPU (that is, the distributed central point SPU) is selected. Finally, the application central point sends a query response to the distributed central point.
4. On receiving the query response, the distributed central point forwards the first packet in flow to the selected SPU in a message directing the SPU to set up a session locally to be used for the packet flow. For example, the distributed central point creates a pending wing (a ->b) for the session. The application central point selects SPU1 to be used for it. The distributed central point sends SPU1 the (a->b) packet along with a message to create a session for the distributed central point.

Example: The distributed central point creates a pending wing (a ->b) for the session. It selects SPU1 to be used for it. It sends SPU1 the (a->b) packet along with a message to create a session for it.

Step 3. The SPU Sets Up the Session.

Each SPU, too, has a session table, which contains information about its sessions. When the SPU receives a message from the distributed central point to set up a session, it checks its session table to ensure that a session does not already exist for the packet.

1. If there is no existing session for the packet, the SPU sets up the session locally.

2. The SPU sends a message to the distributed central point directing it to install the session.



NOTE: During first-packet processing, if NAT is enabled, the SPU allocates IP address resources for NAT. In this case, the first-packet processing for the session is suspended until the NAT allocation process is completed.

The SPU adds to the queue any additional packets for the flow that it might receive until the session has been installed.

Example: SPU1 creates the session for (a->b) and sends a message back to the distributed central point directing it to install the pending session.

Step 4. The Distributed Central Point Installs the Session.

The distributed central point receives the install message from the SPU.

1. The distributed central point sets the state for the session's pending wing to active.
2. The distributed central point installs the reverse wing for the session as an active wing.



NOTE: For some cases, such as NAT, the reverse wing may be installed on a different distributed central point from the init wing distributed central point.

3. It sends an acknowledge (ACK) message to the SPU, indicating that the session is installed.

Example: The distributed central point receives a message from SPU1 to install the session for the (a->b) wing. It sets the session state for the (a->b) wing to active. It installs the reverse wing (b->a) for the session and makes it active; this allows for delivery of packets from the reverse direction of the flow: destination (b) to be delivered to the source (a).

Step 5. The SPU Sets Up the Session on the Ingress and Egress NPUs.


NPUs maintain information about a session for packet forwarding and delivery. Session information is set up on the egress and ingress NPUs (which sometimes are the same) so that packets can be sent directly to the SPU that manages their flows and not to the distributed central point for redirection.

Step 6. Fast-Path Processing Takes Place.

For the remainder of the steps entailed in packet processing, proceed to Step 1 in [“Understanding Fast-Path Processing” on page 16](#).

[Figure 4 on page 16](#) illustrates the first part of the process that the first packet in a flow undergoes after it reaches the device. At this point a session is set up to process the packet and the rest of the packets belonging to its flow. Subsequently, it and the rest of the packets in the flow undergo fast-path processing.

Figure 4: Session Creation: First-Packet Processing



8043352

Understanding Fast-Path Processing

All packets undergo fast-path processing. However, if a session exists for a packet, the packet undergoes fast-path processing and bypasses the first-packet process. When there is already a session for the packet's flow, the packet does not transit the central point.

Here is how fast-path processing works: NPUs at the egress and ingress interfaces contain session tables that include the identification of the SPU that manages a packet's flow. Because the NPUs have this session information, all traffic for the flow, including reverse traffic, is sent directly to that SPU for processing.

To illustrate the fast-path process, this section uses an example with a source "a" and a destination "b". The direction from source to destination for the packets of the flow is referred to as (a->b). The direction from destination to source is referred to as (b->a).

Step 1. A Packet Arrives at the Device and the NPU Processes It.

This section describes how a packet is handled when it arrives at a services gateway's IOC.

1. The packet arrives at the device's IOC and is processed by the NPU on the card.
The NPU performs sanity checks and applies some screens, such as denial-of-service (DoS) screens, to the packet.
2. The NPU identifies an entry for an existing session in its session table that the packet matches.

3. The NPU forwards the packet along with metadata from its session table, including the session ID and packet tuple information, to the SPU that manages the session for the flow, applies stateless firewall filters and CoS features to its packets, and handles the packet's flow processing and application of security and other features.

Example: Packet (a->b) arrives at NPU1. NPU1 performs sanity checks on the packet, applies DoS screens to it, and checks its session table for a tuple match. It finds a match and that a session exists for the packet on SPU1. NPU1 forwards the packet to SPU1 for processing.

Step 2. The SPU for the Session Processes the Packet.

Most of a packet's processing occurs on the SPU to which its session is assigned. The packet is processed for packet-based features such as stateless firewall filters, traffic shapers, and classifiers, if applicable. Configured flow-based security and related services such as firewall features, NAT, ALGs, and so on, are applied to the packet. (For information on how security services are determined for a session, see "[Juniper Networks Devices Processing Overview](#)" on page 3.)

1. Before it processes the packet, the SPU checks its session table to verify that the packet belongs to one of its sessions.
2. The SPU processes the packet for applicable features and services.

Example: SPU1 receives packet (a->b) from NPU1. SPU1 checks its session table to verify that the packet belongs to one of its sessions. Then it processes packet (a->b) according to input filters and CoS features that apply to its input interface. The SPU applies the security features and services that are configured for the packet's flow to it, based on its zone and policies. If any are configured, it applies output filters, traffic shapers and additional screens to the packet.

Step 3. The SPU Forwards the Packet to the NPU.

1. The SPU forwards the packet to the NPU.
2. The NPU applies any applicable screens associated with the interface to the packet.

Example: SPU1 forwards packet (a->b) to NPU2, and NPU2 applies DoS screens.

Step 4. The Interface Transmits the Packet from the Device.

Example: The interface transmits packet (a->b) from the device.

Step 5. A Reverse Traffic Packet Arrives at the Egress Interface and the NPU Processes It.

This step mirrors Step 1 exactly in reverse. See Step 1 in this section for details.

Example: Packet (b->a) arrives at NPU2. NPU2 checks its session table for a tuple match. It finds a match and that a session exists for the packet on SPU1. NPU2 forwards the packet to SPU1 for processing.

Step 6. The SPU for the Session Processes the Reverse Traffic Packet.

This step is the same as Step 2 except that it applies to reverse traffic. See Step 2 in this section for details.

Example: SPU1 receives packet (b->a) from NPU2. It checks its session table to verify that the packet belongs to the session identified by NPU2. Then it applies packet-based features configured for the NPU1's interface to the packet. It processes packet (b->a) according to the security features and other services that are configured for its flow, based on its zone and policies. (See [“Juniper Networks Devices Processing Overview” on page 3.](#))

Step 7. The SPU Forwards the Reverse Traffic Packet to the NPU.

This step is the same as Step 3 except that it applies to reverse traffic. See Step 3 in this section for details.

Example: SPU1 forwards packet (b->a) to NPU1. NPU1 processes any screens configured for the interface.


8. The Interface Transmits the Packet from the Device.

This step is the same as Step 4 except that it applies to reverse traffic. See Step 4 in this section for details.

Example: The interface transmits packet (b->a) from the device.

[Figure 5 on page 18](#) illustrates the process a packet undergoes when it reaches the device and a session exists for the flow that the packet belongs to.

Figure 5: Packet Walk for Fast-Path Processing



Understanding Services Processing Units

For a given physical interface, the SPU receives ingress packets from all network processors in the network processor bundle associated with the physical interface. The SPU extracts network processor bundle information from the physical interface and uses the same 5-tuple hash algorithm to map a flow to a network processor index. To determine the network processor, the SPU does a lookup on the network processor index in the network processor bundle. The SPU sends egress packets to the physical interface's local Physical Interface Module (PIM) for the outward traffic.



NOTE: The network processor and the SPU use the same 5-tuple hash algorithm to get the hash values for the packets.

Understanding Scheduler Characteristics

For SRX5600 and SRX5800 devices, the IOC supports the following hierarchical scheduler characteristics:

- IFL – The configuration of the network processor bundle is stored in the physical interface data structure. For example, SRX5600 and SRX5800 devices have a maximum of 48 PIMs. The physical interface can use a 48-bit bit-mask to indicate the PIM, or the network processor traffic from this physical interface is distributed in addition to the physical interface's primary network processor.

On SRX5000 line devices, the iflset functionality is not supported for aggregated interfaces like *reth*.

- IFD – The logical interface associated with the physical interface of a network processor bundle is passed to all the IOCs that have a PIM in the network processor bundle.

Understanding Network Processor Bundling

The network processor bundling feature is available on SRX5000 line devices. This feature enables distribution of data traffic from one interface to multiple network processors for packet processing. A primary network processor is assigned for an interface that receives the ingress traffic and distributes the packets to several other secondary network processors. A single network processor can act as a primary network processor or as a secondary network processor to multiple interfaces. A single network processor can join only one network processor bundle.

Network Processor Bundling Limitations

Network processor bundling functionality has the following limitations:

- Network processor bundling allows a total of 16 PIMs per bundle and 8 different network processor bundle systems.
- You need to reboot the device to apply the configuration changes on the bundle.

- Network processor bundling is below the reth interface in the overall architecture. You can choose one or both interfaces from the network processor bundle to form the reth interface.
- If the IOC is removed from a network processor bundle, the packets forwarded to the PIM on that IOC are lost.
- When the network processor bundle is enabled, the ICMP, UDP, and TCP sync flooding thresholds no longer apply to an interface. Packets are distributed to multiple network processors for processing. These thresholds apply to each network processor in the network processor bundle.
- Network processor bundling is not supported in Layer 2 mode.
- Because of memory constraints on the network processor, the number of network processor bundled ports that are supported per PIM is limited. Within the network processor bundle, each port needs to have a global port index. The global port index is calculated using the following formula:
$$\text{Global\_port\_index} = (\text{global\_pic} * 16) + \text{port\_offset}$$
- Link aggregation groups (LAGs) and redundant Ethernet interface LAGs in chassis cluster implementations can coexist with network processor bundling. However, neither LAGs nor redundant Ethernet interface LAGs can overlap with or share physical links with a network processor bundle.

SRX3000 Line and SRX1400 Devices Processing Overview

Junos OS for the SRX1400, SRX3400 and SRX3600 Services Gateways integrates the world-class network security and routing capabilities of Juniper networks. Junos OS for these service gateways includes the wide range of security services including policies, screens, network address translation, class-of-service classifiers, and the rich, extensive set of flow-based services that are also supported on the other devices in the services gateways

The distributed parallel processing architecture of the SRX1400, SRX3400 and SRX3600 devices includes multiple processors to manage sessions and run security and other services processing. This architecture provides greater flexibility and allows for high throughput and fast performance.

The following sections describe the processing architecture using SRX3400 and SRX3600 devices as an example:

This topic includes the following information:

- [Components Involved in Setting Up a Session on page 21](#)
- [Understanding the Data Path for Unicast Sessions on page 21](#)
- [Session Lookup and Packet Match Criteria on page 22](#)
- [Understanding Session Creation: First Packet Processing on page 22](#)
- [Understanding Fast-Path Processing on page 24](#)

Components Involved in Setting Up a Session

Here is an overview of the main components involved in setting up a session for a packet and processing the packets as they transit the SRX3400 and SRX3600 devices:

- **Services Processing Units (SPUs)**—The main processors of the SRX3400 and SRX3600 devices reside on Services Processing Cards (SPCs). They establish and manage traffic flows and perform most of the packet processing on a packet as it transits the device. Each SPU maintains a hash table for fast session lookup. The SPU performs all flow-based processing for a packet, including application of security services, classifiers, and traffic shapers. All packets that belong to the same flow are processed by the same SPU.

The SPU maintains a session table with entries for all sessions that it established and whose packets it processes. When an SPU receives a packet from an NPU, it checks its session table to ensure that the packet belongs to it.

For SRX3400 and SRX3600 devices, one SPU acts in concert performing its regular session management and flow processing functions and acting as a central point in which it arbitrates sessions and allocates resources. When an SPU performs in this manner it is said to be in combo mode.

- **Central Point**—The central point is used to allocate session management to SPUs based on load balancing criteria. It distributes sessions in an intelligent way to avoid occurrences in which multiple SPUs might wrongly handle the same flow. The central point follows load balancing criteria in allocating sessions to SPUs. If the session exists, the central point forwards packets for that flow to the SPU hosting it. It also redirects packets to the correct SPU in the event that the NPU fails to do so.

For the SRX3400 and SRX3600 devices, one SPU always runs in what is referred to as combo mode in which it implements both the functionality of the central point and the flow and session management functionality. In combo mode, the SPU and the central point share the same load-balancing thread (LBT) and packet-ordering thread (POT) infrastructure. For more information, see [“Understanding SRX Series Services Gateways Central Point Architecture” on page 7](#).

- **Routing Engine (RE)**—The Routing Engine runs the control plane and manages the Control Plane Processor (CPP).

Understanding the Data Path for Unicast Sessions

Junos OS for the SRX3400 and SRX3600 Services Gateways is a distributed parallel processing high throughput and high performance system. This topic describes the process of establishing a session for packets belonging to a flow that transits the device.

To illustrate session establishment and the packet “walk” including the points at which services are applied to the packets of a flow, the following example uses the simple case of a unicast session. This packet “walk” brings together the packet-based processing and flow-based processing that the Junos OS performs on the packet.

Session Lookup and Packet Match Criteria

To determine if a packet belongs to an existing flow, the device attempts to match the packet's information to that of an existing session based on the following six match criteria:

- Source address
- Destination address
- Source port
- Destination port
- Protocol
- Unique token from a given zone and virtual router

Understanding Session Creation: First Packet Processing

This topic explains how a session is set up to process the packets composing a flow. To illustrate the process, this topic uses an example with a source "a" and a destination "b". The direction from source to destination for the packets of the flow is referred to as (a -> b). The direction from destination to source is referred to as (b -> a).

1. A packet arrives at an interface on the device and the IOC processes it.

The IOC dequeues the packet and sends it to the NPU with which it communicates.

2. The NPU receives the packet from the IOC and processes it.
 - The NPU performs basic sanity checks on the packet and applies some screens configured for the interface to the packet.
 - If a session match is found, the session has already been created on an SPU that was assigned to it, so the NPU forwards the packet to the SPU for processing along with the session ID.

Example: Packet (a ->b) arrives at NPU1 from IOC1. NPU1 performs sanity checks and applies DoS screens to the packet. NPU1 checks its session table for a tuple match and no existing session is found. NPU1 forwards the packet to the central point on SPU1 for assignment to an SPU.

3. The central point creates a session with a "Pending" state.

The central point maintains a global session table that includes entries for all sessions that exist across all SPUs on the device. It participates in session creation and delegates and arbitrates session resources allocation.

This process entails the following parts:

- a. The central point checks its session table and gate table to determine if a session or a gate exists for the packet it receives from the NPU. (An NPU has forwarded a packet to the central point because its table indicates there is no session for it. The central point verifies this information before allocating an SPU for the session.)

b. If there is no entry that matches the packet in either table, the central point creates a pending wing for the session and selects an SPU to be used for the session, based on its load-balancing algorithm.

c. The central point forwards the first packet of the flow to the selected SPU in a message telling it to set up a session locally to be used for the packet flow.

Example: The central point creates pending wing (a ->b) for the session. It selects SPU1 to be used for the session. It sends SPU1 the (a->b) packet along with a message to create a session for it. (It happens to be the case that SPU1 is the SPU that runs in combo mode. Therefore, its session-management and flow-processing services are used for the session.

4. The SPU sets up the session.

Each SPU, too, has a session table, which contains information about its sessions. When the SPU receives a message from the central point to set up a session, it checks its session table to ensure that a session does not already exist for the packet.

a. If there is no existing session for the packet, the SPU sets up the session locally.

b. The SPU sends a message to the central point, telling it to install the session.

During first-packet processing, if NAT is enabled, the SPU allocates IP address resources for NAT. In this case, the first-packet processing for the session is suspended until the NAT allocation process is completed.

The SPU adds to the queue any additional packets for the flow that it might receive until the session has been installed.

Example: SPU1 creates the session for (a ->b) and sends a message back to the central point (implemented on the same SPU) telling it to install the pending session.

5. The central point installs the session.

- It sets the state for the session's pending wing to active.
- It installs the reverse wing for the session as an active wing.
- It sends an ACK (acknowledge) message to the SPU, indicating that the session is installed.

Example: The central point receives a message from SPU1 to install the session for (a->b). It sets the session state for (a->b) wing to active. It installs the reverse wing (b->a) for the session and makes it active; this allows for delivery of packets from the reverse direction of the flow: destination (b) to be delivered to the source (a).

6. The SPU sets up the session on the ingress and egress NPUs.

NPUs maintain information about a session for packet forwarding and delivery. Session information is set up on the egress and ingress NPUs (which sometimes are the same) so that packets can be sent directly to the SPU that manages their flows and not to the central point for redirection.

7. Fast-path processing takes place.

For the remainder of the steps entailed in packet processing, proceed to Step 1 in "Understanding Fast-Path Processing".

Understanding Fast-Path Processing

All packets undergo fast-path processing. However, if a session exists for a packet, the packet undergoes fast-path processing and bypasses the first-packet process. When there is already a session for the packet's flow, the packet does not transit the central point.

Here is how fast-path processing works: NPUs at the egress and ingress interfaces contain session tables that include the identification of the SPU that manages a packet's flow. Because the NPUs have this session information, all traffic for the flow, including reverse traffic, is sent directly to that SPU for processing.

On SRX1400, SRX3400, and SRX3600 devices, the iflset functionality is not supported for aggregated interfaces like *reth*.

Related Documentation

- [Juniper Networks Devices Processing Overview on page 3](#)
- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)

SRX210 Services Gateway Processing Overview

This topic describes the process that the SRX210 Services Gateway undertakes in establishing a session for packets belonging to a flow that transits the device. The flow services of the SRX210 device are single-threaded and non-distributed. Although it differs from the other SRX Series devices in this respect, the same flow model is followed and the same command line interface (CLI) is implemented.

To illustrate session establishment and the packet “walk” including the points at which services are applied to the packets of a flow, the example described in the following sections uses the simple case of a unicast session:

- [Understanding Flow Processing and Session Management on page 24](#)
- [Understanding First-Packet Processing on page 25](#)
- [Understanding Session Creation on page 25](#)
- [Understanding Fast-Path Processing on page 25](#)

Understanding Flow Processing and Session Management

This topic explains how a session is set up to process the packets composing a flow. In the following topic, the SPU refers to the data plane thread of the SRX210 Services Gateway.

At the outset, the data plane thread fetches the packet and performs basic sanity checks on it. Then it processes the packet for stateless filters and CoS classifiers and applies some screens.

Understanding First-Packet Processing

To determine if a packet belongs to an existing flow, the device attempts to match the packet's information to that of an existing session based on the following six match criteria:

- Source address
- Destination address
- Source port
- Destination port
- Protocol
- Unique token from a given zone and virtual router

The SPU checks its session table for an existing session for the packet. If no existent session is found, the SPU sets up a session for the flow. If a session match is found, the session has already been created, so the SPU performs fast-path processing on the packet.

Understanding Session Creation

In setting up the session, the SPU executes the following services for the packet:

- Screens
- Route lookup
- Policy lookup
- Service lookup
- NAT, if required

After a session is set up, it is used for all packets belonging to the flow. Packets of a flow are processed according to the parameters of its session. For the remainder of the steps entailed in packet processing, proceed to Step 1 in “Fast-Path Processing”. All packets undergo fast-path processing.

Understanding Fast-Path Processing

If a packet matches a session, Junos OS performs fast-path processing as described in the following steps. After a session has been set up for the first packet in a flow, also undergoes fast-path processing. All packets undergo fast-path processing.

1. The SPU applies flow-based security features to the packet.
 - Configured screens are applied.
 - TCP checks are performed.
 - Flow services, such as NAT, ALG, and IPsec are applied, if required.
2. The SPU prepares the packet for forwarding and transmits it.

- Routing packet filters are applied.
- Traffic shaping is applied.
- Traffic prioritizing is applied.
- Traffic scheduling is applied.
- The packet is transmitted.

**Related
Documentation**

- [Juniper Networks Devices Processing Overview on page 3](#)
- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)

PART 2

Configuring Flow-Based Sessions

- [Configuring Security Flow Sessions on page 29](#)

CHAPTER 2

Configuring Security Flow Sessions

- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)
- [Understanding Aggressive Session Aging on page 30](#)
- [Example: Controlling Session Termination for SRX Series Services Gateways on page 30](#)
- [Understanding TCP Session Checks per Policy on page 32](#)
- [Example: Disabling TCP Packet Security Checks for SRX Series Services Gateways on page 33](#)
- [Example: Setting the Maximum Segment Size for All TCP Sessions for SRX Series Services Gateways on page 34](#)
- [Example: Configuring TCP Packet Security Checks Per Policy on page 36](#)
- [Configuring the Timeout Value for Multicast Flow Sessions on page 37](#)
- [Clearing Sessions for SRX Series Services Gateways on page 39](#)

Understanding Session Characteristics for SRX Series Services Gateways

Sessions are created, based on routing and other classification information, to store information and allocate resources for a flow. Sessions have characteristics, some of which you can change, such as when they are terminated. For example, you might want to ensure that a session table is never entirely full to protect against an attacker's attempt to flood the table and thereby prevent legitimate users from starting sessions.

Depending on the protocol and service, a session is programmed with a timeout value. For example, the default timeout for TCP is 1800 seconds. The default timeout for UDP is 60 seconds. When a flow is terminated, it is marked as invalid, and its timeout is reduced to 2 to 4 seconds.

If no traffic uses the session before the service timeout, the session is aged out and freed to a common resource pool for reuse. You can affect the life of a session in the following ways:

- You can specify circumstances for terminating sessions by using any of the following methods:
 - Age out sessions based on how full the session table is
 - Set an explicit timeout for aging out TCP sessions
 - Configure a TCP session to be invalidated when it receives a TCP RST (reset) message

- You can configure sessions to accommodate other systems as follows:
 - Disable TCP packet security checks
 - Change the maximum segment size

Related Documentation

- [Juniper Networks Devices Processing Overview on page 3](#)
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
- [Clearing Sessions for SRX Series Services Gateways on page 39](#)
- [Example: Controlling Session Termination for SRX Series Services Gateways on page 30](#)

Understanding Aggressive Session Aging

The session table is a limited resource for SRX Series devices. If the session table is full, any new sessions will be rejected by the device.

The aggressive session-aging mechanism accelerates the session timeout process when the number of sessions in the session table exceeds the specified high-watermark threshold. This mechanism minimizes the likelihood that the SRX Series devices will reject new sessions when the session table becomes full.

Configure the following parameters to perform aggressive session aging:

- *high-watermark*—The device performs aggressive session aging when the number of sessions in the session table exceeds the *high-watermark* threshold.
- *low-watermark*—The device exits aggressive session aging and returns to normal when the number of sessions in the session table dips below the *low-watermark* threshold.
- *early-ageout*—During aggressive session aging, the sessions with an age-out time lower than the *early-ageout* threshold are marked as invalid.

On SRX1400, SRX3400, SRX3600, SRX5600, and SRX5800 devices, the SPU checks the session table, locates the sessions for which the timeout value is lower than the early-ageout time value, and then marks them as invalid.

Related Documentation

- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)
- [early-ageout on page 184](#)
- [high-watermark on page 189](#)
- [low-watermark on page 196](#)

Example: Controlling Session Termination for SRX Series Services Gateways

This example shows how to terminate sessions for SRX Series devices based on aging out after a certain period of time, or when the number of sessions in the session table is

full or reaches a specified percentage. You specify a timeout value or the number of sessions in the session table.

- [Requirements on page 31](#)
- [Overview on page 31](#)
- [Configuration on page 31](#)
- [Verification on page 32](#)

Requirements

Before you begin, understand the circumstances for terminating sessions. See [“Understanding Session Characteristics for SRX Series Services Gateways” on page 29](#).

Overview

You can control session termination in certain situations—for example, after receiving a TCP FIN Close or receiving an RST message, when encountering ICMP errors for UDP, and when no matching traffic is received before the service timeout. When sessions are terminated, their resources are freed up for use by other sessions.

In this example, you configure the following circumstances to terminate the session:

- A timeout value of 20 seconds.



NOTE: The minimum value you can configure for TCP session initialization is 4 seconds. The default value is 20 seconds; if required you can set the TCP session initialization value to less than 20 seconds.

- An explicit timeout value of 280 seconds, which changes the TCP session timeout during the three-way handshake.

The command sets the initial TCP session timeout to 280 in the session table during the TCP three-way handshake. The timer is initiated when the first SYN packet is received, and reset with each packet during the three-way handshake. Once the three-way handshake is completed, the session timeout is reset to the timeout defined by the specific application. If the timer expires before the three-way handshake is complete, the session is removed from the session table.

- Any session that receives a TCP RST (reset) message is invalidated.

Configuration

Step-by-Step Procedure

The following example requires you to navigate various levels in the configuration hierarchy. For instructions on how to do that, see *Using the CLI Editor in Configuration Mode* in the *CLI User Guide*.

To control session termination for SRX Series devices:

1. Specify an age-out value for the session.

[edit security flow]

- ```
user@host# set aging early-ageout 20
```
2. Configure an aging out value.  

```
[edit security flow]
user@host# set tcp-session tcp-initial-timeout 280
```
  3. Invalidate any session that receives a TCP RST message.  

```
[edit security flow]
user@host# set tcp-session rst-invalidate-session
```
  4. If you are done configuring the device, commit the configuration.  

```
[edit]
user@host# commit
```

## Verification

To verify the configuration is working properly, enter the **show security flow** command.

### Related Documentation

- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)
- [Example: Disabling TCP Packet Security Checks for SRX Series Services Gateways on page 33](#)
- [Example: Setting the Maximum Segment Size for All TCP Sessions for SRX Series Services Gateways on page 34](#)

## Understanding TCP Session Checks per Policy

---

By default, the TCP SYN check and sequence check options are enabled on all TCP sessions. The Junos operating system (Junos OS) performs the following operations during TCP sessions:

- Checks for SYN flags in the first packet of a session and rejects any TCP segments with non-SYN flags that attempt to initiate a session.
- Validates the TCP sequence numbers during stateful inspection.

The TCP session check per-policy feature enables you to configure SYN and sequence checks for each policy. Currently, the TCP options flags, no-sequence-check and no-syn-check, are available at a global level to control the behavior of services gateways. To support per-policy TCP options, the following two options are available:

- **sequence-check-required:** The sequence-check-required value overrides the global value no-sequence-check.
- **syn-check-required:** The syn-check-required value overrides the global value no-syn-check.

To configure per-policy TCP options, you must turn off the respective global options; otherwise, the commit check will fail. If global TCP options are disabled and SYN flood protection permits the first packet, then the per-policy TCP options will control whether SYN and/or sequence checks are performed.

**NOTE:**

- The per-policy SYN check required option will not override the behavior of the `set security flow tcp-session no-syn-check-in-tunnel` CLI command.
- Disabling the global SYN check reduces the effectiveness of the device in defending against packet flooding.

Disabling the global SYN check and enforcing the SYN check after policy search will greatly impact the number of packets that the router can process. This in turn will result in intense CPU operations. When you disable global SYN check and enable per-policy SYN check enforcement, you should be aware of this performance impact.

**Related  
Documentation**

- [Example: Configuring TCP Packet Security Checks Per Policy on page 36](#)

## Example: Disabling TCP Packet Security Checks for SRX Series Services Gateways

This example shows how to disable TCP packet security checks in the device.

- [Requirements on page 33](#)
- [Overview on page 33](#)
- [Configuration on page 34](#)
- [Verification on page 34](#)

### Requirements

Before you begin, understand the circumstances for disabling TCP packet security checks. See [“Understanding Session Characteristics for SRX Series Services Gateways” on page 29](#).

### Overview

Junos OS provides a mechanism for disabling security checks on TCP packets to ensure interoperability with hosts and devices with faulty TCP implementations. During no-SYN-check the Junos OS does not look for the TCP SYN packet for session creation. No-sequence check disables TCP sequence checking validation. Also, increases throughput. SYN check and sequence check are enabled by default. The `set security flow` command disables TCP SYN checks and TCP sequence checks on all TCP sessions thus reduces security. This may be required in scenarios with customers like big transfer files, or with applications that do not correctly work with standards.

## Configuration

**Step-by-Step Procedure** The following example requires you to navigate various levels in the configuration hierarchy. For instructions on how to do that, see *Using the CLI Editor in Configuration Mode* in the *CLI User Guide*.

To disable TCP packet security checks:

1. Disable the checking of the TCP SYN bit before creating a session.  
  
[edit security flow]  
user@host# **set tcp-session no-syn-check**
2. Disable the checking of sequence numbers in TCP segments during stateful inspection.  
  
[edit security flow]  
user@host# **set tcp-session no-sequence-check**
3. If you are done configuring the device, commit the configuration.  
  
[edit ]  
user@host# **commit**

## Verification

To verify the configuration is working properly, enter the **show security flow** command.

- Related Documentation**
- [Example: Controlling Session Termination for SRX Series Services Gateways on page 30](#)
  - [Example: Setting the Maximum Segment Size for All TCP Sessions for SRX Series Services Gateways on page 34](#)

---

## Example: Setting the Maximum Segment Size for All TCP Sessions for SRX Series Services Gateways

---

This example shows how to set the maximum segment size for all TCP sessions for SRX Series devices.

- [Requirements on page 34](#)
- [Overview on page 35](#)
- [Configuration on page 35](#)
- [Verification on page 36](#)

## Requirements

Before you begin, understand the circumstances for setting the maximum segment size. See “[Understanding Session Characteristics for SRX Series Services Gateways](#)” on [page 29](#).



## Overview

You can terminate all TCP sessions by changing the TCP maximum segment size (TCP-MSS). To diminish the likelihood of fragmentation and to protect against packet loss, you can use the `tcp-mss` statement to specify a lower TCP MSS value. This statement applies to all TCP SYN packets traversing the router's ingress interfaces whose MSS value is higher than the one you specify.

If the DF bit is set, it will not fragment the packet and Junos OS will send ICMP error type 3 code 4 packet to the application server (Destination Unreachable; Fragmentation Needed and DF set). This ICMP error message contains the correct MTU (as defined in `tcp-mss`) to be used by the application server, which should receive this message and adjust the packet size accordingly. This is specifically required with VPNs, as IPsec has added packet overhead; thus `tcp-mss` must be lowered appropriately.



**NOTE:** When running SRX Series devices in packet mode, you use the `set system internet-options tcp-mss` statement to adjust the TCP-MSS value. All ports are affected by the TCP-MSS configuration; you cannot exclude a particular port. When running SRX Series devices in flow mode, although you can use the `set system internet-options tcp-mss` statement, we recommend using only the `set security flow tcp-mss` statement to adjust the TCP-MSS value. If both statements are configured, the lower of the two values will take effect.

## Configuration

### Step-by-Step Procedure

To configure the maximum segment size for all TCP sessions:

1. Set the TCP maximum segment size for all TCP sessions.

```
[edit security flow]
user@host# set tcp-mss all-tcp mss 1300
```

2. If you are done configuring the device, commit the configuration.

```
[edit]
user@host# commit
```

### Results

From configuration mode, confirm your configuration by entering the **show security flow** command. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

For brevity, this **show** command output includes only the configuration that is relevant to this example. Any other configuration on the system has been replaced with ellipses (...).

```
[edit]
user@host# show security flow
...
```

```
tcp-mss{
 all-tcp{
 mss 1300;
 }
}
...
```

## Verification

To verify the configuration is working properly, enter the **show configuration security flow** command from operational mode.

```
user@host> show configuration security flow
tcp-mss{
 all-tcp{
 mss 1300;
 }
}
```

### Related Documentation

- [Example: Controlling Session Termination for SRX Series Services Gateways on page 30](#)
- [Example: Disabling TCP Packet Security Checks for SRX Series Services Gateways on page 33](#)

---

## Example: Configuring TCP Packet Security Checks Per Policy

This example shows how to configure TCP packet security checks for each policy in the device.

- [Requirements on page 36](#)
- [Overview on page 36](#)
- [Configuration on page 36](#)
- [Verification on page 37](#)

## Requirements

Before you begin, you must disable the tcp options, **tcp-syn-check**, and **tcp-sequence-check** that are configured at global level. See [“Example: Disabling TCP Packet Security Checks for SRX Series Services Gateways” on page 33](#).

## Overview

The SYN and sequence check options are enabled by default on all TCP sessions. In environments that need to support large file transfers, or that run nonstandard applications, it might be necessary to configure sequence and sync checks differently for each policy. In this example, you configure sequence and sync check for policy **pol1**.

## Configuration

### Step-by-Step Procedure

To configure TCP packet security checks at the policy level:

1. Configure the checking for the TCP SYN bit before creating a session.

```
[edit]
user@host# set security policies from-zone Zone-A to-zone Zone-B policy pol1 then
 permit tcp-options syn-check-required
```

2. Configure the checking for sequence numbers in TCP segments during stateful inspection.

```
[edit]
user@host# set security policies from-zone Zone-A to-zone Zone-B policy pol1 then
 permit tcp-options sequence-check-required
```

3. If you are done configuring the device, commit the configuration.

```
[edit]
user@host# commit
```

## Verification

To verify that the configuration is working properly, enter the **show security policies detail** command.

### Related Documentation

- [Understanding TCP Session Checks per Policy on page 32](#)
- [Example: Disabling TCP Packet Security Checks for SRX Series Services Gateways on page 33](#)
- [Example: Setting the Maximum Segment Size for All TCP Sessions for SRX Series Services Gateways on page 34](#)

## Configuring the Timeout Value for Multicast Flow Sessions

You can configure the timeout value for multicast flow sessions by configuring a custom application and associating the application with a policy.

Multicast flow sessions have one template session and one or more leaf sessions. Because these sessions are linked together, they can have only one timeout value. The timeout value for multicast flow sessions is determined by considering the timeout values configured in the leaf session policies and the IP protocol timeout values. The highest of these timeout values is selected as the multicast flow session timeout.

If no leaf session timeout values are configured, the IP protocol timeout value is automatically used as the timeout value for the multicast flow session. The IP protocol timeout is the default and is not configurable.

Configuring leaf session timeouts can be especially helpful for multicast streams that have a longer packet interval than the default IP protocol timeout. For example, multicast streams with a packet interval of more than 60 seconds would experience premature aging-out of flow sessions and packet drops with the UDP timeout value, which is always 60 seconds. For such streams, you can configure a higher leaf session timeout value and prevent packet drop.

To set the leaf session timeout value, configure a custom application and associate the application with a policy:

1. Create a custom application, specify its properties, and specify bypassing the application type.

```
[edit]
user@host# edit applications application my-udp

[edit applications application my-udp]
user@host# set protocol udp
user@host# set destination-port 5000
user@host# set application-protocol ignore
```

2. Set the timeout value for the application protocol.

```
[edit applications application my-udp]
user@host# set inactivity-timeout 500
```

3. Create a policy.

```
[edit]
user@host# edit security policies from-zone vr-zone-1 to-zone junos-host policy
my-policy

[edit security policies from-zone vr-zone-1 to-zone junos-host policy my-policy]
user@host# set match source-address 18.1.1.2
user@host# set match destination-address any
```

4. Associate the custom application (with the configured timeout) to the policy.

```
[edit security policies from-zone vr-zone-1 to-zone junos-host policy my-policy]
user@host# set match application my-udp
user@host# set then permit
```

5. If you are done configuring the device, commit the configuration.

```
[edit]
user@host# commit
```

6. To verify the updated session timeout value, enter the **show security flow session** command.

```
user@host> show security flow session destination-prefix 224.1.1.1
```

```
Session ID: 2363, Policy name: N/A, Timeout: 498, Valid
 In: 18.1.1.2/17767-->224.1.1.1/5000;udp, If: ge-0/0/1.0, Pkts:0, Bytes:0
 Out: 255.255.255.255/5000-->255.255.255.255/17767;udp, If:.local..4, Pkts:0,
 Bytes:0
```

```
Session ID: 2364, Policy name: my-policy/4, Timeout: -1, Valid
 In: 18.1.1.2/17767-->224.1.1.1/5000;udp, If:ge-0/0/1.0, Pkts:1011,
 Bytes:258816
 Out: 224.1.1.1/5000-->18.1.1.2/17767;udp, If:ppe0.32769, Pkts:0, Bytes:0
Total sessions: 2
```

In this output, the session ID 2363 section displays a template session. A timeout value of 498 indicates that the template session timeout value is ticking down from the configured value of 500 seconds.

The session ID 2364 section displays a leaf session. The timeout value of -1 essentially indicates that the session will not age out unless the template session ages out.

In this example, the configured leaf session timeout value of 500 seconds is the highest timeout value and is accepted as the template session timeout value for the multicast flow session.

**Related  
Documentation**

- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
- [Multicast Feature Guide for Security Devices](#)

---

## Clearing Sessions for SRX Series Services Gateways

You can use the **clear** command to terminate sessions. You can clear all sessions, including sessions of a particular application type, sessions that use a specific destination port, sessions that use a specific interface or port, sessions that use a certain IP protocol, sessions that match a source prefix, and resource manager sessions.

- [Terminating Sessions for SRX Series Services Gateways on page 39](#)
- [Terminating a Specific Session for SRX Series Services Gateways on page 39](#)
- [Using Filters to Specify the Sessions to Be Terminated for SRX Series Services Gateways on page 39](#)

### Terminating Sessions for SRX Series Services Gateways

You can use the following command to terminate all sessions except tunnel and resource manager sessions. The command output shows the number of sessions cleared. Be aware that this command terminates the management session through which the clear command is issued.

```
user@host> clear security flow session all
```

### Terminating a Specific Session for SRX Series Services Gateways

You can use the following command to terminate the session whose session ID you specify.

```
user@host> clear security flow session session-identifier 40000381
```

### Using Filters to Specify the Sessions to Be Terminated for SRX Series Services Gateways

You can terminate one or more sessions based on the filter parameter you specify for the **clear** command. The following example uses the protocol as a filter.

```
user@host> clear security flow session protocol 89
```



## PART 3

# Improving Flow-Based Performance

- Expanding Session Capacity by Device on page 43
- Managing Sessions and Flow Distribution on page 47
- Reducing Long Packet-Processing Latency by Express Path on page 53





## CHAPTER 3

# Expanding Session Capacity by Device

- [Expanding Session Capacity by Device on page 43](#)
- [Expanding Session Capacity on an SRX3400 or SRX3600 Device on page 44](#)
- [Reverting to Default Session Capacity on an SRX5800 Device on page 44](#)
- [Verifying the Current Session Capacity on page 44](#)

## Expanding Session Capacity by Device

---

To take advantage of the processing potential of a fully loaded SRX3400, SRX3600, or SRX5800 device, you can expand the maximum number of concurrent sessions for these devices.

[Table 4 on page 43](#) shows the maximum number of concurrent sessions allowed on these devices by default and with expanded capacity.

**Table 4: Maximum Central Point Session Increases**

| SRX Series Devices | Maximum Concurrent Sessions on a Fully Loaded System |                         |
|--------------------|------------------------------------------------------|-------------------------|
|                    | Default                                              | With Expanded Capacity  |
| SRX3400            | 2.25 million                                         | 3 million               |
| SRX3600            | 2.25 million                                         | 6 million               |
| SRX5400            | 42 million                                           | Expansion not available |
| SRX5600            | 114 million                                          | Expansion not available |
| SRX5800            | 258 million                                          | Expansion not available |

The method used for expanding session capacity depends on the device:

- Central point session license installation and validation on an SRX3400 or SRX3600 device
- CLI optimization option on an SRX5800 device

## Expanding Session Capacity on an SRX3400 or SRX3600 Device

---

Expanding session capacity on an SRX3400 or SRX3600 device requires validation of a central point session license on the device.

1. Obtain the central point session license key and install the license on the device. For license installation details, see *Administration Guide for Security Devices*.
2. Reboot the device to implement the expanded session capacity.

### Related Documentation

- [Expanding Session Capacity by Device on page 43](#)

## Reverting to Default Session Capacity on an SRX5800 Device

---

Reverting to the default session capacity on an SRX5800 device requires a CLI configuration change.

1. Enter the following command at the CLI configuration prompt to reestablish the default session capacity value:

```
user@host# set security gprs gtp enable
```

2. Reboot the device to implement the new value.

## Verifying the Current Session Capacity

---

**Purpose** The central point session summary includes the maximum sessions setting for the device. From this value you can determine if the session capacity has been modified as you expected.

**Action** To verify the current setting of the central point session capacity, enter the following CLI command.

```
user@host> show security flow cp-session summary
```

```
DCP Flow Sessions on FPC10 PIC0:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

```
DCP Flow Sessions on FPC10 PIC1:
```

```
Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 2
Maximum sessions: 7549747
Maximum inet6 sessions: 7549747
```

## DCP Flow Sessions on FPC10 PIC2:

Valid sessions: 2  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 2  
Maximum sessions: 7549747  
Maximum inet6 sessions: 7549747

## DCP Flow Sessions on FPC10 PIC3:

Valid sessions: 1  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 1  
Maximum sessions: 7549747  
Maximum inet6 sessions: 7549747

**Meaning** The **Maximum sessions** value reflects the current session capacity on your device. A value of 14000000 means that the SRX5800 device is configured for the expanded number of central point sessions.



## CHAPTER 4

# Managing Sessions and Flow Distribution

- [Understanding Load Distribution in High-End SRX Series Devices on page 47](#)
- [Understanding Load Distribution on SRX5000 Line Devices Using the Packet-Ordering Function on page 49](#)
- [Disabling Packet-Ordering Mode on SRX5000 Line Devices on page 50](#)

## Understanding Load Distribution in High-End SRX Series Devices

---

The load distribution algorithm is adjusted based on session capacity and processing power.

Hash-based session distribution uses a hash table. The SPU session weight table is used to assign an SPU ID to each hash index in the session distribution hash table. This way, the number of sessions created on each SPU using hash-based distribution is proportional to the SPU's weight in the SPU session weight table. Each NPU also keeps an identical SPU session weight table and session distribution hash table that it uses to select an SPU to forward packets that do not match an NPU session.

In hash-based session distribution, weights are based on session capacity. We recommend the hash session distribution mode when high session capacity is required.



**NOTE:** Load distribution on SRX5000 line devices is always hash-based.

Insertion and removal of SPCs causes recalculation of the SPU session weight table at central point initialization time because the chassis must reboot after insertion.

## Hash-Based Forwarding on the SRX5K-MPC, SRX5K-MPC3-40G10G (IOC3), and the SRX5K-MPC3-100G10G (IOC3)

On a high-end SRX Series device, a packet goes through a series of events involving different components as it progresses from ingress to egress processing. With the datapath packet forwarding feature, you can obtain quick delivery of I/O traffic over the SRX 5000 line of devices.

The SRX5K-MPC, SRX5K-MPC3-40G10G (IOC3), and SRX5K-MPC3-100G10G (IOC3) are interface cards supported on the SRX5400, SRX5600, and SRX5800 devices. The

Modular Port Concentrator (MPC) provides load-balancing services for Services Processing Units (SPUs) by using the hash-based forwarding method.

In hash-based forwarding, the packet might be forwarded by the MPC to a selected SPU (DCP) instead of the central point. This approach enhances session scaling and prevents overloading of the central point.

Hash value calculation involves the following steps:

- For IPv4 packets, the hash-based forwarding module generates the hash value based on Layer 3 and Layer 4 information, depending on different Layer 4 protocol types.
- For Stream Control Transmission Protocol (SCTP), TCP, UDP, Authentication Header (AH), edge service provider (ESP), and Internet Control Message Protocol (ICMP) protocols, the hash module utilizes Layer 4 information to generate the hash value. For any other protocols, only Layer 3 information is used in hash generation.
- For IPv4 fragment packets, the hash value is calculated using only the Layer 3 information. This also applies to the first fragment of the packet.
- For non-IP packets, the hash-based forwarding module uses the Layer 2 information to calculate the hash value.

Once a hash value is calculated according to the packet's Layer 2, Layer 3, or Layer 4 information, an SPU ID is assigned to each hash index in the session distribution hash table.



**NOTE:** The SRX5K-MPC (IOC2), SRX5K-MPC3-40G10G (IOC3), and SRX5K-MPC3-100G10G (IOC3) can only be used on SRX5400, SRX5600, and SRX5800 devices that are configured for hash-based session distribution.

When the hash-based session distribution mode is enabled, the system changes its behavior to high-session-capacity-based mode when the SRX5K-MPC, SRX5K-MPC3-40G10G (IOC3), and SRX5K-MPC3-100G10G (IOC3) are installed on the device.



**NOTE:** On SRX5000 line devices with an SRX5K-MPC, SRX5K-MPC3-40G10G (IOC3), or SRX5K-MPC3-100G10G (IOC3) installed, during a system or an SPU reboot, when the hash-based session distribution mode is enabled, traffic will pass only when all SPUs are up after the reboot.

The MPCs on the IOC3 provide load-balancing services for SPUs by performing hash-based datapath packet forwarding to interconnect with all existing IOCs and SPCs.

The IOC3 processes ingress and egress packets. The IOC3 parses the ingress packet and sends it to the SPU for further security processing, including flow session lookup, zone and policy check, VPN, ALG, and so on.

The IOC3 manages packet data memory and fabric queuing for packet lookup and encapsulation functions.



**NOTE:** Starting with Junos OS Release 15.1X49-D10, hash-based session distribution is the default mode for the SRX5400, SRX5600, and SRX5800 devices. Selection of hash keys depends on application protocols.

The IOC3 sets up a security flow table (IPv4 and IPv6) including key, result table, and packet memory.

The following functions are provided with the flow table:

- Flow lookup
- Flow insertion and deletion
- Security flow aging out
- Security flow statistics

## Understanding Load Distribution on SRX5000 Line Devices Using the Packet-Ordering Function

The packet-ordering function improves the performance of the device by activating the built-in packet-ordering function of the Packet Ordering Engine on the XLP processor on the application central point. When you activate the packet-ordering function, the load-balancing thread (LBT) and the packet-ordering thread (POT) are removed and their core is freed to run the flow thread.

The flow thread receives the packets, processes them, and sends or drops them. For packets that require no ordering, the flow thread notifies the Network Acceleration Engine (NAE) egress to send or drop the packets. For packets that require ordering, the flow thread notifies the Packet Ordering Engine to dequeue the packets from the ordering list and to send or drop the packets in order.

The packet-ordering functionality using the Packet Ordering Engine is supported on SRX5400, SRX5800 and SRX5600 devices with next-generation SPCs.

### Related Documentation

- [Understanding SRX Series Services Gateways Central Point Architecture on page 7](#)
- [Disabling Packet-Ordering Mode on SRX5000 Line Devices on page 50](#)
- [packet-ordering-mode \(Application Services\) on page 202](#)

## Disabling Packet-Ordering Mode on SRX5000 Line Devices

---

The packet-ordering functionality using the Packet Ordering Engine is supported on SRX5400, SRX5800 and SRX5600 devices with next-generation SPCs. By default, packet-ordering mode using the Packet Ordering Engine is enabled. To disable the packet-ordering functionality using the Packet Ordering Engine, you must update the packet-ordering mode on the device.

The following packet ordering modes are supported:

- software—Disables the packet-ordering mode using the Packet Ordering Engine.
- hardware—Enables the packet-ordering mode using the Packet Ordering Engine. This is the default option.

To disable the packet-ordering mode using the Packet Ordering Engine:

1. Enter the following command at the CLI configuration prompt to specify the packet-ordering mode.

```
[edit]
user@host# set security forwarding-process application-services
packet-ordering-mode software
```

2. Use the **show security forwarding-process** command to review your configuration.

```
[edit]
user@host# show security forwarding-process
application-services{
 packet-ordering-mode software;
}
```

3. Check your changes to the configuration before committing.

```
[edit]
user@host# commit check
```

```
warning: System packet ordering mode changed, reboot is required to take effect.
If you have deployed a cluster, be sure to reboot all nodes.
configuration check succeeds
```

4. Commit the configuration.

```
[edit]
user@host# commit
```

```
warning: System packet ordering mode changed, reboot is required to take effect.
If you have deployed a cluster, be sure to reboot all nodes.
commit complete
```

5. Reboot the device at an appropriate time.

6. Use the **show security flow status** command to verify the packet-ordering mode.

```
user@host> show security flow status
```

```
Flow forwarding mode:
Inet forwarding mode: flow based
Inet6 forwarding mode: drop
MPLS forwarding mode: drop
```



ISO forwarding mode: drop  
Flow trace status  
Flow tracing status: off  
Flow session distribution  
Distribution mode: RR-based  
Flow packet ordering  
Ordering mode: Software (reboot needed to change to Software)

**Related Documentation** • [Understanding Load Distribution on SRX5000 Line Devices Using the Packet-Ordering Function on page 49](#)



## CHAPTER 5

# Reducing Long Packet-Processing Latency by Express Path

- Understanding Session Cache on page 53
- Express Path Overview on page 57
- Understanding the Express Path Solution on page 69
- Enabling and Disabling Express Path on page 70
- Example: Enabling Express Path in Security Policies on page 72
- Example: Configuring an NPC on SRX3000 Line Devices or SRX1400 Devices to Support Express Path on page 74
- Example: Configuring an IOC on SRX5000 Line Devices to Support Express Path on page 75
- Example: Configuring an NP-IOC on SRX3000 Line Devices or SRX1400 Devices to Support Express Path on page 77
- Example: Configuring an SRX5K-MPC on an SRX5000 Line Device to Support Express Path on page 78
- Example: Configuring SRX5K-MPC3-100G10G (IOC3) and SRX5K-MPC3-40G10G (IOC3) on an SRX5000 Line Device to Support Express Path on page 81
- Example: Configuring Low Latency on page 83

## Understanding Session Cache

---

- Overview on page 53
- Selective Session Cache Installation on page 55
- IPsec VPN Session Affinity Enhancement Using Session Cache on page 56
- Fragmentation Packet Ordering Using NP Session Cache on page 56

### Overview

The SRX5K-MPC (IOC2), SRX5K-MPC3-100G10G (IOC3), and SRX5K-MPC3-40G10G (IOC3) on SRX5400, SRX5600, and SRX5800 devices support session cache and selective installation of the session cache.

Session cache is used to cache a conversation between the network processor (NP) and the SPU on an IOC. A conversation could be a session, GTP-U tunnel traffic, IPsec VPN tunnel traffic, and so on. A conversation has two session cache entries, one for incoming traffic and the other for reverse traffic. Depending on where the traffic ingress and egress ports are, two entries might reside in the same network processor or in different network processors. IOCs support session cache for IPv6 sessions.

A session cache entry is also called a *session wing*.

Session cache on the IOC leverages Express Path (formerly known as *services offloading*) functionality and helps prevent issues such as high latency and IPsec performance drop.

A session cache entry records:

- To which SPU the traffic of the conversion should be forwarded
- To which egress port the traffic of the conversion should be forwarded in Express Path mode
- What processing to do for egress traffic, for example, NAT translation in Express Path mode

Prior to Junos OS Release 15.1X49-D10, on the IOC2, session cache was used for Express Path sessions only. Other traffic was hashed to SPUs based on their 5-tuple key information. VPN traffic employed the concept of the anchored SPU, which did not necessarily coincide with the functions of the flow SPU. The network processor could only forward the packets to the flow SPU based on the 5-tuple hash. The flow SPU then forwarded the packet to the anchored SPU. This created an extra hop for VPN traffic, which wasted the switch fabric bandwidth and reduced the VPN throughput roughly by half. This performance reduction occurred because the traffic still had to go back to the flow SPU after processing on the anchored SPU.

Starting with Junos OS Release 15.1X49-D10, the session cache of the sessions in the IOC helps solve these issues. The SPU can now instruct the IOC session cache to forward subsequent traffic to a specific anchor SPU.

The session cache table is extended on IOC to support the NP sessions. Express Path traffic and NP traffic share the same session cache table on IOCs. Express Path traffic is forwarded by the IOC itself either locally or to another IOC, because the traffic does not require any services from the SPU. NP traffic is forwarded to the SPU specified in the session cache for further processing. All the session cache entries are shared by both Express Path session traffic and NP traffic.

To enable session cache on the IOCs you need to run the **set chassis fpc <fpc-slot> np-cache** command.



**NOTE:** The IOC2 and the IOC3 utilize the delay sessions delete mechanism. The same sessions (sessions with the same five tuples) that are deleted and then reinstalled immediately are not cached on the IOCs.

---

## Selective Session Cache Installation

To avoid high latency, improve IPSec performance, and to better utilize the valuable resources, certain priority mechanisms are applied to both flow module and the IOC.

The IOCs maintain and monitor session cache usage threshold levels. The IOCs also communicate the session cache usage to the SPU, so that when a certain session cache usage threshold is reached, the SPU only sends session cache installation requests for selective high-priority traffic sessions.

The following three priority levels are used to determine which type of traffic can install session cache on the IOCs:

- **Priority 1 (P1)**—Express Path qualified traffic
- **Priority 2 (P2)**—IPsec tunneling, Fragmentation ordering, and NAT/SZ traffic
- **Priority 3 (P3)**—All other types of traffic

The IOCs maintain and monitor session cache usage threshold levels. Session cache usage less than 25 percent is defined as “green,” 26 to 50 percent is “yellow,” 51 to 99 percent is “orange,” and 99 percent and above is defined as “red.” The IOCs update current real-time session cache usage to the SPU. The SPU requests the IOC to install the session cache for selective high-priority traffic sessions. When the session cache usage is green, the session cache will be installed for all types of traffic. When the usage is yellow, session can be installed only for certain sessions including IPsec, Fragmentation, and NAT/SZ traffic sessions, and when the usage is orange, only Express Path qualified sessions will be installed. When the session cache usage is red, NP cache and the Express Path sessions are not allowed to install from SPU to the IOCs.

[Table 5 on page 55](#) shows the NP cache installation bars for different types of traffic.

**Table 5: Session Cache Installation Bars**

| Traffic Type                             | Green | Yellow | Orange | Red |
|------------------------------------------|-------|--------|--------|-----|
| Express Path traffic                     | Yes   | Yes    | Yes    | No  |
| IPsec, Fragmentation, and NAT/SZ traffic | Yes   | Yes    | No     | No  |
| Other traffic                            | Yes   | No     | No     | No  |

To conserve session entries on the IOC, the flow module selectively installs sessions on the IOC. To facilitate the session install selection, the IOC maintains corresponding thresholds to provide an indication to the flow module (on how full the session cache table is on the IOCs). Two bits in the meta header (see [Table 6 on page 56](#)) are added to indicate the current cache table utilization status. All packets going to the SPU will carry these two status bits to inform the flow module of the utilization of the cache table on the IOC.

Table 6 on page 56 shows the cache table utilization (CTU) bits and the respective session cache table utilization.

**Table 6: Session Cache Table Utilization Bits Status**

| Session Cache Table Utilization (CTU) Bits | IOC Session Cache/Express Path Table Utilization | Action                                                                                                                   |
|--------------------------------------------|--------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| 00                                         | 0% < utilization < 25%                           | Flowd installs any eligible session.                                                                                     |
| 01                                         | 25% < utilization < 75%                          | Flowd installs only high-priority sessions, such as Express Path, IPsec, IPsec clear-text, NAT, and fragmented sessions. |
| 10                                         | 75% < utilization < 100%                         | Flowd installs only Express Path sessions.                                                                               |
| 11                                         | NP cache/Express Path table is full              | Flowd stops installing sessions.                                                                                         |

## IPsec VPN Session Affinity Enhancement Using Session Cache

SRX Series devices are fully distributed systems, and an IPsec tunnel is allocated and anchored to a specific SPU. All the traffic that belongs to an IPsec tunnel is encrypted and decrypted on its tunnel-anchored SPU. In order to achieve better IPsec performance, IOC improves the flow module to create sessions for IPsec tunnel-based traffic (before encryption and after decryption) on its tunnel-anchored SPU, and installs session cache for the sessions so that the IOC can redirect the packets directly to the same SPU to minimize packet-forwarding overhead. Express Path traffic and NP traffic share the same session cache table on IOCs.

You need to enable session cache on the IOCs and set the security policy to determine whether a session is for Express Path (formerly known as *services offloading*) mode on the selected Flexible PIC Concentrator (FPC).

To enable IPsec VPN affinity use, the **set security flow load-distribution session-affinity ipsec** command.

## Fragmentation Packet Ordering Using NP Session Cache

A session might consist of both normal and fragmented packets. With hash-based distribution, 5-tuple and 3-tuple key can be used to distribute normal and fragmented packets to different SPUs, respectively. On SRX Series devices, all the packets of the session are forwarded to a processing SPU. Due to forwarding and processing latency, the processing SPU might not guarantee packet ordering of the session.

Session cache on the IOCs ensure ordering of packets of a session with fragmented packets. A session cache entry is allocated for normal packets of the session and a 3-tuple key is used to find the fragmented packets. On receipt of the first fragmented packet of the session, the flow module allows the IOC to update the session cache entry to

remember the fragmented packets for the SPU. Later, IOC forwards all subsequent packets of the session to the SPU to ensure ordering of packets of a session with fragmented packets.

- Related Documentation**
- [Express Path Overview on page 57](#)
  - [Understanding VPN Session Affinity](#)

---

## Express Path Overview

### Understanding Express Path Functionality

Express Path (formerly known as *services offloading*) is a mechanism for processing fast-path packets in the network processor instead of in the Services Processing Unit (SPU). This method reduces the packet-processing latency that arises when packets are forwarded from network processors to SPUs for processing and back to I/O cards (IOCs) for transmission.

Express Path considerably reduces packet-processing latency by 500–600 percent.

When the first packet arrives at the interface, the network processor forwards it to the SPU. If the SPU verifies that the traffic is qualified for Express Path, an Express Path session is created on the network processor. If the traffic does not qualify for Express Path, a normal session is created on the network processor. If an Express Path session is created, the subsequent fast-path packets are processed in the network processor itself.



**NOTE:** A normal session forwards packets from the network processor to the SPU for fast-path processing, whereas an Express Path session processes fast-path packets in the network processor and the packets exit out of the network processor itself.

When an Express Path session is created on the network processor, subsequent packets of the flow match the session on the network processors. The network processor then processes and forwards the packet. The network processor also handles additional processing such as TCP sequence check, time to live (TTL) processing, Network Address Translation (NAT), and Layer 2 header translation.

The network processor forwards packets to the SPU in the following cases:

- When the first packet arrives at the interface, the network processor forwards it to the central point (CP). The central point in turn forwards the packet to the SPU. The SPU then creates a session on the network processor.
- When an SPU session exists even if no network processor session exists, the network processor forwards a packet to the central point, which in turn forwards the packet to the SPU. The SPU then creates a session on the network processor.
- When a packet matches a normal session on the network processor, it is forwarded to the SPU.



**NOTE:** Prior to Junos OS Release 12.3X48-D10, Express Path was a licensed software feature. Starting with Junos OS Release 12.3X48-D10, the Express Path license is no longer required to enable this functionality. Your previously acquired Express Path license will not be effective anymore.

## Understanding Express Path Support on SRX Series Devices

Table 7 on page 58 provides details about the Express Path support on different SRX Series cards.

**Table 7: Express Path Support on SRX Series Device Cards**

| SRX Series Device                                        | Card Name and Model Number                                                                                                                                                                               | Earliest Supported Release   |
|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>SRX5000 Line Devices I/O Cards (IOCs)</b>             |                                                                                                                                                                                                          |                              |
| SRX5600, SRX5800                                         | SRX5K-40GE-SFP                                                                                                                                                                                           | Junos OS Release 11.4        |
| SRX5600, SRX5800                                         | SRX5K-4XGE-XFP                                                                                                                                                                                           | Junos OS Release 11.4        |
| SRX5600, SRX5800                                         | SRX5K-FPC-IOC containing one of the following cards: <ul style="list-style-type: none"> <li>SRX-IOC-16GE-TX</li> <li>SRX-IOC-4XGE-XFP</li> <li>SRX-IOC-16GE-SFP</li> </ul>                               | Junos OS Release 11.4        |
| SRX5400, SRX5600, SRX5800                                | SRX5K-MPC containing one of the following MICs: <ul style="list-style-type: none"> <li>SRX-MIC-10XGE-SFFP</li> <li>SRX-MIC-2X40GE-OSFP</li> <li>SRX-MIC-1X100GE-CFP</li> <li>SRX-MIC-20GE-SFP</li> </ul> | Junos OS Release 12.3X48-D10 |
| SRX5400, SRX5600, SRX5800                                | SRX5K-MPC3 (IOC3) containing one of the following MPCs: <ul style="list-style-type: none"> <li>SRX5K-MPC3-40G10G (24x10GE + 6x40GE MPC)</li> <li>SRX5K-MPC3-100G10G (2x100GE + 4x10GE MPC)</li> </ul>    | Junos OS Release 15.1X49-D10 |
| <b>SRX1400 and SRX3000 Line Devices I/O Cards (IOCs)</b> |                                                                                                                                                                                                          |                              |
| SRX1400, SRX3400, SRX3600                                | SRX3K-16GE-TX                                                                                                                                                                                            | Junos OS Release 11.4        |
| SRX1400, SRX3400, SRX3600                                | SRX3K-16GE-SFP                                                                                                                                                                                           | Junos OS Release 11.4        |



Table 7: Express Path Support on SRX Series Device Cards (*continued*)

| SRX Series Device                                 | Card Name and Model Number | Earliest Supported Release   |
|---------------------------------------------------|----------------------------|------------------------------|
| SRX1400, SRX3400, SRX3600                         | SRX3K-2XGE-XFP             | Junos OS Release 11.4        |
| <b>SRX1400 and SRX3000 Line Devices NP-IOC</b>    |                            |                              |
| SRX1400, SRX3400, SRX3600                         | SRX1K3K-NP-2XGE-SFPP       | Junos OS Release 12.1X44-D10 |
| <b>SRX3000 Line Devices Switch Fabric Board</b>   |                            |                              |
| SRX3400, SRX3600                                  | SRX3K-SFB-12GE             | Junos OS Release 11.4        |
| <b>SRX1400 Devices System I/O Cards (SYSIOCs)</b> |                            |                              |
| SRX1400                                           | SRX1K-SYSIO-GE             | Junos OS Release 11.4        |
| SRX1400                                           | SRX1K-SYSIO-XGE            | Junos OS Release 11.4        |



**NOTE:** Different Express Path features are supported on different cards for different Junos OS releases. See the *Junos OS Release Notes* for details.



**NOTE:** On the SRX5600 and SRX5800 Services Gateways, the Express Path sessions for traffic that traverse between legacy IOC cards and the SRX5K-MPC or the SRX5K-MPC3 are not supported.

The Express Path sessions traversing only on legacy IOC cards or only on the SRX5K-MPC (IOC2), the SRX5K-MPC3-100G10G (IOC3), or the SRX5K-MPC3-40G10G (IOC3) are supported. However, the SRX5K-MPC (IOC2), the SRX5K-MPC3-100G10G (IOC3), the SRX5K-MPC3-40G10G (IOC3), and the legacy IOCs can still be present on the same chassis.

### Express Path Support on NP-IOC Card

The NP-IOC card integrates an existing I/O card (IOC) with a Network Processing Card (NPC) in one card with simplified Layer 2 functions in the hardware. This new hardware changes the way the interface is interpreted in the system. Currently, in the SRX3000 line all interfaces are assigned an internal global port number for interface configuration and management purposes. However, this method limits the slot positions in which an IOC card can be inserted (that is, an IOC can only be present in slot numbers 0–3). An NP-IOC can be present in any of the slots, meaning that there also can be an interface at any slot.



**NOTE:** Each interface in the NP-IOC card can only be attached to the network processor on the NP-IOC card. This fixed attachment setup requires the network processor to manage the interfaces as local or relative interfaces, instead of systemwide global interfaces.

Besides providing physical layer network connections, another function of the NP-IOC card is to distribute packets coming into the physical ports to the Services Processing Units (SPUs) and to forward packets out of the physical ports. For parallel security processing, flow sessions are assigned to multiple SPUs, based on a load balance algorithm. The network processor on the NP-IOC is responsible for directing traffic to the proper SPU based on the session table installed in its local memory.

In Express Path mode, the first packet is processed as is, meaning the packet is forwarded to the central point and the central point assigns an SPU and passes the packet to the SPU. For packets in fast-path, instead of forwarding all packets to the SPU, the network processor forwards the packets to an egress network processor, which can be different from or the same as the ingress network processor.

### Express Path Support on SRX5K Modular Port Concentrator

The SRX5K-MPC is a Modular Port Concentrator (MPC) that is supported on the SRX5400, SRX5600, and SRX5800.

The SRX5K-MPC is an interface card with two slots that accept MICs, which add Ethernet ports to your services gateway. An MPC with MICs installed functions in the same way as a regular I/O card (IOC) but allows you to add different types of Ethernet ports to your device.

Each MPC is equipped with Trio chipsets, which perform control functions tailored to the MPC's media type.

When a Trio chipset receives the first packet, the packet is forwarded to an SPU based on the hash value (which is determined by a hash function of the 5 tuples of the session).

If the SPU verifies that the traffic is qualified for Express Path (formerly known as *services loading*), an Express Path session is created on the Trio chipset. If the traffic does not qualify for Express Path, it is forwarded by default hash-based forwarding to SPUs. If an Express Path session is created, the subsequent fast-path packets are processed in the Trio chipset itself.

The Trio chipset performs all the necessary checks to forward the packet, including TTL checking and decreasing, TCP sequence check, NAT translation, and Layer 2 header encapsulation. In addition, the Trio chipset sends a session refresh message to the SPU every second. This message is used to refresh the SPU session, detect the current state of the Trio chip set and update SPU session statistics.

The session table on the SRX5K-MPC, managed by the SPU, provides the following functions:

- Flow insert or delete
- Flow lookup
- Flow aging
- Flow statistics

The SPU inserts and deletes flow entries in the session table based on policy matching results.



**NOTE:** Configuring the screen options on an SRX5K-MPC when operating in Express Path mode is the same as when the card is operating in normal mode.

### Express Path Support on SRX5K-MPC3-100G10G (IOC3) and SRX5K-MPC3-40G10G (IOC3)

Express Path (formerly known as *services loading*) on the IOC3 is based on processing fast-path packets through the Trio chipset instead of in the SPU to offload some basic firewall functions to the IOC3.

When the Express Path feature is enabled, the IOC3 provides much lower latency, and also supports higher throughput by removing the overload on the SPU. The IOC3 supports both intra-card traffic flow and inter-card traffic flow. To achieve the best latency results, both the ingress port and egress port of a traffic flow need to be on the same XM chip of the IOC3.

The flow table on the IOC3 is managed by the SPU of the flow module. The SPU inserts and deletes flow entries in the flow table based on policy matching results. In the data plane, the IOC3 parses packets, and looks them up in the flow table. If the IOC3 finds a match in the flow table, then it forwards packets based on the instructions given in the flow table. The IOC3 can perform NAT, encapsulate the Level 2 (L2) header, and forward the packets out of the egress interface. The egress interface can be located on the same IOC3 (intra-card case) or on another IOC3 (inter-card case).



**NOTE:** Flow table lookup in the IOC3 occurs only in ingress. Egress datapath packet handling is the same as supported in the previous release.

When the IOC3 receives the first packet, it does not match any existing fast-forward session. The default hash-based forwarding is performed to send the first packet to the SPU. The SPU then creates the security session. If the SPU finds that the traffic is qualified for fast forwarding, and the related IOC3 supports fast forwarding, it will install fast-forward session to the IOC3. If fast forwarding cannot be applied to the traffic, no session message is sent, and the IOC3 uses the default hash-based forwarding to forward the packets to the SPU.

In fast-forward IOC3 processing, if a fast-forward session is matched, the packet can be directly forwarded according to the session flow result. The IOC3 takes all the necessary actions, including forwarding the packet, TTL checking and decreasing, NAT translation, L2 header encapsulation and so on.

In addition, the XL chip sends one copy of the forwarding packet to the SPU at every predefined time. This copy is used to refresh the SPU session, detect the current XL chip state, and so on. The SPU consumes this packet and does not forward it, because the real packet has been processed and transmitted.

Express Path support on IOC3 is illustrated in Figure 6 on page 62, Figure 7 on page 62, and Figure 8 on page 63

Figure 6: IOC3 Intra-PFE Express Path




Figure 7: IOC3 Inter-PFE Express Path





Figure 8: Inter-IOC3 Express Path



## Understanding Express Path Features

### Wing Statistics Counter

The network processor in Express Path mode provides the option for each flow entry to keep a per-wing bytes counter. The counter captures the number of bytes that the network processor sends out over the wing.

When the counter is enabled, for every ingress packet, the network processor searches its flow entry (a session wing). If the packet belongs to an established flow entry, the network processor increases the byte counter of the flow entry by byte count in the packet. The network processor periodically copies a packet (called a copy-packet) of each flow entry to its associated SPU, allowing the SPU to maintain the session. The network processor sends flow byte counter values in the header of copy-packet packets. The SPU accumulates and keeps per-wing statistics counters.



**NOTE:** The counter value carried to the SPU is always one packet short to allow the SPU to add the current packet's byte count to the counter to get the correct total. For example, if packet N's copy carries a counter value to the SPU, the counter value is the total bytes received in the flow up to packet N-1.

The counter value does not include packets that were sent before the session was set up on the network processor. Therefore, the SPU might need to account for the three-way handshake packet and other packets sent through the SPU. The actual session byte counter shown on the SPU might be short by the amount of bytes sent by the client during the copy interval. This discrepancy results because these bytes can be counted locally by the network processor, but have not yet been reported to the SPU.



**NOTE:** You cannot change the statistics configuration during the life cycle of a live session. Disabling or enabling the per-wing statistics configuration while a session is alive at the network processor invalidates the session statistics on the current session. The new sessions statistics can be valid only after the configuration changes are committed. Network processor per-wing counters cannot be cleared.



**NOTE:** Wing statistics counter configuration is not supported on the SRX5K-MPC.

### Sessions per Wing Statistics

The NP-IOC has a larger static RAM (SRAM) to accommodate session resources, thus hosting more sessions per PIC. [Table 8 on page 64](#) displays the total number of session wings, including both Express Path and non-Express Path.

**Table 8: Total Number of Sessions per Wing in Network Processor Express Path Configuration Mode**

| Total Number of Wings                    |                                | Number of Express Path UDP Wings |                 | Number of Express Path TCP Wings |                 |
|------------------------------------------|--------------------------------|----------------------------------|-----------------|----------------------------------|-----------------|
| Cards and SRX Series Device              | Non-Express Path Mode Sessions | Without Statistics               | With Statistics | Without Statistics               | With Statistics |
| IOC                                      | 1.3 million                    | 1.3 million                      | 900,000         | 600,000                          | 400,000         |
| FIOC                                     | 2.3 million                    | 198,000                          | 900,000         | 600,000                          | 400,000         |
| SRX3000 line device/NP-IOC               | 2.3 million                    | 2.3 million                      | 2.3 million     | 2 million                        | 1.5 million     |
| SRX3000 line device/NPC                  | 2.3 million                    | 512,000                          | 256,000         | 170,000                          | 128,000         |
| SRX5000 line device<br>SRX5K-MPC         | NA                             | 1.8 million                      | 1.8 million     | 1.8 million                      | 1.8 million     |
| SRX5000 line device<br>SRX5K-MPC3 (IOC3) | NA                             | 2.0 million                      | 2.0 million     | 2.0 million                      | 2.0 million     |

### Cross-Network Traffic

Express Path provides additional cross-network-processor support; therefore, it is no longer restricted to the ports of the same network processor. If network processors for both the ingress and egress ports are in Express Path mode, then Express Path packets

are directly forwarded from the ingress network processor to the egress network processor in the fast-flow path. Packets cross switch fabric when they are forwarded from one network processor to another, thus increasing the latency of the packet. In Express Path mode, the latency of cross-network-processor packets is higher than the packets that are forwarded within an individual network processor.



**NOTE:** The SRX5K-MPC receives session messages from the SPU. The session messages carry the information to support inter- and intra-Packet Forwarding Engine Express Path for IPv4.

### LAG Support in Express Path Mode

Ethernet link aggregation groups (LAGs) combine links and provide increased bandwidth and link availability. Express Path reduces packet latency by processing and forwarding packets in the network processor instead of in the Services Processing Unit (SPU). Supporting LAG in the Express Path mode combines the benefits of both these features and provides enhanced throughput, link redundancy, and reduced packet latency.

#### *Qualifying for Express Path Mode*

You can use the links in a LAG as ingress or egress interfaces in Express Path mode. The LAG links can include links from different network processors (in case of legacy cards such as IOCs or Flex IOCs) or from the same modular port concentrator (in case of SRX5K-MPC). For a LAG link to qualify for Express Path, all its member links should be connected to Express Path-enabled network processors. If Express Path is disabled on any of the member links in a LAG, a regular session (non-Express Path session) is created. Also, LAG links are not supported between legacy cards such as IOCs or Flex IOCs and the SRX5K-MPC.

#### *LAG and Network Processor Wings*

The network processor checks the egress interface in the Express Path mode for each wing. Per-wing traffic distribution over a LAG interface is achieved by letting the SPU install wings pointing to egress interfaces with a balanced distribution.

The network processor periodically copies a packet (called a *copy-packet*) to the SPU, allowing it to maintain the session. The copy-packet contains the egress interface information, which the SPU uses to handle LAG member change cases; for example, when a link is down or disabled. When there is no member interface that can be used as an egress interface for transmitting traffic, the network processor session is updated from Express Path to non-Express Path and the packet is sent to the SPU. A new Express Path network processor session is then installed using a new, valid egress interface.

- **First wing**—On the egress interface, the SPU selects one LAG active member link as the outgoing interface for a specific fast-forward session. The SPU treats this active member interface just like any physical interface in the Express Path mode and records the interface to the network processor fast-forward session. After that, all traffic that matches this network processor session is directly transmitted through that member link.

- Reverse wing—the reverse network processor session is installed only when all LAG member links are connected to a single network processor. When member links of a LAG are from multiple network processors, the reverse network processor session is initiated by reverse traffic later (it is not preinstalled).

The Express Path network processor session needs to have outgoing interface information to send traffic. If the incoming interface is a physical interface, then it can be used as an outgoing interface for the reverse wing. However, if the incoming interface is an aggregated Ethernet interface, the SPU selects a member interface to be the outgoing interface.

### ***LAG and Network Processor Session Updates***

Some changes in the LAG interfaces can cause network processor session updates:

- LAG interface status changes—The LAG interface status can change due to several reasons—for example, when member interfaces are deleted, when an interface is down, or when an active LAG member is removed. In such cases, a session scan is triggered and network processor sessions related to the LAG interface are removed. The packet then installs a new network processor session, which could be a fast-forward session, if it qualifies.
- An active member is deactivated or removed from the LAG—In cases when the LAG still has an active member, neither a reroute nor session scan is triggered. The traffic is redistributed on the failed LAG member by monitoring outgoing logical interface status in the SPU.
- A new member is added to the LAG—The network processor session is not updated. A new network processor session is created, which might use the newly added interface or not, depending on the member selection algorithm for the LAG.

### ***Redistribution of Traffic on a Failed LAG Interface***

When a LAG member fails, the traffic needs to be redistributed. To redistribute traffic, the system monitors the status of the egress interface in the SPU. When the system detects a failure, it updates the Routing Engine kernel, and passes the physical interface information down to all SPUs. On receiving a copy of the session, the SPU extracts the egress interface index and checks the physical interface information. If the physical interface is down, the SPU uninstalls the session and the ingress network processor deletes the session cache.

For the next ingress packet of the same conversation, the network processor forwards the packet to the SPU to select an active member interface in the LAG as an egress interface. The SPU performs the distribution algorithm to select a new egress interface. A new session with the new egress interface index is installed in the ingress network processor and a new fast-flow path is created.

### ***End-to-End Debugging***

---

For regular flow packets, end-to-end debugging functions are the same as in the non-Express Path mode; packet filter and action items are supported in this flow mode. For traffic that matches Express Path sessions, the end-to-end debugging function



supports one packet copy to the host CPU when the filter and the action are both affirmative in the end-to-end search results.



**NOTE:** End-to-end debugging is not supported on the SRX5K-MPC when Express Path mode is enabled.

### Per-Session Statistics CLI

To enable the per-session statistics, copy and paste the following command into the CLI at the **[edit]** hierarchy level.

```
set chassis fpc <fpc-slot> pic <pic_slot> services-offload per-session-statistics
```

Verify that the **services-offload per-session-statistics** command is enabled.

```
show configuration chassis
user@host> show configuration chassis
fpc 1 {
 pic 1 {
 services-offload {
 per-session-statistics;
 }
 }
}
```



**NOTE:** The **services-offload per-session-statistics** command is not applicable for the SRX5K modular port concentrators when Express Path is configured, because every session has statistics by default.

Use the **show chassis hardware** command to display hardware information.

**show chassis fpc pic-status (SRX5600 and SRX5800 devices When Express Path [Services-Offload] is Configured)**

```
user@host> show chassis fpc pic-status

Slot 0 Online SRX5k DPC 40x 1GE
PIC 0 Online 10x 1GE RichQ
PIC 1 Online 10x 1GE RichQ
PIC 2 Online 10x 1GE RichQ
PIC 3 Online 10x 1GE RichQ
Slot 2 Online SRX5k IOC II
PIC 0 Online 12x 10GE SFP+- np-cache/services-offload
Slot 3 Online SRX5k IOC II
PIC 0 Online 10x 10GE SFP+- np-cache/services-offload
PIC 2 Online 10x 10GE SFP+- np-cache/services-offload
Slot 5 Online SRX5k SPC
PIC 0 Online SPU Cp-Flow
PIC 1 Online SPU Flow
```

## Disabling TCP Packet Security Checks

On an SRX Series device, you can disable security checks on TCP packets to ensure interoperability with hosts and devices with faulty TCP implementations.

The **no-sequence-check** option disables TCP sequence checks. It also increases the throughput.

The **set security flow tcp-session no-sequence-check** command disables the TCP sequence checks on all TCP sessions in default or hash-based modes. This command is also supported in Express Path mode.

## Express Path Limitations

The Junos OS Express Path implementation has the following limitations.

- **Unsupported features**—The following features are not supported with Express Path:
  - Transparent mode is not supported. If transparent mode is configured, a normal (non-Express Path) session is installed.
  - Only multicast sessions with one fan-out are supported. If a multicast session with more than one fan-out exists, a normal session is installed.
  - Only active/passive chassis cluster configuration is supported. Active/active chassis cluster configuration is not supported.
  - Fragmented packets are not supported. If fragmented packets exist, a normal session is installed.
  - IPv6 is not supported. If IPv6 is configured, a normal session is installed.
  - When Express Path mode is enabled on an SRX5K-MPC, you might not be able to enable the firewall filter. In general, all processes related to Jflow v5/v8/v9 in an SRX Series device takes place in SPU. When security flow session is of Express Path type, the Jflow configuration will not take effect.
  - Class of Service (CoS) on egress interfaces is not supported.
  - Configuration of protection against a teardrop (Screen) attack is not supported when Express Path is enabled.
  - Asymmetric IOC configuration is not supported in when Express Path is enabled on a device operating in chassis cluster mode.
  - Configuring different MTU size values is not supported on SRX5K-MPC when Express Path is enabled on the device.
- **Performance drop**—The following drops in performance occur when Express Path is enabled:
  - Normal (non-Express Path) sessions—When Express Path is enabled, for normal sessions, the performance can drop by approximately 20 percent for connections per second (CPS) and 15 percent for packets per second (pps) when compared with normal sessions.

- Express Path sessions—When Express Path is enabled, for fast-forward sessions, the performance can drop by approximately 13 percent for connections per second (CPS).
- Chassis cluster—When the device is operating in chassis cluster mode:
  - If a child link goes down from the LACP-enabled redundant Ethernet interface of an IOC with Express Path enabled on its FPC, all traffic on this link is distributed to other active child links of the interface. If the child link comes up and rejoins the redundant Ethernet interface, then the existing traffic or sessions might not be redistributed over this newly rejoined active child link. New sessions might however traverse through this link.
  - If a new child link is added on the LACP-enabled redundant Ethernet interface of an IOC with Express Path enabled on its FPC, then the existing traffic or sessions might not be redistributed over this new child link. New sessions might however traverse through this link.

**Related  
Documentation**

- [Example: Configuring Low Latency on page 83](#)
- [Understanding the Express Path Solution on page 69](#)
- [Enabling and Disabling Express Path on page 70](#)

---

## Understanding the Express Path Solution

---

The high-end SRX Series devices have long packet-processing latency because the packets are processed through the Services Processing Unit (SPU) and through several stages of buffers in the data path.

This feature introduces a local forwarding solution where the fast-path packets are processed by the network processor on the I/O Card (IOC), without going through the switch fabric or the SPU. This solution reduces the packet-processing latency.

The behavior of the network processor in different scenarios is as follows:

- **First-path flow**—The first-path flow is the same as the current network processor flow process. When the first packet arrives at the network processor, the network processor parses the TCP or the UDP packet to extract a 5-tuple key and then performs session lookup in the flow table. The network processor then forwards the first packet to the central point. The central point cannot find a match at this time, because this is the first packet. The central point and the SPU create a session and match it against user-configured policies to determine if the session is a normal session or a services-offload session.

If the user has specified the session to be handled with Express Path, the SPU creates a session entry in the network processor flow table, enabling the services-offload flag in the session entry table; otherwise, the SPU creates a normal session entry in the network processor without the services-offload flag.

- **Fast-path flow**—After the session entry is created in the network processor, subsequent packets of the session will match the session entry table.

- If the services-offload flag is not set, then the network processor forwards the packet to the SPU specified in the session entry table. The packet goes through the normal flow process.
- If the network processor finds the services-offload flag in the session entry table, it will process the packet locally and send the packet out directly.



**NOTE:** The fast-forwarding function on the network processor supports one-fanout multicast sessions. The egress port in the session must also be associated with the same network processor of the ingress port. All other multicast cases need to be handled as normal sessions.

- **NAT process**—The SPU is responsible for mapping between the internal IP address or port and the external IP address or port. When the first packet of the session arrives, the SPU allocates the IP address or port mapping and stores the information in the network processor session entry. The network processor does the actual packet modification if the NAT flag is set.
- **Session age-out**—To improve traffic throughput for services-offload sessions, a copy of a packet is sent to the SPU at every predefined time period to reduce the packet processing demand on the SPU. To limit the number of packet copies sent to the SPU, a timestamp is implemented for each services-offload session. This enables the network processor to calculate the elapsed time since the last session match. If the elapsed time is greater than the predefined time period, then the network processor sends a copy of the packet to the SPU, and updates the session timestamp.
- **Session termination and deletion**—If the network processor receives an IP packet with a FIN (finished data) or a RST (reset connection) flag, it forwards the packet to the SPU. The SPU then deletes the session. The network processor does not change session status even after the FIN or RST packet is received. It continues to receive and process any packets during the transit session.

Related  
Documentation

- [Enabling and Disabling Express Path on page 70](#)

---

## Enabling and Disabling Express Path

---



**NOTE:** Prior to Junos OS Release 12.3X48-D10, Express Path was a licensed software feature. Starting with Junos OS Release 12.3X48-D10, the Express Path license is no longer required to enable this functionality. Your previously acquired Express Path license will not be effective anymore.

You can enable Express Path mode as follows:

- Set the Express Path mode on the selected card.
- Reboot the device containing the Express Path network processor to load the Express Path firmware image on the network processors.

- Configure a policy to define the traffic that should take fast-path.



**NOTE:** For SRX5600 and SRX5800 devices, enable Express Path on the IOC PIC. For SRX3400 and SRX3600 devices, enable the Express Path on the network processor. For SRX5K modular port concentrators (SRX5K-MPC), SRX5K-MPC3-100G10G (IOC3), and SRX5K-MPC3-40G10G (IOC3) on SRX5000 line devices, enable Express Path on the FPCs.



**NOTE:** When device is operating in chassis cluster mode, you need to reboot both the nodes when changing FPC(s) to Express Path mode.

To configure the Express Path mode:

- For SRX3400 and SRX3600 devices, use the **set chassis fpc fpc-number pic pic-number services-offload** command.



**NOTE:** During initialization, when a network processor is configured to perform Express Path, then the FPC CPU will load a special image to the network processor.

- For configuring Express Path on an SRX5000 line device, use the **set chassis fpc fpc-number pic pic-number services-offload** command.
- For configuring Express Path on an SRX5000 line device with Modular Port Concentrator (MPC), enable NP cache on the IOC using the **set chassis fpc fpc-number np-cache** command. Then configure the security policy to determine if the session is for Express Path.



**NOTE:** The **set chassis fpc fpc-number services-offload** command is deprecated.

- To disable Express Path on SRX3000 line and SRX5000 line devices, use the **delete chassis fpc fpc-number pic pic-number services-offload** command.
- To disable Express Path on an SRX5000 line device with Modular Port Concentrator (MPC), use the **delete chassis fpc fpc-number np-cache** command.



**NOTE:** The **delete chassis fpc fpc-number services-offload** command is deprecated.



**NOTE:** You need to reboot the device when you disable Express Path.

System log files are stored locally on the device in the default `/var/log/security` directory. You can use system log files to retrieve information about the Express Path configuration changes.

**Related  
Documentation**

- [Understanding the Express Path Solution on page 69](#)
- [Example: Configuring an IOC on SRX5000 Line Devices to Support Express Path on page 75](#)
- [Example: Configuring an SRX5K-MPC on an SRX5000 Line Device to Support Express Path on page 78](#)

---

## Example: Enabling Express Path in Security Policies

---

This example shows how to enable Express Path (formerly known as *services offloading*) in security policies.

- [Requirements on page 72](#)
- [Overview on page 72](#)
- [Configuration on page 72](#)
- [Verification on page 73](#)

### Requirements

Before you begin, see “[Express Path Overview](#)” on page 57.

### Overview

In this example, you enable Express Path in security policies to specify whether the traffic qualifies for Express Path.

### Configuration

**CLI Quick  
Configuration**

To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
source-address 1.1.1.0
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
destination-address 2.2.2.0
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
application junos-http
set security policies from-zone untrust to-zone trust policy services-offload-pol1 then
permit services-offload
```

**Step-by-Step Procedure** The following example requires you to navigate various levels in the configuration hierarchy. For instructions on how to do that, see *Using the CLI Editor in Configuration Mode* in the *CLI User Guide*.

To configure Express Path in policies:

1. Configure a policy to process the traffic that goes to the HTTP static ports.  

```
[edit security policies from-zone untrust to-zone trust policy services-offload-pol1]
user@host# set match source-address 1.1.1.0
user@host# set match destination-address 2.2.2.0
user@host# set match application junos-http
```
2. Enable Express Path in the security policy.  

```
[edit security policies from-zone untrust to-zone trust policy services-offload-pol1]
user@host# set then permit services-offload
```

**Results** From configuration mode, confirm your configuration by entering the **show security policies** command. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

```
[edit]
user@host# show security policies
from-zone untrust to-zone trust {
 policy services-offload-pol1 {
 match {
 source-address 1.1.1.0;
 destination-address 2.2.2.0;
 application junos-http;
 }
 then {
 permit {
 services-offload;
 }
 }
 }
}
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

Confirm that the configuration is working properly.

### Verifying Express Path in Policies

**Purpose** Verify that Express Path is enabled.

**Action** From operational mode, enter the **show security policies** command.

**Related Documentation**

- [Express Path Overview on page 57](#)

## Example: Configuring an NPC on SRX3000 Line Devices or SRX1400 Devices to Support Express Path

---

This example shows how to configure an NPC on the SRX3000 line of devices to support Express Path (formerly known as *services offloading*).

- [Requirements on page 74](#)
- [Overview on page 74](#)
- [Configuration on page 74](#)
- [Verification on page 75](#)

### Requirements

Before you begin, see “[Express Path Overview](#)” on page 57.

### Overview

In this example, you configure an NPC on SRX3000 line devices to perform Express Path.

### Configuration

**CLI Quick Configuration** To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
set chassis fpc 6 pic 0 services-offload
```

**Step-by-Step Procedure** To configure the NPC on an SRX3000 line device for Express Path:

1. Enable the Express Path mode on the NPC.

```
[edit]
```

```
user@host# set chassis fpc 6 pic 0 services-offload
```



**NOTE:** For SRX3000 line devices, the NPC slot number is 6.

---

2. Commit the configuration.

```
[edit]
```

```
user@host# commit
```

```
warning: System restart is required after fpc 6 pic 0 changed to
services-offload mode.
```

```
commit complete
```

3. Reboot the device.



**Results** From configuration mode, confirm your configuration by entering the **show chassis** command. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

```
[edit]
user@host> show chassis fpc pic-status
Slot 0 Online SRX3k SFB 12GE
 PIC 0 Online 8x 1GE-TX 4x 1GE-SFP
Slot 1 Online SRX3k 16xGE SFP
 PIC 0 Online 16x 1GE-SFP
Slot 5 Online SRX3k SPC
 PIC 0 Online SPU Cp-Flow
Slot 6 Online SRX3k NPC
 PIC 0 Online NPC PIC- services-offload
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

### Verifying the Configuration of NPC for Express Path

**Purpose** Verify that the NPC was configured properly for Express Path.

**Action** From operational mode, enter the **show chassis fpc pic-status** command.

**Related Documentation**

- [Express Path Overview on page 57](#)
- [Example: Enabling Express Path in Security Policies on page 72](#)

## Example: Configuring an IOC on SRX5000 Line Devices to Support Express Path

This example shows how to configure an IOC on SRX5000 line of devices to support Express Path (formerly known as *services offloading*).

- [Requirements on page 75](#)
- [Overview on page 75](#)
- [Configuration on page 75](#)
- [Verification on page 76](#)

## Requirements

Before you begin, see “[Express Path Overview](#)” on page 57.

## Overview

In this example, you configure the IOC on SRX5000 line devices to perform Express Path.

## Configuration

**CLI Quick Configuration** To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network

configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

**set chassis fpc 3 pic 0 services-offload**



**NOTE:** For SRX5000 line devices, the IOC slot number is 3.

#### Step-by-Step Procedure

To configure the IOC you need to run the following commands:

1. Set the services offload mode on the IOC.  

```
[edit]
user@host# set chassis fpc 3 pic 0 services-offload
```
2. Commit the configuration.  

```
[edit]
user@host# commit
warning: System restart is required after fpc 3 pic 0 changed to
services-offload mode.
commit complete
```
3. Reboot the device.

#### Results

From configuration mode, confirm your configuration by entering the **show chassis** command. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

```
[edit]
user@host> show chassis fpc pic-status
Slot 0 Online SRX5k SPC
 PIC 0 Online SPU Cp-Flow
 PIC 1 Online SPU Flow
Slot 1 Online SRX5k FIOC
 PIC 0 Online 4x 10GE XFP
 PIC 1 Online 16x 1GE SFP
Slot 3 Online SRX5k DPC 4X 10GE
 PIC 0 Online 1x 10GE(LAN/WAN) RichQ- services-offload
 PIC 1 Online 1x 10GE(LAN/WAN) RichQ
 PIC 2 Online 1x 10GE(LAN/WAN) RichQ
 PIC 3 Online 1x 10GE(LAN/WAN) RichQ
Slot 5 Online SRX5k DPC 40x 1GE
 PIC 0 Online 10x 1GE RichQ
 PIC 1 Online 10x 1GE RichQ
 PIC 2 Online 10x 1GE RichQ
 PIC 3 Online 10x 1GE RichQ
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

### Verifying the Configuration of IOC for Express Path

**Purpose** Verify that the IOC was configured properly for Express Path.

**Action** From operational mode, enter the **show chassis fpc pic-status** command.

- Related Documentation**
- [Express Path Overview on page 57](#)
  - [Example: Enabling Express Path in Security Policies on page 72](#)

## Example: Configuring an NP-IOC on SRX3000 Line Devices or SRX1400 Devices to Support Express Path

---

This example shows how to configure a network processor I/O card (NP-IOC) on either the SRX3000 line of devices or the SRX1400 device for Express Path (formerly known as *services offloading*).

- [Requirements on page 77](#)
- [Overview on page 77](#)
- [Configuration on page 77](#)
- [Verification on page 78](#)

### Requirements

Before you begin, see “[Express Path Overview](#)” on page 57.

This example uses the following software and hardware components:

- Junos OS Release 12.1X44-D10
- One SRX3000 line of devices or one SRX1400 device
- One Services Processing Card (SPC)

### Overview

In this example, you configure an NP-IOC on either an SRX3000 line of devices or the SRX1400 device to perform Express Path. Express Path considerably reduces packet processing latency by 500-600 percent.

### Configuration

**CLI Quick Configuration** To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
set chassis fpc 10 pic 0 services-offload
```

**Step-by-Step Procedure** To configure an NP-IOC on an SRX3000 line device or an SRX1400 device for Express Path:

1. Enable the services offload mode on the NP-IOC.  
  
[edit]  
user@host# **set chassis fpc 10 pic 0 services-offload**

2. Commit the configuration.

```
[edit]
user@host# commit
warning: System restart is required after fpc 10 pic 0 changed to
services-offload mode.
commit complete
```

3. Reboot the device.

**Results** From configuration mode, confirm your configuration by entering the **show chassis** command. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

```
[edit]
user@host> show chassis fpc pic-status
Slot 0 Online SRX3k SFB 12GE
 PIC 0 Online 8x 1GE-TX 4x 1GE-SFP
Slot 1 Online SRX3k SPC
 PIC 0 Online SPU Cp-Flow
Slot 2 Online SRX3k SPC
 PIC 0 Online SPU Flow
Slot 5 Online SRX3k 2x10GE XFP
 PIC 0 Online 2x 10GE-XFP
Slot 10 Online SRX1k3k 2x10GE NP-IOC
 PIC 0 Online 2x 10GE-SFP+ services-offload
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

---

### Verifying the Configuration of NP-IOC for Express Path

---

**Purpose** Verify that the NP-IOC was configured properly for Express Path.

**Action** From operational mode, enter the **show chassis fpc pic-status** command.

**Related Documentation**

- [Express Path Overview on page 57](#)
- [Example: Configuring Low Latency on page 83](#)

---

## Example: Configuring an SRX5K-MPC on an SRX5000 Line Device to Support Express Path

---

This example shows how to configure an SRX5K-MPC on an SRX5000 line device to support Express Path (formerly known as *services offloading*).

- [Requirements on page 79](#)
- [Overview on page 79](#)
- [Configuration on page 79](#)
- [Verification on page 80](#)

## Requirements

This example uses the following hardware and software components:

- One SRX5000 line device with an SRX5K-MPC
- Junos OS Release 12.3X48 or later for SRX Series devices

Before you begin, see [“Express Path Overview” on page 57](#).

No special configuration beyond device initialization is required before configuring this feature.

## Overview

In this example, you configure the SRX5K-MPC on an SRX5000 line device to perform NP cache and Express Path.

## Configuration

### CLI Quick Configuration

To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
set chassis fpc 2 np-cache
set chassis fpc 3 np-cache
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
 source-address 1.1.1.0
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
 destination-address 2.2.2.0
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
 application junos-http
set security policies from-zone untrust to-zone trust policy services-offload-pol1 then
 permit services-offload
```

### Step-by-Step Procedure

To configure an SRX5K-MPC on an SRX5000 line device to perform Express Path:

1. Set NP cache mode on the SRX5K-MPC on FPC 1 and FPC 2.
 

```
[edit]
user@host# set chassis fpc 2 np-cache
user@host# set chassis fpc 3 np-cache
```
2. Configure a policy to process the traffic that goes to the HTTP static ports.
 

```
[edit security policies from-zone untrust to-zone trust policy services-offload-pol1]
user@host# set match source-address 1.1.1.0
user@host# set match destination-address 2.2.2.0
user@host# set match application junos-http
```
3. Enable Express Path in the security policy.
 

```
[edit security policies from-zone untrust to-zone trust policy services-offload-pol1]
user@host# set then permit services-offload
```
4. Commit the configuration.

```
[edit]
user@host# commit
```

warning: System or cluster nodes need to reboot after fpc 3 changed to np-cache mode.

5. Reboot the device.

**Results** From configuration mode, confirm your configuration by entering the **show chassis** command. If the output does not display the intended configuration, repeat the instructions in this example to correct the configuration.

For brevity, this **show** command output includes only the configuration that is relevant to this example. Any other configuration on the system has been replaced with ellipses (...).

```
...
fpc 2 {
 np-cache;
}
fpc 3 {
 np-cache;
}
...
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

Confirm that the configuration is working properly.

### Verifying the Configuration of an SRX5K-MPC for Express Path

---

**Purpose** Verify that the SRX5K-MPC was configured properly for Express Path.

**Action** From operational mode, enter the **show chassis fpc pic-status** command.

```
Slot 0 Online SRX5k DPC 40x 1GE
PIC 0 Online 10x 1GE RichQ
PIC 1 Online 10x 1GE RichQ
PIC 2 Online 10x 1GE RichQ
PIC 3 Online 10x 1GE RichQ
Slot 2 Online SRX5k IOC II
PIC 0 Online 2x 40GE QSFP+- np-cache/services-offload
Slot 3 Online SRX5k IOC II
PIC 0 Online 10x 10GE SFP+- np-cache/services-offload
PIC 2 Online 10x 10GE SFP+- np-cache/services-offload
Slot 5 Online SRX5k SPC
PIC 0 Online SPU Cp-Flow
PIC 1 Online SPU Flow
```

**Meaning** The output provides the status of PICs with Express Path enabled on them.

- Related Documentation**
- [Express Path Overview on page 57](#)
  - [Example: Enabling Express Path in Security Policies on page 72](#)
  - [Enabling and Disabling Express Path on page 70](#)

## Example: Configuring SRX5K-MPC3-100G10G (IOC3) and SRX5K-MPC3-40G10G (IOC3) on an SRX5000 Line Device to Support Express Path

This example shows how to configure an SRX5K-MPC3-100G10G (IOC3) or an SRX5K-MPC3-40G10G (IOC3) on an SRX5000 line device to support Express Path (formerly known as *services offloading*).

- [Requirements on page 81](#)
- [Overview on page 81](#)
- [Configuration on page 81](#)
- [Verification on page 83](#)

### Requirements

This example uses the following hardware and software components:

- One SRX5000 line device with an SRX5K-MPC3-40G10G (IOC3)
- Junos OS Release 15.1X49-D10 or later for SRX Series devices

Before you begin, see “[Express Path Overview](#)” on page 57.

No special configuration beyond device initialization is required before configuring this feature.

### Overview

In this example, you configure an SRX5K-MPC3-40G10G (IOC3) on an SRX5000 line device to perform Express Path.

### Configuration

- CLI Quick Configuration**
- To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
set chassis fpc 4 np-cache
set chassis fpc 5 np-cache
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
 source-address 1.1.1.0
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
 destination-address 2.2.2.0
set security policies from-zone untrust to-zone trust policy services-offload-pol1 match
 application junos-http
set security policies from-zone untrust to-zone trust policy services-offload-pol1 then
 permit services-offload
```

**Step-by-Step Procedure** To configure an SRX5K-MPC3-40G10G (IOC3) on an SRX5000 line device to perform Express Path:

1. Set the Express Path mode on the SRX5K-MPC3 on FPC 4 and FPC 5.  

```
[edit]
user@host# set chassis fpc 4 np-cache
user@host# set chassis fpc 5 np-cache
```
2. Configure a policy to process the traffic that goes to the HTTP static ports.  

```
[edit security policies from-zone untrust to-zone trust policy services-offload-pol1]
user@host# set match source-address 1.1.1.0
user@host# set match destination-address 2.2.2.0
user@host# set match application junos-http
```
3. Enable Express Path in the security policy.  

```
[edit security policies from-zone untrust to-zone trust policy services-offload-pol1]
user@host# set then permit services-offload
```
4. Commit the configuration.  

```
[edit]
user@host# commit
```

warning: System or cluster nodes need to reboot after fpc 3 changed to np-cache mode.
5. Reboot the device.

**Results** From configuration mode, confirm your configuration by entering the **show chassis** command. If the output does not display the intended configuration, repeat the instructions in this example to correct the configuration.

For brevity, this **show** command output includes only the configuration that is relevant to this example. Any other configuration on the system has been replaced with ellipses (...).

```
...
fpc 4{
 services-offload;
}
fpc 5{
 services-offload;
}
...
...
from-zone <fzone> to-zone <tzone> {
 policy <policy-name> {
 match {
 <match-tuples>
 }
 then {
 action (
 permit {
 ...
 services-offload
 }
)
 }
 }
}
```



```

 ^^^^^^^^^^^^^^^^^^^^^
 }
 reject
 deny
 log
);
}
scheduler-name <scheduler-name>;
}
...
}

```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

Confirm that the configuration is working properly.

### Verifying the Configuration of an SRX5K-MPC3 (IOC3) for Express Path

**Purpose** Verify that the SRX5K-MPC3-40G10G (IOC3) was configured properly for Express Path.

**Action** From operational mode, enter the **show chassis fpc pic-status** command.

```

Slot 0 Offline SRX5k DPC 40x 1GE
Slot 1 Online SRX5k SPC II
 PIC 0 Online SPU Cp
 PIC 1 Online SPU Flow
 PIC 2 Online SPU Flow
 PIC 3 Online SPU Flow
Slot 2 Offline SRX5k SPC
Slot 4 Online SRX5k IOC3 24XGE+6XLG
 PIC 2 Online 3x 40GE QSFP+- np-cache/services-offload
 PIC 3 Online 3x 40GE QSFP+- np-cache/services-offload
Slot 5 Online SRX5k IOC II
 PIC 0 Online 10x 1GE(LAN) SFP- np-cache/services-offload
 PIC 1 Online 10x 1GE(LAN) SFP- np-cache/services-offload
 PIC 2 Online 10x 10GE SFP+- np-cache/services-offload

```

**Meaning** The output provides the status of PICs with Express Path enabled on them.

**Related Documentation**

- [Express Path Overview on page 57](#)
- [Example: Enabling Express Path in Security Policies on page 72](#)
- [Enabling and Disabling Express Path on page 70](#)
- [Understanding Session Cache on page 53](#)

## Example: Configuring Low Latency

The low latency feature allows you to configure the mode of the network processor's traffic manager (TM) on the egress path. If low latency is enabled, the network processor

is initialized without the traffic manager, thus reducing the overall latency in the Express Path (formerly known as *services offloading*).



**NOTE:** Because all SRX Series CoS functions are supported by the traffic manager, CoS functions are not supported when low latency is enabled.

Low latency reduces the total NPC integrated with an existing IOC (NP-IOC) latency by 0.7 us. This latency reduction brings the NP-IOC card total latency to 8.7 us. The low-latency feature is supported for intra-NP-IOC card traffic only; it is not applicable to inter-NP traffic.

In the low-latency mode, the network processor does not have an egress buffer at the traffic manager. Packets are delivered directly to the system packet interface (SPI) for the field-programmable gate array (FPGA) to process.



**NOTE:** The low latency feature is only applicable to the NP-IOC card. It does not apply to the NPC card in SRX1400, SRX3400, and SRX3600 devices.

- [Requirements on page 84](#)
- [Overview on page 84](#)
- [Configuration on page 84](#)
- [Verification on page 85](#)

## Requirements

Before you begin, see “[Express Path Overview](#)” on [page 57](#).

This example uses the following software and hardware components:

- Junos OS Release 12.1X44-D10
- One SRX3000 line of devices or one SRX1400 device
- One Services Processing Card (SPC)

## Overview

In this example, you configure the network processor for low latency mode.

## Configuration

### CLI Quick Configuration

To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
set chassis fpc 7 pic 0 services-offload low-latency
```

**Step-by-Step Procedure**

To enable low-latency mode:

1. Enable the Express Path mode on the NP-IOC.  

```
[edit]
user@host# set chassis fpc 7 pic 0 services-offload
```
2. Enable low latency.  

```
[edit]
user@host# low-latency
```
3. Commit the configuration.  

```
[edit]
user@host# commit
warning: System restart is required after fpc 7 pic 0 changed to
services-offload mode.
commit complete
```
4. Reboot the device.

**Results** From configuration mode, confirm your configuration by entering the **show configuration chassis** command. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

```
[edit]
user@host> show configuration chassis
fpc 7 {
 pic 0 {
 services-offload {
 low-latency;
 }
 }
}
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

### Verifying Low Latency Configuration

**Purpose** Verify that low-latency was enabled.

**Action** From operational mode, enter the **show chassis fpc pic-status** command.

```
root@kg04> show chassis fpc pic-status
Slot 0 Online SRX3k SFB 12GE
PIC 0 Online 8x 1GE-TX 4x 1GE-SFP
Slot 1 Online SRX3k 2x10GE XFP
PIC 0 Online 2x 10GE-XFP
Slot 2 Online SRX3k SPC
PIC 0 Online SPU Cp-Flow
Slot 7 Online SRX1k3k 2x10GE NP-IOC
PIC 0 Online 2x 10GE-SFP+- services-offload low-latency
```

- Related Documentation**
- [Express Path Overview on page 57](#)
  - [Example: Enabling Express Path in Security Policies on page 72](#)



## PART 4

# Managing Flow-Based Processing for IPv6

- Enabling IPv6 Flow-Based Processing on page 89
- Managing IPv6 Packets on page 101
- Configuring IPv6 Dual-Stack on page 109



## CHAPTER 6

# Enabling IPv6 Flow-Based Processing

- [IPv6 Advanced Flow on page 89](#)
- [Understanding Sessions for IPv6 Flows on page 90](#)
- [Understanding IPv6 Flow Processing on High-End SRX Series Devices on page 91](#)
- [Enabling Flow-Based Processing for IPv6 Traffic on page 94](#)
- [Using Filters to Display IPv6 Session and Flow Information for SRX Series Services Gateways on page 95](#)

## IPv6 Advanced Flow

---

IPv6 advanced flow adds IPv6 support for firewall, NAT, NAT-PT, multicast (local link and transit), IPsec, IDP, JSF framework, TCP Proxy, and Session manager on SRX Series devices. MIBs are not used in the IPv6 flow.

In order to avoid the impact on the current IPv4 environment, IPv6 security is used. If IPv6 security is enabled, extended sessions and gates are allocated. The existing address fields and gates are used to store the index of extended sessions or gates. If IPv6 security is disabled, IPv6 security-related resources are not allocated.

New logs are used for IPv6 flow traffic to prevent impact on performance in the existing IPv4 system.

The behavior and implementation of the IPv6 advanced flow are the same as those of IPv4 in most cases.

Some of the differences are explained below:

- **Header Parse** IPv6 advanced flow stops parsing the headers and interprets the packet as the corresponding protocol packet if it encounters the following extension headers:
  - TCP/UDP
  - ESP/AH
  - ICMPv6

IPv6 advanced flow continues parsing headers if it encounters the following extension headers:

- Hop-by-Hop

- Routing and Destination, Fragment

IPv6 advanced flow interprets the packets as an unknown protocol packet if it encounters the extension header **No Next Header**

- **Sanity Checks** IPv6 advanced flow supports the following sanity checks:
  - TCP length
  - UDP length
  - Hop-by-hop
  - IP data length error
  - Layer 3 sanity checks (for example, IP version and IP length)
  - **ICMPv6 Packets** In IPv6 advanced flow, the ICMPv6 packets share the same behavior as normal IPv6 traffic with the following exceptions:
    - Embedded ICMPv6 packet
    - Path MTU message
- **Host Inbound and Outbound Traffic** IPv6 advanced flow supports all route and management protocols running on the Routing Engine (RE), including OSPF v3, RIPng, Telnet, and SSH. Note that no flow label is used in the flow.
- **Tunnel Traffic** IPv6 advanced flow supports the following tunnel types:
  - IPv4 IP-IP
  - IPv4 GRE
  - IPv4 IPsec
  - Dual-stack lite
- **Events and Logs** The following logs are for IPv6-related flow traffic:
  - RT\_FLOW\_IPVX\_SESSION\_DENY
  - RT\_FLOW\_IPVX\_SESSION\_CREATE
  - RT\_FLOW\_IPVX\_SESSION\_CLOSE

The implementations of sessions, gates, ip-actions, processing of multithread, distribution, locking, synchronization, serialization, ordering, packet queuing, asynchronous messaging, IKE traffic issues, sanity check, and queues for IPv6 are similar to IPv4 implementations.

**Related  
Documentation**

- [About IPv6 Packet Header Verification Performed by the Flow Module for SRX Series Devices on page 105](#)

---

## Understanding Sessions for IPv6 Flows

This topic gives an overview of flow-based sessions.



Most packet processing occurs in the context of a flow, including management of policies, zones, and most screens. A session is created for the first packet of a flow for the following purposes:

- To store most of the security measures to be applied to the packets of the flow.
- To cache information about the state of the flow. For example, logging and counting information for a flow is cached in its session. (Also, some stateful firewall screens rely on threshold values that pertain to individual sessions or across all sessions.)
- To allocate resources required for features for the flow.
- To provide a framework for features such as Application Layer Gateways (ALGs).

**Related  
Documentation**

- [Understanding IPv6 Flow Processing on High-End SRX Series Devices on page 91](#)

## Understanding IPv6 Flow Processing on High-End SRX Series Devices

This topic introduces the architecture for the high-end SRX Series devices and uses it as a model to explain IP version 6 (IPv6) processing. Flow processing is similar on branch SRX Series devices

High-end SRX Series Services Gateway devices include I/O cards (IOCs) and Services Processing Cards (SPCs) that each contain processing units that process a packet as it traverses the device. These processing units have different responsibilities.

- A Network Processing Unit (NPU) runs on an IOC. An IOC has one or more NPUs. An NPU processes packets discretely and performs basic flow management functions.

When an IPv6 packet arrives at an IOC, the packet flow process begins.

- The NPU performs the following IPv6 sanity checks for the packet:
  - For the IPv6 basic header, it performs the following header checks:
    - Version. It verifies that the header specifies IPv6 for the version.
    - Payload length. It checks the payload length to ensure that the combined length of the IPv6 packet and the Layer 2 header is shorter than the Layer 2 frame length.
    - Hop limit. It checks to ensure that the hop limit does not specify 0 (zero).
    - Address checks. It checks to ensure that the source IP address does not specify ::0 or FF::00 and that the destination IP address does not specify ::0 or ::1.
- The NPU performs IPv6 extension header checks, including the following:
  - Hop-by-hop options. It verifies that this is the first extension header to follow the IPv6 basic header.
  - Routing extension. It verifies that there is only one routing extension header.

- Destination options. It verifies that no more than two destination options extension headers are included.
- Fragment. It verifies that there is only one fragment header.



**NOTE:** The NPU treats any other extension header as a Layer 4 header.

- The NPU performs Layer 4 TCP, UDP, and ICMP6 protocol checks, including the following:
  - UDP. It checks to ensure that IP Payload Length packets, other than a first-fragment packet, are at least 8 bytes long.
  - TCP. It checks to ensure that IP Payload Length packets, other than a first-fragment packet, are at least 20 bytes long.
  - ICMPv6. It checks to ensure that IP Payload Length packets, other than a first-fragment packet, are at least 8 bytes long.
- If the packet specifies a TCP or a UDP protocol, the NPU creates a tuple from the packet header data using the following information:
  - Source IP address
  - Destination IP address
  - Source port
  - Destination port
  - Protocol
  - Virtual router identifier (VRID)

The device looks up the VRID from a VRID table.
- For Internet Control Message Protocol version 6 (ICMPv6) packets, the tuple contains the same information as used for the TCP and the UDP search key, except for the source and destination port fields. The source and destination port fields are replaced with the following information extracted from the ICMPv6 packet:
  - For ICMP error packets: The pattern "0x00010001"
  - For ICMP information packets: The type, or code, field identifier
- For packets with an Authentication Header (AH) or an Encapsulating Security Payload (ESP) header, the search key is the same as that used for the TCP and the UDP tuple, except for the source and destination port fields. In this case, the security parameter index (SPI) field value is used instead of the source and destination ports. For Encapsulating Security Payload (ESP) header and Authentication Header (AH), before enhancements to the central point architecture it is hashed by the 3-tuple and the security parameter index (SPI) field, after enhancements to the central point architecture it is hashed by an IP pair.

- If a session exists for the packet's flow, the NPU sends the packet to the SPU that manages the session.
- If a matching session does not exist,
  - The NPU sends the packet information to the central point, which creates a pending session.
  - The central point selects an SPU to process the packet and create sessions for it.
  - The SPU then sends session creation messages to the central point and the ingress and egress NPUs, directing them to create a session for the packet flow.
- A central point, which can run on a dedicated SPU, or share the resources of one if there is only one SPU. A central point takes care of arbitration and allocation of resources, and it distributes sessions in an intelligent way. The central point assigns an SPU to be used for a particular session when the SPU processes the first packet of its flow.
  - For SRX5000 line devices, the central point architecture is divided into two modules—the application central point and the distributed central point (DCP). The App-CP is responsible for global resource management and loading balancing, while DCP is responsible for traffic identification (global session matching). The App-CP functionality runs on the dedicated central point SPU, while the DCP functionality is distributed to the rest of the SPUs.
  - For SRX3000 line devices, you have the option to use Extreme mode to turn the central point into a full central point and disable combo mode.
- One or more SPUs that run on a Services Processing Card (SPC). All flow-based services for a packet are executed on a single SPU, within the context of a session that is set up for the packet flow.

The SPC for SRX5000 line devices has two SPUs. The SPC for SRX3000 line devices has one SPU.

Several SPCs can be installed in a chassis.

Primarily, an SPU performs the following tasks:

- It manages the session and applies security features and other services to the packet.
- It applies packet-based stateless firewall filters, classifiers, and traffic shapers.
- If a session does not already exist for a packet, the SPU sends a request message to the NPU that performed the search for the packet's session, to direct it to add a session for it.

These discrete, cooperating parts of the system store the information identifying whether a session exists for a stream of packets and the information against which a packet is matched to determine if it belongs to an existing session.

## Enabling Flow-Based Processing for IPv6 Traffic

---

By default, the SRX Series device drops IP version 6 (IPv6) traffic. To enable processing by security features such as zones, screens, and firewall policies, you must enable flow-based forwarding for IPv6 traffic.

To enable flow-based forwarding for IPv6 traffic, modify the **mode** statement at the **[edit security forwarding-options family inet6]** hierarchy level:

```
security {
 forwarding-options {
 family {
 inet6 {
 mode flow-based;
 }
 }
 }
}
```

The following example shows the CLI commands you use to configure forwarding for IPv6 traffic.

1. Use the **set** command to change the forwarding option mode for IPv6 to flow-based.

```
[edit]
user@host# set security forwarding-options family inet6 mode flow-based
```

2. Use the **show** command to review your configuration.

```
[edit]
user@host# show security forwarding-options
family {
 inet6 {
 mode flow-based;
 }
}
```

3. Check your changes to the configuration before committing.

```
[edit]
user@host# commit check
warning: You have enabled/disabled inet6 flow.
You must reboot the system for your change to take effect.
If you have deployed a cluster, be sure to reboot all nodes.
configuration check succeeds
```

4. Commit the configuration.

```
[edit]
user@host# commit
warning: You have enabled/disabled inet6 flow.
You must reboot the system for your change to take effect.
If you have deployed a cluster, be sure to reboot all nodes.
commit complete
```

5. At an appropriate time, reboot the device.



**NOTE:** SRX Series devices only process IPv6 Routing Header 0 (RH0) to-self packets, the segleft field of which is zero. Other packets will be dropped.

Table 9 on page 95 summarizes device status upon forwarding option configuration change.

**Table 9: Device Status Upon Configuration Change**

| Configuration Change       | Commit Warning | Reboot Required | Impact on Existing Traffic Before Reboot | Impact on New Traffic Before Reboot |
|----------------------------|----------------|-----------------|------------------------------------------|-------------------------------------|
| Drop to flow-based         | Yes            | Yes             | Dropped                                  | Dropped                             |
| Drop to packet-based       | No             | No              | Packet-based                             | Packet-based                        |
| Flow-based to packet-based | Yes            | Yes             | None                                     | Flow sessions created               |
| Flow-based to drop         | Yes            | Yes             | None                                     | Flow sessions created               |
| Packet-based to flow-based | Yes            | Yes             | Packet-based                             | Packet-based                        |
| Packet-based to drop       | No             | No              | Dropped                                  | Dropped                             |

To process IPv6 traffic, you also need to configure IPv6 addresses for the transit interfaces that receive and forward the traffic. For information on the inet6 protocol family and procedures for configuring IPv6 addresses for interfaces, see the [Interfaces Feature Guide for Security Devices](#).

**Related Documentation**

- [Understanding IPv6 Address Space, Addressing, Address Format, and Address Types](#)
- [Using Filters to Display IPv6 Session and Flow Information for SRX Series Services Gateways on page 95](#)

## Using Filters to Display IPv6 Session and Flow Information for SRX Series Services Gateways

**Purpose** You can display flow and session information about one or more sessions with the **show security flow session** command. IPv6 sessions are included in aggregated statistics.

You can use the following filters with the **show security flow session** command: application, destination-port, destination-prefix, family, idp, interface, nat, protocol, resource-manager, session-identifier, source-port, source-prefix, and tunnel.



**NOTE:** Except for the session-identifier filter, the output of all the other filters can be viewed in brief, summary, and extensive mode. Brief mode is the default mode. The output of the session-identifier filter can be viewed only in the brief mode.

You can use the same filter options with the **clear security flow session** command to terminate sessions.

**Action** The following examples show how to use IPv6-related filters to display summaries and details for IPv6 sessions.

#### Filtered summary report based on family

```
root> show security flow session summary family ?
Possible completions:
 inet Show IPv4 sessions
 inet6 Show IPv6/IPv6-NATPT sessions
```

```
root> show security flow session summary family inet6
Flow Sessions on FPC10 PIC1:
```

```
Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 2
```

```
Flow Sessions on FPC10 PIC2:
```

```
Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1
```

```
Flow Sessions on FPC10 PIC3:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 1
Sessions in other states: 0
Total sessions: 1
```

### Filtered detailed report based on family

```

root> show security flow session family ?
Possible completions:
 inet Show IPv4 sessions
 inet6 Show IPv6/IPv6-NATPT sessions

root> show security flow session family inet6
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:
Total sessions: 0

Flow Sessions on FPC10 PIC3:

Session ID: 430000026, Policy name: default-policy-00/2, Timeout: 1794, Valid
 In: 6001::10/64712 --> 5001::2/21;tcp, If: ge-7/1/0.0, Pkts: 8, Bytes: 562, CP
 Session ID: 430000025
 Out: 5001::2/21 --> 6001::10/64712;tcp, If: ge-7/1/1.0, Pkts: 12, Bytes: 1014,
 CP Session ID: 430000025
Total sessions: 1

```

### Filtered brief report based on family

```

root> show security flow session family inet brief
Flow Sessions on FPC10 PIC1:

Session ID: 410000031, Policy name: default-policy-00/2, Timeout: 48, Valid
 In: 200.0.0.10/3 --> 60.0.0.2/43053;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
 CP Session ID: 410000039
 Out: 60.0.0.2/43053 --> 200.0.0.10/3;icmp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0,
 CP Session ID: 410000039
Total sessions: 1

Flow Sessions on FPC10 PIC2:

Session ID: 420000034, Policy name: default-policy-00/2, Timeout: 48, Valid
 In: 200.0.0.10/4 --> 60.0.0.2/43053;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
 CP Session ID: 420000041
 Out: 60.0.0.2/43053 --> 200.0.0.10/4;icmp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0,
 CP Session ID: 420000041
Total sessions: 1

Flow Sessions on FPC10 PIC3:

Session ID: 430000042, Policy name: default-policy-00/2, Timeout: 44, Valid
 In: 200.0.0.10/2 --> 60.0.0.2/43053;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
 CP Session ID: 430000041
 Out: 60.0.0.2/43053 --> 200.0.0.10/2;icmp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0,
 CP Session ID: 430000041
Total sessions: 1

```

### Filtered detailed report based on an IPv6 source-prefix

```

root> show security flow session source-prefix 6001::10
Flow Sessions on FPC10 PIC1:

Session ID: 410000066, Policy name: default-policy-00/2, Timeout: 2, Valid
 In: 6001::10/3 --> 5001::1/7214;icmp6, If: ge-7/1/0.0, Pkts: 1, Bytes: 104, CP
 Session ID: 410000076

```

```
Out: 5001::1/7214 --> 6001::10/3;icmp6, If: .local..0, Pkts: 1, Bytes: 104, CP
Session ID: 410000076
```

```
Session ID: 410000068, Policy name: default-policy-00/2, Timeout: 2, Valid
In: 6001::10/4 --> 5001::1/7214;icmp6, If: ge-7/1/0.0, Pkts: 1, Bytes: 104, CP
Session ID: 410000077
Out: 5001::1/7214 --> 6001::10/4;icmp6, If: .local..0, Pkts: 1, Bytes: 104, CP
Session ID: 410000077
Total sessions: 2
```

Flow Sessions on FPC10 PIC2:

```
Session ID: 420000067, Policy name: default-policy-00/2, Timeout: 28, Valid
In: 6001::10/4 --> 5001::2/6702;icmp6, If: ge-7/1/0.0, Pkts: 1, Bytes: 104, CP
Session ID: 420000080
Out: 5001::2/6702 --> 6001::10/4;icmp6, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP
Session ID: 420000080
Total sessions: 1
```

Flow Sessions on FPC10 PIC3:

```
Session ID: 430000077, Policy name: default-policy-00/2, Timeout: 28, Valid
In: 6001::10/3 --> 5001::2/6702;icmp6, If: ge-7/1/0.0, Pkts: 1, Bytes: 104, CP
Session ID: 430000075
Out: 5001::2/6702 --> 6001::10/3;icmp6, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP
Session ID: 430000075
```

```
Session ID: 430000078, Policy name: default-policy-00/2, Timeout: 30, Valid
In: 6001::10/5 --> 5001::2/6702;icmp6, If: ge-7/1/0.0, Pkts: 1, Bytes: 104, CP
Session ID: 430000076
Out: 5001::2/6702 --> 6001::10/5;icmp6, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP
Session ID: 430000076
```

```
Session ID: 430000079, Policy name: default-policy-00/2, Timeout: 2, Valid
In: 6001::10/5 --> 5001::1/7214;icmp6, If: ge-7/1/0.0, Pkts: 1, Bytes: 104, CP
Session ID: 430000077
Out: 5001::1/7214 --> 6001::10/5;icmp6, If: .local..0, Pkts: 1, Bytes: 104, CP
Session ID: 430000077
Total sessions: 3
```

### Multiple-filtered detailed report based on family, protocol and source-prefix

```
root> show security flow session family inet protocol icmp source-prefix 200.0.0.10
```

Flow Sessions on FPC10 PIC1:

```
Session ID: 410000074, Policy name: default-policy-00/2, Timeout: 2, Valid
In: 200.0.0.10/1 --> 60.0.0.2/26935;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 410000195
Out: 60.0.0.2/26935 --> 200.0.0.10/1;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 410000195
Total sessions: 1
```

Flow Sessions on FPC10 PIC2:

```
Session ID: 420000075, Policy name: default-policy-00/2, Timeout: 2, Valid
In: 200.0.0.10/3 --> 60.0.0.2/26935;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 420000159
Out: 60.0.0.2/26935 --> 200.0.0.10/3;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 420000159
Total sessions: 1
```



Flow Sessions on FPC10 PIC3:

```
Session ID: 430000085, Policy name: default-policy-00/2, Timeout: 2, Valid
 In: 200.0.0.10/4 --> 60.0.0.2/26935;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 430000083
 Out: 60.0.0.2/26935 --> 200.0.0.10/4;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 430000083
Total sessions: 1
```

#### Clearing all sessions, including IPv6 sessions

```
root> clear security flow session all
This command may terminate the current session too.
Continue? [yes,no] (no) yes

0 active sessions cleared
1 active sessions cleared
1 active sessions cleared
1 active sessions cleared
```

#### Clearing only IPv6 sessions

```
root> clear security flow session family ?
Possible completions:
 inet Clear IPv4 sessions
 inet6 Clear IPv6/IPv6-NATPT sessions

root> clear security flow session family inet6
0 active sessions cleared
1 active sessions cleared
1 active sessions cleared
1 active sessions cleared
```

**Related  
Documentation**

- [Enabling Flow-Based Processing for IPv6 Traffic on page 94](#)
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
- [Displaying a Summary of Sessions for SRX Series Services Gateways on page 121](#)
- [Displaying Session and Flow Information About Sessions for SRX Series Services Gateways on page 121](#)
- [Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways on page 122](#)
- [Information Provided in Session Log Entries for SRX Series Services Gateways on page 123](#)
- [Clearing Sessions for SRX Series Services Gateways on page 39](#)

## CHAPTER 7

# Managing IPv6 Packets

- [The IPv6 Packet Header and SRX Series Overview on page 101](#)
- [About the IPv6 Basic Packet Header on page 102](#)
- [Understanding IPv6 Packet Header Extensions on page 103](#)
- [About IPv6 Packet Header Verification Performed by the Flow Module for SRX Series Devices on page 105](#)
- [Understanding Path MTU Messages for IPv6 Packets on page 105](#)
- [Understanding How SRX Series Devices Handle Packet Fragmentation for IPv6 Flows on page 107](#)
- [Understanding How SRX Series Devices Handle ICMPv6 Packets on page 107](#)

### The IPv6 Packet Header and SRX Series Overview

This topic identifies the IP version 6 (IPv6) packet header and its extensions and options.

Every IPv6 packet at a minimum has a basic packet header, 40 bytes (320 bits) long. They optionally may have extension headers.

For IPv6 packets, flow processing parses the extension headers and transport layer headers in the following way:

- If the software encounters a TCP, a UDP, an ESP, an AH, or an ICMPv6 header, it parses the header and assumes that the packet payload corresponds to the specified protocol type.
- If the software encounters a hop-by-hop header, a routing and destination header, or a fragment header, it continues to parse the next extension header.
- If it encounters the no-next-header extension header, the software detects that the packet is that of an unknown protocol (protocol equals 0).
- For other extension headers, the software parses the header and identifies the packet as belonging to the protocol indicated by the extension header.

#### **Related Documentation**

- [About the IPv6 Basic Packet Header on page 102](#)
- [Understanding IPv6 Packet Header Extensions on page 103](#)

## About the IPv6 Basic Packet Header

---

This topic identifies the IP version 6 (IPv6) basic packet header fields with their bit lengths and uses.

| Header Name    | Bit Length | Purpose                                                                                                                                                                                                                                                                                                                 |
|----------------|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Version        | 4          | Specifies that IP version 6 is used. The IPv6 version field contains a value of 6 indicating that IPv6 is used, as opposed to 4 for IP version 4.                                                                                                                                                                       |
| Traffic Class  | 8          | Allows source nodes or routers to identify different classes (or priorities for quality of service) for IPv6 packets. (This field replaces the IPv4 Type of Service field.)                                                                                                                                             |
| Flow Label     | 20         | Identifies the flow to which the packet belongs. Packets in a flow share a common purpose, or belong to a common category, as interpreted by external devices such as routers or destination hosts.<br><br><b>NOTE:</b> For IPv6 flow-based packets, Junos OS for SRX Series devices does not use the flow label field. |
| Payload Length | 16         | Specifies the length of the IPv6 packet payload, or contents, expressed in octets.                                                                                                                                                                                                                                      |

| Header Name            | Bit Length | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------------------------|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Next Header            | 8          | <p>Identifies the type of Internet Protocol for the header that immediately follows the IPv6 header. The Next Header field replaces the IPv4 Protocol field. It is an optional field.</p> <p>This protocol can be one of two types:</p> <ul style="list-style-type: none"> <li>• An IPv6 extension header. For example, if the device performs IP security on exchanged packets, the Next Header value is probably 50 (ESP extension header) or 51 (AH extension header). Extension headers are optional.</li> <li>• An upper-layer Protocol Data Unit (PDU). For example, the Next Header value could be 6 (for TCP), 17 (for UDP), or 58 (for ICMPv6).</li> </ul> <p>The flow module processes these headers sequentially within the context of a packet flow.</p> <p>If it encounters one of the following extension headers, the software parses it and regards the packet as a corresponding protocol packet.</p> <ul style="list-style-type: none"> <li>• Internet Control Message Protocol version 6 (ICMPv6)</li> <li>• Transport Control Protocol (TCP)</li> </ul> <p><b>NOTE:</b> The device checks the TCP header length as part of its sanity checks.</p> <ul style="list-style-type: none"> <li>• UDP</li> </ul> <p><b>NOTE:</b> The device checks the UDP length as part of its sanity checks.</p> <ul style="list-style-type: none"> <li>• Enhanced Security Protocol (ESP) or Authentication Header (AH)</li> </ul> |
| Hop Limit              | 8          | <p>Specifies the maximum number of hops the packet can make after transmission from the host device. When the Hop Limit value is zero, the device drops the packet and generates an error message. (This field is similar to the Time to Live IPv4 field.)</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Source IP Address      | 128        | <p>Identifies the host device, or interface on a node, that generated the IPv6 packet.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Destination IP Address | 128        | <p>Identifies the host device, or interface on a node, to which the IPv6 packet is to be sent.</p> <p><b>NOTE:</b> The destination address can appear twice, the first instance after the hop limit following the source IP address and the second instance after the final extension header.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

**Related Documentation** • [Understanding IPv6 Packet Header Extensions on page 103](#)

## Understanding IPv6 Packet Header Extensions

This topic defines IP version 6 (IPv6) packet header extensions.

IPv6 extension headers contain supplementary information used by network devices (such as routers, switches, and endpoint hosts) to decide how to direct or process an IPv6 packet. The length of each extension header is an integer multiple of 8 octets. This allows subsequent extension headers to use 8-octet structures.

Any header followed by an extension header contains a Next Header value that identifies the extension header type. Extension headers always follow the basic IPv6 header in order as shown in [Table 10 on page 104](#):



**NOTE:** The destination IP address can appear twice, once after the hop-by-hop header and again after the last extension header.

**Table 10: IPv6 Extension Headers**

| Header Name                    | Purpose                                                                                                                                                                                                                                                                                                                                                 |
|--------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hop-by-Hop Options             | Specifies delivery parameters at each hop on the path to the destination host.<br><br><b>NOTE:</b> A hop-by-hop option can appear only following the IPv6 basic header. If it is used, it should be the first extension header. It cannot appear after another extension header.                                                                        |
| Destination Options            | Specifies packet delivery parameters for either intermediate destination devices or the final destination host. When a packet uses this header, the Next Header value of the previous header must be 60.                                                                                                                                                |
| Routing                        | Defines strict source routing and loose source routing for the packet. (With strict source routing, each intermediate destination device must be a single hop away. With loose source routing, intermediate destination devices can be one or more hops away.) When a packet uses this header, the Next Header value of the previous header must be 43. |
| Fragment                       | Specifies how to perform IPv6 fragmentation and reassembly services. When a packet uses this header, the Next Header value of the previous header must be 44.<br><br>A source node uses the fragment extension header to tell the destination node the size of the packet that was fragmented so that the destination node can reassemble the packet.   |
| Authentication                 | Provides authentication, data integrity, and anti-replay protection. When a packet uses this header, the Next Header value of the previous header must be 51.                                                                                                                                                                                           |
| Encapsulating Security Payload | Provides data confidentiality, data authentication, and anti-replay protection for Encapsulated Security Payload (ESP) packets. When a packet uses this header, the Next Header value of the previous header must be 50.                                                                                                                                |
| Destination IP Address         | Identifies the host device, or interface on a node, to which the IPv6 packet is to be sent.<br><br><b>NOTE:</b> The destination address may appear twice, the first instance after the hop limit following the source IP address and the second instance after the final extension header.                                                              |

**Related Documentation** • [About the IPv6 Basic Packet Header on page 102](#)

## About IPv6 Packet Header Verification Performed by the Flow Module for SRX Series Devices

This topic gives an overview of some of the IP version 6 (IPv6) packet header verification that the flow module for SRX Series devices performs.

To ensure the integrity of an IPv6 packet, the flow module performs the following sanity checks.

For all IPv6 packets, it checks the following parts of the header:

- TCP length
- UDP length
- Hop-by-hop extension to ensure that it follows the basic IPv6 header and does not come after another extension header
- That the IP data length error (IP length—total extension header length is not less than zero (<0))

In addition to these verifications, the software performs other standard checks such as verifying that the correct IP version is specified and that the length of the IP address is correct.

### Related Documentation

- [About the IPv6 Basic Packet Header on page 102](#)
- [Understanding IPv6 Packet Header Extensions on page 103](#)

## Understanding Path MTU Messages for IPv6 Packets

This topic describes path maximum transmission unit (MTU) and explains how the flow module for SRX Series devices processes and uses path MTU messages.

Every link has an MTU size that specifies the size of the largest packet the link can transmit. A larger MTU size means that fewer packets are required to transmit a certain amount of data. To achieve the best data transmission performance, IPv6 data packets sent from one node (the source) to another node (the destination) should be the largest possible size that can traverse the path between the nodes. (Larger and fewer packets constrain the cost of packet header processing and routing processes that can affect transmission performance.)

However, for a packet to successfully traverse the path from the source node to the destination node, the MTU size of the source node interface must be no larger than that of the smallest MTU size of all nodes on the path between the source and destination. This value is referred to as the path maximum transmission unit (path MTU). If a packet is larger than a link's MTU size, it is likely that the link will drop it. For IPv6, an intermediate node cannot fragment a packet.

IPv6 defines a standard mechanism called path MTU discovery that a source node can use to learn the path MTU of a path that a packet is likely to traverse. If any of the packets

sent on that path are too large to be forwarded by a node along the path, that node discards the packet and returns an ICMPv6 Packet Too Big message. The source node can then adjust the MTU size to be smaller than that of the node that dropped it and sent the ICMPv6 message, and then retransmit the packet. A source node might receive Packet Too Big messages repeatedly until its packet traverses all nodes along the path successfully.



**NOTE:** On all SRX Series devices, the Routing Engine cannot detect the path MTU of an IPv6 multicast address (with a large size packet).

After the path MTU size is determined and the appropriate MTU size is set, an outgoing packet might be routed along a different path with a node whose link MTU size is smaller than the path MTU size determined previously. In this case, the flow module engages the path MTU discovery process again.

When the flow module receives an ICMP Packet Too Big message with a destination address that belongs to it, it:

- Checks to determine if the embedded 5-tuple data of the packet is for a tunnel interface. (That is, it checks to determine if the embedded 5-tuple data matches a tunnel session.) If there is a match, the flow module updates the tunnel interface's MTU size. Then it performs post-fragment processing for the encrypted packets that follow the first packet. Afterward, the flow module delivers the packet to the ICMPv6 stack on the Routing Engine (RE) for it to continue processing it.
- If the packet is a transit one, the flow module searches for a session that matches the packet's embedded 5-tuple data. If it finds a matching session, it delivers the packet to it. If there is no matching session, it drops the packet.

When the flow module receives a packet, before it transmits it to the egress interface, it checks to determine if the MTU size of the egress interface is greater than the packet length.

- If the MTU size is greater than the packet length, it continues to process the packet.
- If the MTU size is less than the packet length, it drops the packet and sends an ICMPv6 Packet Too Big message to the source node.



**NOTE:** When chassis cluster is configured and the path MTU updates the MTU of the tunnel interface, the flow module does not synchronize the new MTU to peer nodes. The MTU size might be updated again by a larger packet on a peer node, which has no impact on packet transmission.

**Related  
Documentation**

- [Understanding How SRX Series Devices Handle ICMPv6 Packets on page 107](#)
- [About the IPv6 Basic Packet Header on page 102](#)



---

## Understanding How SRX Series Devices Handle Packet Fragmentation for IPv6 Flows

---

This topic explains packet fragmentation for IP version 6 (IPv6).

For IPv4 Internet Control Message Protocol (IPv4 ICMP), if a node within the path between a source node and a destination node receives a packet that is larger than its MTU size, it can fragment the packet and transmit the resulting smaller packets. For IPv6, only a source node (the node that sent the packet) can fragment a packet, and this is done to accommodate a path MTU size-adjustment requirement. Nodes along the path of a packet cannot fragment the packet to transmit it.

### Related Documentation

- [Understanding How SRX Series Devices Handle ICMPv6 Packets on page 107](#)
- [Understanding Path MTU Messages for IPv6 Packets on page 105](#)
- [Understanding IPv6 Packet Header Extensions on page 103](#)

---

## Understanding How SRX Series Devices Handle ICMPv6 Packets

---

This topic explains Internet Control Message Protocol (ICMP), ICMP messages, and how Junos OS for SRX Series Services Gateways uses them.

ICMP provides a framework for reporting packet processing errors, for diagnostic purposes, and for implementation-specific functions. ICMP error messages make it possible for one node to inform another node that something has gone wrong during the course of data transfer. When IP version 6 (IPv6) was defined, the differences between IP version 4 (IPv4) and it were significant enough to require a new version of ICMP.

Every ICMPv6 message is preceded by an IPv6 header and zero or more IPv6 extension headers. The ICMPv6 header is identified by a Next Header value of 58 in the immediately preceding header. This is different from the value used to identify ICMP for IPv4. All ICMPv6 error messages have 32 bits of type-specific data to help the packet recipient locate the embedded invoking packet.

Most ICMPv6 packets have the same characteristics and behavior as normal IPv6 packets, and the Junos OS flow module processes them through first path and fast-path processing in the same way that it does normal IPv6 packets. [Table 11 on page 108](#) shows the ICMPv6 embedded packet types that the flow module handles differently from normal ICMPv6 packets.

For these packets, the flow module uses a tuple that it creates from the embedded ICMPv6 packet to search for a matching session. It continues to process the packet without modifying the maximum transmission unit (MTU) until it finds a matching session, unless it receives an ICMPv6 Packet Too Big message for the interface. In this case, it modifies the MTU size for that interface. If the flow module does not find a matching session or if it cannot obtain a valid IPv6 header from the embedded payload, it drops the packet.



**NOTE:** A Packet Too Big message is the only kind of ICMPv6 packet that will cause the flow module to modify an interface.

**Table 11: ICMPv6 Packets That Junos OS Handles Differently from Other ICMPv6 Packets**

| Message                    | Meaning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 01-Destination Unreachable | <p>When a packet cannot be delivered because of a problem with the way it is being sent, it is useful to have a feedback mechanism that can tell the source about the problem, including the reason why delivery of the packet failed. For IPv6, the Destination Unreachable message serves this purpose.</p> <p>Each message includes a code that indicates the nature of the problem that caused the packet delivery to fail. It also includes all or part of the packet that could not be delivered, to help the source device resolve the problem.</p> <p>When the flow module encounters a Destination Unreachable ICMP packet whose embedded packet header data matches the 5-tuple data for a session, the software terminates the session.</p>                          |
| 02-Packet Too Big          | <p>When the flow module receives an ICMPv6 Packet Too Big message intended for it, the flow module sends the packet to the ICMP protocol stack on the Routing Engine to engage the path maximum transmission unit (path MTU) discovery process.</p> <p>If the Packet Too Big message does not pertain to the device but rather is a transit packet, the device attempts to match the embedded 5-tuple data with a session.</p> <ul style="list-style-type: none"> <li>• If a matching session exists, the device delivers it to the source node.</li> <li>• If a matching session does not exist, the device drops the packet</li> </ul> <p><b>NOTE:</b> A Packet Too Big message is the only kind of ICMPv6 packet that will cause the flow module to modify an interface.</p> |
| 03-Time Exceeded           | <p>When the flow module receives a packet that cannot be delivered because it has exceeded the hop count specified in the basic header hop-by-hop field, it sends this message to inform the packet's source node that the packet was discarded for this reason.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 04-Parameter Problem       | <p>When the device finds a problem with a field in the IPv6 header or extension headers that makes it impossible for it to process the packet, the software discards it and sends this ICMPv6 message to the packet's source node, indicating the type and location of the problem.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

**Related Documentation**

- [Understanding Path MTU Messages for IPv6 Packets on page 105](#)
- [Understanding How SRX Series Devices Handle Packet Fragmentation for IPv6 Flows on page 107](#)

## CHAPTER 8

# Configuring IPv6 Dual-Stack

- [Understanding IPv6 Dual-Stack Lite on page 109](#)
- [Example: Configuring IPv6 Dual-Stack Lite on page 112](#)

### Understanding IPv6 Dual-Stack Lite

---


IPv6 dual-stack lite (DS-Lite) is a technology that enables Internet service providers to move to an IPv6 network while simultaneously handling IPv4 address depletion.

IPv4 addresses are becoming depleted; therefore, broadband service providers (DSL, cable, and mobile) need new addresses to support new users. Providing IPv6 addresses alone is often not workable because most of the systems that make up the public Internet are still enabled and support only IPv4, and many users' systems do not yet fully support IPv6.

DS-Lite allows service providers to migrate to an IPv6 access network without changing end-user software. The device that accesses the Internet remains the same, thus allowing IPv4 users to continue accessing IPv4 internet content with minimum disruption to their home networks, while enabling IPv6 users to access IPv6 content.

[Figure 9 on page 110](#) illustrates the DS-Lite architecture which uses IPv6-only links between the provider and the user while maintaining the IPv4 (or dual-stack) hosts in the user network.

Figure 9: DS-Lite NAT (IPv4-in-IPv6)



The DS-Lite deployment model consists of the following components:

- Software initiator for the DS-Lite home router--Encapsulates the IPv4 packet and transmits it across an IPv6 tunnel.

- Software concentrator for DS-Lite carrier-grade Network Address Translation (NAT)—Decapsulates the IPv4-in-IPv6 packet and also performs IPv4-IPv4 NAT translations.

When a user's device sends an IPv4 packet to an external destination, DS-Lite encapsulates the IPv4 packet in an IPv6 packet for transport into the provider network. These IPv4-in-IPv6 tunnels are called *softwires*. Tunneling IPv4 over IPv6 is simpler than translation and eliminates performance and redundancy concerns.

The softwires terminate in a software concentrator at some point in the service provider network, which decapsulates the IPv4 packets and sends them through a carrier-grade Network Address Translation (NAT) device. There, the packets undergo source NAT processing to hide the original source address.

IPv6 packets originated by hosts in the subscriber's home network are transported natively over the access network.

The DS-Lite carrier-grade NAT translates IPv4-to-IPv4 addresses to multiple subscribers through a single global IPv4 address. Overlapping address spaces used by subscribers are disambiguated through the identification of tunnel endpoints. One concentrator can be the endpoint of multiple softwires.

The IPv4 packets originated by the end hosts have private (and possibly overlapping) IP addresses. Therefore, NAT must be applied to these packets. If end hosts have overlapping addresses, Network Address Port Translation (NAPT) is needed.

Using NAPT, the system adds the source address of the encapsulating IPv6 packet in the subscriber network to the inside IPv4 source address and port. Because each user's IPv6 address is unique, the combination of the IPv6 source address with the IPv4 source address and port creates an unambiguous mapping.

The system takes the following actions when it receives a responding IPv4 packet from outside the subscriber network:

- Encapsulates the IPv4 packet in an IPv6 packet using the mapped IPv6 address as the IPv6 destination address.
- Forwards the packet to the user.

Table 12 on page 111 lists the maximum number of softwire initiators and softwire concentrators per device.

**Table 12: Softwire Initiator and Softwire Concentrator Capacity**

| Description                                      | SRX650 | SRX3400 | SRX3600 | SRX5600 | SRX5800 |
|--------------------------------------------------|--------|---------|---------|---------|---------|
| Maximum softwire initiators connected per device | 50,000 | 100,000 | 100,000 | 100,000 | 100,000 |
| Maximum softwire concentrator numbers per device | 16     | 32      | 32      | 32      | 32      |



**NOTE:** The most recent IETF draft documentation for DS-Lite uses new terminology:

- The term *softwire initiator* has been replaced by *B4*.
- The term *softwire concentrator* has been replaced by *AFTR*.

Junos OS documentation generally uses the original terms when discussing configuration in order to be consistent with the CLI statements used to configure DS-Lite.

For more information, see the following documents:

- *draft-ietf-softwire-dual-stack-lite-06, Dual-Stack Lite Broadband Deployments Following IPv4 Exhaustion*, August 2010.
- RFC 2473, *Generic Packet Tunneling in IPv6 Specification*, December 1998.
- RFC 2663, *IP Network Address Translator (NAT) Terminology and Considerations*, August 1999.
- RFC 4787, *Network Address Translation (NAT) Behavioral Requirements for Unicast UDP, BCP 127*, January 2007.
- RFC 4925, *Softwire Problem Statement*, July 2007.
- RFC 5382, *NAT Behavioral Requirements for TCP, BCP 142*, October 2008.
- RFC 5508, *NAT Behavioral Requirements for ICMP, BCP 148*, April 2009.
- <http://www.potaroo.net/tools/ipv4/index.html>
- <http://www.iana.org/assignments/ipv4-address-space/ipv4-address-space.xhtml>

**Related  
Documentation**

- [Example: Configuring IPv6 Dual-Stack Lite on page 112](#)
- [Understanding How SRX Series Devices Handle ICMPv6 Packets on page 107](#)
- [About the IPv6 Basic Packet Header on page 102](#)

---

## Example: Configuring IPv6 Dual-Stack Lite

When an ISP begins to allocate IPv6 addresses and IPv6-capable equipment to new subscriber homes, dual-stack lite (DS-Lite) provides a method for the private IPv4 addresses behind the IPv6 CE WAN equipment to reach the IPv4 network. DS-Lite enables IPv4 customers to continue to access the Internet using their current hardware by using a softwire initiator at the customer edge to encapsulate IPv4 packets into IPv6 packets with minimum disruption to their home network, while enabling IPv6 customers to access IPv6 content. The softwire concentrator decapsulates the IPv4-in-IPv6 packets and also performs IPv4-IPv4 NAT translations.

This example shows you how to configure a software concentrator for IPv4-in-IPv6 addresses.

- [Requirements on page 113](#)
- [Overview on page 113](#)
- [Configuration on page 113](#)
- [Verification on page 114](#)

## Requirements

Before you begin:

- Review the overview section on DS-Lite. See “[Understanding IPv6 Dual-Stack Lite](#)” on [page 109](#).
- Review how ICMPv6 packets are handled by the SRX Series devices. See “[Understanding How SRX Series Devices Handle ICMPv6 Packets](#)” on [page 107](#).

## Overview

This configuration example shows how to configure a software concentrator, the software name, the concentrator address, and the software type.



**NOTE:** The software concentrator IPv6 address can match an IPv6 address configured on a physical interface or an IPv6 address configured on a loopback interface.

## Configuration

**CLI Quick Configuration** To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
set security softwires software-name my_sc1 software-concentrator 2001:100::1
software-type IPv4-in-IPv6
```

**Step-by-Step Procedure** The following example requires you to navigate various levels in the configuration hierarchy. For instructions on how to do that, see *Using the CLI Editor in Configuration Mode* in the *CLI User Guide*.

To configure a DS-Lite software concentrator to convert IPv4 packets into IPv6 packets:

1. Assign a name for the software concentrator.  

```
[edit security]
user@host# edit softwires software-name my_sc1
```
2. Specify the address of the software concentrator.  

```
[edit security softwires software-name my_sc1]
user@host# set software-concentrator 2001:100::1
```

3. Specify the software type for IPv4 to IPv6.

```
[edit security softwares software-name my_sc1 software-concentrator 2001:100::1
user@host# set software-type IPv4-in-IPv6
```

**Results** From configuration mode, confirm your configuration by entering the **show** command. If the output does not display the intended configuration, repeat the instructions in this example to correct the configuration.

```
[edit security softwares software-name my_sc1]
user@host# show
software-concentrator 2001:100::1;
software-type ipv4-in-ipv6;
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

From operational mode, enter the **show security softwares** command. If a software is not connected, the operational output looks like the following sample:

```
user@host# show security softwares
```

| Software Name | SC Address  | Status | Number of SI connected |
|---------------|-------------|--------|------------------------|
| my-sc1        | 2001:100::1 | Active | 0                      |

If a software is connected, the operational output looks like the following sample:

```
user@host# show security softwares
```

| Software Name | SC Address  | Status    | Number of SI connected |
|---------------|-------------|-----------|------------------------|
| my-sc1        | 2001:100::1 | Connected | 1                      |

- Related Documentation**
- [Understanding IPv6 Dual-Stack Lite on page 109](#)
  - [About the IPv6 Basic Packet Header on page 102](#)



## PART 5

# Monitoring Flow-Based Sessions

- [Monitoring Security Flow Sessions on page 117](#)
- [Monitoring X2 Traffic By Configuring Mirror Filters on page 129](#)



## CHAPTER 9

# Monitoring Security Flow Sessions

- [Monitoring Security Flow Sessions Overview on page 117](#)
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
- [Displaying Global Session Parameters for All SRX Series Services Gateways on page 120](#)
- [Displaying a Summary of Sessions for SRX Series Services Gateways on page 121](#)
- [Displaying Session and Flow Information About Sessions for SRX Series Services Gateways on page 121](#)
- [Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways on page 122](#)
- [Using Filters to Display Session and Flow Information for SRX Series Services Gateways on page 123](#)
- [Information Provided in Session Log Entries for SRX Series Services Gateways on page 123](#)

### Monitoring Security Flow Sessions Overview

Junos OS allows you to configure and start the monitoring of flow sessions using operational mode commands. Thus, you can debug without having to commit or modify your running configuration. This approach can be especially useful when you do not want to change the state of your device by committing the configuration to turn on trace options.

To configure flow session monitoring, you must define flow filters, specify the output file, and start monitoring. Flow session monitoring does not start unless a filter (at least one) and an output file are specified. Also, defining the filters themselves does not trigger monitoring. You have to explicitly use the **monitor security flow start** and **monitor security flow stop** commands to enable and disable monitoring, respectively.

- Define flow filters—Define the flow sessions that you want to monitor using combinations of match criteria, such as source address, destination address, source port, destination port, IP protocol number, name of the incoming or outgoing interface, and the logical system name. You can delete filters using the **clear monitor security flow filter** command.



**NOTE:** Unlike filters defined in the configuration mode, filters defined using operational mode commands are cleared when you reboot your system.

- Specify the output file—Create an output file in which the security flow monitoring information is to be saved. This file is saved in the `/var/log/` directory. You can view the contents of this file by using the **show log filename** command. Use the **monitor security flow file** command to specify output file characteristics, such as its maximum size, maximum number, and type.
- Start monitoring—Use the **monitor security flow start** command to start monitoring. Once monitoring starts, any traffic that matches the filters is saved in the specified output file in the `/var/log/` directory. The basic-datapath flag is the default flag and turns on as monitoring starts.

Use the **monitor security flow stop** command to stop monitoring. Once monitoring stops, the basic-datapath flag is cleared.

- Display monitoring flow information—Use the **show monitoring security flow** command to display details about the monitoring operation.



**NOTE:** You can configure flow session monitoring and debugging by using the monitoring operational mode commands and flow traceoptions configuration statements. These two operations cannot run in parallel. When you turn on security flow monitoring, the flow traceoption session is blocked and when the flow traceoption session is running, monitoring of the flow session is blocked.

**Related  
Documentation**

- [monitor security flow start on page 258](#)
- [monitor security flow file on page 254](#)
- [monitor security flow filter on page 256](#)
- [show monitor security flow on page 347](#)
- [monitor security flow stop on page 259](#)
- [clear monitor security flow filter on page 231](#)

## Understanding How to Obtain Session Information for SRX Series Services Gateways

You can obtain information about the sessions and packet flows active on your device, including detailed information about specific sessions. (The SRX Series device also

displays information about failed sessions.) You can display this information to observe activity and for debugging purposes. For example, you can use the `show security flow session` command:

- To display a list of incoming and outgoing IP flows, including services
- To show the security attributes associated with a flow, for example, the policies that apply to traffic belonging to that flow
- To display the session timeout value, when the session became active, for how long it has been active, and if there is active traffic on the session



**NOTE:** If an interface NAT is configured and sessions are set up with the NAT using that interface IP address, whenever the interface IP address changes, the sessions set up with NAT get refreshed and new sessions will be setup with new IP address. This you can verify using `show security flow session` CLI command.

Session information can also be logged if a related policy configuration includes the logging option. See [“Information Provided in Session Log Entries for SRX Series Services Gateways” on page 123](#) for details about session information provided in system logs.

For the flow session log on all SRX Series devices, policy configuration has been enhanced. Information on the packet incoming interface parameter in the session log for session-init and session-close and when a session is denied by a policy or by the application firewall is provided to meet Common Criteria (CC) Medium Robustness Protection Profiles (MRPP) compliance:

Policy configuration—To configure the policy for the session for which you want to log matches as log `session-init` or `session-close` and to record sessions in syslog:

- `set security policies from-zone untrustZone to-zone trust zone policy policy13 match source-address extHost1`
- `set security policies from-zone untrustZone to-zone trust zone policy policy13 match source-address extHost1`
- `set security policies from-zone untrustZone to-zone trustZone policy policy13 match application junos-ping`
- `set security policies from-zone untrustZone to-zone trustZone policy policy13 then permit`
- `set security policies from-zone untrustZone to-zone trustZone policy policy13 then log session-init`
- `set security policies from-zone untrustZone to-zone trustZone policy policy13 then log session-close`

**Example :** Flow match policy13 will record the following information in the log:

```
<14>1 2010-09-30T14:55:04.323+08:00 mrpp-srx650-dut01 RT_FLOW -
RT_FLOW_SESSION_CREATE [junos@2636.1.1.1.2.40 source-address="1.1.1.2"
```

```

source-port="1" destination-address="2.2.2.2" destination-port="46384"
service-name="icmp" nat-source-address="1.1.1.2" nat-source-port="1"
nat-destination-address="2.2.2.2" nat-destination-port="46384"
src-nat-rule-name="None" dst-nat-rule-name="None" protocol-id="1"
policy-name="policy1" source-zone-name="trustZone"
destination-zone-name="untrustZone" session-id-32="41"
packet-incoming-interface="ge-0/0/1.0"] session created 1.1.1.2/1-->2.2.2.2/46384 icmp
1.1.1.2/1-->2.2.2.2/46384 None None 1 policy1 trustZone untrustZone 41 ge-0/0/1.0

```

```

<14>1 2010-09-30T14:55:07.188+08:00 mrpp-srx650-dut01 RT_FLOW -
RT_FLOW_SESSION_CLOSE [junos@2636.1.1.1.2.40 reason="response received"
source-address="1.1.1.2" source-port="1" destination-address="2.2.2.2"
destination-port="46384" service-name="icmp" nat-source-address="1.1.1.2"
nat-source-port="1" nat-destination-address="2.2.2.2" nat-destination-port="46384"
src-nat-rule-name="None" dst-nat-rule-name="None" protocol-id="1"
policy-name="policy1" source-zone-name="trustZone"
destination-zone-name="untrustZone" session-id-32="41" packets-from-client="1"
bytes-from-client="84" packets-from-server="1" bytes-from-server="84"
elapsed-time="0" packet-incoming-interface="ge-0/0/1.0"] session closed response
received: 1.1.1.2/1-->2.2.2.2/46384 icmp 1.1.1.2/1-->2.2.2.2/46384 None None 1 policy1
trustZone untrustZone 41 1(84) 1(84) 0 ge-0/0/1.0

```

- Related Documentation**
- [Understanding Session Characteristics for SRX Series Services Gateways on page 29](#)
  - [Clearing Sessions for SRX Series Services Gateways on page 39](#)
  - [Displaying Global Session Parameters for All SRX Series Services Gateways on page 120](#)
  - [allow-embedded-icmp on page 175](#)

## Displaying Global Session Parameters for All SRX Series Services Gateways

- |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b> | Obtain information about configured parameters that apply to all flows or sessions.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Action</b>  | To view session information in the CLI, enter the following command:<br><br><pre>user@host# show security flow</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Meaning</b> | The <b>show security flow</b> configuration command displays the following information: <ul style="list-style-type: none"> <li>• <b>allow-dns-reply</b>—Identifies if unmatched incoming Domain Name System (DNS) reply packets are allowed.</li> <li>• <b>route-change-timeout</b>—If enabled, displays the session timeout value to be used on a route change to a nonexistent route.</li> <li>• <b>tcp-mss</b>—Shows the current configuration for the TCP maximum segment size value to be used for all TCP packets for network traffic.</li> <li>• <b>tcp-session</b>—Displays all configured parameters that control session parameters.</li> <li>• <b>syn-flood-protection-mode</b>—Displays the SYN Proxy mode.</li> </ul> |

- Related Documentation**
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
  - [Displaying a Summary of Sessions for SRX Series Services Gateways on page 121](#)
  - [Displaying Session and Flow Information About Sessions for SRX Series Services Gateways on page 121](#)
  - [Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways on page 122](#)
  - [Using Filters to Display Session and Flow Information for SRX Series Services Gateways on page 123](#)
  - [Information Provided in Session Log Entries for SRX Series Services Gateways on page 123](#)

---

## Displaying a Summary of Sessions for SRX Series Services Gateways

**Purpose** Determine the kinds of sessions on your device, how many of each kind there are—for example, the number of unicast sessions and multicast sessions—the number of failed sessions, the number of sessions that are currently used and the maximum number of sessions that the device supports. This command also displays the details of the sessions that are currently used. For example, valid sessions, pending sessions, invalidated sessions and sessions in other states.

**Action** To view session summary information in the CLI, enter the following CLI command:

```
user@host> show security flow session summary
```

- Related Documentation**
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
  - [Displaying Global Session Parameters for All SRX Series Services Gateways on page 120](#)
  - [Displaying Session and Flow Information About Sessions for SRX Series Services Gateways on page 121](#)
  - [Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways on page 122](#)
  - [Using Filters to Display Session and Flow Information for SRX Series Services Gateways on page 123](#)
  - [Information Provided in Session Log Entries for SRX Series Services Gateways on page 123](#)

---

## Displaying Session and Flow Information About Sessions for SRX Series Services Gateways

**Purpose** Display information about all sessions on your device, including the session ID, the virtual system the session belongs to, the Network Address Translation (NAT) source pool (if source NAT is used), the configured timeout value for the session and its standard timeout,

and the session start time and how long the session has been active. The display also shows all standard flow information, including the direction of the flow, the source address and port, the destination address and port, the IP protocol, and the interface used for the session.

**Action** To view session flow information in the CLI, enter the following command:

```
user@host> show security flow session
```

- Related Documentation**
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
  - [Displaying Global Session Parameters for All SRX Series Services Gateways on page 120](#)
  - [Displaying a Summary of Sessions for SRX Series Services Gateways on page 121](#)
  - [Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways on page 122](#)
  - [Using Filters to Display Session and Flow Information for SRX Series Services Gateways on page 123](#)
  - [Information Provided in Session Log Entries for SRX Series Services Gateways on page 123](#)

---

## Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways

---

**Purpose** When you know the session identifier, you can display all session and flow information for a specific session rather than for all sessions.

**Action** To view information about a specific session in the CLI, enter the following command:

```
user@host> show security flow session session-identifier 40000381
```

- Related Documentation**
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
  - [Displaying Global Session Parameters for All SRX Series Services Gateways on page 120](#)
  - [Displaying a Summary of Sessions for SRX Series Services Gateways on page 121](#)
  - [Displaying Session and Flow Information About Sessions for SRX Series Services Gateways on page 121](#)
  - [Using Filters to Display Session and Flow Information for SRX Series Services Gateways on page 123](#)
  - [Information Provided in Session Log Entries for SRX Series Services Gateways on page 123](#)



## Using Filters to Display Session and Flow Information for SRX Series Services Gateways

**Purpose** You can display flow and session information about one or more sessions by specifying a filter as an argument to the **show security flow session** command. You can use the following filters: application, destination-port, destination-prefix, family, idp, interface, nat, protocol, resource-manager, session-identifier, source-port, source-prefix and tunnel. The device displays the information for each session followed by a line specifying the number of sessions reported on. Here is an example of the command using the source-prefix filter.

**Action** To view information about selected sessions using filters in the CLI, enter the following command:

```
user@host> show security flow session source-prefix 10/8
```

- Related Documentation**
- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
  - [Displaying Global Session Parameters for All SRX Series Services Gateways on page 120](#)
  - [Displaying a Summary of Sessions for SRX Series Services Gateways on page 121](#)
  - [Displaying Session and Flow Information About Sessions for SRX Series Services Gateways on page 121](#)
  - [Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways on page 122](#)
  - [Information Provided in Session Log Entries for SRX Series Services Gateways on page 123](#)

## Information Provided in Session Log Entries for SRX Series Services Gateways

Session log entries are tied to policy configuration. Each main session event—create, close, and deny—will create a log entry if the controlling policy has enabled logging.

Different fields are logged for session create, session close, and session deny events as shown in [Table 13 on page 123](#), [Table 14 on page 124](#), and [Table 15 on page 127](#). The same field name under each type indicates that the same information is logged, but each table is a full list of all data recorded for that type of session log.

The following table defines the fields displayed in session log entries.

**Table 13: Session Create Log Fields**

| Field               | Description                                                    |
|---------------------|----------------------------------------------------------------|
| source-address      | Source IP address of the packet that created the session.      |
| source-port         | Source port of the packet that created the session.            |
| destination-address | Destination IP address of the packet that created the session. |

Table 13: Session Create Log Fields (*continued*)

| Field                          | Description                                                                                                                                                                                                                         |
|--------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>destination-port</b>        | Destination port of the packet that created the session.                                                                                                                                                                            |
| <b>service-name</b>            | Application that the packet traversed (for example, "junos-telnet" for Telnet traffic during the session allowed by a policy that permits native Telnet).                                                                           |
| <b>nat-source-address</b>      | The translated NAT source address if NAT was applied; otherwise, the source address as above.                                                                                                                                       |
| <b>nat-source-port</b>         | The translated NAT source port if NAT was applied; otherwise, the source port as above.                                                                                                                                             |
| <b>nat-destination-address</b> | The translated NAT destination address if NAT was applied; otherwise, the destination address as above.                                                                                                                             |
| <b>nat-destination-port</b>    | The translated NAT destination port if NAT was applied; otherwise, the destination port as above.                                                                                                                                   |
| <b>src-nat-rule-name</b>       | The source NAT rule that was applied to the session (if any). If static NAT is also configured and applied to the session and if source address translation takes place, then this field shows the static NAT rule name.*           |
| <b>dst-nat-rule-name</b>       | The destination NAT rule that was applied to the session (if any). If static NAT is also configured and applied to the session and if destination address translation takes place, then this field shows the static NAT rule name.* |
| <b>protocol-id</b>             | The protocol ID of the packet that created the session.                                                                                                                                                                             |
| <b>policy-name</b>             | The name of the policy that permitted the session creation.                                                                                                                                                                         |
| <b>session-id-32</b>           | The 32-bit session ID.                                                                                                                                                                                                              |

\* Note that some sessions might have both destination and source NAT applied and the information logged.

Table 14: Session Close Log Fields

| Field                      | Description                                                                                                                                               |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>reason</b>              | The reason the session was closed.                                                                                                                        |
| <b>source-address</b>      | Source IP address of the packet that created the session.                                                                                                 |
| <b>source-port</b>         | Source port of the packet that created the session.                                                                                                       |
| <b>destination-address</b> | Destination IP address of the packet that created the session.                                                                                            |
| <b>destination-port</b>    | Destination port of the packet that created the session.                                                                                                  |
| <b>service-name</b>        | Application that the packet traversed (for example, "junos-telnet" for Telnet traffic during the session allowed by a policy that permits native Telnet). |

Table 14: Session Close Log Fields (*continued*)

| Field                          | Description                                                                                                                                                                                                                                                                                                                                     |
|--------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>nat-source-address</b>      | The translated NAT source address if NAT was applied; otherwise, the source address as above.                                                                                                                                                                                                                                                   |
| <b>nat-source-port</b>         | The translated NAT source port if NAT was applied; otherwise, the source port as above.                                                                                                                                                                                                                                                         |
| <b>nat-destination-address</b> | The translated NAT destination address if NAT was applied; otherwise, the destination address as above.                                                                                                                                                                                                                                         |
| <b>nat-destination-port</b>    | The translated NAT destination port if NAT was applied; otherwise, the destination port as above.                                                                                                                                                                                                                                               |
| <b>src-nat-rule-name</b>       | The source NAT rule that was applied to the session (if any). If static NAT is also configured and applied to the session and if source address translation takes place, then this field shows the static NAT rule name.*                                                                                                                       |
| <b>dst-nat-rule-name</b>       | The destination NAT rule that was applied to the session (if any). If static NAT is also configured and applied to the session and if destination address translation takes place, then this field shows the static NAT rule name.*                                                                                                             |
| <b>protocol-id</b>             | The protocol ID of the packet that created the session.                                                                                                                                                                                                                                                                                         |
| <b>policy-name</b>             | The name of the policy that permitted the session creation.                                                                                                                                                                                                                                                                                     |
| <b>session-id-32</b>           | The 32-bit session ID.                                                                                                                                                                                                                                                                                                                          |
| <b>packets-from-client</b>     | The number of packets sent by the client related to this session.                                                                                                                                                                                                                                                                               |
| <b>bytes-from-client</b>       | The number of data bytes sent by the client related to this session.                                                                                                                                                                                                                                                                            |
| <b>packets-from-server</b>     | The number of packets sent by the server related to this session.                                                                                                                                                                                                                                                                               |
| <b>bytes-from-server</b>       | The number of data bytes sent by the server related to this session.                                                                                                                                                                                                                                                                            |
| <b>elapsed-time</b>            | The total session elapsed time from permit to close, given in seconds.                                                                                                                                                                                                                                                                          |
| <b>unset</b>                   | <p>During the session creation, you can set the session close reason as <b>unset</b>.</p> <p>The session closes with the reason <b>unset</b> if the session installation on the control point is not successful. The reason for session installation varies, for example, nonavailability of memory for nonmanagement session installation.</p> |
| <b>TCP RST</b>                 | RST received from either end.                                                                                                                                                                                                                                                                                                                   |

Table 14: Session Close Log Fields (*continued*)

| Field                                  | Description                                                                                                                                         |
|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| TCP FIN                                | FIN received from either end.                                                                                                                       |
| response received                      | Response received for a packet request (for example, ICMP req-reply).                                                                               |
| ICMP error                             | ICMP error received.                                                                                                                                |
| aged out                               | Session aged out was reached.                                                                                                                       |
| ALG                                    | ALG errors closed the session (for example, remote access server (RAS) maximum limit reached).                                                      |
| HA                                     | HA message closed the session.                                                                                                                      |
| auth                                   | Authentication failed.                                                                                                                              |
| IDP                                    | IDP closed the session because of security module (SM) internal error.                                                                              |
| synproxy failure                       | SYN proxy failure closed the session.                                                                                                               |
| synproxy limit                         | Reason for failure in allocating minor session, need to free original session.                                                                      |
| parent closed                          | Parent session closed.                                                                                                                              |
| CLI                                    | Session cleared by a CLI statement.                                                                                                                 |
| CP NACK                                | CP NACK response received.                                                                                                                          |
| CP delete                              | CP ACK deletion closed the session.                                                                                                                 |
| policy delete                          | Corresponding policy marked for deletion.                                                                                                           |
| fwd session                            | Session closed because of forwarding session deletion.                                                                                              |
| multicast route change                 | Session closed because multicast route changed.                                                                                                     |
| first path reroute, session recreated  | The first path is rerouted and session is re-created.                                                                                               |
| source NAT allocation failure          | SPU received ACK message from the central point but failed to receive the DIP resource. Therefore this packet is dropped and the session is closed. |
| other                                  | Session closed because of all other reasons (for example, the pim reg tun needed refreshing).                                                       |
| error create IKE pass-through template | IKE pass-through template creation errors.                                                                                                          |

Table 14: Session Close Log Fields (*continued*)

| Field                                 | Description                                                                    |
|---------------------------------------|--------------------------------------------------------------------------------|
| IKE pass-through child session ageout | Session is deleted because the IKE pass through template session has no child. |
| sess timeout on pending state         | Pending session closed because time out timer reached the pending state.       |
| unknown                               | Session closed because of unknown reasons.                                     |

*\* Note that some sessions might have both destination and source NAT applied and the information logged.*

Table 15: Session Deny Log Fields

| Field               | Description                                                                              |
|---------------------|------------------------------------------------------------------------------------------|
| source-address      | Source IP address of the packet that attempted to create the session.                    |
| source-port         | Source port of the packet that attempted to create the session.                          |
| destination-address | Destination IP address of the packet that attempted to create the session.               |
| destination-port    | Destination port of the packet that attempted to create the session.                     |
| service-name        | Application that the packet attempted to traverse.                                       |
| protocol-id         | The protocol ID of the packet that attempted to create the session.                      |
| icmp-type           | The ICMP type if the denied packet was ICMP configured; otherwise, this field will be 0. |
| policy-name         | The name of the policy that denied the session creation.                                 |

#### Related Documentation

- [Understanding How to Obtain Session Information for SRX Series Services Gateways on page 118](#)
- [Displaying Global Session Parameters for All SRX Series Services Gateways on page 120](#)
- [Displaying a Summary of Sessions for SRX Series Services Gateways on page 121](#)
- [Displaying Session and Flow Information About Sessions for SRX Series Services Gateways on page 121](#)
- [Displaying Session and Flow Information About a Specific Session for SRX Series Services Gateways on page 122](#)
- [Clearing Sessions for SRX Series Services Gateways on page 39](#)
- [Using Filters to Display Session and Flow Information for SRX Series Services Gateways on page 123](#)



## CHAPTER 10

# Monitoring X2 Traffic By Configuring Mirror Filters

- [Understanding X2 Traffic Monitoring on page 129](#)
- [Example: Configuring Mirror Filters for X2 Traffic Monitoring on page 132](#)

## Understanding X2 Traffic Monitoring

---

In an LTE mobile network, SRX Series devices act as secure gateways and connect Evolved Node Bs (eNodeBs) for signal handover, monitoring, and radio coverage. SRX Series devices use IPsec tunnels to connect eNodeBs. The user plane and control plane traffic that flows from one eNodeB to the other eNodeB is called the X2 traffic.

This topic covers X2 traffic monitoring on SRX Series devices:

- [X2 Traffic Monitoring Overview on page 129](#)
- [Limitations of X2 Traffic Monitoring on page 131](#)
- [X2 Traffic Terminology on page 131](#)

## X2 Traffic Monitoring Overview

The X2 traffic passing through IPsec tunnels is encrypted; thus the mobile network operators need a way to monitor X2 traffic so that they can debug handover issues across eNodeBs. The Junos OS implementation allows monitoring of the X2 traffic by snooping into the cleartext X2 traffic as it flows through the SRX Series device coming out of one IPsec tunnel and going into the other IPsec tunnel—after traffic is decrypted and before it is encrypted again.

[Figure 10 on page 130](#) shows the flow of X2 traffic within the SRX Series device. As the traffic reaches the SRX Series device on one st0.x interface, it gets decrypted. Then it is encrypted and forwarded to the destination eNodeB through its dedicated st0.y interface. Snooping is performed on the decrypted X2 traffic on the SRX Series device.

Figure 10: SRX Series Device in an LTE Mobile Network





Figure 11 on page 130 shows a mobile operators network with an SRX Series device providing IPsec tunnel connection between the two eNodeBs. The SRX Series device is connected to a packet analyzer (also called a *sniffing* device) that is used for collecting and checking the X2 interface traffic. The IPsec tunnel from each eNodeB terminates on a dedicated secure tunnel interface on the SRX Series device. Traffic coming out of the IPsec tunnel is decrypted while traffic in the opposite direction is encrypted.

Figure 11: Monitoring X2 Traffic



To monitor the X2 interface, you configure mirror filters on the SRX Series device and filter the traffic that you want to analyze. The filtered packets are duplicated and sent to a physical interface. You also specify the output interface on the SRX Series device and the MAC address of the packet analyzer. Because the output interface is connected to the same Layer 2 network as the packet analyzer, once the mirror filtering is turned on, the packet analyzer collects and verifies the X2 traffic.



## Limitations of X2 Traffic Monitoring

The X2 traffic monitoring feature has a limitation—for X2 traffic in a chassis cluster setup, mirrored packets cannot traverse through the data link (fabric interface).

## X2 Traffic Terminology

Table 16 on page 131 lists some X2 traffic related terms and their descriptions.

**Table 16: X2 Traffic Terminology**

| Term                                                         | Description                                                                                                                                                                                                                                                                                                                                                       |
|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Evolved packet core (EPC)                                    | Main component of System Architecture Evolution (SAE) and is also known as the SAE core. The EPC supports the IP network and serves as the equivalent of a General Packet Radio Service (GPRS) network, using the mobility management entity (MME), Serving Gateway (SGW), and Packet Data Network Gateway (PGW) subcomponents.                                   |
| Evolved Universal Terrestrial Radio Access Network (E-UTRAN) | A radio access network standard. E-UTRAN is a new air interface system. It provides higher data rates and lower latency and is optimized for packet data. It uses Orthogonal Frequency-Division Multiple Access (OFDMA) for the downlink and Single-carrier Frequency Division Multiple Access for the uplink.                                                    |
| Evolved Node B (eNodeB)                                      | A device connected to the mobile phone network that communicates directly with mobile handsets, like a base transceiver station in Global System for Mobile Communications (GSM) networks. An eNodeB is controlled by a radio network controller (RNC).                                                                                                           |
| Long Term Evolution (LTE)                                    | A standard for wireless communication of high-speed data for mobile phones and data terminals. It increases the capacity and speed using a different radio interface and makes core network improvements.                                                                                                                                                         |
| X2 interface                                                 | A point-to-point logical interface between two eNodeBs with the E-UTRAN. It supports the exchange of signaling information between two eNodeBs and supports the forwarding of protocol data units (PDUs) to the respective tunnel endpoints.                                                                                                                      |
| X2 Application Protocol (X2AP)                               | Protocol used by the X2 interface. It is used for handling the user equipment mobility within the E-UTRAN and provides the following functions: <ul style="list-style-type: none"> <li>• Manages mobility and load</li> <li>• Reports general error situations</li> <li>• Sets and resets the X2 interface</li> <li>• Updates the eNodeB configuration</li> </ul> |

- Related Documentation**
- [Example: Configuring Mirror Filters for X2 Traffic Monitoring on page 132](#)
  - [mirror-filter \(Security Forwarding Options\) on page 197](#)

## Example: Configuring Mirror Filters for X2 Traffic Monitoring

This example shows how to configure mirror filters to monitor X2 traffic between two eNodeBs in an LTE mobile network.

- [Requirements on page 132](#)
- [Overview on page 132](#)
- [Configuration on page 133](#)
- [Verification on page 134](#)

### Requirements

Before you begin:

- Understand X2 traffic monitoring. See [“Understanding X2 Traffic Monitoring” on page 129](#).
- Configure the interfaces, security zones, security policies, and the route-based VPN tunnels to allow data to be securely transferred between the SRX Series device and the two eNodeBs. See [Example: Configuring a Route-Based VPN](#).


### Overview

In this example, an SRX Series device uses IPsec tunnels to connect two eNodeBs in an LTE mobile network. You, as a network operator, need a way to monitor the X2 traffic to debug any handover issues across eNodeBs. Traffic coming out of an IPsec tunnel is decrypted and then encrypted again to go into the other IPsec tunnel in the opposite direction.

To monitor traffic, you configure mirror filters on the SRX Series device. The traffic that matches your specified filters is mirrored and sent to an output interface that is connected to a packet analyzer (also called a *sniffing* device). The packet analyzer analyzes the traffic allowing you to monitor the X2 traffic.

[Figure 12 on page 132](#) shows the SRX Series device connecting to the eNodeBs using IPsec tunnels. The SRX Series device is also connected to a packet analyzer.

**Figure 12: Configuring Mirror Filters for X2 Traffic Monitoring**



In this example, you specify the following match conditions for the filters:

- Protocol—ICMP
- Source-prefix—11.1.1.0/24
- Destination-prefix—41.1.1.0/24
- Incoming logical interface—st0.1
- Outgoing logical interface—st0.2

Packets that match these conditions are mirrored and sent through the output interface ge-0/0/5 to the packet analyzer with a MAC address 00:50:56:87:20:5E. The packet analyzer analyzes traffic that you can use for monitoring and debugging the X2 traffic on the SRX Series device.

## Configuration

**CLI Quick Configuration** To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
set security forwarding-options mirror-filter m1 protocol icmp
set security forwarding-options mirror-filter m1 source-prefix 11.1.1.0/24
set security forwarding-options mirror-filter m1 destination-prefix 41.1.1.0/24
set security forwarding-options mirror-filter m1 interface-in st0.1
set security forwarding-options mirror-filter m1 interface-out st0.2
set security forwarding-options mirror-filter m1 output interface ge-0/0/5
set security forwarding-options mirror-filter m1 output destination-mac 00:50:56:87:20:5E
```

**Step-by-Step Procedure** The following example requires you to navigate various levels in the configuration hierarchy. For instructions on how to do that, see *Using the CLI Editor in Configuration Mode* in the *CLI User Guide*.

To configure mirror filters for monitoring X2 traffic:

1. Create a mirror filter.  

```
[edit]
user@host# edit security forwarding-options mirror-filter m1
```
2. Specify the match conditions for the mirror filter.  

```
[edit security forwarding-options mirror-filter m1]
user@host# set protocol icmp
user@host# set source-prefix 11.1.1.0/24
user@host# set destination-prefix 41.1.1.0/24
user@host# set interface-in st0.1
user@host# set interface-out st0.2
```
3. Specify the output interface for the mirrored packets.  

```
[edit security forwarding-options mirror-filter m1]
user@host# set output interface ge-0/0/5
```

4. Specify the MAC address of the packet analyzer as a destination for all mirrored packets.

```
[edit security forwarding-options mirror-filter m1]
user@host# set output destination-mac 00:50:56:87:20:5E
```

**Results** From configuration mode, confirm your configuration by entering the **show security forwarding-options** command. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

```
user@host# show security forwarding-options
mirror-filter m1 {
 protocol icmp;
 source-prefix 11.1.1.0/24;
 destination-prefix 41.1.1.0/24;
 interface-in st0.1;
 interface-out st0.2;
 output {
 interface ge-0/0/5;
 destination-mac 00:50:56:87:20:5E;
 }
}
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

Confirm that the configuration is working properly.

### Verifying the Status of Mirror Filter

---

**Purpose** Verify that mirror filter is active or not.

**Action** From operational mode, enter the **show security forward-options mirror-filter** command.

```
user@host> show security forward-options mirror-filter m1
Security mirror status

mirror-filter-name: m1
interface-in: st0.1
interface-out: st0.2
protocol: 1
source-prefix: 11.1.1.0
destination-prefix: 41.1.1.0
filter-counters: 2
output-counters: 2
```

**Meaning** The output provides the mirror filter status. It shows that a mirror filter named m1 is active. The match conditions for the filter are set—source prefix, destination prefix, protocol and incoming and outgoing interfaces.

This output shows that two packets were matched for mirroring and two packets were sent to the packet analyzer. It also correctly shows that the filter and output counters are the same. This means that the number of packets matched for mirroring and the number of packets sent to the packet analyzer are the same.

- Related Documentation**
- [mirror-filter \(Security Forwarding Options\) on page 197](#)
  - [clear security forward-options mirror filter on page 253](#)



## PART 6

# Configuring Packet-Based Forwarding

- [Configuring Selective Stateless Packet-Based Services on page 139](#)





## CHAPTER 11

# Configuring Selective Stateless Packet-Based Services


- [Understanding Packet-Based Processing on page 139](#)
- [Understanding Selective Stateless Packet-Based Services on page 140](#)
- [Selective Stateless Packet-Based Services Configuration Overview on page 142](#)
- [Example: Configuring Selective Stateless Packet-Based Services for End-to-End Packet-Based Forwarding on page 144](#)
- [Example: Configuring Selective Stateless Packet-Based Services for Packet-Based to Flow-Based Forwarding on page 154](#)

## Understanding Packet-Based Processing

Packets that enter and exit a Juniper Networks device running Junos OS can undergo packet-based processing. Packet-based, or stateless, packet processing treats packets discretely. Each packet is assessed individually for treatment. Stateless packet-based forwarding is performed on a packet-by-packet basis without regard to flow or state information. Each packet is assessed individually for treatment.

[Figure 13 on page 139](#) shows the traffic flow for packet-based forwarding.

**Figure 13: Traffic Flow for Packet-Based Forwarding**



As packets enter the device, classifiers, filters and policers are applied to it. Next, the egress interface for the packet is determined through a route lookup. Once the egress interface for the packet is found, filters are applied and the packet is sent to the egress interface where it is queued and scheduled for transmission.

Packet-based forwarding does not require any information about either previous or subsequent packets that belong to a given connection, and any decision to allow or deny

traffic is packet specific. This architecture has the benefit of massive scaling because it forwards packets without keeping track of individual flows or state.

On SRX Series devices, the default mode for processing traffic is flow mode. To configure an SRX Series device as a border router, you must change the mode from flow-based processing to packet-based processing. Use the **set security forwarding-options family mpls mode packet-based** statement to configure the SRX device to packet mode. You must reboot the device for the configuration to take effect.

**Related  
Documentation**

- [Understanding Selective Stateless Packet-Based Services on page 140](#)
- [Selective Stateless Packet-Based Services Configuration Overview on page 142](#)
- [Example: Configuring Selective Stateless Packet-Based Services for End-to-End Packet-Based Forwarding on page 144](#)
- [Example: Configuring Selective Stateless Packet-Based Services for Packet-Based to Flow-Based Forwarding on page 154](#)
- *forwarding-options (Security)*

---

## Understanding Selective Stateless Packet-Based Services

---

Selective stateless packet-based services allow you to use both flow-based and packet-based forwarding simultaneously on a system. You can selectively direct traffic that requires packet-based, stateless forwarding to avoid stateful flow-based forwarding by using stateless firewall filters, also known as access control lists (ACLs). The traffic not so directed follows the default flow-based forwarding path. Bypassing flow-based forwarding can be useful for traffic for which you explicitly want to avoid flow session-scaling constraints.


By default, Juniper Networks devices running Junos OS use flow-based forwarding. Selective stateless packet-based services allows you to configure the device to provide only packet-based processing for selected traffic based on input filter terms. Other traffic is processed for flow-based forwarding. Bypassing flow-based forwarding is useful for deployments where you want to avoid session-scaling constraints and session creation and maintenance costs.

When you configure the device for selective stateless packet-based processing, packets entering the system are treated differently depending on certain conditions:

- If a packet satisfies matching conditions specified in input filter terms, it is marked for packet mode and all configured packet mode features are applied to it. No flow-based security features are applied. It bypasses them.
- If a packet has not been flagged for packet-mode, it undergoes normal processing. All services except for MPLS can be applied to this traffic.

[Figure 14 on page 141](#) shows traffic flow with selective stateless packet-based services bypassing flow-based processing.

Figure 14: Traffic Flow with Selective Stateless Packet-Based Services



When the packet comes in on an interface, the input packet filters configured on the interface are applied.

- If the packet matches the conditions specified in the firewall filter, a **packet-mode** action modifier is set to the packet. The packet-mode action modifier updates a bit field in the packet key buffer—this bit field is used to determine if the flow-based forwarding needs to be bypassed. As a result, the packet with the packet-mode action modifier bypasses the flow-based forwarding completely. The egress interface for the packet is determined through a route lookup. Once the egress interface for the packet is found, filters are applied and the packet is sent to the egress interface where it is queued and scheduled for transmission.
- If the packet does not match the conditions specified in this filter term, it is evaluated against other terms configured in the filter. If, after all terms are evaluated, a packet matches no terms in a filter, the packet is silently discarded. To prevent packets from being discarded, you configure a term in the filter specifying an action to accept all packets.

A defined set of stateless services is available with selective stateless packet-based services:

- IPv4 routing (unicast and multicast protocols)
- Class of service (CoS)
- Link fragmentation and interleaving (LFI)
- Generic routing encapsulation (GRE)
- Layer 2 switching
- Multiprotocol Label Switching (MPLS)
- Stateless firewall filters
- Compressed Real-Time Transport Protocol (CRTP)

Although traffic requiring MPLS services must be processed in packet mode, under some circumstances it might be necessary to concurrently apply certain services to this traffic that can only be provided in flow mode, such as stateful inspection, NAT, and IPsec. To

direct the system to process traffic in both flow and packet modes, you must configure multiple routing instances connected through a tunnel interface. One routing instance must be configured to process the packets in flow mode and the other routing instance must be configured to process the packets in packet mode. When you use a tunnel interface to connect routing instances, traffic between those routing instances is injected again into the forwarding path and it can then be reprocessed using a different forwarding method.

**Related  
Documentation**

- [Understanding Packet-Based Processing on page 139](#)
- [Selective Stateless Packet-Based Services Configuration Overview on page 142](#)
- [Example: Configuring Selective Stateless Packet-Based Services for End-to-End Packet-Based Forwarding on page 144](#)
- [Example: Configuring Selective Stateless Packet-Based Services for Packet-Based to Flow-Based Forwarding on page 154](#)

---

## Selective Stateless Packet-Based Services Configuration Overview

You configure selective stateless packet-based services using the stateless firewall filters, also known as access control lists (ACLs). You classify traffic for packet-based forwarding by specifying match conditions in the firewall filters and configure a **packet-mode** action modifier to specify the action. Once match conditions and actions are defined, firewall filters are applied to relevant interfaces.

To configure a firewall filter:

1. Define the address family—First define the address family of the packets that a firewall filter matches. To define the family name, specify **inet** to filter IPv4 packets. Specify **mpls** to filter MPLS packets. Specify **ccc** to filter Layer 2 switching cross-connects.
2. Define terms—Define one or more terms that specify the filtering criteria and the action to take if a match occurs. Each term consists of two components—match conditions and actions.
  - Match conditions—Specify certain characteristics that the packet must match for the action to be performed. You can define various match conditions, such as the IP source address field, IP destination address field, and IP protocol field.
  - Action—Specify what is to be done with the packet if it matches the match conditions. Possible actions are to accept, discard, or reject a packet; go to the next term; or take no action.

You can specify only one **action** statement (or omit it) in a term, but you can specify any combination of action modifiers with it. Action modifiers include a default **accept** action. For example, if you specify an action modifier and do not specify an action, the specified action modifier is implemented and the packet is accepted.

The **packet-mode** action modifier specifies traffic to bypass flow-based forwarding. Like other action modifiers, you can configure the **packet-mode** action modifier along with other actions, such as **accept** or **count**.

3. Apply firewall filters to interfaces—Apply the firewall filter to the interface to have the firewall filter take effect.

When the packet comes in on an interface, the input packet filters configured on the interface are applied. If the packet matches the specified conditions and **packet-mode** action is configured, the packet bypasses the flow-based forwarding completely.

When configuring filters, be mindful of the order of the terms within the firewall filter. Packets are tested against each term in the order in which it is listed in the configuration. When the first matching conditions are found, the action associated with that term is applied to the packet and the evaluation of the firewall filter ends, unless the **next term** action modifier is included. If the **next term** action is included, the matching packet is then evaluated against the next term in the firewall filter; otherwise, the matching packet is not evaluated against subsequent terms in the firewall filter.

When configuring firewall filters for selective stateless packet-based services:

- Accurately identify traffic that needs to bypass flow to avoid unnecessary packet drops.
- Make sure to apply the firewall filter with packet-mode action on all interfaces involved in the packet-based flow path.
- Make sure to configure host-bound TCP traffic to use flow-based forwarding—exclude this traffic when specifying match conditions for the firewall filter term containing the **packet-mode** action modifier. Any host-bound TCP traffic configured to bypass flow is dropped. Asynchronous flow-mode processing is not supported with selective stateless packet-based services.
- Configure input packet filters (not output) with the **packet-mode** action modifier.



**NOTE:** Nested firewall filters (configuring a filter within the term of another filter) are not supported with selective stateless packet-based services.

Some typical deployment scenarios where you can configure selective stateless packet-based services are as follows:

- Traffic flow between private LAN and WAN interfaces, such as for Intranet traffic, where end-to-end forwarding is packet-based
- Traffic flow between private LAN and not-so-secure WAN interfaces, where traffic uses packet-based and flow-based forwarding for secure and not so secure traffic respectively
- Traffic flow between the private LAN and WAN interface with failover to flow-based IPsec WAN when the private WAN link is down
- Traffic flow from flow-based LAN to packet-based MPLS WAN

#### Related Documentation

- [Understanding Packet-Based Processing on page 139](#)
- [Understanding Selective Stateless Packet-Based Services on page 140](#)

- [Example: Configuring Selective Stateless Packet-Based Services for End-to-End Packet-Based Forwarding on page 144](#)
- [Example: Configuring Selective Stateless Packet-Based Services for Packet-Based to Flow-Based Forwarding on page 154](#)

## Example: Configuring Selective Stateless Packet-Based Services for End-to-End Packet-Based Forwarding

---

This example shows how to configure selective stateless packet-based services for end-to-end packet-based forwarding.

- [Requirements on page 144](#)
- [Overview on page 144](#)
- [Configuration on page 145](#)
- [Verification on page 151](#)

### Requirements

Before you begin:

- Understand how to configure stateless firewall filters. See the *Junos OS Routing Protocols Library for Security Devices*.
- Establish basic connectivity. See the *Getting Started Guide for Branch SRX Series*.

### Overview


In this example, you configure the IP addresses for the interfaces on each of the devices. For R0 it is 10.1.1.2/24; for R1 they are 10.1.1.1/24, 10.2.1.1/24, and 1.1.1.1/30; for R2 it is 1.1.1.2/30; and for R3 it is 10.2.1.2/24. You create static routes and associate next-hop addresses for the devices as follows: R0 is 10.1.1.1, R1 is 1.1.1.2, R2 is 1.1.1.1, and R3 is 10.2.1.1.

Then on device R1 you configure a zone called untrust and assign it to interface ge-0/0/3. You also create a zone called trust and assign interfaces ge-0/0/1 and ge-0/0/2 to it. You configure trust and untrust zones to allow all supported application services as inbound services. You allow traffic from any source address, destination address, and application to pass between the zones.

You then create the firewall filter bypass-flow-filter and define the terms bypass-flow-term-1 and bypass-flow-term-2 that match the traffic between internal interfaces ge-0/0/1 and ge-0/0/2 and that contain the packet-mode action modifier. You define the term accept-rest to accept all remaining traffic. Finally, you apply the firewall filter bypass-flow-filter to internal interfaces ge-0/0/1 and ge-0/0/2 (not on the external interface). As a result, all internal traffic bypasses flow-based forwarding and the traffic to and from the Internet does not bypass flow-based forwarding.

[Figure 15 on page 145](#) shows the network topology used in this example.

Figure 15: Intranet Traffic Using End-to-End Packet-Based Services



Your company's branch offices are connected to each other through a private WAN. For this internal traffic, packet forwarding is required because security is not an issue. Hence for this traffic, you decide to configure selective stateless packet-based services to bypass flow-based forwarding. The remaining traffic, to and from the Internet, uses flow-based forwarding.

## Configuration

### CLI Quick Configuration

To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
{device R0}
[edit]
set interfaces description "Internal 1" ge-0/0/1 unit 0 family inet address 10.1.1.2/24
set routing-options static route 0.0.0.0/0 next-hop 10.1.1.1

{device R1}
set interfaces description "Internal 1" ge-0/0/1 unit 0 family inet address 10.1.1.1/24
set interfaces description "Internal 2" ge-0/0/2 unit 0 family inet address 10.2.1.1/24
set interfaces description "Internet" ge-0/0/3 unit 0 family inet address 1.1.1.1/30
set routing-options static route 0.0.0.0/0 next-hop 1.1.1.2
set security zones security-zone untrust interfaces ge-0/0/3
set security zones security-zone trust interfaces ge-0/0/1
set security zones security-zone trust interfaces ge-0/0/2
set security zones security-zone trust host-inbound-traffic system-services all
set security zones security-zone untrust host-inbound-traffic system-services all
set security policies from-zone trust to-zone untrust policy Internet-traffic match
 source-address any destination-address any application any
set security policies from-zone trust to-zone untrust policy Internet-traffic then permit
set security policies from-zone untrust to-zone trust policy Incoming-traffic match
 source-address any destination-address any application any
set security policies from-zone untrust to-zone trust policy Incoming-traffic then permit
set security policies from-zone trust to-zone trust policy Intrazone-traffic match
 source-address any destination-address any application any
```

```

set security policies from-zone trust to-zone trust policy Intrazone-traffic then permit
set firewall family inet filter bypass-flow-filter term bypass-flow-term-1 from
 source-address 10.1.1.0/24
set firewall family inet filter bypass-flow-filter term bypass-flow-term-1 from
 destination-address 10.2.1.0/24
set firewall family inet filter bypass-flow-filter term bypass-flow-term-1 then packet-mode
set firewall family inet filter bypass-flow-filter term bypass-flow-term-2 from
 source-address 10.2.1.0/24
set firewall family inet filter bypass-flow-filter term bypass-flow-term-2 from
 destination-address 10.1.1.0/24
set firewall family inet filter bypass-flow-filter term bypass-flow-term-2 then packet-mode
set firewall family inet filter bypass-flow-filter term accept-rest then accept
set interfaces description "Internal 1" ge-0/0/1 unit 0 family inet filter input
 bypass-flow-filter
set interfaces description "Internal 2" ge-0/0/2 unit 0 family inet filter input
 bypass-flow-filter

{device R2}
set interfaces description "Internet" ge-0/0/3 unit 0 family inet address 1.1.1.2/30
set routing-options static route 0.0.0.0/0 next-hop 1.1.1.1

{device R3}
[edit]
set interfaces description "Internal 2" ge-0/0/2 unit 0 family inet address 10.2.1.2/24
set routing-options static route 0.0.0.0/0 next-hop 10.2.1.1

```

#### Step-by-Step Procedure

The following example requires you to navigate various levels in the configuration hierarchy. For instructions on how to do that, see *Using the CLI Editor in Configuration Mode* in the *CLI User Guide*.

To configure selective stateless packet-based services for end-to-end packet-based forwarding:

1. Configure the IP addresses for the interfaces on devices R0, R1, R2, and R3.

```

{device R0}
[edit]
user@host# set interfaces description "Internal 1" ge-0/0/1 unit 0 family inet address
 10.1.1.2/24

{device R1}
[edit]
user@host# set interfaces description "Internal 1" ge-0/0/1 unit 0 family inet address
 10.1.1.1/24
user@host# set interfaces description "Internal 2" ge-0/0/2 unit 0 family inet address
 10.2.1.1/24
user@host# set interfaces description "Internet" ge-0/0/3 unit 0 family inet address
 1.1.1.30

{device R2}
[edit]
user@host# set interfaces description "Internet" ge-0/0/3 unit 0 family inet address
 1.1.1.2/30

{device R3}
[edit]
user@host# set interfaces description "Internal 2" ge-0/0/2 unit 0 family inet address
 10.2.1.2/24

```



2. Create static routes and associate the appropriate next-hop addresses for devices R0, R1, R2, and R3.

```
{device R0}
[edit]
user@host# set routing-options static route 0.0.0.0/0 next-hop 10.1.1.1

{device R1}
[edit]
user@host# set routing-options static route 0.0.0.0/0 next-hop 1.1.1.2

{device R2}
[edit]
user@host# set routing-options static route 0.0.0.0/0 next-hop 1.1.1.1

{device R3}
[edit]
user@host# set routing-options static route 0.0.0.0/0 next-hop 10.2.1.1
```

3. Configure security zones and assign interfaces.

```
{device R1}
[edit]
user@host# set security zones security-zone untrust interfaces ge-0/0/3
user@host# set security zones security-zone trust interfaces ge-0/0/1
user@host# set security zones security-zone trust interfaces ge-0/0/2
```

4. Configure application services for zones.

```
{device R1}
[edit]
user@host# set security zones security-zone trust host-inbound-traffic
system-services all
user@host# set security zones security-zone untrust host-inbound-traffic
system-services all
```

5. Configure a security policy

```
{device R1}
[edit]
user@host# set security policies from-zone trust to-zone untrust policy
Internet-traffic match source-address any destination-address any application
any
user@host# set security policies from-zone trust to-zone untrust policy
Internet-traffic then permit
user@host# set security policies from-zone untrust to-zone trust policy
Incoming-traffic match source-address any destination-address any application
any
user@host# set security policies from-zone untrust to-zone trust policy
Incoming-traffic then permit
user@host# set security policies from-zone trust to-zone trust policy Intrazone-traffic
match source-address any destination-address any application any
user@host# set security policies from-zone trust to-zone trust policy Intrazone-traffic
then permit
```

6. Create a firewall filter and define terms for all the packet-based forwarding traffic.

```
{device R1}
[edit]
```

```

user@host# set firewall family inet filter bypass-flow-filter term bypass-flow-term-1
from source-address 10.1.1.0/24
user@host# set firewall family inet filter bypass-flow-filter term bypass-flow-term-1
from destination-address 10.2.1.0/24
user@host# set firewall family inet filter bypass-flow-filter term bypass-flow-term-1
then packet-mode
user@host# set firewall family inet filter bypass-flow-filter term bypass-flow-term-2
from source-address 10.2.1.0/24
user@host# set firewall family inet filter bypass-flow-filter term bypass-flow-term-2
from destination-address 10.1.1.0/24
user@host# set firewall family inet filter bypass-flow-filter term bypass-flow-term-2
then packet-mode

```

7. Specify another term for the remaining traffic.

```

{device R1}
[edit]
user@host# set firewall family inet filter bypass-flow-filter term accept-rest then
accept

```

8. Apply the firewall filter to relevant interfaces.

```

{device R1}
[edit]
user@host# set interfaces description "Internal 1" ge-0/0/1 unit 0 family inet filter
input bypass-flow-filter
user@host# set interfaces description "Internal 2" ge-0/0/2 unit 0 family inet filter
input bypass-flow-filter

```

**Results** From configuration mode, confirm your configuration by entering the **show interfaces**, **show routing-options**, and **show firewall** commands. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

```

{device R0}
[edit]
user@host# show interfaces
ge-0/0/1 {
 description "Internal 1"
 unit 0 {
 family inet {
 address 10.1.1.2/24
 }
 }
}
{
}

{device R0}
[edit]
user@host# show routing-options
static {
 route 0.0.0.0/0 next-hop 10.1.1.1;
}

{device R2}
[edit]
user@host# show interfaces
ge-0/0/3 {

```

```

description "Internet"
unit 0 {
 family inet {
 address 1.1.1.2/30;
 }
}

{device R2}
[edit]
user@host# show routing-options
static {
 route 0.0.0.0/0 next-hop 1.1.1.1;
}

{device R3}
[edit]
user@host# show interfaces
ge-0/0/2 {
 description "Internal 2"
 unit 0 {
 family inet {
 address 10.2.1.2/24;
 }
 }
}

{device R3}
user@host# show routing-options
static {
 route 0.0.0.0/0 next-hop 10.2.1.1;
}

{device R1}
[edit]
user@host# show interfaces
ge-0/0/1 {
 description "Internal 1"
 unit 0 {
 family inet {
 filter {
 input bypass-flow-filter;
 }
 address 10.1.1.1/24;
 }
 }
}
ge-0/0/2 {
 description "Internal 2"
 unit 0 {
 family inet {
 filter {
 input bypass-flow-filter;
 }
 address 10.2.1.1/24;
 }
 }
}

```

```
}
ge-0/0/3 {
 description "Internet"
 unit 0 {
 family inet {
 address 1.1.1.1/30;
 }
 }
}
{device R1}
[edit]
user@host# show routing-options
static {
 route 0.0.0.0/0 next-hop 1.1.1.2;
}
{device R1}
[edit]
user@host# show firewall
family inet {
 filter bypass-flow-filter {
 term bypass-flow-term-1 {
 from {
 source-address {
 10.1.1.0/24;
 }
 destination-address {
 10.2.1.0/24;
 }
 }
 then packet-mode;
 }
 term bypass-flow-term-2 {
 from {
 source-address {
 10.2.1.0/24;
 }
 destination-address {
 10.1.1.0/24;
 }
 }
 then packet-mode;
 }
 term accept-rest {
 then accept;
 }
 }
}
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

Confirm that the configuration is working properly.

- [Verifying the End-to-End Packet-Based Configuration on page 151](#)
- [Verifying Session Establishment on Intranet Traffic on page 151](#)
- [Verifying Session Establishment on Internet Traffic on page 152](#)

### Verifying the End-to-End Packet-Based Configuration

**Purpose** Verify that the selective stateless packet-based services are configured.

**Action** From configuration mode, enter the **show interfaces**, **show routing-options**, **show security zones**, **show security policies**, and **show firewall** commands.

Verify that the output shows the intended configuration of the firewall filter, interfaces, and policies.

Verify that the terms are listed in the order in which you want the packets to be tested. You can move terms within a firewall filter by using the **insert** command.

### Verifying Session Establishment on Intranet Traffic

**Purpose** Verify that sessions are established when traffic is transmitted to interfaces within the Intranet.

**Action** To verify that sessions are established, perform the following tasks:

1. On device **R1**, enter the operational mode **clear security flow session all** command to clear all existing security flow sessions.
2. On device **R0**, enter the operational mode **ping** command to transmit traffic to device **R3**.
3. On device **R1**, with traffic transmitting from devices **R0** to **R3** through **R1**, enter the operational mode **show security flow session** command.

Flow Sessions on FPC10 PIC1:  
Total sessions: 0

Flow Sessions on FPC10 PIC2:  
Total sessions: 0

Flow Sessions on FPC10 PIC3:  
Total sessions: 0



**NOTE:** To verify established sessions, make sure to enter the **show security flow session** command while the **ping** command is sending and receiving packets.

```
{device R0}
user@host> ping 60.0.0.1 -c 10
```

```
PING 60.0.0.2 (60.0.0.2) 56(84) bytes of data.
64 bytes from 60.0.0.2: icmp_seq=1 ttl=63 time=6.07 ms
64 bytes from 60.0.0.2: icmp_seq=2 ttl=63 time=4.24 ms
64 bytes from 60.0.0.2: icmp_seq=3 ttl=63 time=2.85 ms
64 bytes from 60.0.0.2: icmp_seq=4 ttl=63 time=6.14 ms
...
```

```
{device R1}
user@host> show security flow session
```

Flow Sessions on FPC10 PIC1:

```
Session ID: 410000077, Policy name: Internet-traffic/5, Timeout: 2, Valid
In: 200.0.0.10/3 --> 60.0.0.2/32055;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 410000198
Out: 60.0.0.2/32055 --> 200.0.0.10/3;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 410000198
Total sessions: 1
```

Flow Sessions on FPC10 PIC2:

```
Session ID: 420000079, Policy name: Internet-traffic/5, Timeout: 2, Valid
In: 200.0.0.10/5 --> 60.0.0.2/32055;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 420000163
Out: 60.0.0.2/32055 --> 200.0.0.10/5;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 420000163
Total sessions: 1
```

Flow Sessions on FPC10 PIC3:

```
Session ID: 430000090, Policy name: Internet-traffic/5, Timeout: 4, Valid
In: 200.0.0.10/7 --> 60.0.0.2/32055;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 430000088
Out: 60.0.0.2/32055 --> 200.0.0.10/7;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 430000088
Total sessions: 1
```

The output shows traffic transmitting from **R0** to **R3** and no sessions are established. In this example, you applied the **bypass-flow-filter** with the **packet-mode** action modifier on interfaces **Internal 1** and **Internal 2** for your company's Intranet traffic. This output verifies that the traffic between the two interfaces is correctly bypassing flow-based forwarding and hence no sessions are established.

---

### Verifying Session Establishment on Internet Traffic

- |                |                                                                                                                                                                                                                                                                                                                                  |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b> | Verify that sessions are established when traffic is transmitted to the Internet.                                                                                                                                                                                                                                                |
| <b>Action</b>  | To verify that traffic to the Internet is using flow-based forwarding and sessions are established, perform the following tasks: <ol style="list-style-type: none"><li>1. On device <b>R1</b>, enter the operational mode <b>clear security flow session all</b> command to clear all existing security flow sessions.</li></ol> |

2. On device **R0**, enter the operational mode **ping** command to transmit traffic to device **R2**.
3. On device **R1**, with traffic transmitting from **R0** to **R2** through **R1**, enter the operational mode **show security flow session** command.



**NOTE:** To verify established sessions, make sure to enter the **show security flow session** command while the **ping** command is sending and receiving packets.

```
{device R0}
user@host> ping 1.1.1.2

PING 1.1.1.2 (1.1.1.2): 56 data bytes
64 bytes from 1.1.1.2: icmp_seq=0 ttl=63 time=2.326 ms
64 bytes from 1.1.1.2: icmp_seq=1 ttl=63 time=2.569 ms
64 bytes from 1.1.1.2: icmp_seq=2 ttl=63 time=2.565 ms
64 bytes from 1.1.1.2: icmp_seq=3 ttl=63 time=2.563 ms
64 bytes from 1.1.1.2: icmp_seq=4 ttl=63 time=2.306 ms
64 bytes from 1.1.1.2: icmp_seq=5 ttl=63 time=2.560 ms
64 bytes from 1.1.1.2: icmp_seq=6 ttl=63 time=4.130 ms
64 bytes from 1.1.1.2: icmp_seq=7 ttl=63 time=2.316 ms
...
```

```
{device R1}
user@host> show security flow session
```

```
Flow Sessions on FPC10 PIC1:
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC3:
Total sessions: 0
```

The output shows traffic transmitting from devices **R0** to **R1** and established sessions. In this example, you did not apply the **bypass-flow-filter** with the **packet-mode** action modifier on interface **Internet** for your company's Internet traffic. This output verifies that the traffic to the Internet is correctly using flow-based forwarding and hence sessions are established.

Transmit traffic from device **R3** to **R2** and use the commands in this section to verify established sessions.

#### Related Documentation

- [Understanding Selective Stateless Packet-Based Services on page 140](#)
- [Selective Stateless Packet-Based Services Configuration Overview on page 142](#)
- [Example: Configuring Selective Stateless Packet-Based Services for Packet-Based to Flow-Based Forwarding on page 154](#)

## Example: Configuring Selective Stateless Packet-Based Services for Packet-Based to Flow-Based Forwarding

---

This example shows how to configure selective stateless packet-based services for packet-based to flow-based forwarding.

- [Requirements on page 154](#)
- [Overview on page 154](#)
- [Configuration on page 155](#)
- [Verification on page 160](#)

### Requirements

Before you begin:

- Understand how to configure stateless firewall filters. See the *Junos OS Routing Protocols Library for Security Devices*.
- Establish basic connectivity. See the *Getting Started Guide for Branch SRX Series*.

### Overview

In this example, you configure the IP addresses for the interfaces on each of the devices. For device R0 as 9.9.9.9/24; for R1 the are 9.9.9.10/24 and 5.5.5.5/24; and for R2 it is 5.5.5.9/24. On device R1, you set an internal service interface lt-0/0/0 between routing instances and configure a peer relationship between two virtual devices. You then create a security zone called HOST, assign all interfaces to it, and configure it to allow all supported applications and protocols.


Then you configure policies and specify that all packets are permitted. You configure a virtual device routing instance Internet-VR and assign interfaces for flow-based forwarding. You enable OSPF on devices R0, R1, and R2. On Device R2, you configure the filter bypass-flow-filter with the term bypass-flow-term that contains the packet-mode action modifier. Because you have not specified any match conditions, this filter applies to all traffic that traverses the interfaces on which it is applied.

Finally, on device R1 you apply the firewall filter bypass-flow-filter to internal interfaces ge-0/0/2.0 and lt-0/0/0.0. You do not apply the filter to the interfaces associated with the Internet-VR routing instance. As a result, all traffic that traverses the LAN interfaces associated with the master routing instance uses packet-based forwarding and all traffic that traverses the Internet-VR routing instance uses flow-based forwarding.

[Figure 16 on page 155](#) shows the network topology used in this example.



Figure 16: Selective Stateless Packet-Based Services for Packet-Based Forwarding



The interface facing the private LAN does not need any security services, but the interface facing the WAN needs security. In this example, you decide to configure both packet-based and flow-based forwarding for secure and not so secure traffic by configuring two routing instances—one handling the packet-based forwarding and the other handling the flow-based forwarding.

## Configuration

### CLI Quick Configuration

To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level, and then enter **commit** from configuration mode.

```
{device R0}
set interfaces description "Connect to Master VR" ge-0/0/2 unit 0 family inet address 9.9.9.9/24
set protocols ospf area 0.0.0.0 interface ge-0/0/2.0

{device R1}
set interfaces description "Connect to R0" ge-0/0/2 unit 0 family inet address 9.9.9.10/24
set interfaces description "Connect to R2" ge-0/0/3 unit 0 family inet address 5.5.5.9/24
set interfaces lt-0/0/0 unit 0 encapsulation frame-relay dlci 100 peer-unit 1 family inet address 1.1.1.1/16
set interfaces lt-0/0/0 unit 1 encapsulation frame-relay dlci 100 peer-unit 0 family inet address 1.1.1.2/16
set security zones security-zone HOST host-inbound-traffic system-services any-service
set security zones security-zone HOST host-inbound-traffic protocols all
set security zones security-zone HOST interfaces all
set security policies default-policy permit-all
set routing-instances Internet-VR instance-type virtual-router interface lt-0/0/0.1
set routing-instances Internet-VR instance-type virtual-router interface ge-0/0/3.0
set protocols ospf area 0.0.0.0 interface ge-0/0/2.0
set protocols ospf area 0.0.0.0 interface lt-0/0/0.0
set routing-instances Internet-VR protocols ospf area 0.0.0.0 interface lt-0/0/0.1
set routing-instances Internet-VR protocols ospf area 0.0.0.0 interface ge-0/0/3.0
set firewall family inet filter bypass-flow-filter term bypass-flow-term then accept
```

```

set firewall family inet filter bypass-flow-filter term bypass-flow-term then packet-mode
set interfaces ge-0/0/2 unit 0 family inet bypass-flow-filter
set interfaces lt-0/0/0 unit 0 family inet bypass-flow-filter

{device R2}
set interfaces description "Connect to Internet-VR" ge-0/0/3 unit 0 family inet address
 5.5.5.9/24
set protocols ospf area 0.0.0.0 interface ge-0/0/3

```

### Step-by-Step Procedure

The following example requires you to navigate various levels in the configuration hierarchy. For instructions on how to do that, see *Using the CLI Editor in Configuration Mode* in the *CLI User Guide*.

To configure selective stateless packet-based services for end-to-end packet-based forwarding:

1. Configure the IP addresses for the interfaces.

```

{device R0}
[edit]
user@host# set interfaces description "Connect to Master VR" ge-0/0/2 unit 0
 family inet address 9.9.9.9/24

{device R1}
[edit]
user@host# set interfaces description "Connect to R0" ge-0/0/2 unit 0 family inet
 address 9.9.9.10/24
user@host# set interfaces description "Connect to R2" ge-0/0/3 unit 0 family inet
 address 5.5.5.5/24

{device R2}
[edit]
user@host# set interfaces description "Connect to Internet-VR" ge-0/0/3 unit 0
 family inet address 5.5.5.9/24

```

2. Set an internal service interface between routing instances.

```

{device R1}
[edit]
user@host# set interfaces lt-0/0/0 unit 0 encapsulation frame-relay dlci 100
 peer-unit 1 family inet address 1.1.1.1/16
user@host# set interfaces lt-0/0/0 unit 1 encapsulation frame-relay dlci 100
 peer-unit 0 family inet address 1.1.1.2/16

```

3. Configure security zones.

```

{device R1}
[edit]
user@host# set security zones security-zone HOST host-inbound-traffic
 system-services any-service
user@host# set security zones security-zone HOST host-inbound-traffic protocols
 all
user@host# set security zones security-zone HOST interfaces all

```

4. Configure policies.

```

{device R1}
[edit]
user@host# set security policies default-policy permit-all

```

5. Configure a virtual device routing instance.

```
{device R1}
[edit]
user@host# set routing-instances Internet-VR instance-type virtual-router interface
lt-0/0/0.1
user@host# set routing-instances Internet-VR instance-type virtual-router interface
ge-0/0/3.0
```

6. Enable OSPF on all interfaces in the network.

```
{device R0}
[edit]
user@host# set protocols ospf area 0.0.0.0 interface ge-0/0/2.0

{device R1 for Master-VR}
[edit]
user@host# set protocols ospf area 0.0.0.0 interface ge-0/0/2.0
user@host# set protocols ospf area 0.0.0.0 interface lt-0/0/0.0

{device R1 for Internet-VR}
[edit]
user@host# set routing-instances Internet-VR protocols ospf area 0.0.0.0 interface
lt-0/0/0.1
user@host# set routing-instances Internet-VR protocols ospf area 0.0.0.0 interface
ge-0/0/3.0

{device R2}
[edit]
user@host# set protocols ospf area 0.0.0.0 interface ge-0/0/3
```

7. Create a firewall filter and define a term for packet-based forwarding traffic.

```
{device R1}
[edit]
user@host# set firewall family inet filter bypass-flow-filter term bypass-flow-term
then accept
user@host# set firewall family inet filter bypass-flow-filter term bypass-flow-term
then packet-mode
```

8. Apply the firewall filter to relevant interfaces.

```
{device R1}
[edit]
user@host# set interfaces ge-0/0/2 unit 0 family inet bypass-flow-filter
user@host# set interfaces lt-0/0/0 unit 0 family inet bypass-flow-filter
```

**Results** From configuration mode, confirm your configuration by entering the **show interfaces**, **show protocols**, **show security**, **show routing-instances**, and **show firewall** commands. If the output does not display the intended configuration, repeat the configuration instructions in this example to correct it.

```
{device R0}
[edit]
user@host# show interfaces
ge-0/0/2 {
 description "Connect to Master-VR"
 unit 0 {
 family inet {
```

```
 address 9.9.9.9/24
 }
}

{device R0}
[edit]
user@host# show protocols
ospf {
 area 0.0.0.0/0 {
 interface ge-0/0/2.0;
 }
}

{device R2}
[edit]
user@host# show interfaces
ge-0/0/3 {
 description "Connect to Internet-VR"
 unit 0 {
 family inet {
 address 5.5.5.9/24;
 }
 }
}

{device R2}
[edit]
user@host# show protocols
ospf {
 area 0.0.0.0/0 {
 interface ge-0/0/3.0;
 }
}

{device R1}
[edit]
user@host# show interfaces
ge-0/0/2 {
 description "Connect to R0"
 unit 0 {
 family inet {
 filter {
 input bypass-flow-filter;
 }
 address 9.9.9.10/24;
 }
 }
}

lt-0/0/0 {
 unit 0 {
 encapsulation frame-relay;
 dlci 100;
 peer-unit 1;
 family inet {
 filter {
 input bypass-flow-filter
 }
 }
 }
}
```

```

 }
 address 1.1.1.1/16;
 }
}
unit 1{
 encapsulation frame-relay;
 dlci 100;
 peer-unit 0;
 family inet {
 address 1.1.1.2/16;
 }
}
}
{device R1}
[edit]
user@host# show protocols
ospf {
 area 0.0.0.0/0 {
 interface ge-0/0/2.0;
 interface lt-0/0/0.0;
 }
}
{device R1}
[edit]
user@host# show firewall
filter bypass-flow-filter {
 term bypass-flow-term {
 then {
 packet-mode;
 accept;
 }
 }
}
{device R1}
[edit]
user@host# show routing-instances
Internet-VR {
 instance-type virtual-router;
 interface lt-0/0/0.1;
 interface ge-0/0/3.0;
 protocols {
 ospf {
 area 0.0.0.0 {
 interface ge-0/0/3.0;
 lt-0/0/0.1;
 }
 }
 }
}
{device R1}
[edit]
user@host# show security
zones {
 security-zone HOST {
 host-inbound-traffic {

```

```
system-services {
 any-service;
}
protocols {
 all;
}
interfaces {
 all;
}
policies {
 default-policy {
 permit-all;
 }
}
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

Confirm that the configuration is working properly.

- [Verifying the Packet-Based to Flow-Based Configuration on page 160](#)
- [Verifying Session Establishment on LAN Traffic on page 160](#)
- [Verifying Session Establishment on Internet Traffic on page 161](#)

---

### Verifying the Packet-Based to Flow-Based Configuration

**Purpose** Verify that the selective stateless packet-based services are configured for packet-based to flow-based forwarding.

**Action** From configuration mode, enter the **show interfaces**, **show protocols**, **show security**, **show routing-instances**, and **show firewall** commands.

Verify that the output shows the intended configuration of the firewall filter, routing instances, interfaces, and policies.

Verify that the terms are listed in the order in which you want the packets to be tested. You can move terms within a firewall filter by using the **insert** command.

---

### Verifying Session Establishment on LAN Traffic

**Purpose** Verify that the sessions are established when traffic is transmitted on interfaces within the LAN.

**Action** To verify that sessions are established, perform the following tasks:

1. On device **R1**, from operational mode enter the **clear security flow session all** command to clear all existing security flow sessions.

2. On device **R0**, from operational mode enter the **ping** command to transmit traffic to device **Master-VR**.
3. On device **R1**, with traffic transmitting from devices **R0** through **R1**, from operational mode enter the **show security flow session** command.



**NOTE:** To verify established sessions, ensure that you enter the **show security flow session** command while the **ping** command is sending and receiving packets.

```
{device R0}
user@host> ping 1.1.1.1

PING 1.1.1.1 (1.1.1.1): 56 data bytes
64 bytes from 1.1.1.1: icmp_seq=0 ttl=63 time=2.208 ms
64 bytes from 1.1.1.1: icmp_seq=1 ttl=63 time=2.568 ms
64 bytes from 1.1.1.1: icmp_seq=2 ttl=63 time=2.573 ms
64 bytes from 1.1.1.1: icmp_seq=3 ttl=63 time=2.310 ms
64 bytes from 1.1.1.1: icmp_seq=4 ttl=63 time=1.566 ms
64 bytes from 1.1.1.1: icmp_seq=5 ttl=63 time=1.569 ms
...
```

```
{device R1}
user@host> show security flow session

0 sessions displayed
```

The output shows traffic transmitting from **R0** to **Master-VR** and no sessions are established. In this example, you applied the **bypass-flow-filter** with the **packet-mode** action modifier on interfaces **ge-0/0/0** and **lt-0/0/0.0** for your company's LAN traffic. This output verifies that the traffic between the two interfaces is correctly bypassing flow-based forwarding and hence no sessions are established.

### Verifying Session Establishment on Internet Traffic

**Purpose** Verify that sessions are established when traffic is transmitted to the Internet.

**Action** To verify that traffic to the Internet is using flow-based forwarding and sessions are established, perform the following tasks:

1. On device **R1**, from operational mode enter the **clear security flow session all** command to clear all existing security flow sessions.
2. On device **R0**, from operational mode enter the **ping** command to transmit traffic to device **R2**.
3. On device **R1**, with traffic transmitting from **R0** to **R2** through **R1**, from operational mode enter the **show security flow session** command.

```
root@host> show security flow session
Flow Sessions on FPC10 PIC1:
Total sessions: 0
```

Flow Sessions on FPC10 PIC2:  
Total sessions: 0

Flow Sessions on FPC10 PIC3:  
Total sessions: 0



**NOTE:** To verify established sessions, ensure that you enter the `show security flow session` command while the ping command is sending and receiving packets.

```
{device R0}
user@host> ping 60.0.0.1 -c 10

PING 60.0.0.1 (60.0.0.1) 56(84) bytes of data.
64 bytes from 60.0.0.1: icmp_seq=1 ttl=64 time=1.98 ms
64 bytes from 60.0.0.1: icmp_seq=2 ttl=64 time=1.94 ms
64 bytes from 60.0.0.1: icmp_seq=3 ttl=64 time=1.92 ms
64 bytes from 60.0.0.1: icmp_seq=4 ttl=64 time=1.89 ms

...

{device R1}
user@host> show security flow session

Session ID: 189900, Policy name: default-policy/2, Timeout: 2
 In: 9.9.9.9/0 --> 5.5.5.9/5924;icmp, If: lt-0/0/0.1
 Out: 5.5.5.9/5924 --> 9.9.9.9/0;icmp, If: ge-0/0/3.0

Session ID: 189901, Policy name: default-policy/2, Timeout: 2
 In: 9.9.9.9/1 --> 5.5.5.9/5924;icmp, If: lt-0/0/0.1
 Out: 5.5.5.9/5924 --> 9.9.9.9/1;icmp, If: ge-0/0/3.0

Session ID: 189902, Policy name: default-policy/2, Timeout: 4
 In: 9.9.9.9/2 --> 5.5.5.9/5924;icmp, If: lt-0/0/0.1
 Out: 5.5.5.9/5924 --> 9.9.9.9/2;icmp, If: ge-0/0/3.0

3 sessions displayed
```

The output shows traffic transmitting from devices **R0** to **R2** and established sessions. In this example, you did not apply the **bypass-flow-filter** with the **packet-mode** action modifier on routing instance **Internet-VR** for your company's Internet traffic. This output verifies that the traffic to the Internet is correctly using flow-based forwarding and hence sessions are established.

Note that sessions are established only when traffic is flowing between **lt-0/0/0.1** and **ge-0/0/3** and not when traffic is flowing between **ge-0/0/2** and **lt-0/0/0.0**.

#### Related Documentation

- [Understanding Selective Stateless Packet-Based Services on page 140](#)
- [Selective Stateless Packet-Based Services Configuration Overview on page 142](#)
- [Example: Configuring Selective Stateless Packet-Based Services for End-to-End Packet-Based Forwarding on page 144](#)



## PART 7

# Configuration Statements and Operational Commands

- Configuration Statements on page 165
- Operational Commands on page 227



## CHAPTER 12

# Configuration Statements

- Chassis Configuration Statement Hierarchy on page 167
- Security Configuration Statement Hierarchy on page 170
- [edit security flow] Hierarchy Level on page 171
- [edit security forwarding-process] Hierarchy Level on page 172
- aging on page 173
- all-tcp on page 174
- allow-dns-reply on page 174
- allow-embedded-icmp on page 175
- application-services (Security Forwarding Process) on page 176
- apply-to-half-close-state on page 177
- ethernet-switching on page 178
- destination-header on page 179
- destination-port (Security Forwarding Options) on page 180
- destination-prefix (Security Forwarding Options) on page 184
- early-ageout on page 184
- fin-invalidate-session on page 185
- force-ip-reassembly on page 185
- forwarding-process on page 186
- fru-poweron-sequence on page 187
- gre-in on page 188
- gre-out on page 189
- high-watermark on page 189
- hop-by-hop-header on page 190
- icmpv6-malformed on page 191
- inline-tap on page 191
- interface-in (Security Forwarding Options) on page 192
- interface-out (Security Forwarding Options) on page 192
- ipv4-template (Services) on page 192

- [ipv6-extension-header](#) on page 193
- [ipv6-extension-header-limit](#) on page 194
- [ipv6-malformed-header](#) on page 194
- [ipv6-template \(Services\)](#) on page 195
- [low-latency](#) on page 195
- [low-watermark](#) on page 196
- [maximize-idp-sessions](#) on page 196
- [mirror-filter \(Security Forwarding Options\)](#) on page 197
- [mode \(Security Forwarding Options\)](#) on page 198
- [no-sequence-check](#) on page 199
- [no-tcp-reset](#) on page 199
- [output \(Security Forwarding Options\)](#) on page 200
- [packet-filter](#) on page 201
- [packet-ordering-mode \(Application Services\)](#) on page 202
- [pending-sess-queue-length](#) on page 203
- [propagate-settings](#) on page 203
- [protocol \(Security Forwarding Options\)](#) on page 204
- [resource-manager](#) on page 205
- [route-change-timeout](#) on page 205
- [rst-invalidate-session](#) on page 206
- [rst-sequence-check](#) on page 206
- [sampling](#) on page 207
- [services-offload](#) on page 208
- [np-cache \(Flexible PIC Concentrator\)](#) on page 209
- [source-port \(Security Forwarding Options\)](#) on page 210
- [source-prefix \(Security Forwarding Options\)](#) on page 214
- [syn-flood-protection-mode](#) on page 214
- [tcp-initial-timeout](#) on page 215
- [tcp-mss \(Security Flow\)](#) on page 216
- [tcp-session](#) on page 217
- [time-wait-state](#) on page 218
- [traceoptions \(Security\)](#) on page 219
- [traceoptions \(Security Flow\)](#) on page 221
- [transport \(Security Log\)](#) on page 224
- [weight \(Security\)](#) on page 225

## Chassis Configuration Statement Hierarchy

Use the statements in the **chassis** configuration hierarchy to configure alarms, aggregated devices, clusters, the Routing Engine, and other chassis properties.

```
chassis {
 aggregated-devices {
 ethernet {
 device-count number;
 lacp {
 link-protection {
 non-revertive;
 }
 system-priority number;
 }
 }
 sonet {
 device-count number;
 }
 }
 alarm {
 ds1 {
 ais (ignore | red | yellow);
 ylw (ignore | red | yellow);
 }
 ethernet {
 link-down (ignore | red | yellow);
 }
 integrated-services {
 failure (ignore | red | yellow);
 }
 management-ethernet {
 link-down (ignore | red | yellow);
 }
 serial {
 cts-absent (ignore | red | yellow);
 dcd-absent (ignore | red | yellow);
 dsr-absent (ignore | red | yellow);
 loss-of-rx-clock (ignore | red | yellow);
 loss-of-tx-clock (ignore | red | yellow);
 }
 services {
 hw-down (ignore | red | yellow);
 linkdown (ignore | red | yellow);
 pic-hold-reset (ignore | red | yellow);
 pic-reset (ignore | red | yellow);
 rx-errors (ignore | red | yellow);
 sw-down (ignore | red | yellow);
 tx-errors (ignore | red | yellow);
 }
 t3 {
 ais (ignore | red | yellow);
 exz (ignore | red | yellow);
 ferf (ignore | red | yellow);
 }
 }
}
```

```

 idle (ignore | red | yellow);
 lcv (ignore | red | yellow);
 lof (ignore | red | yellow);
 los (ignore | red | yellow);
 pll (ignore | red | yellow);
 ylw (ignore | red | yellow);
 }
}
cluster {
 control-link-recovery;
 heartbeat-interval milliseconds;
 heartbeat-threshold number;
 network-management {
 cluster-master;
 }
 redundancy-group group-number {
 gratuitous-arp-count number;
 hold-down-interval number;
 interface-monitor interface-name {
 weight number;
 }
 }
 ip-monitoring {
 family {
 inet {
 ipv4-address {
 interface {
 logical-interface-name;
 secondary-ip-address ip-address;
 }
 weight number;
 }
 }
 }
 global-threshold number;
 global-weight number;
 retry-count number;
 retry-interval seconds;
 }
 node (0 | 1) {
 priority number;
 }
 preempt;
}
reth-count number;
traceoptions {
 file {
 filename;
 files number;
 match regular-expression;
 (world-readable | no-world-readable);
 size maximum-file-size;
 }
 flag flag;
 level {
 (alert | all | critical | debug | emergency | error | info | notice | warning);
 }
}

```

```

 no-remote-trace;
 }
}
config-button {
 no-clear;
 no-rescue;
}
craft-lockout;
fpc slot-number {
 offline;
 pic slot-number {
 aggregate-ports;
 framing {
 (e1 | e3 | sdh | sonet | t1 | t3);
 }
 ingress-policer-overhead bytes
 max-queues-per-interface (4 | 8);
 mlfr-uni-nni-bundles number;
 no-multi-rate;
 np-cache;
 port slot-number {
 framing (e1 | e3 | sdh | sonet | t1 | t3);
 speed (oc12-stm4 | oc3-stm1 | oc48-stm16);
 }
 q-pic-large-buffer (large-scale | small-scale);
 services-offload {
 low-latency;
 per-session-statistics;
 }
 shdsl {
 pic-mode (1-port-atm | 2-port-atm | 4-port-atm | efm);
 }
 sparse-dlcis;
 traffic-manager {
 egress-shaping-overhead number;
 ingress-shaping-overhead number;
 mode (egress-only | ingress-and-egress);
 }
 tunnel-queuing;
 }
 services-offload;
}
ioc-npc-connectivity {
 ioc slot-number {
 npc (npc-slot-number | none);
 }
}
maximum-ecmp (16 | 32 | 64);
network-services (ethernet | IP);
routing-engine {
 bios {
 no-auto-upgrade;
 }
 on-disk-failure {
 disk-failure-action (halt | reboot);
 }
}

```

```
 usb-wwan {
 port 1;
 }
}
usb {
 storage {
 disable;
 }
}
```

**Related Documentation**

- *cluster (Chassis)*
- *ip-monitoring*

---

## Security Configuration Statement Hierarchy

Use the statements in the **security** configuration hierarchy to configure actions, certificates, dynamic virtual private networks (VPNs), firewall authentication, flow, forwarding options, group VPNs, Intrusion Detection Prevention (IDP), Internet Key Exchange (IKE), Internet Protocol Security (IPsec), logging, Network Address Translation (NAT), public key infrastructure (PKI), policies, resource manager, rules, screens, secure shell known hosts, trace options, user identification, Unified Threat Management (UTM), and zones. Statements that are exclusive to the SRX Series devices running Junos OS are described in this section.

Each of the following topics lists the statements at a sub-hierarchy of the **[edit security]** hierarchy.

- *[edit security address-book] Hierarchy Level*
- *[edit security analysis] Hierarchy Level*
- *[edit security alarms] Hierarchy Level*
- *[edit security alg] Hierarchy Level*
- *[edit security analysis] Hierarchy Level*
- *[edit security application-firewall] Hierarchy Level*
- *[edit security application-tracking] Hierarchy Level*
- *[edit security certificates] Hierarchy Level*
- *[edit security datapath-debug] Hierarchy Level*
- *[edit security firewall-authentication] Hierarchy Level*
- [\[edit security flow\] Hierarchy Level on page 171](#)
- *[edit security forwarding-options] Hierarchy Level*
- [\[edit security forwarding-process\] Hierarchy Level on page 172](#)
- *[edit security gprs] Hierarchy Level*
- *[edit security idp] Hierarchy Level*



- *[edit security ike] Hierarchy Level*
- *[edit security ipsec] Hierarchy Level*
- *[edit security log] Hierarchy Level*
- *[edit security nat] Hierarchy Level*
- *[edit security pki] Hierarchy Level*
- *[edit security policies] Hierarchy Level*
- *[edit security screen] Hierarchy Level*
- *[edit security softwires] Hierarchy Level*
- *[edit security ssh-known-hosts] Hierarchy Level*
- *[edit security traceoptions] Hierarchy Level*
- *[edit security user-identification] Hierarchy Level*
- *[edit security utm] Hierarchy Level*
- *[edit security zones] Hierarchy Level*

**Related Documentation**

- *CLI User Guide*
- [CLI Explorer](#)

## **[edit security flow] Hierarchy Level**

```
security {
 flow {
 aging {
 early-ageout seconds;
 high-watermark percent;
 low-watermark percent;
 }
 allow-dns-reply;
 allow-embedded-icmp;
 ethernet-switching {
 block-non-ip-all;
 bpdu-vlan-flooding;
 bypass-non-ip-unicast;
 no-packet-flooding {
 no-trace-route;
 }
 }
 force-ip-reassembly;
 ipsec-performance-acceleration;
 load distribution {
 session-affinity ipsec;
 }
 pending-sess-queue-length (high | moderate | normal);
 route-change-timeout seconds;
 syn-flood-protection-mode (syn-cookie | syn-proxy);
 tcp-mss {
```

```
all-tcp mss value;
gre-in {
 mss value;
}
gre-out {
 mss value;
}
ipsec-vpn {
 mss value;
}
}
tcp-session {
 fin-invalidate-session;
 no-sequence-check;
 no-syn-check;
 no-syn-check-in-tunnel;
 rst-invalidate-session;
 rst-sequence-check;
 strict-syn-check;
 tcp-initial-timeout seconds;
 time-wait-state {
 (session-ageout | session-timeout seconds);
 }
}
traceoptions {
 file {
 filename;
 files number;
 match regular-expression;
 (no-world-readable | world-readable);
 size maximum-file-size;
 }
 flag flag;
 no-remote-trace;
 packet-filter filter-name {
 destination-port port-identifier;
 destination-prefix address;
 interface interface-name;
 protocol protocol-identifier;
 source-port port-identifier;
 source-prefix address;
 }
 rate-limit messages-per-second;
}
}
```

- Related Documentation**
- [Security Configuration Statement Hierarchy on page 170](#)
  - [Juniper Networks Devices Processing Overview on page 3](#)

---

## [edit security forwarding-process] Hierarchy Level

```
security {
 forwarding-process {
```

```

 application-services {
 maximize-alg-sessions;
 maximize-idp-sessions {
 inline-tap;
 weight (equal | firewall | idp);
 }
 packet-ordering-mode {
 (hardware | software);
 }
 }
}

```

- Related Documentation**
- [Security Configuration Statement Hierarchy on page 170](#)
  - [Juniper Networks Devices Processing Overview on page 3](#)

## aging

|                                 |                                                                                                                                                                                                                                         |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | aging {<br>early-ageout <i>seconds</i> ;<br>high-watermark <i>percent</i> ;<br>low-watermark <i>percent</i> ;<br>}                                                                                                                      |
| <b>Hierarchy Level</b>          | [edit security flow]                                                                                                                                                                                                                    |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                           |
| <b>Description</b>              | Direct the device to begin aggressively aging out sessions when the percentage of entries in the session table exceeds the high-watermark setting and then stops when the percentage of sessions falls below the low-watermark setting. |
| <b>Options</b>                  | The remaining statements are explained separately. See <a href="#">CLI Explorer</a> .                                                                                                                                                   |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                   |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                              |

## all-tcp

---

|                                 |                                                                                                                                                                                        |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | all-tcp mss <i>value</i> ;                                                                                                                                                             |
| <b>Hierarchy Level</b>          | [edit security flow tcp-mss]                                                                                                                                                           |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                          |
| <b>Description</b>              | Set the TCP maximum segment size (MSS) value to enable MSS override for all TCP packets in network traffic.                                                                            |
| <b>Options</b>                  | <b>mss <i>value</i></b> —TCP MSS value.<br><b>Range:</b> 64 through 65,535 bytes                                                                                                       |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                  |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">tcp-mss (Security Flow) on page 216</a></li><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul> |

## allow-dns-reply

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | allow-dns-reply;                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Hierarchy Level</b>          | [edit security flow]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Description</b>              | Allow an incoming Domain Name Service (DNS) reply packet without a matched request. By default, if an incoming UDP first-packet has dst-port 53, the device checks the DNS message packet header to verify that the query bit (QR) is 0, which denotes a query message. If the QR bit is 1, which denotes a response message, the device drops the packet, does not create a session, and increments the illegal packet flow counter for the interface. Using the <b>allow-dns-reply</b> statement directs the device to skip the check. |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                 |

## allow-embedded-icmp

---

|                                 |                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | allow-embedded-icmp;                                                                                                                                                                                                                                                                                                                              |
| <b>Hierarchy Level</b>          | [edit security flow]                                                                                                                                                                                                                                                                                                                              |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.3X48-D10.                                                                                                                                                                                                                                                                                             |
| <b>Description</b>              | Allow an embedded ICMP packet to pass through the device even when there is no session match. Once enabled, all packets encapsulated in ICMP pass through and no policy affects this behavior. This feature is useful when you have asymmetric routing in your network and you want to use traceroute and other ICMP applications on your device. |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                                          |

## application-services (Security Forwarding Process)

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre> application-services {   maximize-alg-sessions;   maximize-idp-sessions {     inline-tap;     weight (equal   firewall   idp);   }   packet-ordering-mode {     (hardware   software);   } } </pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Hierarchy Level</b>          | [edit security forwarding-process]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 9.6. Statement updated in Junos OS Release 10.4.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Description</b>              | <p>You can configure the device to switch from an integrated firewall mode to maximize IDP mode to increase the capacity of IDP processing with the <b>maximize-idp-sessions</b> option. When you maximize IDP, you are decoupling IDP processes from firewall processes, allowing the device to support the same number of firewall and IDP sessions.</p> <p>You can configure maximum ALG sessions by using the <b>maximize-alg-sessions</b> option. By default the session capacity number for RTSP, FTP, and TFTP ALG sessions is 10K per flow SPU. You must reboot the device (and its peer in chassis cluster mode) for the configuration to take effect. The <b>maximize-alg-sessions</b> option now enables you to increase defaults as follows:</p> <ul style="list-style-type: none"> <li>• RTSP, FTP, and TFTP ALG session capacity: 25K per flow SPU</li> <li>• TCP Proxy connection capacity: 40K per flow SPU</li> </ul> <div style="border: 1px solid #ccc; padding: 10px; margin-top: 10px;"> <p> <b>NOTE:</b> Flow session capacity will be reduced to half per flow SPU and that the above capacity numbers will not change on CP-flow.</p> </div> |
| <b>Options</b>                  | The remaining statements are explained separately. See <a href="#">CLI Explorer</a> .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Required Privilege Level</b> | <p>security—To view this statement in the configuration.</p> <p>security-control—To add this statement to the configuration.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">Security Configuration Statement Hierarchy on page 170</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

## apply-to-half-close-state

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | apply-to-half-close-state;                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Hierarchy Level</b>          | [edit security flow tcp-session time-wait-state]                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                                                                                                                                                                              |
| <b>Description</b>              | Configure the TCP session timeout in a half-closed state. This enables the system to apply the configured session timeout on receiving only one FIN packet (either client-to-server or server-to-client). When this statement is not configured, the default behavior takes effect—applying the configured TCP session timeout on receiving both the FIN packets. The default session timeout remains 150 seconds. |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                              |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                                                                                                           |

## ethernet-switching

---

|                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                                                                                                                                                                                                           | <pre>ethernet-switching {<br/>    block-non-ip-all;<br/>    bpdu-vlan-flooding;<br/>    bypass-non-ip-unicast;<br/>    no-packet-flooding {<br/>        no-trace-route;<br/>    }<br/>}</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Hierarchy Level</b>                                                                                                                                                                                                  | [edit security flow]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Release Information</b>                                                                                                                                                                                              | Statement introduced in Junos OS Release 9.5.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Description</b>                                                                                                                                                                                                      | Changes default Layer 2 forwarding behavior.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Options</b>                                                                                                                                                                                                          | <ul style="list-style-type: none"><li>• <b>block-non-ip-all</b>—Block all Layer 2 non-IP and non-ARP traffic, including multicast and broadcast traffic.</li><li>• <b>bpdu-vlan-flooding</b>—Set 802.1D bridge protocol data unit (BPDU) flooding based on VLAN.</li><li>• <b>bypass-non-ip-unicast</b>—Allow all Layer 2 non-IP traffic to pass through the device.</li><li>• <b>no-packet-flooding</b>—Stop IP flooding and send ARP or ICMP requests to discover the destination MAC address for a unicast packet.<ul style="list-style-type: none"><li>• <b>no-trace-route</b>—Do not send ICMP requests to discover the destination MAC address for a unicast packet. Only ARP requests are sent. This option only allows the device to discover the destination MAC address for a unicast packet if the destination IP address is in the same subnetwork as the ingress IP address.</li></ul></li></ul> |
| <div> <b>NOTE:</b> The <b>block-non-ip-all</b> and <b>bypass-non-ip-unicast</b> options cannot be configured at the same time.</div> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Required Privilege Level</b>                                                                                                                                                                                         | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Related Documentation</b>                                                                                                                                                                                            | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |



## destination-header

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>destination-header {   ILNP-nonce-option;   home-address-option;   line-identification-option;   tunnel-encapsulation-limit-option;   user-defined-option-type <i>low</i>   &lt;to <i>high</i>&gt;; }</pre>                                                                                                                                                                                                                                                                                                       |
| <b>Hierarchy Level</b>          | [edit security screen ids-option <i>screen-name</i> ip ipv6-extension-header]                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Description</b>              | Define the IPv6 destination header screen option.                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Options</b>                  | <p><b>ILNP-nonce-option</b>—Enable the Identifier-Locator Network Protocol nonce screen option.</p> <p><b>home-address-option</b>—Enable the home address screen option.</p> <p><b>line-identification-option</b>—Enable the line identification screen option.</p> <p><b>tunnel-encapsulation-limit-option</b>—Enable the tunnel encapsulation limit screen option.</p> <p><b>user-defined-header-type <i>low</i>   &lt;to <i>high</i>&gt;</b>—Define the type of header range.<br/> <b>Range:</b> 1 through 255.</p> |
| <b>Required Privilege Level</b> | <p><b>security</b>—To view this statement in the configuration.</p> <p><b>security-control</b>—To add this statement to the configuration.</p>                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">ipv6-extension-header on page 193</a></li> <li>• <a href="#">hop-by-hop-header on page 190</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                         |

## destination-port (Security Forwarding Options)

---

|                            |                                                                                                                                                                                                                                                 |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | <code>destination-port <i>port-number</i>;</code>                                                                                                                                                                                               |
| <b>Hierarchy Level</b>     | <code>[edit security forwarding-options mirror-filter <i>filter-name</i>]</code>                                                                                                                                                                |
| <b>Release Information</b> | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                           |
| <b>Description</b>         | Specify a Transmission Control Protocol (TCP) or User Datagram Protocol (UDP) destination port number to be matched for mirroring. You can specify a numeric value or one of the text synonyms listed in <a href="#">Table 17 on page 181</a> . |

Table 17: Ports Supported by Services Interfaces

| Port Name    | Corresponding Port Number |
|--------------|---------------------------|
| afs          | 1483                      |
| bgp          | 179                       |
| biff         | 512                       |
| bootpc       | 68                        |
| bootps       | 67                        |
| cmd          | 514                       |
| cvspserver   | 2401                      |
| dhcp         | 67                        |
| domain       | 53                        |
| eklogin      | 2105                      |
| ekshell      | 2106                      |
| excc         | 512                       |
| finger       | 79                        |
| ftp          | 21                        |
| ftp-data     | 20                        |
| http         | 80                        |
| https        | 443                       |
| ident        | 113                       |
| imap         | 143                       |
| kerberos-sec | 88                        |
| klogin       | 543                       |
| kpasswd      | 761                       |
| krb-prop     | 754                       |
| krbupdate    | 760                       |

Table 17: Ports Supported by Services Interfaces (*continued*)

| Port Name      | Corresponding Port Number |
|----------------|---------------------------|
| kshell         | 544                       |
| ldap           | 389                       |
| ldp            | 646                       |
| login          | 513                       |
| mobileip-agent | 434                       |
| mobilip-mn     | 435                       |
| msdp           | 639                       |
| netbios-dgm    | 138                       |
| netbios-ns     | 137                       |
| netbios-ssn    | 139                       |
| nfsd           | 2049                      |
| nnntp          | 119                       |
| ntalk          | 518                       |
| ntp            | 123                       |
| pop3           | 110                       |
| pptp           | 1723                      |
| printer        | 515                       |
| radacct        | 1813                      |
| radius         | 1812                      |
| rip            | 520                       |
| rkinit         | 2108                      |
| smtp           | 25                        |
| snmp           | 161                       |
| snmp-trap      | 162                       |

Table 17: Ports Supported by Services Interfaces (*continued*)

| Port Name | Corresponding Port Number |
|-----------|---------------------------|
| snpp      | 444                       |
| socks     | 1080                      |
| ssh       | 22                        |
| sunrpc    | 111                       |
| syslog    | 514                       |
| tacacs    | 49                        |
| tacacs-ds | 65                        |
| talk      | 517                       |
| telnet    | 23                        |
| tftp      | 69                        |
| timed     | 525                       |
| who       | 513                       |
| xmcp      | 177                       |

**Required Privilege Level** security—To view this statement in the configuration.  
security-control—To add this statement to the configuration.

**Related Documentation**

- [mirror-filter \(Security Forwarding Options\) on page 197](#)
- [show security forward-options mirror-filter on page 486](#)

## destination-prefix (Security Forwarding Options)

---

|                                 |                                                                                                                                                                                                             |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>destination-prefix <i>destination-prefix</i>;</code>                                                                                                                                                  |
| <b>Hierarchy Level</b>          | <code>[edit security forwarding-options mirror-filter <i>filter-name</i>]</code>                                                                                                                            |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                       |
| <b>Description</b>              | Specify the destination IP prefix or address to be matched for mirroring.                                                                                                                                   |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">mirror-filter (Security Forwarding Options) on page 197</a></li><li>• <a href="#">show security forward-options mirror-filter on page 486</a></li></ul> |

## early-ageout

---

|                                 |                                                                                                                                                                               |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>early-ageout <i>seconds</i>;</code>                                                                                                                                     |
| <b>Hierarchy Level</b>          | <code>[edit security flow aging]</code>                                                                                                                                       |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                 |
| <b>Description</b>              | Define the value before the device aggressively ages out a session from its session table.                                                                                    |
| <b>Options</b>                  | <b><i>seconds</i></b> —Amount of time that elapses before the device aggressively ages out a session.<br><b>Range:</b> 1 through 65,535 seconds<br><b>Default:</b> 20 seconds |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                      |

## fin-invalidate-session

---

|                                 |                                                                                                                                            |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | fin-invalidate-session;                                                                                                                    |
| <b>Hierarchy Level</b>          | [edit security flow tcp-session]                                                                                                           |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 10.4 R13.                                                                                         |
| <b>Description</b>              | Invalidates a TCP session immediately on reception of a FIN/ACK packet. New incoming SYN packets will need to establish a new TCP session. |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                 |

## force-ip-reassembly

---

|                                 |                                                                                                                                                                           |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | force-ip-reassembly;                                                                                                                                                      |
| <b>Hierarchy Level</b>          | [edit security flow]                                                                                                                                                      |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 11.2.                                                                                                                            |
| <b>Description</b>              | <p>Reassemble all IP fragmented packets before forwarding.</p> <p>This option is disabled by default. You can disable this option by deleting this flag from the CLI.</p> |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                     |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                |

## forwarding-process

---

**Syntax**

```
forwarding-process {
 application-services {
 maximize-alg-sessions;
 maximize-idp-sessions {
 inline-tap;
 weight (equal | firewall | idp);
 }
 packet-ordering-mode {
 (hardware | software);
 }
 }
}
```

**Hierarchy Level** [edit security]

**Release Information** Statement introduced in Junos OS Release 9.6.

**Description** If you are deploying IDP policies, you can tune the device to increase IDP session capacity. By using the provided commands to change the way the system allocates resources, you can achieve a higher IDP session capacity.

**Options** The remaining statements are explained separately. See [CLI Explorer](#).

**Required Privilege Level** security—To view this statement in the configuration.  
security-control—To add this statement to the configuration.

**Related Documentation**

- [Juniper Networks Devices Processing Overview on page 3](#)
- [Security Configuration Statement Hierarchy on page 170](#)



## fru-poweron-sequence

|                            |                                                                                                                               |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | <code>fru-poweron-sequence <i>fru-poweron-sequence</i>;</code>                                                                |
| <b>Hierarchy Level</b>     | [edit chassis]                                                                                                                |
| <b>Release Information</b> | Statement introduced in Junos OS Release 12.1X44-D10.                                                                         |
| <b>Description</b>         | Configure the power-on sequence for FPCs installed in the chassis.                                                            |
| <b>Options</b>             | <b>fru-poweron-sequence</b> —Power-on sequence for the FPCs in the chassis. The numbers indicate the slot number of the FPCs. |



**NOTE:** If the power-on sequence is not configured by including the `fru-poweron-sequence` statement, Junos OS uses the ascending order of the the FPC slot numbers as the sequence for powering on the FPCs.



**NOTE:** The FPC online sequence is not dependent on the FPC power-on sequence.

|                                 |                                                                                                                            |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul> |

## gre-in

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>gre-in {<br/>    mss <i>value</i>;<br/>}</pre>                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Hierarchy Level</b>          | [edit security flow tcp-mss]                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Description</b>              | Enable and specify the TCP maximum segment size (TCP MSS) for Generic Routing Encapsulation (GRE) packets that are coming out from an IPsec VPN tunnel. If the device receives a GRE-encapsulated TCP packet with the SYN bit and TCP MSS option set and the TCP MSS option specified in the packet exceeds the TCP MSS specified by the device, the device modifies the TCP MSS value accordingly. By default, a TCP MSS for GRE packets is not set. |
| <b>Options</b>                  | <p><b>mss <i>value</i></b> —TCP MSS for GRE packets. Value is optional.</p> <p><b>Range:</b> 64 through 63535 bytes</p> <p><b>Default:</b> 1320 bytes, if no value is specified</p>                                                                                                                                                                                                                                                                   |
| <b>Required Privilege Level</b> | <p>security—To view this statement in the configuration.</p> <p>security-control—To add this statement to the configuration.</p>                                                                                                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                                                                                                                                              |

## gre-out

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>gre-out {<br/>    mss <i>value</i>;<br/>}</code>                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Hierarchy Level</b>          | [edit security flow tcp-mss]                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Description</b>              | Enable and specify the TCP maximum segment size (TCP MSS) for Generic Routing Encapsulation (GRE) packets that are going into an IPsec VPN tunnel. If the device receives a GRE-encapsulated TCP packet with the SYN bit and TCP MSS option set and the TCP MSS option specified in the packet exceeds the TCP MSS specified by the device, the device modifies the TCP MSS value accordingly. By default, a TCP MSS for GRE packets is not set. |
| <b>Options</b>                  | <b>mss <i>value</i></b> —TCP MSS for GRE packets. Value is optional.<br><b>Range:</b> 64 through 65,535 bytes<br><b>Default:</b> 1320 bytes                                                                                                                                                                                                                                                                                                      |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                                                            |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                       |

## high-watermark

---

|                                 |                                                                                                                                                                         |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>high-watermark <i>percent</i>;</code>                                                                                                                             |
| <b>Hierarchy Level</b>          | [edit security flow aging]                                                                                                                                              |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                           |
| <b>Description</b>              | Sets the point at which the aggressive aging-out process begins.                                                                                                        |
| <b>Options</b>                  | <b><i>percent</i></b> —Percentage of session-table capacity at which aggressive aging-out starts.<br><b>Range:</b> 1 through 100 percent<br><b>Default:</b> 100 percent |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                   |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                              |

## hop-by-hop-header

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>hop-by-hop-header {<br/>    CALIPSO-option;<br/>    RPL-option;<br/>    SFM-DPD-option;<br/>    jumbo-payload-option;<br/>    quick-start-option;<br/>    router-alert-option;<br/>    user-defined-option-type <i>low</i>   &lt;to <i>high</i>&gt;;<br/>}</pre>                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Hierarchy Level</b>          | [edit security screen ids-option <i>screen-name</i> ip ipv6-extension-header]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Description</b>              | Define the IPv6 hop-by-hop screen option.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Options</b>                  | <p><b>CALIPSO-option</b>—Enable the Common Architecture Label IPv6 Security Option.</p> <p><b>RPL-option</b>—Enable the Routing Protocol for Low-Power and Lossy Networks screen option.</p> <p><b>SFM-DPD-option</b>—Enable the Simplified Multicast Forwarding IPv6 Duplicate Packet Detection screen option.</p> <p><b>jumbo-payload-option</b>—Enable the IPv6 jumbo payload screen option.</p> <p><b>quick-start-option</b>—Enable the IPv6 quick start screen option.</p> <p><b>router-alert-option</b>—Enable the IPv6 router alert screen option.</p> <p><b>user-defined-header-type <i>low</i>   &lt;to <i>high</i>&gt;</b>—Define the type of header range.<br/>Range: 1 through 255.</p> |
| <b>Required Privilege Level</b> | <p>security—To view this statement in the configuration.</p> <p>security-control—To add this statement to the configuration.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">ipv6-extension-header on page 193</a></li><li>• <a href="#">destination-header on page 179</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

## icmpv6-malformed

---

|                                 |                                                                                                                       |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | icmpv6-malformed;                                                                                                     |
| <b>Hierarchy Level</b>          | [edit security screen ids-option <i>screen-name</i> icmp]                                                             |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                 |
| <b>Description</b>              | Enable the ICMPv6 malformed intrusion detection service (IDS) option.                                                 |
| <b>Options</b>                  | This statement has no options.                                                                                        |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration. |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">ipv6-extension-header on page 193</a></li> </ul>                 |

## inline-tap

---

|                                 |                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | inline-tap;                                                                                                                                                                                                                                                                                                                                |
| <b>Hierarchy Level</b>          | [edit security forwarding-process application-services maximize-idp-sessions]                                                                                                                                                                                                                                                              |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                             |
| <b>Description</b>              | Enable IDP inline tap mode. The inline tap feature provides passive, inline detection of application layer threats for traffic matching security policies which have the IDP application service enabled. When a device is in inline tap mode, packets pass through firewall inspection and are also copied to the independent IDP module. |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">Security Configuration Statement Hierarchy on page 170</a></li> </ul>                                                                                                                               |

## interface-in (Security Forwarding Options)

---

|                                 |                                                                                                                                                                                                             |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | interface-in <i>interface-name</i> ;                                                                                                                                                                        |
| <b>Hierarchy Level</b>          | [edit security forwarding-options mirror-filter <i>filter-name</i> ]                                                                                                                                        |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                       |
| <b>Description</b>              | Specify the incoming logical interface to be matched for mirroring.                                                                                                                                         |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">mirror-filter (Security Forwarding Options) on page 197</a></li><li>• <a href="#">show security forward-options mirror-filter on page 486</a></li></ul> |

## interface-out (Security Forwarding Options)

---

|                                 |                                                                                                                                                                                                             |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | interface-out <i>interface-name</i> ;                                                                                                                                                                       |
| <b>Hierarchy Level</b>          | [edit security forwarding-options mirror-filter <i>filter-name</i> ]                                                                                                                                        |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                       |
| <b>Description</b>              | Specify the outgoing logical interface to be matched for mirroring.                                                                                                                                         |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">mirror-filter (Security Forwarding Options) on page 197</a></li><li>• <a href="#">show security forward-options mirror-filter on page 486</a></li></ul> |

## ipv4-template (Services)

---

|                                 |                                                                                                                       |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | ipv4-template;                                                                                                        |
| <b>Hierarchy Level</b>          | [edit services flow-monitoring version9 template <i>template-name</i> ]                                               |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 10.4.                                                                        |
| <b>Description</b>              | Specify that the flow monitoring version 9 template is used only for IPv4 records.                                    |
| <b>Required Privilege Level</b> | services—To view this statement in the configuration.<br>services-control—To add this statement to the configuration. |

## ipv6-extension-header

```
Syntax ipv6-extension-header {
 AH-header;
 ESP-header
 HIP-header;
 destination-header {
 ILNP-nonce-option;
 home-address-option;
 line-identification-option;
 tunnel-encapsulation-limit-option;
 user-defined-option-type low | <to high>;
 }
 fragment-header;
 hop-by-hop-header {
 CALIPSO-option;
 RPL-option;
 SFM-DPD-option;
 jumbo-payload-option;
 quick-start-option;
 router-alert-option;
 user-defined-option-type low | <to high>;
 }
 mobility-header;
 no-next-header;
 routing-header;
 shim6-header
 user-defined-option-type low | <to high>;
 }
```

**Hierarchy Level** [edit security screen ids-option *screen-name* ip]

**Release Information** Statement introduced in Junos OS Release 12.1X46-D10.

**Description** Define the IPv6 extension header for the intrusion detection service (IDS).

**Options** **AH-header**—Enable the IPv6 Authentication Header screen option.

**ESP-header**—Enable the IPv6 Encapsulating Security Payload header screen option.

**HIP-header**—Enable the IPv6 Host Identify Protocol header screen option.

**fragment-header**—Enable the IPv6 fragment header screen option.

**mobility-header**—Enable the IPv6 mobility header screen option.

**no-next-header**—Enable the IPv6 no next header screen option.

**routing-header**—Enable the IPv6 routing header screen option.

**shim6-header**—Enable the IPv6 shim header screen option.

**user-defined-header-type *low* | <to *high*>**—Define the type of header range.

**Range:** 0 through 255.

The remaining statements are explained separately. See [CLI Explorer](#).

|                                 |                                                              |
|---------------------------------|--------------------------------------------------------------|
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.        |
|                                 | security-control—To add this statement to the configuration. |
| <b>Related Documentation</b>    | • <a href="#">hop-by-hop-header on page 190</a>              |
|                                 | • <a href="#">destination-header on page 179</a>             |

---

## ipv6-extension-header-limit

---

|                                 |                                                                                                                                                          |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | ipv6-extension-header-limit <i>limit</i> ;                                                                                                               |
| <b>Hierarchy Level</b>          | [edit security screen ids-option <i>screen-name</i> ip]                                                                                                  |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                    |
| <b>Description</b>              | Define the IPv6 extension header number limit for screen options. The screen blocks packets that have more than the defined number of extension headers. |
| <b>Options</b>                  | <i>limit</i> —Set the number of IPv6 extension headers that can pass through the screen.<br><b>Range:</b> 0 through 32.                                  |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.                                                                                                    |
|                                 | security-control—To add this statement to the configuration.                                                                                             |
| <b>Related Documentation</b>    | • <i>Understanding IPv6 Support for Screens</i>                                                                                                          |
|                                 | • <a href="#">ipv6-extension-header on page 193</a>                                                                                                      |

---

## ipv6-malformed-header

---

|                                 |                                                                            |
|---------------------------------|----------------------------------------------------------------------------|
| <b>Syntax</b>                   | ipv6-malformed-header;                                                     |
| <b>Hierarchy Level</b>          | [edit security screen ids-option <i>screen-name</i> ip]                    |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                      |
| <b>Description</b>              | Enable the IPv6 malformed header intrusion detection service (IDS) option. |
| <b>Options</b>                  | This statement has no options.                                             |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.                      |
|                                 | security-control—To add this statement to the configuration.               |
| <b>Related Documentation</b>    | • <i>Understanding IPv6 Support for Screens</i>                            |
|                                 | • <a href="#">ipv6-extension-header on page 193</a>                        |



## ipv6-template (Services)

---

|                                 |                                                                                                                            |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | ipv6-template;                                                                                                             |
| <b>Hierarchy Level</b>          | [edit services flow-monitoring version9 template <i>template-name</i> ]                                                    |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X45-D10.                                                                      |
| <b>Description</b>              | Specify that the flow monitoring version 9 template is used only for IPv6 records.                                         |
| <b>Required Privilege Level</b> | services—To view this statement in the configuration.<br>services-control—To add this statement to the configuration.      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul> |

## low-latency

---

|                                 |                                                                                                                                                                                                   |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | low-latency                                                                                                                                                                                       |
| <b>Hierarchy Level</b>          | [edit chassis fpc <i>fpc-slot-number</i> pic <i>pic-slot-number</i> services-offload]                                                                                                             |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X44-D10.                                                                                                                                             |
| <b>Description</b>              | Enables the low-latency mode on the selected NP-IOC.                                                                                                                                              |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">Example: Configuring Low Latency on page 83</a></li> </ul> |

## low-watermark

---

|                                 |                                                                                                                                                                |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>low-watermark percent;</code>                                                                                                                            |
| <b>Hierarchy Level</b>          | [edit security flow aging]                                                                                                                                     |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                  |
| <b>Description</b>              | Set the point at which the aggressive aging-out process ends.                                                                                                  |
| <b>Options</b>                  | <b>percent</b> —Percentage of session-table capacity at which aggressive aging-out ends.<br><b>Range:</b> 0 through 100 percent<br><b>Default:</b> 100 percent |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                          |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                       |

## maximize-idp-sessions

---

|                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                                                                                                                                                                   | <pre>maximize-idp-sessions {<br/>    inline-tap;<br/>    weight (equal   firewall   idp);<br/>}</pre>                                                                                                                                                                                            |
| <b>Hierarchy Level</b>                                                                                                                                                          | [edit security forwarding-process application-services]                                                                                                                                                                                                                                          |
| <b>Release Information</b>                                                                                                                                                      | Statement introduced in Junos OS Release 9.6.                                                                                                                                                                                                                                                    |
| <b>Description</b>                                                                                                                                                              | If you are deploying IDP policies, you can tune the device to increase IDP session capacity. By using the provided commands to change the way the system allocates resources, you can achieve a higher IDP session capacity. See <code>weight</code> for information about the options provided. |
| <div> <b>NOTE:</b> The IDP session capacity is restricted to 100,000 sessions per SPU.</div> |                                                                                                                                                                                                                                                                                                  |
| <b>Options</b>                                                                                                                                                                  | The remaining statements are explained separately. See <a href="#">CLI Explorer</a> .                                                                                                                                                                                                            |
| <b>Required Privilege Level</b>                                                                                                                                                 | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                            |
| <b>Related Documentation</b>                                                                                                                                                    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li><li>• <a href="#">Security Configuration Statement Hierarchy on page 170</a></li></ul>                                                                                        |

## mirror-filter (Security Forwarding Options)

**Syntax** mirror-filter *filter-name* {  
     destination-port *port-number*;  
     destination-prefix *destination-prefix*;  
     interface-in *interface-name*;  
     interface-out *interface-name*;  
     output {  
         destination-mac *mac-address*;  
         interface *interface-name*;  
     }  
     protocol *protocol*;  
     source-port *port-number*;  
     source-prefix *source-prefix*;  
 }

**Hierarchy Level** [edit security forwarding-options]

**Release Information** Statement introduced in Junos OS Release 12.1X46-D10.

**Description** Specify match conditions for filtering packets for mirroring. You can specify the packet filter for the incoming and outgoing interfaces. A maximum of 15 filters are supported at the same time.

**Options** The remaining statements are explained separately. See [CLI Explorer](#).

**Required Privilege Level** security—To view this statement in the configuration.  
 security-control—To add this statement to the configuration.

**Related Documentation**

- [show security forward-options mirror-filter on page 486](#)
- [clear security forward-options mirror filter on page 253](#)

## mode (Security Forwarding Options)

|                            |                                                                                                                                                                                                                                                     |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | mode (drop   flow-based   packet-based);                                                                                                                                                                                                            |
| <b>Hierarchy Level</b>     | [edit security forwarding-options family inet6]                                                                                                                                                                                                     |
| <b>Release Information</b> | Support on SRX Series devices for flow-based mode for family inet6 added in Junos OS Release 10.2.                                                                                                                                                  |
| <b>Description</b>         | Specify forwarding options for IPv6 traffic.                                                                                                                                                                                                        |
| <b>Options</b>             | <ul style="list-style-type: none"> <li>• <b>drop</b>—Drop IPv6 packets. This is the default setting.</li> <li>• <b>flow-based</b>—Perform flow-based packet forwarding.</li> <li>• <b>packet-based</b>—Perform simple packet forwarding.</li> </ul> |



**NOTE:** Packet-based processing is not supported on the following SRX Series devices: SRX1400, SRX3400, SRX3600, SRX5600, and SRX5800.

If you change the forwarding option mode for IPv6, you might have to perform a reboot to initialize the configuration change. [Table 18 on page 198](#) summarizes device status upon configuration change.

**Table 18: Device Status Upon Configuration Change**

| Configuration Change       | Commit Warning | Reboot Required | Impact on Existing Traffic Before Reboot | Impact on New Traffic Before Reboot |
|----------------------------|----------------|-----------------|------------------------------------------|-------------------------------------|
| Drop to flow-based         | Yes            | Yes             | Dropped                                  | Dropped                             |
| Drop to packet-based       | No             | No              | Packet-based                             | Packet-based                        |
| Flow-based to packet-based | Yes            | Yes             | None                                     | Flow sessions created               |
| Flow-based to drop         | Yes            | Yes             | None                                     | Flow sessions created               |
| Packet-based to flow-based | Yes            | Yes             | Packet-based                             | Packet-based                        |
| Packet-based to drop       | No             | No              | Dropped                                  | Dropped                             |

**Required Privilege Level** security—To view this statement in the configuration.  
security-control—To add this statement to the configuration.

**Related Documentation** • [Juniper Networks Devices Processing Overview on page 3](#)

## no-sequence-check

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | no-sequence-check;                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Hierarchy Level</b>          | [edit security flow tcp-session]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Description</b>              | Specify that the device does not check sequence numbers in TCP segments during stateful inspection. By default, the device monitors the sequence numbers in TCP segments. The device detects the window scale specified by source and destination hosts in a session and adjusts a window for an acceptable range of sequence numbers according to their specified parameters. The device then monitors the sequence numbers in packets sent between these hosts. If the device detects a sequence number outside this range, it drops the packet. |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                         |

## no-tcp-reset

|                                 |                                                                                                                                                                           |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | no-tcp-reset {<br>drop-all-tcp;<br>drop-tcp-with-sync-only;<br>}                                                                                                          |
| <b>Hierarchy Level</b>          | [edit system internet-options]                                                                                                                                            |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 11.1.                                                                                                                            |
| <b>Description</b>              | Do not send reset RST TCP packets for packets sent to non-listening ports.                                                                                                |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>drop-all-tcp</b>—Drop all TCP packets.</li> <li>• <b>drop-tcp-with-sync-only</b>— Drop TCP packets with a SYN bit.</li> </ul> |
| <b>Required Privilege Level</b> | system—To view this statement in the configuration.<br>system-control—To add this statement to the configuration.                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                |

## output (Security Forwarding Options)

---

|                          |                                                                                                                                                                                                             |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Syntax                   | <pre>output {<br/>    destination-mac <i>mac-address</i>;<br/>    interface <i>interface-name</i>;<br/>}</pre>                                                                                              |
| Hierarchy Level          | [edit security forwarding-options mirror-filter <i>filter-name</i> ]                                                                                                                                        |
| Release Information      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                       |
| Description              | Specify the MAC address or interface for mirrored traffic.                                                                                                                                                  |
| Options                  | <p><b>destination-mac <i>mac-address</i></b>—Specify the MAC address for the mirrored traffic.</p> <p><b>interface <i>interface-name</i></b>—Specify the logical interface for the mirrored traffic.</p>    |
| Required Privilege Level | <p>security—To view this statement in the configuration.</p> <p>security-control—To add this statement to the configuration.</p>                                                                            |
| Related Documentation    | <ul style="list-style-type: none"><li>• <a href="#">mirror-filter (Security Forwarding Options) on page 197</a></li><li>• <a href="#">show security forward-options mirror-filter on page 486</a></li></ul> |

## packet-filter

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>packet-filter <i>packet-filter-name</i> {   action-profile (<i>profile-name</i>   default);   destination-port (<i>port-range</i>   <i>protocol-name</i>);   destination-prefix <i>destination-prefix</i>;   interface <i>logical-interface-name</i>;   protocol (<i>protocol-number</i>   <i>protocol-name</i>);   source-port (<i>port-range</i>   <i>protocol-name</i>);   source-prefix <i>source-prefix</i>; }</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Hierarchy Level</b>          | [edit security datapath-debug]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Release Information</b>      | <p>Command introduced in Junos OS Release 9.6 ; Support for IPv6 addresses for the <b>destination-prefix</b> and <b>source-prefix</b> options added in Junos OS Release 10.4.</p> <p>Support for IPv6 filter for the <b>interface</b> option added in Junos OS Release 10.4.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Description</b>              | Set packet filter for taking the datapath-debug action. A maximum of four filters are supported at the same time.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>action-profile</b> (<i>profile-name</i>   default)—Identify the action profile to use. You can specify the name of the action profile to use or select default action profile.</li> <li>• <b>destination-port</b> (<i>port-range</i>   <i>protocol name</i>)—Specify a destination port to match TCP/UDP destination port.</li> <li>• <b>destination-prefix</b> <i>destination-prefix</i>—Specify a destination IPv4/IPv6 address prefix.</li> <li>• <b>interface</b> <i>logical-interface-name</i>—Specify a logical interface name.</li> <li>• <b>protocol</b> (<i>protocol-number</i>   <i>protocol-name</i>)—Match IP protocol type.</li> <li>• <b>source-port</b> (<i>port-range</i>   <i>protocol-name</i>)—Match TCP/UDP source port.</li> <li>• <b>source-prefix</b> <i>source-prefix</i>—Specify a source IP address prefix.</li> </ul> |
| <b>Required Privilege Level</b> | <p>security—To view this statement in the configuration</p> <p>security-control—To add this statement to the configuration.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Security Configuration Statement Hierarchy on page 170</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

## packet-ordering-mode (Application Services)

---

|                                 |                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>packet-ordering-mode {<br/>    (hardware   software);<br/>}</pre>                                                                                                                                                                                                                                                              |
| <b>Hierarchy Level</b>          | [edit security forwarding-process application-services]                                                                                                                                                                                                                                                                             |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X45-D10.                                                                                                                                                                                                                                                                               |
| <b>Description</b>              | <p>Enables or disables the packet-ordering functionality using the Packet Ordering Engine. By default, packet-ordering functionality using the Packet Ordering Engine (hardware) is enabled.</p> <p>A system reboot is required when this feature is enabled or disabled, and a warning message is displayed during the commit.</p> |
|                                 | <div> <b>NOTE:</b> This feature is supported on SRX5800 and SRX5600 devices with next-generation SPCs.</div>                                                                                                                                       |
| <b>Options</b>                  | <p><b>hardware</b>— Enables packet-ordering functionality using the Packet Ordering Engine.</p> <p><b>software</b>— Disables packet-ordering functionality using the Packet Ordering Engine.</p>                                                                                                                                    |
| <b>Required Privilege Level</b> | <ul style="list-style-type: none"><li>• security—To view this statement in the configuration.</li><li>• security-control—To add this statement to the configuration.</li></ul>                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                            |



## pending-sess-queue-length

---

|                                 |                                                                                                                                                                                                                                                                 |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | pending-sess-queue-length (high   moderate   normal);                                                                                                                                                                                                           |
| <b>Hierarchy Level</b>          | [edit security flow]                                                                                                                                                                                                                                            |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 11.4.                                                                                                                                                                                                                  |
| <b>Description</b>              | Configure the maximum queued length per pending session.                                                                                                                                                                                                        |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>high</b>— Allow the maximum number of queued sessions.</li> <li>• <b>moderate</b>—Allow more queued sessions than the normal number.</li> <li>• <b>normal</b>—Allow the normal number of queued session.</li> </ul> |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                           |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                      |

## propagate-settings

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | propagate-settings <i>interface-name</i> ;                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Hierarchy Level</b>          | [edit system services dhcp]<br>[edit system services dhcp pool]                                                                                                                                                                                                                                                                                                                                                           |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Description</b>              | Enable or disable the propagation of TCP/IP settings received on the device acting as Dynamic Host Configuration Protocol (DHCP) client. The settings can be propagated to the server pool running on the device. Use the <b>system services dhcp</b> statement to set this feature globally. Use the <b>system services dhcp pool</b> statement to set the feature for the address pool and override the global setting. |
| <b>Options</b>                  | <b>logical-interface-name</b> —Name of the logical interface to receive TCP/IP settings from the external network for propagation to the DHCP pool running on the device.                                                                                                                                                                                                                                                 |
| <b>Required Privilege Level</b> | system—To view this statement in the configuration.<br>system-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                |

## protocol (Security Forwarding Options)

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>protocol protocol;</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Hierarchy Level</b>          | <code>[edit security forwarding-options mirror-filter <i>filter-name</i>]</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Description</b>              | Specify the networking protocol name or number to be matched for mirroring.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Options</b>                  | <p><b><i>protocol-name</i></b>—Networking protocol name or number. The following text values are supported. For a complete list of possible numeric values, see RFC 1700, <i>Assigned Numbers (for the Internet Protocol Suite)</i>.</p> <p><b>ah</b>—IP Security Authentication header</p> <p><b>egp</b>—Exterior gateway protocol</p> <p><b>esp</b>—IPsec Encapsulating Security Payload</p> <p><b>gre</b>—Generic routing encapsulation</p> <p><b>icmp</b>—Internet Control Message Protocol</p> <p><b>icmp6</b>—Internet Control Message Protocol version 6</p> <p><b>igmp</b>—Internet Group Management Protocol</p> <p><b>ipip</b>—IP over IP</p> <p><b>ospf</b>—Open Shortest Path First</p> <p><b>pim</b>—Protocol Independent Multicast</p> <p><b>rsvp</b>—Resource Reservation Protocol</p> <p><b>sctp</b>—Stream Control Transmission Protocol</p> <p><b>tcp</b>—Transmission Control Protocol</p> <p><b>udp</b>—User Datagram Protocol</p> |
| <b>Required Privilege Level</b> | <p>security—To view this statement in the configuration.</p> <p>security-control—To add this statement to the configuration.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">mirror-filter (Security Forwarding Options) on page 197</a></li><li>• <a href="#">show security forward-options mirror-filter on page 486</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

## resource-manager

---

|                                 |                                                                                                                            |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | resource-manager {<br>traceoptions {<br>flag <i>flag</i> ;<br>}<br>}                                                       |
| <b>Hierarchy Level</b>          | [edit security]                                                                                                            |
| <b>Release Information</b>      | Statement introduced before Junos OS Release 12.1.                                                                         |
| <b>Description</b>              | Configure resource manager security options.                                                                               |
| <b>Options</b>                  | The remaining statements are explained separately. See <a href="#">CLI Explorer</a> .                                      |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul> |

## route-change-timeout

---

|                                 |                                                                                                                                                                          |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | route-change-timeout <i>seconds</i> ;                                                                                                                                    |
| <b>Hierarchy Level</b>          | [edit security flow]                                                                                                                                                     |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5. Support for default value set to 6 seconds added in Junos OS Release 12.1X45-D10.                                          |
| <b>Description</b>              | Specify the session timeout when a session is rerouted but there is a reroute failure (for example, the new route uses a different egress zone from the previous route). |
| <b>Options</b>                  | <p><b><i>seconds</i></b> —Amount of time before sessions are timed out.</p> <p><b>Range:</b> 6 through 1800 seconds</p> <p><b>Default:</b> 6 seconds</p>                 |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                    |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                               |

## rst-invalidate-session

---

|                                 |                                                                                                                                                                                                                                                               |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | rst-invalidate-session;                                                                                                                                                                                                                                       |
| <b>Hierarchy Level</b>          | [edit security flow tcp-session]                                                                                                                                                                                                                              |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                 |
| <b>Description</b>              | Enable the device to mark a session for immediate termination when it receives a TCP reset (RST) message. By default, this feature is disabled and the device applies the normal session timeout interval. For TCP, the normal session timeout is 30 minutes. |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                      |

## rst-sequence-check

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | rst-sequence-check;                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Hierarchy Level</b>          | [edit security flow tcp-session]                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                              |
| <b>Description</b>              | Verify that the TCP sequence number in a TCP segment with the RST bit enabled matches the previous sequence number for a packet in that session or is the next higher number incrementally. If the sequence number does not match either of these expected numbers, the device drops the packet and sends the host a TCP ACK message with the correct sequence number. By default, this check is disabled. |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                                                                                                   |

## sampling

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>sampling {   command <i>binary-file-path</i>;   disable;   failover (alternate-media   other-routing-engine); }</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Hierarchy Level</b>          | [edit system processes]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Description</b>              | Perform packet sampling based on particular input interfaces and various fields in the packet header.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>command <i>binary-file-path</i></b>—Path to the binary process.</li> <li>• <b>disable</b>—Disable the traffic sampling control process.</li> <li>• <b>failover</b>—Configure the device to reboot if the software process fails four times within 30 seconds, and specify the software to use during the reboot. <ul style="list-style-type: none"> <li>• <b>alternate-media</b>—Configure the device to switch to backup media that contains a version of the system if a software process fails repeatedly.</li> <li>• <b>other-routing-engine</b>—Instruct the secondary Routing Engine to take mastership if a software process fails. If this statement is configured for a process, and that process fails four times within 30 seconds, then the device reboots from the secondary Routing Engine.</li> </ul> </li> </ul> |
| <b>Required Privilege Level</b> | system—To view this statement in the configuration.<br>system-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

## services-offload

---

|                                 |                                                                                                                          |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>services-offload {<br/>    low-latency;<br/>    per-session-statistics;<br/>}</pre>                                 |
| <b>Hierarchy Level</b>          | [edit chassis fpc <i>fpc-slot-number</i> pic <i>pic-slot-number</i> ]                                                    |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 11.4.                                                                           |
| <b>Description</b>              | Enables the Express Path mode (formerly known as <i>services offloading</i> ) mode on the selected network processor.    |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.    |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul> |

## np-cache (Flexible PIC Concentrator)

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | np-cache;                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Hierarchy Level</b>          | [edit chassis fpc <i>fpc-slot-number</i> ]                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 15.1X49-D10.                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Description</b>              | <p>Enable session cache table on IOC.</p> <p>Starting with Junos OS Release 15.1X49-D10, NP cache is supported on the SRx5K-MPC (IOC2), SRX5K-MPC3-100G10G (IOC3), and SRX5K-MPC3-40G10G (IOC3) for SRX5400, SRX5600, and SRX5800 devices.</p> <p>The security policy determines whether a session is for Express Path (formerly known as <i>services offloading</i>) mode on the selected Flexible PIC Concentrator (FPC).</p> |
|                                 | <p> <b>NOTE:</b> The IOC2 and the IOC3 utilize the delay sessions delete mechanism. The same sessions (sessions with the same five tuples) that are deleted and then reinstalled immediately are not cached on the IOCs.</p>                                                                                                                   |
| <b>Required Privilege Level</b> | <p>security—To view this statement in the configuration.</p> <p>security-control—To add this statement to the configuration.</p>                                                                                                                                                                                                                                                                                                |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Chassis Configuration Statement Hierarchy on page 167</a></li> <li>• <a href="#">Example: Configuring an SRX5K-MPC on an SRX5000 Line Device to Support Express Path on page 78</a></li> <li>• <a href="#">Example: Configuring SRX5K-MPC3-100G10G (IOC3) and SRX5K-MPC3-40G10G (IOC3) on an SRX5000 Line Device to Support Express Path on page 81</a></li> </ul>         |

## source-port (Security Forwarding Options)

---

|                            |                                                                                                                                                                                                                                            |
|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | source-port <i>port-number</i> ;                                                                                                                                                                                                           |
| <b>Hierarchy Level</b>     | [edit security forwarding-options mirror-filter <i>filter-name</i> ]                                                                                                                                                                       |
| <b>Release Information</b> | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                      |
| <b>Description</b>         | Specify a Transmission Control Protocol (TCP) or User Datagram Protocol (UDP) source port number to be matched for mirroring. You can specify a numeric value or one of the text synonyms listed in <a href="#">Table 19 on page 211</a> . |



Table 19: Ports Supported by Services Interfaces

| Port Name    | Corresponding Port Number |
|--------------|---------------------------|
| afs          | 1483                      |
| bgp          | 179                       |
| biff         | 512                       |
| bootpc       | 68                        |
| bootps       | 67                        |
| cmd          | 514                       |
| cvspserver   | 2401                      |
| dhcp         | 67                        |
| domain       | 53                        |
| eklogin      | 2105                      |
| ekshell      | 2106                      |
| excc         | 512                       |
| finger       | 79                        |
| ftp          | 21                        |
| ftp-data     | 20                        |
| http         | 80                        |
| https        | 443                       |
| ident        | 113                       |
| imap         | 143                       |
| kerberos-sec | 88                        |
| klogin       | 543                       |
| kpasswd      | 761                       |
| krb-prop     | 754                       |
| krbupdate    | 760                       |

Table 19: Ports Supported by Services Interfaces (*continued*)

| Port Name      | Corresponding Port Number |
|----------------|---------------------------|
| kshell         | 544                       |
| ldap           | 389                       |
| ldp            | 646                       |
| login          | 513                       |
| mobileip-agent | 434                       |
| mobilip-mn     | 435                       |
| msdp           | 639                       |
| netbios-dgm    | 138                       |
| netbios-ns     | 137                       |
| netbios-ssn    | 139                       |
| nfsd           | 2049                      |
| nnntp          | 119                       |
| ntalk          | 518                       |
| ntp            | 123                       |
| pop3           | 110                       |
| pptp           | 1723                      |
| printer        | 515                       |
| radacct        | 1813                      |
| radius         | 1812                      |
| rip            | 520                       |
| rkinit         | 2108                      |
| smtp           | 25                        |
| snmp           | 161                       |
| snmp-trap      | 162                       |

Table 19: Ports Supported by Services Interfaces (*continued*)

| Port Name | Corresponding Port Number |
|-----------|---------------------------|
| snpp      | 444                       |
| socks     | 1080                      |
| ssh       | 22                        |
| sunrpc    | 111                       |
| syslog    | 514                       |
| tacacs    | 49                        |
| tacacs-ds | 65                        |
| talk      | 517                       |
| telnet    | 23                        |
| tftp      | 69                        |
| timed     | 525                       |
| who       | 513                       |
| xmcp      | 177                       |

**Required Privilege Level** security—To view this statement in the configuration.  
security-control—To add this statement to the configuration.

**Related Documentation**

- [mirror-filter \(Security Forwarding Options\) on page 197](#)
- [show security forward-options mirror-filter on page 486](#)

## source-prefix (Security Forwarding Options)

---

|                                 |                                                                                                                                                                                                             |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>source-prefix <i>source-prefix</i>;</code>                                                                                                                                                            |
| <b>Hierarchy Level</b>          | <code>[edit security forwarding-options mirror-filter <i>filter-name</i>]</code>                                                                                                                            |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                       |
| <b>Description</b>              | Specify the source IP prefix or address to be matched for mirroring.                                                                                                                                        |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">mirror-filter (Security Forwarding Options) on page 197</a></li><li>• <a href="#">show security forward-options mirror-filter on page 486</a></li></ul> |

## syn-flood-protection-mode

---

|                                 |                                                                                                                                                                                                                                                 |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>syn-flood-protection-mode (syn-cookie   syn-proxy);</code>                                                                                                                                                                                |
| <b>Hierarchy Level</b>          | <code>[edit security flow]</code>                                                                                                                                                                                                               |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5; support for IPv6 addresses added in Junos OS Release 10.4.                                                                                                                                        |
| <b>Description</b>              | Enable SYN cookie or SYN proxy defenses against SYN attacks. SYN flood protection mode is enabled globally on the device and is activated when the configured <b>syn-flood attack-threshold value</b> is exceeded.                              |
| <b>Options</b>                  | <ul style="list-style-type: none"><li>• <b>syn-cookie</b>—Uses a cryptographic hash to generate a unique Initial Sequence Number (ISN). This is enabled by default.</li><li>• <b>syn-proxy</b>—Uses a proxy to handle the SYN attack.</li></ul> |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                           |

## tcp-initial-timeout

|                                                                                                                                                                                                                                                                                                                            |                                                                                                                                                                                                            |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                                                                                                                                                                                                                                                                                                              | tcp-initial-timeout <i>seconds</i> ;                                                                                                                                                                       |
| <b>Hierarchy Level</b>                                                                                                                                                                                                                                                                                                     | [edit security flow tcp-session]                                                                                                                                                                           |
| <b>Release Information</b>                                                                                                                                                                                                                                                                                                 | Statement introduced in Junos OS Release 8.5.                                                                                                                                                              |
| <b>Description</b>                                                                                                                                                                                                                                                                                                         | Define the length of time (in seconds) that the device keeps an initial TCP session in the session table before dropping it, or until the device receives a FIN (no more data) or RST (reset) packet.      |
| <b>Options</b>                                                                                                                                                                                                                                                                                                             | <p><b>seconds</b>—Number of seconds that the device keeps an initial TCP session in the session table before dropping it.</p> <p><b>Range:</b> 4 through 300 seconds</p> <p><b>Default:</b> 20 seconds</p> |
| <div>  <p><b>NOTE:</b> The minimum value you can configure for TCP session initialization is 4 seconds. The default value is 20 seconds; if required you can set the TCP session initialization value to less than 20 seconds.</p> </div> |                                                                                                                                                                                                            |
| <b>Required Privilege Level</b>                                                                                                                                                                                                                                                                                            | <p>security—To view this statement in the configuration.</p> <p>security-control—To add this statement to the configuration.</p>                                                                           |
| <b>Related Documentation</b>                                                                                                                                                                                                                                                                                               | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                 |

## tcp-mss (Security Flow)

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>tcp-mss {   all-tcp mss <i>value</i>;   gre-in {     mss <i>value</i>;   }   gre-out {     mss <i>value</i>;   }   ipsec-vpn {     mss <i>value</i>;   } }</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Hierarchy Level</b>          | [edit security flow]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Description</b>              | <p>Configure TCP maximum segment size (TCP MSS) for the following packet types:</p> <ul style="list-style-type: none"><li>• All TCP packets for network traffic.</li><li>• GRE packets entering the IPsec VPN tunnel.</li><li>• GRE packets exiting the IPsec VPN tunnel.</li><li>• TCP packets entering the IPsec VPN tunnel.</li></ul> <p>If all the four TCP MSS options are configured simultaneously, then the order of preference is as follows:</p> <ul style="list-style-type: none"><li>• If TCP packet enters an IPsec VPN tunnel, then an ipsec-vpn mss value has high priority over all-tcp mss value, hence ipsec-vpn mss value is set.</li><li>• If TCP packet enters GRE, then gre-in mss value overrides all-tcp mss value, hence gre-in mss value is set.</li><li>• If TCP packet exits GRE, then all-tcp mss value overrides gre-in mss value, hence all-tcp mss value is set.</li></ul> |
| <b>Options</b>                  | The remaining statements are explained separately. See <a href="#">CLI Explorer</a> .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">all-tcp on page 174</a></li><li>• <a href="#">gre-in on page 188</a></li><li>• <a href="#">gre-out on page 189</a></li><li>• <a href="#">ipsec-vpn (Security Flow)</a></li><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

## tcp-session

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre> tcp-session {   no-sequence-check;   no-syn-check;   no-syn-check-in-tunnel;   rst-invalidate-session;   rst-sequence-check;   strict-syn-check;   tcp-initial-timeout <i>seconds</i>;   time-wait-state {     (session-ageout   session-timeout <i>seconds</i>);   } } </pre>                                                                                                                                                                                                                                                |
| <b>Hierarchy Level</b>          | [edit security flow]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Description</b>              | <p>Configure TCP session attributes:</p> <ul style="list-style-type: none"> <li>• TCP sequence number checking.</li> <li>• TCP SYN bit checking.</li> <li>• Reset (RST) checking.</li> <li>• Initial TCP session timeout—The minimum value you can configure for TCP session initialization is 4 seconds. The default value is 20 seconds; if required you can set the TCP session initialization value to less than 20 seconds.</li> <li>• Strict TCP SYN checking.</li> <li>• TCP session timeout for time-wait state.</li> </ul> |
| <b>Options</b>                  | The remaining statements are explained separately. See <a href="#">CLI Explorer</a> .                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Required Privilege Level</b> | <p>security—To view this statement in the configuration.</p> <p>security-control—To add this statement to the configuration.</p>                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                          |

## time-wait-state

---

|                                 |                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>time-wait-state {<br/>    (session-ageout   session-timeout <i>seconds</i>);<br/>}</pre>                                                                                                                                                                                                                                         |
| <b>Hierarchy Level</b>          | [edit security flow tcp-session]                                                                                                                                                                                                                                                                                                      |
| <b>Release Information</b>      | Statement introduced in Junos OS Release 11.1.                                                                                                                                                                                                                                                                                        |
| <b>Description</b>              | Defines the length of time (in seconds) that the device keeps the defined TCP session in the session table. The default is 150 seconds.                                                                                                                                                                                               |
| <b>Options</b>                  | <ul style="list-style-type: none"><li>• <b>session-ageout</b>—Set a TCP session to age out, using the service based timeout value.</li><li>• <b>session-timeout <i>seconds</i></b>—Set the session timeout value allowed before the device ages out a session from its session table.<br/><br/>Range: 2 through 600 seconds</li></ul> |
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                                                                                                                                                 |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul>                                                                                                                                                                                                              |



## traceoptions (Security)

|                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | <pre> traceoptions {   file {     filename;     files number;     match regular-expression;     size maximum-file-size;     (world-readable   no-world-readable);   }   flag flag;   no-remote-trace;   rate-limit messages-per-second; } </pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Hierarchy Level</b>     | [edit security]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Release Information</b> | Statement modified in Junos OS Release 8.5.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Description</b>         | Configure security tracing options.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Options</b>             | <ul style="list-style-type: none"> <li><b>file</b>—Configure the trace file options. <ul style="list-style-type: none"> <li><b>filename</b>—Name of the file to receive the output of the tracing operation. Enclose the name within quotation marks. All files are placed in the directory <b>/var/log</b>. By default, the name of the file is the name of the process being traced.</li> <li><b>files number</b>—Maximum number of trace files. When a trace file named <b>trace-file</b> reaches its maximum size, it is renamed to <b>trace-file.0</b>, then <b>trace-file.1</b>, and so on, until the maximum number of trace files is reached. The oldest archived file is overwritten.</li> </ul> <p>If you specify a maximum number of files, you also must specify a maximum file size with the <b>size</b> option and a filename.</p> <p>Range: 2 through 1000 files</p> <p>Default: 10 files</p> </li> <li><b>match regular-expression</b>—Refine the output to include lines that contain the regular expression.</li> <li><b>size maximum-file-size</b>—Maximum size of each trace file, in kilobytes (KB), megabytes (MB), or gigabytes (GB). When a trace file named <b>trace-file</b> reaches this size, it is renamed <b>trace-file.0</b>. When the <b>trace-file</b> again reaches its maximum size, <b>trace-file.0</b> is renamed <b>trace-file.1</b> and <b>trace-file</b> is renamed <b>trace-file.0</b>. This renaming scheme continues until the maximum number of trace files is reached. Then the oldest trace file is overwritten.</li> </ul> <p>If you specify a maximum file size, you also must specify a maximum number of trace files with the <b>files</b> option and a filename.</p> <p>Syntax: <b>x K</b> to specify KB, <b>x m</b> to specify MB, or <b>x g</b> to specify GB</p> <p>Range: 10 KB through 1 GB</p> |

Default: 128 KB

- **world-readable | no-world-readable**—By default, log files can be accessed only by the user who configures the tracing operation. The **world-readable** option enables any user to read the file. To explicitly set the default behavior, use the **no-world-readable** option.
- **flag**—Trace operation to perform. To specify more than one trace operation, include multiple **flag** statements.
  - **all**—Trace all security events
  - **compilation**—Trace security compilation events
  - **configuration**—Trace security configuration events
  - **routing-socket**—Trace routing socket events
- **no-remote-trace**—Set remote tracing as disabled.
- **rate-limit *messages-per-second***—Limit the incoming rate of trace messages.

|                                 |                                                           |
|---------------------------------|-----------------------------------------------------------|
| <b>Required Privilege Level</b> | trace—To view this statement in the configuration.        |
|                                 | trace-control—To add this statement to the configuration. |

|                              |                                                                                                                          |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| <b>Related Documentation</b> | <ul style="list-style-type: none"><li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li></ul> |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------|

## traceoptions (Security Flow)

|                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Syntax              | <pre> traceoptions {   file {     filename;     files number;     match regular-expression;     size maximum-file-size;     (world-readable   no-world-readable);   }   flag flag;   no-remote-trace;   packet-filter filter-name {     destination-port port-identifier;     destination-prefix address;     interface interface-name;     protocol protocol-identifier;     source-port port-identifier;     source-prefix address;   }   rate-limit messages-per-second;   trace-level (brief   detail   error); } </pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Hierarchy Level     | [edit security flow]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Release Information | Statement introduced in Junos OS Release 8.5. Statement updated in Junos OS Release 12.1X46-D10 with the <b>trace-level</b> option and additional flags.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Description         | Configure flow tracing options.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Options             | <p><b>file</b>—Configure the trace file options.</p> <p><b>filename</b>—Name of the file to receive the output of the tracing operation. Enclose the name within quotation marks. All files are placed in the directory <b>/var/log</b>. By default, the name of the file is the name of the process being traced.</p> <p><b>files number</b>—Maximum number of trace files. When a trace file named <b>trace-file</b> reaches its maximum size, it is renamed to <b>trace-file.0</b>, then <b>trace-file.1</b>, and so on, until the maximum number of trace files is reached. The oldest archived file is overwritten.</p> <p>If you specify a maximum number of files, you also must specify a maximum file size with the <b>size</b> option and a filename.</p> <p><b>Range:</b> 2 through 1000 files</p> <p><b>Default:</b> 10 files</p> <p><b>match regular-expression</b>—Refine the output to include lines that contain the regular expression.</p> <p><b>size maximum-file-size</b>—Maximum size of each trace file, in kilobytes (KB), megabytes (MB), or gigabytes (GB). When a trace file named <b>trace-file</b> reaches this size, it is renamed <b>trace-file.0</b>. When the <b>trace-file</b> again reaches its maximum size,</p> |

***trace-file.0*** is renamed ***trace-file.1*** and ***trace-file*** is renamed ***trace-file.0***. This renaming scheme continues until the maximum number of trace files is reached. Then the oldest trace file is overwritten.

If you specify a maximum file size, you also must specify a maximum number of trace files with the **files** option and a filename.

Syntax: **x k** to specify KB, **x m** to specify MB, or **x g** to specify GB

**Range:** 0 KB through 1 GB

**Default:** 128 KB

**world-readable | no-world-readable**—By default, log files can be accessed only by the user who configures the tracing operation. The **world-readable** option enables any user to read the file. To explicitly set the default behavior, use the **no-world-readable** option.

**flag**—Trace operation to perform. To specify more than one trace operation, include multiple **flag** statements.

**all**—Trace with all flags enabled

**basic-datapath**—Trace basic packet flow activity

**fragmentation**—Trace IP fragmentation and reassembly events

**high-availability**—Trace flow high-availability information

**host-traffic**—Trace flow host traffic information

**multicast**—Trace multicast flow information

**route**—Trace route lookup information

**session**—Trace session creation and deletion events

**session-scan**—Trace session scan information

**tcp-basic**—Trace TCP packet flow information

**tunnel**—Trace tunnel information

**no-remote-trace**—Set remote tracing as disabled.

**packet-filter *filter-name***—Packet filter to enable during the tracing operation. Configure the filtering options.

**destination-port *port-identifier***—Match TCP/UDP destination port

**destination-prefix *address***—Destination IP address prefix

**interface *interface-name***—Logical interface

**protocol *protocol-identifier***—Match IP protocol type

**source-port *port-identifier***—Match TCP/UDP source port

**source-prefix *address***—Source IP address prefix

**rate-limit *messages-per-second***—Limit the incoming rate of trace messages.

**trace-level**—Set the level for trace logging. This option is available only when the flag is set.

**brief**—Trace key flow information, such as message types sent between SPU and central point, policy match, and packet drop reasons.

**detail**—Trace extensive flow information, such as detailed information about sessions and fragments. Detail is the default level.

**error**—Trace error information, such as system failure, unknown message type, and packet drop.

**Required Privilege Level**    trace—To view this statement in the configuration.  
                                  trace-control—To add this statement to the configuration.

**Related Documentation**    • [Juniper Networks Devices Processing Overview on page 3](#)

---

## transport (Security Log)

---

**Syntax**    transport {  
              protocol (udp | tcp | tls);  
              tls-profile *tls-profile-name*;  
              tcp-connections *tcp-connections*;  
              }

**Hierarchy Level**    [edit security log]

**Release Information**    Statement introduced in Junos OS Release 12.1X46-D25.

**Description**    Configure security log transport options.

**Options**    **protocol**—Specify the type of transport protocol to be used to log the data.

- **UDP**—Set the transport protocol to UDP.
- **TCP**—Set the transport protocol to TCP.
- **TLS**—Set the transport protocol to TLS.

**Default:** UDP.

**tls-profile *tls-profile-name***—Specify the TLS profile name.

**tcp-connections *tcp-connections***—Specify the number of TCP connections per SPU.

**Range:** 1 through 5.

**Default:** 1.

**Required Privilege Level**    security—To view this statement in the configuration.  
                                  security-control—To add this statement to the configuration.

**Related Documentation**    • *Understanding AppTrack*

## weight (Security)

|                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | weight (equal   firewall   idp);                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Hierarchy Level</b>     | [edit security forwarding-process application-services maximize-idp-sessions]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Release Information</b> | Statement introduced in Junos OS Release 9.6.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Description</b>         | <p>If you are deploying IDP policies, you can tune the device to increase IDP session capacity. By using the provided commands to change the way the system allocates resources, you can achieve a higher IDP session capacity.</p> <p>Devices ship with an implicit default session capacity setting. This default value gives more weight to firewall sessions. You can manually override the default by using the <b>maximize-idp-sessions</b> command. The command allows you to choose between these weight values: <b>equal</b>, <b>firewall</b>, and <b>idp</b>. The following table displays the available session capacity weight and approximate throughput for each.</p> |

**Table 20: Session Capacity and Resulting Throughput**

| Weight Value | Firewall Capacity | IDP Capacity | Firewall Throughput | IDP Throughput |
|--------------|-------------------|--------------|---------------------|----------------|
| Default      | 1,000,000         | 256,000      | 10 Gbps             | 2.4 Gbps       |
| equal        | 1,000,000         | 1,000,000    | 8.5 Gbps            | 2 Gbps         |
| firewall     | 1,000,000         | 1,000,000    | 10 Gbps             | 2.4 Gbps       |
| idp          | 1,000,000         | 1,000,000    | 5.5 Gbps            | 1.4 Gbps       |

|                                 |                                                                                                                                                                                                              |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Required Privilege Level</b> | security—To view this statement in the configuration.<br>security-control—To add this statement to the configuration.                                                                                        |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">Security Configuration Statement Hierarchy on page 170</a></li> </ul> |





## CHAPTER 13

# Operational Commands

- clear firewall
- clear monitor security flow filter
- clear security flow ip-action
- clear security flow session all
- clear security flow session application
- clear security flow session destination-port
- clear security flow session family
- clear security flow session interface
- clear security flow session protocol
- clear security flow session resource-manager
- clear security flow session services-offload
- clear security flow session session-identifier
- clear security flow session source-port
- clear security flow session source-prefix
- clear security forward-options mirror filter
- monitor security flow file
- monitor security flow filter
- monitor security flow start
- monitor security flow stop
- show chassis environment (Security)
- show chassis fpc (View)
- show chassis hardware (View)
- show chassis pic (Security)
- show chassis power
- show chassis power sequence
- show firewall (View)
- show interfaces (View Aggregated Ethernet)
- show interfaces (SRX Series)

- `show interfaces diagnostics optics`
- `show interfaces flow-statistics`
- `show interfaces statistics (View)`
- `show interfaces swfabx`
- `show monitor security flow`
- `show security flow cp-session`
- `show security flow cp-session destination-port`
- `show security flow cp-session destination-prefix`
- `show security flow cp-session family`
- `show security flow cp-session protocol`
- `show security flow cp-session source-port`
- `show security flow cp-session source-prefix`
- `show security flow gate`
- `show security flow ip-action`
- `show security flow gate brief node`
- `show security flow gate destination-port`
- `show security flow gate destination-prefix`
- `show security flow gate protocol`
- `show security flow gate summary node`
- `show security flow session`
- `show security flow session brief node`
- `show security flow session destination-port`
- `show security flow session destination-prefix`
- `show security flow session extensive node`
- `show security flow session family`
- `show security flow session interface`
- `show security flow session nat`
- `show security flow session policy-id`
- `show security flow session protocol`
- `show security flow session resource-manager`
- `show security flow session services-offload`
- `show security flow session session-identifier`
- `show security flow session source-port`
- `show security flow session source-prefix`
- `show security flow session summary family`
- `show security flow session summary node`
- `show security flow session summary services-offload`

- `show security flow session tunnel`
- `show security flow statistics`
- `show security flow status`
- `show security forward-options mirror-filter`
- `show security monitoring`
- `show security policies`
- `show security policies hit-count`
- `show security resource-manager group active`
- `show security resource-manager resource active`
- `show security resource-manager settings`
- `show security resource-manager summary`
- `show security screen ids-option`
- `show security screen statistics`
- `show security softwires`
- `show security zones`
- `show security zones type`

## clear firewall

---

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Syntax                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | <code>clear firewall</code><br><code>&lt;all&gt;</code><br><code>&lt;counter <i>counter-name</i>&gt;</code><br><code>&lt;filter <i>filter-name</i>&gt;</code>                                                                                                                                                                                     |
| Release Information                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Command introduced in Junos OS Release 10.0.                                                                                                                                                                                                                                                                                                      |
| Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Clear statistics about configured firewall filters.                                                                                                                                                                                                                                                                                               |
| <div> <b>NOTE:</b> The <code>clear firewall</code> command cannot be used to clear the Routing Engine filter counters on a backup Routing Engine that is enabled for GRES.</div>                                                                                                                                                                                                                        |                                                                                                                                                                                                                                                                                                                                                   |
| <p>If you clear statistics for firewall filters that are applied to Trio-based DPCs and that also use the <b>prefix-action</b> action on matched packets, wait at least 5 seconds before you enter the <code>show firewall prefix-action-stats</code> command. A 5-second pause between issuing the <code>clear firewall</code> and <code>show firewall prefix-action-stats</code> commands avoids a possible timeout of the <code>show firewall prefix-action-stats</code> command.</p> |                                                                                                                                                                                                                                                                                                                                                   |
| Options                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <p><b>all</b>—Clear the packet and byte counts for all filters.</p> <p><b>counter <i>counter-name</i></b>—Clear the packet and byte counts for a filter counter that has been configured with the counter firewall filter action.</p> <p><b>filter <i>filter-name</i></b>—Clear the packet and byte counts for the specified firewall filter.</p> |
| Required Privilege Level                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | clear                                                                                                                                                                                                                                                                                                                                             |
| Related Documentation                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <ul style="list-style-type: none"><li>• <a href="#">show firewall (View) on page 308</a></li></ul>                                                                                                                                                                                                                                                |
| List of Sample Output                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <a href="#">clear firewall all on page 230</a>                                                                                                                                                                                                                                                                                                    |
| Output Fields                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                                                                                                             |

### Sample Output

clear firewall all

```
user@host> clear firewall all
```

## clear monitor security flow filter

|                                 |                                                                                                                                                                                                                                                                   |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear monitor security flow filter < <i>filter-name</i> >                                                                                                                                                                                                         |
| <b>Release Information</b>      | Command introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                               |
| <b>Description</b>              | Specify the security flow filters to be deleted. Once deleted, the filters are removed from the Packet Forwarding Engine and the Routing Engine. .                                                                                                                |
|                                 | <div>  <p><b>NOTE:</b> Specifying the filter name is optional. If no filter is specified, all filters are deleted.</p> </div>                                                    |
| <b>Options</b>                  | This command has no options.                                                                                                                                                                                                                                      |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Monitoring Security Flow Sessions Overview on page 117</a></li> <li>• <a href="#">monitor security flow start on page 258</a></li> <li>• <a href="#">monitor security flow filter on page 256</a></li> </ul> |
| <b>Output Fields</b>            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                             |

## Sample Output

## clear security flow ip-action

---

**Syntax** `clear security flow ip-action [filter]`

**Release Information** Command introduced in Junos OS Release 10.4. Logical systems option introduced in Junos OS Release 11.2.

**Description** Clear IP-action entries, based on filtered options, for IP sessions running on the device.

**Options** *filter*—Filter the display based on the specified criteria.

The following filters display those sessions that match the criteria specified by the filter. Refer to the sample output for filtered output examples.

**all** | [*filter*]  
—All active sessions on the device.

**destination-port** *destination-port*  
—Destination port number of the traffic. Range is 1 through 65,535.

**destination-prefix** *destination-prefix*  
—Destination IP prefix or address.

**family** (*inet* | *inet6*) [*filter*]  
—IPv4 traffic or IPv6-NATPT traffic and filtered options.

**logical-system** *logical-system-name* | **all** [*filter*]  
—Specified logical system or all logical systems.

**protocol** *protocol-name* | *protocol-number* [*filter*]  
—Protocol name or number and filtered options.

- **ah** or 51
- **egp** or 8
- **esp** or 50
- **gre** or 47
- **icmp** or 1
- **icmp6** or 58
- **igmp** or 2
- **ipip** or 4
- **ospf** or 89
- **pim** or 103
- **rsvp** or 46
- **sctp** or 132
- **tcp** or 6
- **udp** or 17

**root-logical-system** [*filter*]  
—Default logical system information and filtered options.

**source-port** *source-port*  
—Source port number of the traffic. Range is 1 through 65,535.

**source-prefix** *source-prefix*  
—Source IP prefix or address of the traffic.

|                          |                                                                                                                                                                                                                                                                                                  |
|--------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Required Privilege Level | clear                                                                                                                                                                                                                                                                                            |
| Related Documentation    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow ip-action on page 370</a></li> </ul>                                                                                                                                                                                     |
| List of Sample Output    | <a href="#">clear security flow ip-action all on page 233</a><br><a href="#">clear security flow ip-action destination-prefix on page 233</a><br><a href="#">clear security flow ip-action family inet on page 233</a><br><a href="#">clear security flow ip-action protocol udp on page 233</a> |
| Output Fields            | When you enter this command, the system responds with the status of your request.                                                                                                                                                                                                                |

## Sample Output

### clear security flow ip-action all

```
user@host>clear security flow ip-action all
1008 ip-action entries cleared
```

### clear security flow ip-action destination-prefix

```
user@host>clear security flow ip-action destination-prefix 5.0.0.0/8
87 ip-action entries cleared
```

### clear security flow ip-action family inet

```
user@host>clear security flow ip-action family inet
2479 ip-action entries cleared
```

### clear security flow ip-action protocol udp

```
user@host>clear security flow ip-action protocol udp
270 ip-action entries cleared
```

## clear security flow session all

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security flow session all<br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5 ; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Description</b>              | Clear all currently active security sessions on the device.                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Options</b>                  | <ul style="list-style-type: none"><li>• <b>all</b>—Clear information about all active sessions.</li><li>• <b>node</b>—(Optional) For chassis cluster configurations, clear all security sessions on a specific node (device) in the cluster.<ul style="list-style-type: none"><li>• <i>node-id</i> —Identification number of the node. It can be 0 or 1.</li><li>• <b>all</b> —Clear all nodes.</li><li>• <b>local</b> —Clear the local node.</li><li>• <b>primary</b>—Clear the primary node.</li></ul></li></ul> |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">show security flow session on page 398</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>List of Sample Output</b>    | <a href="#">clear security flow session all on page 234</a><br><a href="#">clear security flow session all node 0 on page 234</a>                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Output Fields</b>            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                                                                                                                                                                                                                                                                              |

### Sample Output

#### clear security flow session all

```
user@host> clear security flow session all
node0:

1 active sessions cleared
node1:

0 active sessions cleared
```

### Sample Output

#### clear security flow session all node 0

```
user@host> clear security flow session all node 0
node0:

0 active sessions cleared
```



## clear security flow session application

|                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | clear security flow session application<br><i>application-name</i><br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Release Information</b> | Command introduced in Junos OS Release 8.5. The <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Description</b>         | Clear currently active sessions for application types or application sets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Options</b>             | <ul style="list-style-type: none"> <li>• <b><i>application-name</i></b> —Name of the specified application type or application set. <ul style="list-style-type: none"> <li>• <b>dns</b>—Domain Name System</li> <li>• <b>ftp</b>—File Transfer Protocol</li> <li>• <b>ignore</b>—Ignore application type</li> <li>• <b>mgcp-ca</b>—Media Gateway Control Protocol with Call Agent</li> <li>• <b>mgcp-ua</b>—MGCP with User Agent</li> <li>• <b>ms-rpc</b>—Microsoft RPC</li> <li>• <b>pptp</b>—Point-to-Point Tunneling Protocol</li> <li>• <b>q931</b>—ISDN connection control protocol</li> <li>• <b>ras</b>—RAS</li> <li>• <b>realaudio</b>—RealAudio</li> <li>• <b>rsh</b>—UNIX remote shell services</li> <li>• <b>rtsp</b>—Real-Time Streaming Protocol</li> <li>• <b>sccp</b>—Skinny Client Control Protocol</li> <li>• <b>sip</b>—Session Initiation Protocol</li> <li>• <b>sqlnet-v2</b>—Oracle SQLNET</li> <li>• <b>sun-rpc</b>—Sun Microsystems RPC</li> <li>• <b>talk</b>—TALK program</li> <li>• <b>tftp</b>—Trivial File Transfer Protocol</li> </ul> </li> <li>• <b>node</b>—(Optional) For chassis cluster configurations, clear sessions for applications on a specific node (device) in the cluster. <ul style="list-style-type: none"> <li>• <b><i>node-id</i></b> —Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b> —Clear all nodes.</li> </ul> </li> </ul> |

- **local**—Clear the local node.
- **primary**—Clear the primary node.

|                          |                                                                                                                                                           |
|--------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Required Privilege Level | clear                                                                                                                                                     |
| Related Documentation    | <ul style="list-style-type: none"><li>• <i>show security flow session application</i></li></ul>                                                           |
| List of Sample Output    | <a href="#">clear security flow session application dns on page 236</a><br><a href="#">clear security flow session application dns node 0 on page 236</a> |
| Output Fields            | When you enter this command, you are provided feedback on the status of your request.                                                                     |

## Sample Output

### clear security flow session application dns

```
user@host> clear security flow session application dns
node0:

0 active sessions cleared
node1:

0 active sessions cleared
```

## Sample Output

### clear security flow session application dns node 0

```
user@host> clear security flow session application dns node 0
node0:

0 active sessions cleared
```

## clear security flow session destination-port

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security flow session destination-port<br><i>destination-port-number</i><br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5 ; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Description</b>              | Clear each session that uses the specified destination port                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b><i>destination-port-number</i></b> —Number of the destination port.</li> <li>• <b>node</b>—(Optional) For chassis cluster configurations, clear security sessions on the port on a specific node (device) in the cluster. <ul style="list-style-type: none"> <li>• <b><i>node-id</i></b> —Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b> —Clear all nodes.</li> <li>• <b>local</b> —Clear the local node.</li> <li>• <b>primary</b>—Clear the primary node.</li> </ul> </li> </ul> |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow session destination-port on page 408</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>List of Sample Output</b>    | <a href="#">clear security flow session destination-port 1 on page 237</a><br><a href="#">clear security flow session destination-port 1 node 0 on page 237</a>                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Output Fields</b>            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

### Sample Output

#### clear security flow session destination-port 1

```

user@host> clear security flow session destination-port 1
node0:

0 active sessions cleared
node1:

0 active sessions cleared

```

### Sample Output

#### clear security flow session destination-port 1 node 0

```

user@host> clear security flow session destination-port 1 node 0
node0:

0 active sessions cleared

```



## clear security flow session family

|                                 |                                                                                                                                             |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security flow session family (inet   inet6)                                                                                           |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                |
| <b>Description</b>              | Clear sessions that match the specified protocol family.                                                                                    |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>inet</b>—Clear IPv4 sessions.</li> <li>• <b>inet6</b>—Clear IPv6 sessions.</li> </ul>           |
| <b>Required Privilege Level</b> | clear                                                                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow session family on page 422</a></li> </ul>                           |
| <b>List of Sample Output</b>    | <a href="#">clear security flow session family inet on page 239</a><br><a href="#">clear security flow session family inet6 on page 239</a> |
| <b>Output Fields</b>            | When you enter this command, you are provided feedback on the status of your request.                                                       |

## Sample Output

### clear security flow session family inet

```
user@host> clear security flow session family inet
1 active sessions cleared
```

### clear security flow session family inet6

```
user@host> clear security flow session family inet6
1 active sessions cleared
```

## clear security flow session interface

---

|                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Syntax                   | clear security flow session interface<br><i>interface-name</i><br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Release Information      | Command introduced in Junos OS Release 8.5; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Description              | Clear sessions that use the specified interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Options                  | <ul style="list-style-type: none"><li>• <b>interface-name</b> —Name of a specific incoming or outgoing interface.</li><li>• <b>node</b>—(Optional) For chassis cluster configurations, clear security sessions on the interface on a specific node (device) in the cluster.<ul style="list-style-type: none"><li>• <b>node-id</b> —Identification number of the node. It can be 0 or 1.</li><li>• <b>all</b> —Clear all nodes.</li><li>• <b>local</b> —Clear the local node.</li><li>• <b>primary</b>—Clear the primary node.</li></ul></li></ul> |
| Required Privilege Level | clear                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Related Documentation    | <ul style="list-style-type: none"><li>• <a href="#">show security flow session interface on page 427</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                |
| List of Sample Output    | <a href="#">clear security flow session interface ge-0/0/0.0 on page 240</a><br><a href="#">clear security flow session interface ge-0/0/0.0 node 0 on page 240</a>                                                                                                                                                                                                                                                                                                                                                                               |
| Output Fields            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

### Sample Output

#### clear security flow session interface ge-0/0/0.0

```
user@host> clear security flow session interface ge-0/0/0.0
node0:

0 active sessions cleared
node1:

0 active sessions cleared
```

### Sample Output

#### clear security flow session interface ge-0/0/0.0 node 0

```
user@host> clear security flow session interface ge-0/0/0.0 node 0
node0:

0 active sessions cleared
```



## clear security flow session protocol

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security flow session protocol <i>protocol-name</i>   <i>protocol-number</i><br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5 ; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Description</b>              | Clear each session that uses the specified IP protocol.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Options</b>                  | <ul style="list-style-type: none"><li>• <b><i>protocol-name</i></b> — (Optional) Networking protocol name. The following text values are supported.<ul style="list-style-type: none"><li>• <b>ah</b>—IP Security Authentication Header</li><li>• <b>egp</b>—Exterior gateway protocol</li><li>• <b>esp</b>—IPsec Encapsulating Security Payload</li><li>• <b>gre</b>—Generic routing encapsulation</li><li>• <b>icmp</b>—Internet Control Message Protocol</li><li>• <b>igmp</b>—Internet Group Management Protocol</li><li>• <b>ipip</b>—IP over IP</li><li>• <b>ospf</b>—Open Shortest Path First</li><li>• <b>pim</b>—Protocol Independent Multicast</li><li>• <b>rsvp</b>—Resource Reservation Protocol</li><li>• <b>sctp</b>—Stream Control Transmission Protocol</li><li>• <b>tcp</b>—Transmission Control Protocol</li><li>• <b>udp</b>—User Datagram Protocol</li></ul></li><li>• <b><i>protocol-number</i></b> —(Optional) Numeric protocol value. For a complete list of possible numeric values, see RFC 1700, <i>Assigned Numbers (for the Internet Protocol Suite)</i>.<br/><b>Range:</b> 0 through 255</li><li>• <b>node</b>—(Optional) For chassis cluster configurations, clear security on a specific node (device) in the cluster for the user with this identification number.<ul style="list-style-type: none"><li>• <b><i>node-id</i></b> —Identification number of the node. It can be 0 or 1.</li><li>• <b>all</b> —Clear all nodes.</li><li>• <b>local</b> —Clear the local node.</li><li>• <b>primary</b>—Clear the primary node.</li></ul></li></ul> |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |



|                       |                                                                                                                                            |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| Related Documentation | <ul style="list-style-type: none"><li>• <a href="#">show security flow session protocol on page 437</a></li></ul>                          |
| List of Sample Output | <a href="#">clear security flow session protocol pim on page 243</a><br><a href="#">clear security flow session protocol 0 on page 243</a> |
| Output Fields         | When you enter this command, you are provided feedback on the status of your request.                                                      |

## Sample Output

### clear security flow session protocol pim

```
user@host> clear security flow session protocol pim
node0:

0 active sessions cleared
node1:

0 active sessions cleared
```

## Sample Output

### clear security flow session protocol 0

```
user@host> clear security flow session protocol 0
node0:

0 active sessions cleared
node1:

0 active sessions cleared
```

## clear security flow session resource-manager

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security flow session resource-manager<br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                 |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                    |
| <b>Description</b>              | Clear resource-manager sessions.                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Options</b>                  | <ul style="list-style-type: none"><li>• <b>node</b>—(Optional) For chassis cluster configurations, clear the resource manager sessions on a specific node (device) in the cluster.</li><li>• <i>node-id</i> —Identification number of the node. It can be 0 or 1.</li><li>• <b>all</b> —Clear all nodes.</li><li>• <b>local</b> —Clear the local node.</li><li>• <b>primary</b>—Clear the primary node.</li></ul> |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">show security flow session resource-manager on page 442</a></li></ul>                                                                                                                                                                                                                                                                                         |
| <b>List of Sample Output</b>    | <a href="#">clear security flow session resource-manager on page 244</a><br><a href="#">clear security flow session resource-manager node 0 on page 244</a>                                                                                                                                                                                                                                                       |
| <b>Output Fields</b>            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                                                                                                                                                                             |

### Sample Output

#### clear security flow session resource-manager

```
user@host> clear security flow session resource-manager
node0:

0 active sessions cleared
node1:

0 active sessions cleared
```

### Sample Output

#### clear security flow session resource-manager node 0

```
user@host> clear security flow session resource-manager node 0
node0:

0 active sessions cleared
```

## clear security flow session services-offload

|                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | <b>clear security flow session services-offload</b> [ <i>filter</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Release Information</b> | <p>Command introduced in Junos OS Release 11.4.</p> <p>Starting with Junos OS Release 15.1X49-D10, the SRX5K-MPC3-100G10G (IOC3) and the SRX5K-MPC3-40G10G (IOC3) with Express Path (formerly known as <i>services offloading</i>) support are introduced for SRX5400, SRX5600, and SRX5800 devices.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Description</b>         | Clear services-offload security sessions, based on filtered options, on the device. This command also clears a services-offload security session from both the network processor and the Services Processing Unit (SPU) on which the specified session was installed.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Options</b>             | <p><i>filter</i>—Filter the display based on the specified criteria.</p> <p>The following filters clear those sessions that match the criteria specified by the filter. Refer to the sample output for filtered output examples.</p> <p><b>application</b> <i>application-name</i>—Application name.</p> <p><b>destination-port</b> <i>destination-port</i>—Destination port number. Range is from 1 through 65,535.</p> <p><b>destination-prefix</b> <i>destination-prefix</i>—Destination IP prefix or address.</p> <p><b>family</b> (<i>inet</i>   <i>inet6</i>)—IPv4 traffic or IPv6-NAT-PT traffic.</p> <p><b>interface</b> <i>interface-name</i>—Incoming or outgoing interface name.</p> <p><b>logical-system</b> <i>logical-system-name</i>   <b>all</b>—Specified logical system name or all logical systems.</p> <p><b>protocol</b> <i>protocol-name</i>   <i>protocol-number</i> —Protocol name or number.</p> <ul style="list-style-type: none"> <li>• <b>ah</b> or 51</li> <li>• <b>egp</b> or 8</li> <li>• <b>esp</b> or 50</li> <li>• <b>gre</b> or 47</li> <li>• <b>icmp</b> or 1</li> <li>• <b>icmp6</b> or 58</li> <li>• <b>igmp</b> or 2</li> <li>• <b>ipip</b> or 4</li> <li>• <b>ospf</b> or 89</li> <li>• <b>pim</b> or 103</li> <li>• <b>rsvp</b> or 46</li> </ul> |

- `sctp` or 132
- `tcp` or 6
- `udp` or 17

`root-logical-system` [*filter*]—Root logical system information and filtered options.

`source-port` *source-port*—Source port number of the traffic. Range is from 1 through 65,535.

`source-prefix` *source-prefix*—Source IP prefix or address of the traffic.

**Required Privilege Level**

clear

**Related Documentation**

- [show security flow session services-offload on page 446](#)

**List of Sample Output**

[clear security flow session services-offload on page 246](#)  
[clear security flow session services-offload application on page 246](#)  
[clear security flow session services-offload destination-port on page 246](#)  
[clear security flow session services-offload destination-prefix on page 246](#)  
[clear security flow session services-offload family on page 246](#)  
[clear security flow session services-offload interface on page 247](#)  
[clear security flow session services-offload logical-system on page 247](#)  
[clear security flow session services-offload protocol on page 247](#)  
[clear security flow session services-offload root-logical-system on page 247](#)  
[clear security flow session services-offload source-port on page 247](#)  
[clear security flow session services-offload source-prefix on page 247](#)

**Output Fields**

When you enter this command, you are provided feedback on the status of your request.

## Sample Output

### `clear security flow session services-offload`

```
user@host>clear security flow session services-offload
0 active sessions cleared
```

### `clear security flow session services-offload application`

```
user@host>clear security flow session services-offload dns
0 active sessions cleared
```

### `clear security flow session services-offload destination-port`

```
user@host>clear security flow session services-offload destination-port 1
0 active sessions cleared
```

### `clear security flow session services-offload destination-prefix`

```
user@host>clear security flow session services-offload destination-prefix 100.0.0.1
0 active sessions cleared
```

### `clear security flow session services-offload family`

```
user@host>clear security flow session services-offload family inet
```

1 active sessions cleared

#### clear security flow session services-offload interface

```
user@host>clear security flow session services-offload interface ge-0/0/0.0
0 active sessions cleared
```

#### clear security flow session services-offload logical-system

```
user@host>clear security flow session services-offload logical-system all
0 active sessions cleared
```

#### clear security flow session services-offload protocol

```
user@host>clear security flow session services-offload protocol pim
0 active sessions cleared
```

#### clear security flow session services-offload root-logical-system

```
user@host>clear security flow session services-offload root-logical-system application dns
0 active sessions cleared
```

#### clear security flow session services-offload source-port

```
user@host>clear security flow session services-offload source-port 1
0 active sessions cleared
```

#### clear security flow session services-offload source-prefix

```
user@host>clear security flow session services-offload source-prefix 100.0.0.1
0 active sessions cleared
```

## clear security flow session session-identifier

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security flow session session-identifier<br><i>session-identifier</i><br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Description</b>              | Clear the session with the specific identifier.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Options</b>                  | <ul style="list-style-type: none"><li>• <b>session-identifier</b>—Number from 1 through 4,294,967,295 that identifies the security session.</li><li>• <b>node</b>—(Optional) For chassis cluster configurations, clear the specified session on a specific node (device) in the cluster.<ul style="list-style-type: none"><li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li><li>• <b>all</b>—Clear all nodes.</li><li>• <b>local</b>—Clear the local node.</li><li>• <b>primary</b>—Clear the primary node.</li></ul></li></ul> |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">show security flow session session-identifier on page 451</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>List of Sample Output</b>    | <a href="#">clear security flow session session-identifier 1 on page 248</a><br><a href="#">clear security flow session session-identifier 1 node 0 on page 248</a>                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Output Fields</b>            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

### Sample Output

clear security flow session session-identifier 1

```
user@host> clear security flow session session-identifier 1
0 active sessions cleared
```

### Sample Output

clear security flow session session-identifier 1 node 0

```
user@host> clear security flow session session-identifier 1 node 0
node0:

0 active sessions cleared
```

## clear security flow session source-port

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security flow session source-port<br><i>source-port-number</i><br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Description</b>              | Clear each session that uses the specified source port.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>source-port-number</b> —Number that identifies the source port.<br/><b>Range:</b> 1 through 65,535</li> <li>• <b>node</b>—(Optional) For chassis cluster configurations, clear sessions on the specified source port on a specific node (device) in the cluster. <ul style="list-style-type: none"> <li>• <b>node-id</b> —Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b> —Clear all nodes.</li> <li>• <b>local</b> —Clear the local node.</li> <li>• <b>primary</b>—Clear the primary node.</li> </ul> </li> </ul> |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow session source-port on page 455</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>List of Sample Output</b>    | <a href="#">clear security flow session source-port 1 on page 249</a><br><a href="#">clear security flow session source-port 1 node 0 on page 249</a>                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Output Fields</b>            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

### Sample Output

clear security flow session source-port 1

```

user@host> clear security flow session source-port 1
node0:

0 active sessions cleared
node1:

0 active sessions cleared

```

### Sample Output

clear security flow session source-port 1 node 0

```

user@host> clear security flow session source-port 1 node 0

```

node0:

-----  
0 active sessions cleared



## clear security flow session source-prefix

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security flow session source-prefix<br><i>source-prefix-number</i><br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5. The <b>node</b> options added in Junos OS Release 9.0. Support for IPv6 addresses added in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Description</b>              | Clear sessions that match the source prefix.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>source-prefix-number</b>—Source IP prefix or address.</li> <li>• <b>node</b>—(Optional) For chassis cluster configurations, clear security sessions matching the source prefix on a specific node (device) in the cluster. <ul style="list-style-type: none"> <li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Clear all nodes.</li> <li>• <b>local</b>—Clear the local node.</li> <li>• <b>primary</b>—Clear the primary node.</li> </ul> </li> </ul> |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow session source-prefix on page 459</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>List of Sample Output</b>    | <a href="#">clear security flow session source-prefix 100.0.0.1 on page 251</a><br><a href="#">clear security flow session source-prefix 10::10 on page 251</a><br><a href="#">clear security flow session source-prefix 100.0.0.1 node 0 on page 252</a>                                                                                                                                                                                                                                                                                         |
| <b>Output Fields</b>            | When you enter this command, you are provided feedback on the status of your request.                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

### Sample Output

#### clear security flow session source-prefix 100.0.0.1

```

user@host> clear security flow session source-prefix 100.0.0.1
node0:

0 active sessions cleared
node1:

0 active sessions cleared

```

#### clear security flow session source-prefix 10::10

```

user@host> clear security flow session source-prefix 10::10
1 active sessions cleared

```

## Sample Output

clear security flow session source-prefix 100.0.0.1 node 0

```
user@host> clear security flow session source-prefix 100.0.0.1 node 0
node0:
```

```

0 active sessions cleared
```

## clear security forward-options mirror filter

---

|                                 |                                                                                                                                                                                                             |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | clear security forward-options mirror-filter (all   <i>filter-name</i> )                                                                                                                                    |
| <b>Release Information</b>      | Command introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                         |
| <b>Description</b>              | Clear statistics about configured mirror filters.                                                                                                                                                           |
| <b>Options</b>                  | <p><b>all</b>—Clear statistics for all configured mirror filters.</p> <p><b><i>filter-name</i></b>—Clear statistics for the specified mirror filter.</p>                                                    |
| <b>Required Privilege Level</b> | clear                                                                                                                                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">mirror-filter (Security Forwarding Options) on page 197</a></li><li>• <a href="#">show security forward-options mirror-filter on page 486</a></li></ul> |

## monitor security flow file

---

|                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Syntax                   | monitor security flow file<br><file-name><br><files number><br><match regular-expression><br><size maximum-file-size><br><(world-readable   no-world-readable)>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Release Information      | Command introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Description              | Configure options for the security flow monitoring output.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Options                  | <p><b>filename</b>—Name of the file to receive the output of the monitoring operation. All output is saved in the <code>/var/log/</code> directory.</p> <p><b>files number</b>—Maximum number of output files. If you specify a maximum number of files, you must also specify a maximum file size with the <b>size</b> option.<br/>Range: 2 through 1000 files<br/><br/>Default: 10 files</p> <p><b>match regular-expression</b>—Refine the output to include lines that contain the regular expression.</p> <p><b>size maximum-file-size</b>—Maximum size of each output file. When an output file named <b>output</b> reaches this size, it is renamed <b>output.0</b>. When the output file again reaches its maximum size, <b>output.0</b> is renamed <b>output.1</b> and <b>output</b> file is renamed <b>output.0</b>. This renaming scheme continues until the maximum number of output files is reached. Then the oldest output file is overwritten.<br/><br/>If you specify a maximum file size, you also must specify a maximum number of output files with the <b>files</b> option.<br/><br/>Range: 10 KB through 1 GB<br/><br/>Default: 128 KB</p> <p><b>(world-readable   no-world-readable)</b>—By default, the output files can be accessed only by the user who configures the monitoring operation. The <b>world-readable</b> option enables all users to read the file. To explicitly set the default behavior, use the <b>no-world-readable</b> option.</p> |
| Required Privilege Level | trace                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Related Documentation    | <ul style="list-style-type: none"><li>• <a href="#">Monitoring Security Flow Sessions Overview on page 117</a></li><li>• <a href="#">monitor security flow filter on page 256</a></li><li>• <a href="#">monitor security flow start on page 258</a></li><li>• <a href="#">show monitor security flow on page 347</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

**Output Fields** This command produces no output.

## monitor security flow filter

**Syntax** monitor security flow filter *filter-name*  
 <destination-port (*port-range* | *protocol-name*)>  
 <destination-prefix *destination-prefix*>  
 <interface *interface-name*>  
 <logical-system *logical-system-name*>  
 <protocol (*protocol name* | *protocol number*)>  
 <root-logical-system>  
 <source-port (*port-range* | *protocol-name*)>  
 <source-prefix *source-prefix*>

**Release Information** Command introduced in Junos OS Release 12.1X46-D10.

**Description** Set security flow filters to define flow sessions that you want to monitor. A maximum of 64 filters is supported at a time.

Defining the filters themselves does not trigger monitoring. You have to explicitly use the **monitor security flow start** command to enable monitoring. Once monitoring starts, any traffic that matches the specified filters is saved in an output file in the **/var/log/** directory.



**NOTE:** Unlike filters defined in the configuration mode, these filters defined using operational mode commands are cleared when you reboot your system.

- Options**
- filter *filter-name***—Specify a name for the filter. The filter name can contain letters, numbers, underscores (\_) and hyphens (-) and can be up to 64 characters long.
  - destination-port (*port-range* | *protocol-name*)**—Specify the TCP or UDP destination port to match. You can also specify a range of TCP or UDP destination ports and monitor all traffic in this group.
  - destination-prefix *destination-prefix***—Specify the destination IPv4 or IPv6 address prefix to match.
  - interface *interface-name***—Specify the logical interface name to match.
  - logical-system *logical-system-name***—Specify the logical system name to match.
  - protocol (*protocol name* | *protocol number*)**—Specify the IP protocol type to match.
  - root-logical-system**—(Default) Specify the root logical system to match.
  - source-port (*port-range* | *protocol-name*)**—Specify the TCP or UDP source port to match. You can also specify a range of TCP or UDP source ports and monitor all traffic in this group.
  - source-prefix *source-prefix***—Specify the source IP address prefix to match.

**Required Privilege Level**    view

- Related Documentation**
- [Monitoring Security Flow Sessions Overview on page 117](#)
  - [monitor security flow file on page 254](#)
  - [monitor security flow start on page 258](#)
  - [monitor security flow stop on page 259](#)

## monitor security flow start

---

|                                 |                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | monitor security flow start                                                                                                                                                                                                                                                                                                                                  |
| <b>Release Information</b>      | Command introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                                                                                                                          |
| <b>Description</b>              | <p>Start the monitoring of security flow session. Once monitoring starts, any traffic that matches the specified filters is saved in an output file in the <b>var/log/</b> directory. At least one filter must be defined for the monitoring to start.</p> <p>Use the <b>monitor security flow stop</b> command to stop the monitoring of flow sessions.</p> |
| <b>Options</b>                  | This command has no options.                                                                                                                                                                                                                                                                                                                                 |
| <b>Required Privilege Level</b> | trace                                                                                                                                                                                                                                                                                                                                                        |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Monitoring Security Flow Sessions Overview on page 117</a></li><li>• <a href="#">show monitor security flow on page 347</a></li><li>• <a href="#">monitor security flow filter on page 256</a></li><li>• <a href="#">monitor security flow stop on page 259</a></li></ul>                                |
| <b>Output Fields</b>            | This command produces no output.                                                                                                                                                                                                                                                                                                                             |



## monitor security flow stop

---

|                                 |                                                                                                                                                                                            |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | monitor security flow stop                                                                                                                                                                 |
| <b>Release Information</b>      | Command introduced in Junos OS Release 12.1X46-D10.                                                                                                                                        |
| <b>Description</b>              | Stop monitoring the security flow session. Use the <b>monitor security flow start</b> command to start the monitoring of flow sessions.                                                    |
| <b>Options</b>                  | This command has no options.                                                                                                                                                               |
| <b>Required Privilege Level</b> | trace                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">Monitoring Security Flow Sessions Overview on page 117</a></li><li>• <a href="#">monitor security flow start on page 258</a></li></ul> |
| <b>Output Fields</b>            | This command produces no output.                                                                                                                                                           |

## show chassis environment (Security)

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show chassis environment                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Release Information</b>      | Command introduced in Junos OS Release 9.2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Description</b>              | Display environmental information about the services gateway chassis, including the temperature and information about the fans, power supplies, and Routing Engine.                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Options</b>                  | <p><b>none</b>—Display environmental information about the device.</p> <p><b>cb slot-number</b>—Display chassis environmental information for the Control Board.</p> <p><b>fpc fpc-slot</b>—Display chassis environmental information for a specified Flexible PIC Concentrator.</p> <p><b>fpm</b>—Display chassis environmental information for the craft interface (FPM).</p> <p><b>pem slot-number</b>—Display chassis environmental information for the specified Power Entry Module.</p> <p><b>routing-engine slot-number</b>—Display chassis environmental information for the specified Routing Engine.</p> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><a href="#">show chassis hardware (View) on page 274</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>List of Sample Output</b>    | <a href="#">show chassis environment on page 260</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Output Fields</b>            | Table 21 on page 260 lists the output fields for the <b>show chassis environment</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                                                                                              |

Table 21: show chassis environment Output Fields

| Field Name | Field Description                                                                                    |
|------------|------------------------------------------------------------------------------------------------------|
| Temp       | Temperature of air flowing through the chassis in degrees Celsius (C) and Fahrenheit (F).            |
| Fan        | Fan status: <b>OK</b> , <b>Testing</b> (during initial power-on), <b>Failed</b> , or <b>Absent</b> . |

## Sample Output

### show chassis environment

```

user@host> show chassis environment
user@host> show chassis environment
Class Item Status Measurement
Temp PEM 0 OK 40 degrees C / 104 degrees F
 PEM 1 OK 40 degrees C / 104 degrees F
 PEM 2 OK 40 degrees C / 104 degrees F

```

|                      |        |                              |
|----------------------|--------|------------------------------|
| PEM 3                | OK     | 45 degrees C / 113 degrees F |
| Routing Engine 0     | OK     | 31 degrees C / 87 degrees F  |
| Routing Engine 0 CPU | OK     | 27 degrees C / 80 degrees F  |
| Routing Engine 1     | Absent |                              |
| Routing Engine 1 CPU | Absent |                              |
| CB 0 Intake          | OK     | 28 degrees C / 82 degrees F  |
| CB 0 Exhaust A       | OK     | 27 degrees C / 80 degrees F  |
| CB 0 Exhaust B       | OK     | 29 degrees C / 84 degrees F  |
| CB 0 ACBC            | OK     | 29 degrees C / 84 degrees F  |
| CB 0 SF A            | OK     | 36 degrees C / 96 degrees F  |
| CB 0 SF B            | OK     | 31 degrees C / 87 degrees F  |
| CB 1 Intake          | OK     | 27 degrees C / 80 degrees F  |
| CB 1 Exhaust A       | OK     | 26 degrees C / 78 degrees F  |
| CB 1 Exhaust B       | OK     | 29 degrees C / 84 degrees F  |
| CB 1 ACBC            | OK     | 27 degrees C / 80 degrees F  |
| CB 1 SF A            | OK     | 36 degrees C / 96 degrees F  |
| CB 1 SF B            | OK     | 31 degrees C / 87 degrees F  |
| CB 2 Intake          | Absent |                              |
| CB 2 Exhaust A       | Absent |                              |
| CB 2 Exhaust B       | Absent |                              |
| CB 2 ACBC            | Absent |                              |
| CB 2 XF A            | Absent |                              |
| CB 2 XF B            | Absent |                              |
| FPC 0 Intake         | OK     | 47 degrees C / 116 degrees F |
| FPC 0 Exhaust A      | OK     | 44 degrees C / 111 degrees F |
| FPC 0 Exhaust B      | OK     | 52 degrees C / 125 degrees F |
| FPC 0 xlp0 TSen      | OK     | 51 degrees C / 123 degrees F |
| FPC 0 xlp0 Chip      | OK     | 46 degrees C / 114 degrees F |
| FPC 0 xlp1 TSen      | OK     | 51 degrees C / 123 degrees F |
| FPC 0 xlp1 Chip      | OK     | 47 degrees C / 116 degrees F |
| FPC 0 xlp2 TSen      | OK     | 44 degrees C / 111 degrees F |
| FPC 0 xlp2 Chip      | OK     | 42 degrees C / 107 degrees F |
| FPC 0 xlp3 TSen      | OK     | 48 degrees C / 118 degrees F |
| FPC 0 xlp3 Chip      | OK     | 43 degrees C / 109 degrees F |
| FPC 1 Intake         | OK     | 41 degrees C / 105 degrees F |
| FPC 1 Exhaust A      | OK     | 41 degrees C / 105 degrees F |
| FPC 1 Exhaust B      | OK     | 51 degrees C / 123 degrees F |
| FPC 1 LU TSen        | OK     | 46 degrees C / 114 degrees F |
| FPC 1 LU Chip        | OK     | 45 degrees C / 113 degrees F |
| FPC 1 XM TSen        | OK     | 46 degrees C / 114 degrees F |
| FPC 1 XM Chip        | OK     | 52 degrees C / 125 degrees F |
| FPC 1 xlp0 TSen      | OK     | 49 degrees C / 120 degrees F |
| FPC 1 xlp0 Chip      | OK     | 42 degrees C / 107 degrees F |
| FPC 1 xlp1 TSen      | OK     | 49 degrees C / 120 degrees F |
| FPC 1 xlp1 Chip      | OK     | 44 degrees C / 111 degrees F |
| FPC 1 xlp2 TSen      | OK     | 38 degrees C / 100 degrees F |
| FPC 1 xlp2 Chip      | OK     | 39 degrees C / 102 degrees F |
| FPC 1 xlp3 TSen      | OK     | 44 degrees C / 111 degrees F |
| FPC 1 xlp3 Chip      | OK     | 42 degrees C / 107 degrees F |
| FPC 2 Intake         | OK     | 29 degrees C / 84 degrees F  |
| FPC 2 Exhaust A      | OK     | 34 degrees C / 93 degrees F  |
| FPC 2 Exhaust B      | OK     | 40 degrees C / 104 degrees F |
| FPC 2 I3 0 TSensor   | OK     | 42 degrees C / 107 degrees F |
| FPC 2 I3 0 Chip      | OK     | 41 degrees C / 105 degrees F |
| FPC 2 I3 1 TSensor   | OK     | 40 degrees C / 104 degrees F |
| FPC 2 I3 1 Chip      | OK     | 39 degrees C / 102 degrees F |
| FPC 2 I3 2 TSensor   | OK     | 38 degrees C / 100 degrees F |
| FPC 2 I3 2 Chip      | OK     | 37 degrees C / 98 degrees F  |
| FPC 2 I3 3 TSensor   | OK     | 35 degrees C / 95 degrees F  |
| FPC 2 I3 3 Chip      | OK     | 35 degrees C / 95 degrees F  |
| FPC 2 IA 0 TSensor   | OK     | 45 degrees C / 113 degrees F |

|                        |    |                              |
|------------------------|----|------------------------------|
| FPC 2 IA 0 Chip        | OK | 42 degrees C / 107 degrees F |
| FPC 2 IA 1 TSensor     | OK | 41 degrees C / 105 degrees F |
| FPC 2 IA 1 Chip        | OK | 43 degrees C / 109 degrees F |
| FPC 9 Intake           | OK | 29 degrees C / 84 degrees F  |
| FPC 9 Exhaust A        | OK | 41 degrees C / 105 degrees F |
| FPC 9 Exhaust B        | OK | 48 degrees C / 118 degrees F |
| FPC 9 LU TSen          | OK | 48 degrees C / 118 degrees F |
| FPC 9 LU Chip          | OK | 47 degrees C / 116 degrees F |
| FPC 9 XM TSen          | OK | 48 degrees C / 118 degrees F |
| FPC 9 XM Chip          | OK | 54 degrees C / 129 degrees F |
| FPC 9 xlp0 TSen        | OK | 45 degrees C / 113 degrees F |
| FPC 9 xlp0 Chip        | OK | 42 degrees C / 107 degrees F |
| FPC 9 xlp1 TSen        | OK | 49 degrees C / 120 degrees F |
| FPC 9 xlp1 Chip        | OK | 46 degrees C / 114 degrees F |
| FPC 9 xlp2 TSen        | OK | 37 degrees C / 98 degrees F  |
| FPC 9 xlp2 Chip        | OK | 40 degrees C / 104 degrees F |
| FPC 9 xlp3 TSen        | OK | 45 degrees C / 113 degrees F |
| FPC 9 xlp3 Chip        | OK | 41 degrees C / 105 degrees F |
| FPC 10 Intake          | OK | 32 degrees C / 89 degrees F  |
| FPC 10 Exhaust A       | OK | 44 degrees C / 111 degrees F |
| FPC 10 Exhaust B       | OK | 53 degrees C / 127 degrees F |
| FPC 10 LU 0 TSen       | OK | 43 degrees C / 109 degrees F |
| FPC 10 LU 0 Chip       | OK | 52 degrees C / 125 degrees F |
| FPC 10 LU 1 TSen       | OK | 43 degrees C / 109 degrees F |
| FPC 10 LU 1 Chip       | OK | 44 degrees C / 111 degrees F |
| FPC 10 LU 2 TSen       | OK | 43 degrees C / 109 degrees F |
| FPC 10 LU 2 Chip       | OK | 50 degrees C / 122 degrees F |
| FPC 10 LU 3 TSen       | OK | 43 degrees C / 109 degrees F |
| FPC 10 LU 3 Chip       | OK | 58 degrees C / 136 degrees F |
| FPC 10 XM 0 TSen       | OK | 43 degrees C / 109 degrees F |
| FPC 10 XM 0 Chip       | OK | 53 degrees C / 127 degrees F |
| FPC 10 XF 0 TSen       | OK | 43 degrees C / 109 degrees F |
| FPC 10 XF 0 Chip       | OK | 64 degrees C / 147 degrees F |
| FPC 10 PLX Switch TSen | OK | 43 degrees C / 109 degrees F |
| FPC 10 PLX Switch Chip | OK | 44 degrees C / 111 degrees F |
| FPC 11 Intake          | OK | 32 degrees C / 89 degrees F  |
| FPC 11 Exhaust A       | OK | 41 degrees C / 105 degrees F |
| FPC 11 Exhaust B       | OK | 56 degrees C / 132 degrees F |
| FPC 11 LU 0 TSen       | OK | 45 degrees C / 113 degrees F |
| FPC 11 LU 0 Chip       | OK | 50 degrees C / 122 degrees F |
| FPC 11 LU 1 TSen       | OK | 45 degrees C / 113 degrees F |
| FPC 11 LU 1 Chip       | OK | 47 degrees C / 116 degrees F |
| FPC 11 LU 2 TSen       | OK | 45 degrees C / 113 degrees F |
| FPC 11 LU 2 Chip       | OK | 52 degrees C / 125 degrees F |
| FPC 11 LU 3 TSen       | OK | 45 degrees C / 113 degrees F |
| FPC 11 LU 3 Chip       | OK | 60 degrees C / 140 degrees F |
| FPC 11 XM 0 TSen       | OK | 45 degrees C / 113 degrees F |
| FPC 11 XM 0 Chip       | OK | 56 degrees C / 132 degrees F |
| FPC 11 XF 0 TSen       | OK | 45 degrees C / 113 degrees F |
| FPC 11 XF 0 Chip       | OK | 65 degrees C / 149 degrees F |
| FPC 11 PLX Switch TSen | OK | 45 degrees C / 113 degrees F |
| FPC 11 PLX Switch Chip | OK | 46 degrees C / 114 degrees F |
| Fans Top Fan Tray Temp | OK | 34 degrees C / 93 degrees F  |
| Top Tray Fan 1         | OK | Spinning at normal speed     |
| Top Tray Fan 2         | OK | Spinning at normal speed     |
| Top Tray Fan 3         | OK | Spinning at normal speed     |
| Top Tray Fan 4         | OK | Spinning at normal speed     |
| Top Tray Fan 5         | OK | Spinning at normal speed     |
| Top Tray Fan 6         | OK | Spinning at normal speed     |
| Top Tray Fan 7         | OK | Spinning at normal speed     |
| Top Tray Fan 8         | OK | Spinning at normal speed     |

|                      |    |                             |
|----------------------|----|-----------------------------|
| Top Tray Fan 9       | OK | Spinning at normal speed    |
| Top Tray Fan 10      | OK | Spinning at normal speed    |
| Top Tray Fan 11      | OK | Spinning at normal speed    |
| Top Tray Fan 12      | OK | Spinning at normal speed    |
| Bottom Fan Tray Temp | OK | 31 degrees C / 87 degrees F |
| Bottom Tray Fan 1    | OK | Spinning at normal speed    |
| Bottom Tray Fan 2    | OK | Spinning at normal speed    |
| Bottom Tray Fan 3    | OK | Spinning at normal speed    |
| Bottom Tray Fan 4    | OK | Spinning at normal speed    |
| Bottom Tray Fan 5    | OK | Spinning at normal speed    |
| Bottom Tray Fan 6    | OK | Spinning at normal speed    |
| Bottom Tray Fan 7    | OK | Spinning at normal speed    |
| Bottom Tray Fan 8    | OK | Spinning at normal speed    |
| Bottom Tray Fan 9    | OK | Spinning at normal speed    |
| Bottom Tray Fan 10   | OK | Spinning at normal speed    |
| Bottom Tray Fan 11   | OK | Spinning at normal speed    |
| Bottom Tray Fan 12   | OK | Spinning at normal speed    |
| OK                   |    |                             |

## show chassis fpc (View)

**Syntax** `show chassis fpc`  
`<detail < fpc-slot >| <node ( node-id | local | primary)>> |`  
`<node ( node-id | local | primary)> |`  
`<pic-status < fpc-slot >| <node ( node-id | local | primary)>>`

**Release Information** Command modified in Junos OS Release 9.2.  
 Starting with Junos OS Release 15.1X49-D10, the SRX5K-MPC3-100G10G (IOC3) and the SRX5K-MPC3-40G10G (IOC3) are introduced.



**NOTE:** On SRX5K-MPC3-40G10G (IOC3), all four PICs cannot be powered on. A maximum of two PICs can be powered on at the same time. By default, PIC0 and PIC1 are online.

Use the `set chassis fpc <slot> pic <pic> power off` command to choose the PICs you want to power on.

When you use the `set chassis fpc <slot> pic <pic> power off` command to power off PIC0 and PIC1, PIC2 and PIC3 are automatically turned on.

When you switch from one set of PICs to another set of PICs using the `set chassis fpc <slot> pic <pic> power off` command again, ensure that there is 60 seconds duration between the two actions, otherwise core files are seen during the configuration.

The [Table 22 on page 264](#) summarizes the SRX5K-MPC3-40G10G (IOC3) PICs selected for various configuration scenarios.

**Table 22: SRX5K-MPC3-40G10G (IOC3) PIC Selection Summary**

| CLI Configuration                   | PIC Selection                                 |
|-------------------------------------|-----------------------------------------------|
| Default (i.e. no CLI configuration) | Online: PIC-0, PIC-1<br>Offline: PIC-2, PIC-3 |
| PIC-1, PIC-2 and PIC-3 powered OFF  | Online: PIC-0<br>Offline: PIC-1, PIC-2, PIC-3 |
| PIC-0, PIC-2 and PIC-3 powered OFF  | Online: PIC-1<br>Offline: PIC-0, PIC-2, PIC-3 |
| PIC-0, PIC-1 and PIC-3 powered OFF  | Online: PIC-2<br>Offline: PIC-0, PIC-1, PIC-3 |
| PIC-0, PIC-1 and PIC-2 powered OFF  | Online: PIC-3<br>Offline: PIC-0, PIC-1, PIC-2 |

**Table 22: SRX5K-MPC3-40G10G (IOC3) PIC Selection Summary** (*continued*)

| CLI Configuration                                          | PIC Selection                                                                                                                                                                                                    |
|------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PIC-2 and PIC-3 powered OFF                                | Online: PIC-0, PIC-1<br>Offline: PIC-2, PIC-3                                                                                                                                                                    |
| PIC-2 and PIC-3 powered OFF                                | Online: PIC-0, PIC-1<br>Offline: PIC-2, PIC-3                                                                                                                                                                    |
| PIC-1 and PIC-2 powered OFF                                | Online: PIC-0, PIC-3<br>Offline: PIC-1, PIC-2                                                                                                                                                                    |
| PIC-0 and PIC-3 powered OFF                                | Online: PIC-2, PIC-1<br>Offline: PIC-0, PIC-3                                                                                                                                                                    |
| PIC-0 and PIC-1 powered OFF                                | Online: PIC-2, PIC-3<br>Offline: PIC-0, PIC-1                                                                                                                                                                    |
| All other combinations of PICs being powered OFF (Invalid) | Online: PIC-0, PIC-1<br>Offline: PIC-2, PIC-3<br><br>Default PICs will be selected for the invalid combinations. Also, a system log message will be displayed to indicate the invalid combination PIC selection. |

**Description** Display status information about the installed Flexible PIC Concentrators (FPCs) and PICs.

- Options**
- **none**—Display status information for all FPCs.
  - **detail**—(Optional) Display detailed FPC status information.
  - **fpc-slot** —(Optional) Display information about the FPC in this slot.
  - **node**—(Optional) For chassis cluster configurations, display status information for all FPCs or for the specified FPC on a specific node (device) in the cluster.
    - **node-id** —Identification number of the node. It can be 0 or 1.
    - **local**—Display information about the local node.
    - **primary**—Display information about the primary node.

- **pic-status**—(Optional) Display status information for all FPCs or for the FPC in the specified slot (see *fpc-slot*).

**Required Privilege Level** view

**Related Documentation**

- [Juniper Networks Devices Processing Overview on page 3](#)
- [Understanding Interfaces](#)

**List of Sample Output**

[show chassis fpc on page 267](#)  
[show chassis fpc \(SRX1400 devices\) on page 267](#)  
[show chassis fpc \(SRX5600 and SRX5800 devices\) on page 267](#)  
[show chassis fpc \(SRX5400, SRX5600, and SRX5800 devices with SRX5K-MPC3-100G10G \(IOC3\) or SRX5K-MPC3-40G10G \(IOC3\) on page 268](#)  
[show chassis fpc detail 2 on page 268](#)  
[show chassis fpc pic-status \(SRX1400, SRX3400, and SRX3600 devices\) on page 268](#)  
[show chassis fpc pic-status \(SRX5600 and SRX5800 devices\) on page 269](#)  
[show chassis fpc pic-status \(SRX5600 and SRX5800 devices with SPC2\) on page 269](#)  
[show chassis fpc pic-status \(SRX5600 and SRX5800 devices with SRX5K-MPC\) on page 269](#)  
[show chassis fpc pic-status \(SRX5600 and SRX5800 devices when Express Path \[formerly known as services offloading\] is configured\) on page 270](#)  
[show chassis fpc pic-status \(with 20-Gigabit Ethernet MIC with SFP\) on page 270](#)  
[show chassis fpc pic-status\(SRX5400, SRX5600, and SRX5800 devices with SRX5K-MPC3-100G10G \(IOC3\) or SRX5K-MPC3-40G10G \(IOC3 and when Express Path \[formerly known as services offloading\] is configured\) on page 271](#)  
[show chassis fpc pic-status for HA \(SRX3400 and SRX3600 devices\) on page 271](#)  
[show chassis fpc pic-status for HA \(SRX5600 and SRX5800 devices\) on page 272](#)  
[show chassis fpc pic-status for HA\(SRX5400, SRX5600, and SRX5800 devices with SRX5K-MPC3-100G10G \(IOC3\) or SRX5K-MPC3-40G10G \(IOC3\) on page 272](#)

**Output Fields** [Table 23 on page 266](#) lists the output fields for the **show chassis fpc** command. Output fields are listed in the approximate order in which they appear.

**Table 23: show chassis fpc Output Fields**

| Field Name         | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Slot or Slot State | <p>Slot number and state. The state can be one of the following conditions:</p> <ul style="list-style-type: none"> <li>• <b>Dead</b>—Held in reset because of errors.</li> <li>• <b>Diag</b>—Slot is being ignored while the device is running diagnostics.</li> <li>• <b>Dormant</b>—Held in reset.</li> <li>• <b>Empty</b>—No FPC is present.</li> <li>• <b>Online</b>—FPC is online and running.</li> <li>• <b>Present</b>—FPC is detected by the device, but is either not supported by the current version of Junos OS or inserted in the wrong slot. The output also states either <b>Hardware Not Supported</b> or <b>Hardware Not In Right Slot</b>. FPC is coming up but not yet online.</li> <li>• <b>Probed</b>—Probe is complete; awaiting restart of the Packet Forwarding Engine (PFE).</li> <li>• <b>Probe-wait</b>—Waiting to be probed.</li> </ul> |



Table 23: show chassis fpc Output Fields (*continued*)

| Field Name                    | Field Description                                                                                                                                              |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Temp (C) or Temperature       | Temperature of the air passing by the FPC, in degrees Celsius or in both Celsius and Fahrenheit.                                                               |
| Total CPU Utilization (%)     | Total percentage of CPU being used by the FPC's processor.                                                                                                     |
| Interrupt CPU Utilization (%) | Of the total CPU being used by the FPC's processor, the percentage being used for interrupts.                                                                  |
| Memory DRAM (MB)              | Total DRAM, in megabytes, available to the FPC's processor.                                                                                                    |
| Heap Utilization (%)          | Percentage of heap space (dynamic memory) being used by the FPC's processor. If this number exceeds 80 percent, there may be a software problem (memory leak). |
| Buffer Utilization (%)        | Percentage of buffer space being used by the FPC's processor for buffering internal messages.                                                                  |
| Start Time                    | Time when the Routing Engine detected that the FPC was running.                                                                                                |
| Uptime                        | How long the Routing Engine has been connected to the FPC and, therefore, how long the FPC has been up and running.                                            |
| PIC type                      | (pic-status output only) Type of FPC.                                                                                                                          |

## Sample Output

### show chassis fpc

```

user@host> show chassis fpc
 Slot State Temp CPU Utilization (%) Memory Utilization (%)
 0 Online (C) Total Interrupt DRAM (MB) Heap Buffer
 1 Online ----- CPU less FPC -----
 2 Online ----- Not Usable -----
 3 Online ----- CPU less FPC -----

```

### show chassis fpc (SRX1400 devices)

```

user@host> show chassis fpc
 Slot State Temp CPU Utilization (%) Memory Utilization (%)
 0 Online (C) Total Interrupt DRAM (MB) Heap Buffer
 1 Online 49 30 0 1024 3 25
 2 Online 41 30 0 1024 3 25
 3 Online 44 30 0 1024 3 25
 4 Online 54 30 0 1024 3 25

```

### show chassis fpc (SRX5600 and SRX5800 devices)

```

user@host> show chassis fpc
 Slot State Temp CPU Utilization (%) Memory Utilization (%)
 0 Empty (C) Total Interrupt DRAM (MB) Heap Buffer
 1 Empty
 2 Empty

```

|    |        |    |   |   |      |    |    |
|----|--------|----|---|---|------|----|----|
| 3  | Online | 37 | 3 | 0 | 1024 | 7  | 42 |
| 4  | Empty  |    |   |   |      |    |    |
| 5  | Empty  |    |   |   |      |    |    |
| 6  | Online | 30 | 8 | 0 | 1024 | 23 | 30 |
| 7  | Empty  |    |   |   |      |    |    |
| 8  | Empty  |    |   |   |      |    |    |
| 9  | Empty  |    |   |   |      |    |    |
| 10 | Empty  |    |   |   |      |    |    |
| 11 | Empty  |    |   |   |      |    |    |

**show chassis fpc**

(SRX5400, SRX5600, and SRX5800 devices with SRX5K-MPC3-100G10G (IOC3) or SRX5K-MPC3-40G10G (IOC3))

```
user@host> show chassis fpc
```

| Slot | State  | Temp (C) | CPU Utilization (%) Total | CPU Utilization (%) Interrupt | CPU Utilization (%) 1min | CPU Utilization (%) 5min | CPU Utilization (%) 15min | Memory (MB) |      |
|------|--------|----------|---------------------------|-------------------------------|--------------------------|--------------------------|---------------------------|-------------|------|
| 0    | Online | 36       | 20                        | Heap 0                        | Buffer 20                | 19                       | 19                        | 1024        |      |
| 1    | Online | 35       | 8                         | 4                             | 0                        | 26                       | 8                         | 8           | 2048 |
| 2    | Online | 40       | 21                        | 12                            | 0                        | 14                       | 20                        | 20          | 3584 |
|      |        |          |                           | 5                             |                          | 13                       |                           |             |      |

**Sample Output****show chassis fpc detail 2**

```
user@host> show chassis fpc detail 2
```

Slot 2 information:

|                       |                                          |
|-----------------------|------------------------------------------|
| State                 | Online                                   |
| Temperature           | 37                                       |
| Total CPU DRAM        | 1024 MB                                  |
| Total RLDRAM          | 0 MB                                     |
| Total DDR DRAM        | 0 MB                                     |
| Start time:           | 2012-07-18 07:18:50 PDT                  |
| Uptime:               | 4 days, 21 hours, 51 minutes, 59 seconds |
| Max Power Consumption | 0 Watts                                  |

**Sample Output****show chassis fpc pic-status (SRX1400, SRX3400, and SRX3600 devices)**

```
user@host> show chassis fpc pic-status
```

|        |        |                       |
|--------|--------|-----------------------|
| Slot 0 | Online | SRX3k SFB 12GE        |
| PIC 0  | Online | 8x 1GE-TX 4x 1GE-SFP  |
| Slot 1 | Online | SRX3k 2x10GE XFP      |
| PIC 0  | Online | 2x 10GE-XFP           |
| Slot 3 | Online | SRX1k3k 2x10GE NP-IOC |
| PIC 0  | Online | 2x 10GE-SFP+          |
| Slot 4 | Online | SRX3k SPC             |
| PIC 0  | Online | SPU Cp-Flow           |
| Slot 5 | Online | SRX1k3k 2x10GE NP-IOC |

```

PIC 0 Online 2x 10GE-SFP+
Slot 6 Online SRX3k NPC
PIC 0 Online NPC PIC
Slot 7 Online SRX1k3k 2x10GE NP-IOC
PIC 0 Online 2x 10GE-SFP+- services-offload low-latency

```

## Sample Output

### show chassis fpc pic-status (SRX5600 and SRX5800 devices)

```

user@host> show chassis fpc pic-status
Slot 3 Online SRX5k SPC
PIC 0 Online SPU Cp
PIC 1 Online SPU Flow
Slot 6 Online SRX5k DPC 4x 10GE
PIC 0 Online 1x 10GE(LAN/WAN) RichQ
PIC 1 Online 1x 10GE(LAN/WAN) RichQ
PIC 2 Online 1x 10GE(LAN/WAN) RichQ
PIC 3 Online 1x 10GE(LAN/WAN) RichQ

```

### show chassis fpc pic-status (SRX5600 and SRX5800 devices with SPC2)

```

user@host> show chassis fpc pic-status

Slot 0 Online SRX5k DPC 40x 1GE
PIC 0 Online 10x 1GE RichQ
PIC 1 Online 10x 1GE RichQ
PIC 2 Online 10x 1GE RichQ
PIC 3 Online 10x 1GE RichQ
Slot 2 Online SRX5k SPC II
PIC 0 Online SPU Cp
PIC 1 Online SPU Flow
PIC 2 Online SPU Flow
PIC 3 Online SPU Flow
Slot 3 Online SRX5k SPC II
PIC 0 Online SPU Flow
PIC 1 Online SPU Flow
PIC 2 Online SPU Flow
PIC 3 Online SPU Flow
Slot 5 Online SRX5k SPC
PIC 0 Online SPU Flow
PIC 1 Online SPU Flow

```

### show chassis fpc pic-status (SRX5600 and SRX5800 devices with SRX5K-MPC)

```

user@host> show chassis fpc pic-status

Slot 0 Online SRX5k SPC II
PIC 0 Online SPU Cp
PIC 1 Online SPU Flow
PIC 2 Online SPU Flow
PIC 3 Online SPU Flow
Slot 1 Online SRX5k SPC II
PIC 0 Online SPU Flow
PIC 1 Online SPU Flow
PIC 2 Online SPU Flow
PIC 3 Online SPU Flow
Slot 2 Online SRX5k DPC 4X 10GE
PIC 0 Online 1x 10GE(LAN/WAN) RichQ
PIC 1 Online 1x 10GE(LAN/WAN) RichQ
PIC 2 Online 1x 10GE(LAN/WAN) RichQ

```

```

PIC 3 Online 1x 10GE(LAN/WAN) RichQ
Slot 6 Offline SRX5k SPC II
Slot 9 Online SRX5k SPC II
PIC 0 Online SPU Flow
PIC 1 Online SPU Flow
PIC 2 Online SPU Flow
PIC 3 Online SPU Flow
Slot 10 Online SRX5k IOC II
PIC 0 Online 10x 10GE SFP+
PIC 2 Online 1x 100GE CFP
Slot 11 Online SRX5k IOC II
PIC 0 Online 1x 100GE CFP
PIC 2 Online 2x 40GE QSFP+

```

**show chassis fpc pic-status (SRX5600 and SRX5800 devices when Express Path [formerly known as services offloading] is configured)**

```
user@host> show chassis fpc pic-status
```

```

Slot 0 Offline SRX5k DPC 40x 1GE
Slot 1 Online SRX5k SPC II
PIC 0 Online SPU Cp
PIC 1 Online SPU Flow
PIC 2 Online SPU Flow
PIC 3 Online SPU Flow
Slot 2 Offline SRX5k SPC
Slot 4 Online SRX5k IOC3 24XGE+6XLG
PIC 2 Online 3x 40GE QSFP+- np-cache/services-offload
PIC 3 Online 3x 40GE QSFP+- np-cache/services-offload
Slot 5 Online SRX5k IOC II
PIC 0 Online 10x 1GE(LAN) SFP- np-cache/services-offload
PIC 1 Online 10x 1GE(LAN) SFP- np-cache/services-offload
PIC 2 Online 10x 10GE SFP+- np-cache/services-offload

```

**show chassis fpc pic-status (with 20-Gigabit Ethernet MIC with SFP)**

```
user@host> show chassis fpc pic-status
```

```
node0:
```

```

Slot 0 Online SRX5k SPC II
PIC 0 Online SPU Cp
PIC 1 Online SPU Flow
PIC 2 Online SPU Flow
PIC 3 Online SPU Flow
Slot 1 Offline SRX5k SPC II
Slot 2 Online SRX5k DPC 4X 10GE
PIC 0 Online 1x 10GE(LAN/WAN) RichQ
PIC 1 Online 1x 10GE(LAN/WAN) RichQ
PIC 2 Online 1x 10GE(LAN/WAN) RichQ
PIC 3 Online 1x 10GE(LAN/WAN) RichQ
Slot 9 Online SRX5k IOC II
PIC 0 Online 10x 1GE(LAN) SFP
PIC 1 Online 10x 1GE(LAN) SFP
PIC 2 Online 10x 1GE(LAN) SFP
PIC 3 Online 10x 1GE(LAN) SFP
Slot 10 Online SRX5k IOC II
PIC 0 Online 10x 10GE SFP+
PIC 2 Online 1x 100GE CFP
Slot 11 Offline SRX5k IOC II

```

**show chassis fpc pic-status**

(SRX5400, SRX5600, and SRX5800 devices with SRX5K-MPC3-100G10G (IOC3) or SRX5K-MPC3-40G10G (IOC3 and when Express Path [formerly known as services offloading] is configured)

```
user@host> show chassis fpc pic-status
Slot 0 Offline SRX5k DPC 40x 1GE
Slot 1 Online SRX5k SPC II
 PIC 0 Online SPU Cp
 PIC 1 Online SPU Flow
 PIC 2 Online SPU Flow
 PIC 3 Online SPU Flow
Slot 2 Offline SRX5k SPC
Slot 4 Online SRX5k IOC3 24XGE+6XLG
 PIC 2 Online 3x 40GE QSFP+- np-cache/services-offload
 PIC 3 Online 3x 40GE QSFP+- np-cache/services-offload
Slot 5 Online SRX5k IOC II
 PIC 0 Online 10x 1GE(LAN) SFP- np-cache/services-offload
 PIC 1 Online 10x 1GE(LAN) SFP- np-cache/services-offload
 PIC 2 Online 10x 10GE SFP+- np-cache/services-offload
```

**Sample Output**

**show chassis fpc pic-status for HA (SRX3400 and SRX3600 devices)**

```
user@host> show chassis fpc pic-status
node0:

Slot 0 Online SRX3k SFB 12GE
 PIC 0 Online 8x 1GE-TX 4x 1GE-SFP
Slot 1 Online SRX3k 2x10GE XFP
 PIC 0 Online 2x 10GE-XFP
Slot 2 Online SRX3k 16xGE SFP
 PIC 0 Online 16x 1GE-SFP
Slot 7 Online SRX3k SPC
 PIC 0 Online SPU Cp-Flow
Slot 11 Online SRX3k NPC
 PIC 0 Online NPC PIC
Slot 12 Online SRX3k NPC
 PIC 0 Online NPC PIC

node1:

Slot 0 Online SRX3k SFB 12GE
 PIC 0 Online 8x 1GE-TX 4x 1GE-SFP
Slot 1 Online SRX3k 2x10GE XFP
 PIC 0 Online 2x 10GE-XFP
Slot 2 Online SRX3k 16xGE SFP
 PIC 0 Online 16x 1GE-SFP
Slot 7 Online SRX3k SPC
 PIC 0 Online SPU Cp-Flow
Slot 11 Online SRX3k NPC
 PIC 0 Online NPC PIC
Slot 12 Online SRX3k NPC
 PIC 0 Online NPC PIC
```

## Sample Output

show chassis fpc pic-status for HA (SRX5600 and SRX5800 devices)

```
user@host> show chassis fpc pic-status
```

```
node0:
```

```

Slot 4 Online SRX5k DPC 40x 1GE
PIC 0 Online 10x 1GE RichQ
PIC 1 Online 10x 1GE RichQ
PIC 2 Online 10x 1GE RichQ
PIC 3 Online 10x 1GE RichQ
Slot 5 Online SRX5k SPC
PIC 0 Online SPU Cp-Flow
PIC 1 Online SPU Flow
```

```
node1:
```

```

Slot 4 Online SRX5k DPC 40x 1GE
PIC 0 Online 10x 1GE RichQ
PIC 1 Online 10x 1GE RichQ
PIC 2 Online 10x 1GE RichQ
PIC 3 Online 10x 1GE RichQ
Slot 5 Online SRX5k SPC
PIC 0 Online SPU Cp-Flow
PIC 1 Online SPU Flow
```

show chassis fpc pic-status for HA

(SRX5400, SRX5600, and SRX5800 devices with SRX5K-MPC3-100G10G (IOC3) or SRX5K-MPC3-40G10G (IOC3))

```
user@host> show chassis fpc pic-status
```

```
user@host> show chassis fpc pic-status
```

```
node0:
```

```

Slot 2 Online SRX5k IOC3 24XGE+6XLG
PIC 0 Online 12x 10GE SFP+
PIC 1 Online 12x 10GE SFP+
PIC 2 Offline 3x 40GE QSFP+
PIC 3 Offline 3x 40GE QSFP+
Slot 4 Online SRX5k IOC II
PIC 2 Online 10x 10GE SFP+
Slot 5 Online SRX5k SPC II
PIC 0 Online SPU Cp
PIC 1 Online SPU Flow
PIC 2 Offline
PIC 3 Offline
```

```
node1:
```

```

Slot 2 Online SRX5k IOC3 24XGE+6XLG
PIC 0 Online 12x 10GE SFP+
PIC 1 Online 12x 10GE SFP+
PIC 2 Offline 3x 40GE QSFP+
PIC 3 Offline 3x 40GE QSFP+
Slot 4 Online SRX5k IOC II
PIC 2 Online 10x 10GE SFP+
Slot 5 Online SRX5k SPC II
PIC 0 Online SPU Cp
PIC 1 Online SPU Flow
```

```
PIC 2 Offline
PIC 3 Offline
```

## show chassis hardware (View)

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show chassis hardware</b><br><clei-models   detail   extensive   models   node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Release Information</b>      | Command introduced in Junos OS Release 9.2. Command modified in Junos OS Release 9.2 to include <b>node</b> option.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Description</b>              | Display chassis hardware information.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>clei-models</b>—(Optional) Display Common Language Equipment Identifier Code (CLEI) barcode and model number for orderable field-replaceable units (FRUs).</li> <li>• <b>detail   extensive</b>—(Optional) Display the specified level of output.</li> <li>• <b>models</b>—(Optional) Display model numbers and part numbers for orderable FRUs.</li> <li>• <b>node</b>—(Optional) For chassis cluster configurations, display chassis hardware information on a specific node (device) in the cluster. <ul style="list-style-type: none"> <li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> </li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">Interface Naming Conventions</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Output Fields</b>            | <a href="#">Table 24 on page 274</a> lists the output fields for the <b>show chassis hardware</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

Table 24: show chassis hardware Output Fields

| Field Name             | Field Description                                                                                                                                                                                                                       |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Item                   | Chassis component—Information about the backplane; power supplies; fan trays; Routing Engine; each Physical Interface Module (PIM)—reported as FPC and PIC—and each fan, blower, and impeller.                                          |
| Version                | Revision level of the chassis component.                                                                                                                                                                                                |
| Part Number            | Part number for the chassis component.                                                                                                                                                                                                  |
| Serial Number          | Serial number of the chassis component. The serial number of the backplane is also the serial number of the device chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the device chassis. |
| Assb ID or Assembly ID | Identification number that describes the FRU hardware.                                                                                                                                                                                  |



Table 24: show chassis hardware Output Fields (*continued*)

| Field Name       | Field Description                                                                                                                                                                                      |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FRU model number | Model number of FRU hardware component.                                                                                                                                                                |
| CLEI code        | Common Language Equipment Identifier code. This value is displayed only for hardware components that use ID EEPROM format v2. This value is not displayed for components that use ID EEPROM format v1. |
| EEPROM Version   | ID EEPROM version used by hardware component: 0x01 (version 1) or 0x02 (version 2).                                                                                                                    |

Table 24: show chassis hardware Output Fields (*continued*)

| Field Name  | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | <p>Brief description of the hardware item:</p> <ul style="list-style-type: none"> <li>Type of power supply.</li> <li>Switch Control Board (SCB)</li> </ul> <p>Starting with Junos OS Release 12.1X47-D15, the SRX5K-SCBE (SCB2) is introduced.</p> <ul style="list-style-type: none"> <li>There are three SCB slots in SRX5800 devices. The third slot can be used for an SCB or an FPC. When an SRX5K-SCB was used, the third SCB slot was used as an FPC. SCB redundancy is provided in chassis cluster mode.</li> <li>With an SCB2, a third SCB is supported. If a third SCB is plugged in, it provides intra-chassis fabric redundancy.</li> <li>The Ethernet switch in the SCB2 provides the Ethernet connectivity among all the FPCs and the Routing Engine. The Routing Engine uses this connectivity to distribute forwarding and routing tables to the FPCs. The FPCs use this connectivity to send exception packets to the Routing Engine.</li> <li>Fabric connects all FPCs in the data plane. The Fabric Manager executes on the Routing Engine and controls the fabric system in the chassis. Packet Forwarding Engines on the FPC and fabric planes on the SCB are connected through HSL2 channels.</li> <li>SCB2 supports HSL2 with both 3.11 Gbps and 6.22 Gbps (SerDes) link speed and various HSL2 modes. When an FPC is brought online, the link speed and HSL2 mode are determined by the type of FPC.</li> </ul> <p>Starting with Junos OS Release 15.1X49-D10, the SRX5K-SCB3 (SCB3) with enhanced midplanes is introduced.</p> <ul style="list-style-type: none"> <li>All existing SCB software that is supported by SCB2 is supported on SCB3.</li> <li>SRX5K-RE-1800X4 (RE2). Mixed Routing Engine use is not supported.</li> <li>SCB3 works with the SRX5K-MPC (IOC2), SRX5K-MPC3-100G10G (IOC3), SRX5K-MPC3-40G10G (IOC3), and SRX5K-SPC-4-15-320 (SPC2) with current midplanes and the new enhanced midplanes.</li> <li>Mixed SCB use is not supported. If an SCB2 and an SCB3 are used, the system will only power on the master Routing Engine's SCB and will power off the other SCBs. Only the SCB in slot 0 will be powered on and a system log is generated.</li> <li>SCB3 supports up to 400 Gbps per slot with old midplanes and up to 500 Gbps per slot with new midplanes.</li> <li>SCB3 supports fabric intra-chassis redundancy.</li> <li>SCB3 supports the same chassis cluster function as the SRX5K-SCB (SCB1) and the SRX5K-SCBE (SCB2), except for in-service software upgrade (ISSU) and in-service hardware upgrade (ISHU).</li> <li>SCB3 has a second external Ethernet port.</li> <li>Fabric bandwidth increasing mode is not supported.</li> </ul> |

Table 24: show chassis hardware Output Fields (*continued*)

| Field Name | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|            | <ul style="list-style-type: none"> <li>Type of Flexible PIC Concentrator (FPC), Physical Interface Card (PIC), Modular Interface Cards (MICs), and PIMs.</li> <li>IOCs           <p>Starting with Junos OS Release 15.1X49-D10, the SRX5K-MPC3-100G10G (IOC3) and the SRX5K-MPC3-40G10G (IOC3) are introduced.</p> <ul style="list-style-type: none"> <li>IOC3 has two types of IOC3 MPCs, which have different built-in MICs: the 24x10GE + 6x40GE MPC and the 2x100GE + 4x10GE MPC.</li> <li>IOC3 supports SCB3 and SRX5000 line backplane and enhanced backplane.</li> <li>IOC3 can only work with SRX5000 line SCB2 and SCB3. If an SRX5000 line SCB is detected, IOC3 will be offline, an FPC misconfiguration alarm will be raised, and a system log message is generated.</li> <li>IOC3 interoperates with SCB2 and SCB3.</li> <li>IOC3 interoperates with the SRX5K-SPC-4-15-320 (SPC2) and the SRX5K-MPC (IOC2).</li> <li>The maximum power consumption for one IOC3 is 645W. An enhanced power module must be used.</li> <li>The IOC3 does not support the following command to set a PIC to go offline or online:<br/> <b>request chassis pic fpc-slot &lt;fpc-slot&gt; pic-slot &lt;pic-slot&gt; &lt;offline   online&gt; .</b> </li> <li>IOC3 supports 240 Gbps of throughput with the enhanced SRX5000 line backplane.</li> <li>Chassis cluster functions the same as for the SRX5000 line IOC2.</li> <li>IOC3 supports intra-chassis and inter-chassis fabric redundancy mode.</li> <li>IOC3 supports ISSU and ISHU in chassis cluster mode.</li> <li>IOC3 supports intra-FPC and Inter-FPC Express Path (previously known as <i>services offloading</i>) with IPv4.</li> <li>NAT of IPv4 and IPv6 in normal mode and IPv4 for Express Path mode.</li> <li>All four PICs on the 24x10GE + 6x40GE cannot be powered on. A maximum of two PICs can be powered on at the same time.<br/>           Use the <b>set chassis fpc &lt;slot&gt; pic &lt;pic&gt; power off</b> command to choose the PICs you want to power on.</li> </ul> <p><b>NOTE:</b> Fabric bandwidth increasing mode is not supported on IOC3.</p> </li> <li>SRX Clustering Module (SCM)</li> <li>Fan tray</li> <li>For hosts, the Routing Engine type.           <ul style="list-style-type: none"> <li>Starting with Junos OS Release 12.1X47-D15, the SRX5K-RE-1800X4 (RE2) Routing Engine is introduced.</li> <li>The RE2 has an Intel Quad core Xeon processor, 16 GB of DRAM, and a 128-GB solid-state drive (SSD).<br/>           The number 1800 refers to the speed of the processor (1.8 GHz). The maximum required power for this Routing Engine is 90W.</li> </ul> <p><b>NOTE:</b> The RE2 provides significantly better performance than the previously used Routing Engine, even with a single core.</p> </li> </ul> |

**show chassis hardware****show chassis hardware**

```
user@host> show chassis hardware
```

```
Hardware inventory:
```

| Item             | Version | Part number | Serial number | Description              |
|------------------|---------|-------------|---------------|--------------------------|
| Chassis          |         |             | CM0715AK0021  | SRX1500                  |
| Midplane         | REV 08  | 750-058562  | ACMA4255      | SRX1500                  |
| CB 0             | REV 08  | 711-053838  | ACMA7529      | CPU Board SRX700E        |
| Routing Engine 0 |         | BUILTIN     | BUILTIN       | SRX Routing Engine       |
| FPC 0            | REV 07  | 711-053832  | ACMA3311      | FEB                      |
| PIC 0            |         | BUILTIN     | BUILTIN       | 12x1G-T-4x1G-SFP-4x10G   |
| Xcvr 12          | REV 01  | 740-014132  | 61521013      | SFP-T                    |
| Xcvr 13          | REV 02  | 740-013111  | A281604       | SFP-T                    |
| Xcvr 14          | REV 02  | 740-011613  | NRN30NV       | SFP-SX                   |
| Xcvr 15          | REV 02  | 740-011613  | NRN2PWV       | SFP-SX                   |
| Xcvr 16          | REV 01  | 740-021308  | AJA17B5       | SFP+-10G-SR              |
| Xcvr 17          | REV 01  | 740-021308  | MSP056B       | SFP+-10G-SR              |
| Xcvr 18          | REV 01  | 740-031980  | AS920WJ       | SFP+-10G-SR              |
| Xcvr 19          | REV 01  | 740-031980  | AS92W5N       | SFP+-10G-SR              |
| Power Supply 0   | REV 01  | 740-055217  | 1EDP42500JZ   | PS 400W 90-264V AC in    |
| Fan Tray 0       |         |             |               | SRX1500 0, Front to Back |
| Airflow - AFO    |         |             |               |                          |
| Fan Tray 1       |         |             |               | SRX1500 1, Front to Back |
| Airflow - AFO    |         |             |               |                          |
| Fan Tray 2       |         |             |               | SRX1500 2, Front to Back |
| Airflow - AFO    |         |             |               |                          |
| Fan Tray 3       |         |             |               | SRX1500 3, Front to Back |
| Airflow - AFO    |         |             |               |                          |

**show chassis hardware (SRX5600 and SRX5800 devices for SRX5K-MPC)**

```
user@host> show chassis hardware
```

```
Hardware inventory:
```

| Item             | Version | Part number | Serial number | Description               |
|------------------|---------|-------------|---------------|---------------------------|
| Chassis          |         |             | JN12170EAAGA  | SRX 5800                  |
| Midplane         | REV 01  | 710-041799  | ACAX3849      | SRX 5800 Backplane        |
| FPM Board        | REV 01  | 710-024632  | CAAX7297      | Front Panel Display       |
| PDM              | Rev 03  | 740-013110  | QCS170250DU   | Power Distribution Module |
| PEM 0            | Rev 03  | 740-034724  | QCS17020203F  | PS 4.1kW; 200-240V AC in  |
| PEM 1            | Rev 03  | 740-034724  | QCS17020203C  | PS 4.1kW; 200-240V AC in  |
| PEM 2            | Rev 04  | 740-034724  | QCS17100200A  | PS 4.1kW; 200-240V AC in  |
| PEM 3            | Rev 03  | 740-034724  | QCS17080200M  | PS 4.1kW; 200-240V AC in  |
| Routing Engine 0 | REV 11  | 740-023530  | 9012047437    | SRX5k RE-13-20            |
| CB 0             | REV 09  | 710-024802  | CAAX7202      | SRX5k SCB                 |
| CB 1             | REV 09  | 710-024802  | CAAX7157      | SRX5k SCB                 |
| FPC 0            | REV 07  | 750-044175  | CAAD0791      | SRX5k SPC II              |
| CPU              |         | BUILTIN     | BUILTIN       | SRX5k DPC PPC             |
| PIC 0            |         | BUILTIN     | BUILTIN       | SPU Cp                    |
| PIC 1            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| PIC 2            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| PIC 3            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| FPC 1            | REV 07  | 750-044175  | CAAD0751      | SRX5k SPC II              |
| CPU              |         | BUILTIN     | BUILTIN       | SRX5k DPC PPC             |
| PIC 0            |         | BUILTIN     | BUILTIN       | SPU Flow                  |

|            |              |            |           |                        |
|------------|--------------|------------|-----------|------------------------|
| PIC 1      |              | BUILTIN    | BUILTIN   | SPU Flow               |
| PIC 2      |              | BUILTIN    | BUILTIN   | SPU Flow               |
| PIC 3      |              | BUILTIN    | BUILTIN   | SPU Flow               |
| FPC 2      | REV 28       | 750-020751 | CAAW1817  | SRX5k DPC 4X 10GE      |
| CPU        | REV 04       | 710-024633 | CAAZ5269  | SRX5k DPC PMB          |
| PIC 0      |              | BUILTIN    | BUILTIN   | 1x 10GE(LAN/WAN) RichQ |
| Xcvr 0     | REV 02       | 740-014289 | T10A00404 | XFP-10G-SR             |
| PIC 1      |              | BUILTIN    | BUILTIN   | 1x 10GE(LAN/WAN) RichQ |
| PIC 2      |              | BUILTIN    | BUILTIN   | 1x 10GE(LAN/WAN) RichQ |
| PIC 3      |              | BUILTIN    | BUILTIN   | 1x 10GE(LAN/WAN) RichQ |
| FPC 6      | REV 02       | 750-044175 | ZY2552    | SRX5k SPC II           |
| CPU        |              | BUILTIN    | BUILTIN   | SRX5k DPC PPC          |
| FPC 9      | REV 10       | 750-044175 | CAAP5932  | SRX5k SPC II           |
| CPU        |              | BUILTIN    | BUILTIN   | SRX5k DPC PPC          |
| PIC 0      |              | BUILTIN    | BUILTIN   | SPU Flow               |
| PIC 1      |              | BUILTIN    | BUILTIN   | SPU Flow               |
| PIC 2      |              | BUILTIN    | BUILTIN   | SPU Flow               |
| PIC 3      |              | BUILTIN    | BUILTIN   | SPU Flow               |
| FPC 10     | REV 22       | 750-043157 | ZH8192    | SRX5k IOC II CPU       |
| REV 08     | 711-043360   | YX3879     |           | SRX5k MPC PMB          |
| MIC 0      | REV 01       | 750-049488 | YZ2084    | 10x 10GE SFP+          |
| PIC 0      |              | BUILTIN    | BUILTIN   | 10x 10GE SFP+          |
| Xcvr 0     | REV 01       | 740-031980 | AMBOHG3   | SFP+-10G-SR            |
| Xcvr 1     | REV 01       | 740-031980 | AM20B6F   | SFP+-10G-SR            |
| MIC 1      | REV 19       | 750-049486 | CAAH3504  | 1x 100GE CFP           |
| PIC 2      |              | BUILTIN    | BUILTIN   | 1x 100GE CFP           |
| Xcvr 0     | REV 01       | 740-035329 | X000D375  | CFP-100G-SR10          |
| FPC 11     | REV 07.04.07 | 750-043157 | CAAJ8771  | SRX5k IOC II CPU       |
| REV 08     | 711-043360   | CAAJ3881   |           | SRX5k MPC PMB          |
| MIC 0      | REV 19       | 750-049486 | CAAH0979  | 1x 100GE CFP           |
| PIC 0      |              | BUILTIN    | BUILTIN   | 1x 100GE CFP           |
| Xcvr 0     | REV 01       | 740-035329 | UP1020Z   | CFP-100G-SR10          |
| MIC 1      | REV 08       | 750-049487 | CAAM1160  | 2x 40GE QSFP+          |
| PIC 2      |              | BUILTIN    | BUILTIN   | 2x 40GE QSFP+          |
| Xcvr 0     | REV 01       | 740-032986 | QB151094  | QSFP+-40G-SR4          |
| Xcvr 1     | REV 01       | 740-032986 | QB160509  | QSFP+-40G-SR4          |
| Fan Tray 0 | REV 04       | 740-035409 | ACAE0875  | Enhanced Fan Tray      |
| Fan Tray 1 | REV 04       | 740-035409 | ACAE0876  | Enhanced Fan Tray      |

### show chassis hardware (with 20-Gigabit Ethernet MIC with SFP)

```
user@host> show chassis hardware
```

```
Hardware inventory:
```

| Item             | Version | Part number | Serial number | Description               |
|------------------|---------|-------------|---------------|---------------------------|
| Chassis          |         |             | JN108DA5AAGA  | SRX 5800                  |
| Midplane         | REV 02  | 710-013698  | TR0037        | SRX 5600 Midplane         |
| FPM Board        | REV 02  | 710-014974  | JY4635        | Front Panel Display       |
| PDM              | Rev 02  | 740-013110  | QCS10465005   | Power Distribution Module |
| PEM 0            | Rev 03  | 740-023514  | QCS11154040   | PS 1.7kW; 200-240VAC in   |
| PEM 2            | Rev 02  | 740-023514  | QCS10504014   | PS 1.7kW; 200-240VAC in   |
| Routing Engine 0 | REV 05  | 740-015113  | 1000681023    | RE-S-1300                 |
| CB 0             | REV 05  | 710-013385  | JY4775        | SRX5k SCB                 |
| FPC 1            | REV 17  | 750-020751  | WZ6349        | SRX5k DPC 4X 10GE         |
| CPU              | REV 02  | 710-024633  | WZ0718        | SRX5k DPC PMB             |
| PIC 0            |         | BUILTIN     | BUILTIN       | 1x 10GE(LAN/WAN) RichQ    |
| Xcvr 0           |         | NON-JNPR    | C724XM088     | XFP-10G-SR                |
| PIC 1            |         | BUILTIN     | BUILTIN       | 1x 10GE(LAN/WAN) RichQ    |
| Xcvr 0           | REV 02  | 740-011571  | C831XJ085     | XFP-10G-SR                |
| PIC 2            |         | BUILTIN     | BUILTIN       | 1x 10GE(LAN/WAN) RichQ    |
| PIC 3            |         | BUILTIN     | BUILTIN       | 1x 10GE(LAN/WAN) RichQ    |
| FPC 3            | REV 22  | 750-043157  | ZH8189        | SRX5k IOC II              |

|            |        |            |          |                  |
|------------|--------|------------|----------|------------------|
| CPU        | REV 06 | 711-043360 | YX3912   | SRX5k MPC PMB    |
| MIC 0      | REV 01 | 750-055732 | CACF9115 | 20x 1GE(LAN) SFP |
| PIC 0      |        | BUILTIN    | BUILTIN  | 10x 1GE(LAN) SFP |
| Xcvr 2     | REV 02 | 740-013111 | B358549  | SFP-T            |
| Xcvr 9     | REV 02 | 740-011613 | PNB1FQS  | SFP-SX           |
| PIC 1      |        | BUILTIN    | BUILTIN  | 10x 1GE(LAN) SFP |
| Xcvr 9     | REV 02 | 740-011613 | PNB1FFF  | SFP-SX           |
| FPC 5      | REV 01 | 750-027945 | JW9665   | SRX5k FIOC       |
| CPU        |        |            |          |                  |
| FPC 8      | REV 08 | 750-023996 | XA7234   | SRX5k SPC        |
| CPU        | REV 02 | 710-024633 | XA1599   | SRX5k DPC PMB    |
| PIC 0      |        | BUILTIN    | BUILTIN  | SPU Cp-Flow      |
| PIC 1      |        | BUILTIN    | BUILTIN  | SPU Flow         |
| Fan Tray 0 | REV 03 | 740-014971 | TP0902   | Fan Tray         |
| Fan Tray 1 | REV 01 | 740-014971 | TP0121   | Fan Tray         |

**show chassis hardware**

(SRX5600 and SRX5800 devices with SRX5000 line SRX5K-SCBE (SCB2) and SRX5K-RE-1800X4 (RE2))

user@host&gt; show chassis hardware

node0:

-----  
Hardware inventory:

| Item             | Version | Part number | Serial number | Description             |
|------------------|---------|-------------|---------------|-------------------------|
| Chassis          |         |             | JN122A040AGA  | SRX5800                 |
| Midplane         | REV 01  | 710-041799  | ACRA7817      | SRX5800 Backplane       |
| FPM Board        | REV 01  | 760-058099  | CACA2100      | Front Panel Display     |
| PDM              | Rev 03  | 740-013110  | QCS1739517Z   | Power Distribution Modu |
| le               |         |             |               |                         |
| PEM 0            | Rev 05  | 740-034724  | QCS17460203K  | PS 4.1kW; 200-240V AC i |
| n                |         |             |               |                         |
| PEM 1            | Rev 04  | 740-034724  | QCS172302017  | PS 4.1kW; 200-240V AC i |
| n                |         |             |               |                         |
| Routing Engine 0 | REV 01  | 740-056658  | 9013040855    | SRX5k RE-1800X4         |
| Routing Engine 1 |         |             |               |                         |
| CB 0             | REV 01  | 750-056587  | CACG1424      | SRX5k SCB II            |
| CB 1             | REV 01  | 750-056587  | CACC9307      | SRX5k SCB II            |
| CB 2             | REV 01  | 750-056587  | CAAZ1128      | SRX5k SCB II            |
| FPC 0            | REV 10  | 750-056758  | CACS2667      | SRX5k SPC II            |
| CPU              |         | BUILTIN     | BUILTIN       | SRX5k DPC PPC           |
| PIC 0            |         | BUILTIN     | BUILTIN       | SPU Cp                  |
| PIC 1            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| PIC 2            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| PIC 3            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| FPC 1            | REV 18  | 750-054877  | CACH4092      | SRX5k SPC II            |
| CPU              |         | BUILTIN     | BUILTIN       | SRX5k DPC PPC           |
| PIC 0            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| PIC 1            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| PIC 2            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| PIC 3            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| FPC 2            | REV 10  | 750-056758  | CACV0038      | SRX5k SPC II            |
| CPU              |         | BUILTIN     | BUILTIN       | SRX5k DPC PPC           |
| PIC 0            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| PIC 1            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| PIC 2            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| PIC 3            |         | BUILTIN     | BUILTIN       | SPU Flow                |
| FPC 3            | REV 10  | 750-043157  | CACB6877      | SRX5k IOC II            |
| CPU              | REV 04  | 711-043360  | CACH6074      | SRX5k MPC PMB           |

|            |        |            |             |                   |
|------------|--------|------------|-------------|-------------------|
| MIC 0      | REV 19 | 750-049486 | CAAH3504    | 1x 100GE CFP      |
| PIC 0      |        | BUILTIN    | BUILTIN     | 1x 100GE CFP      |
| Xcvr 0     | REV 01 | 740-035329 | UP1020Z     | CFP-100G-SR10     |
| MIC 1      | REV 04 | 750-049488 | CACB6429    | 10x 10GE SFP+     |
| PIC 2      |        | BUILTIN    | BUILTIN     | 10x 10GE SFP+     |
| Xcvr 0     | REV 01 | 740-031980 | AP21RJ5     | SFP+-10G-SR       |
| Xcvr 1     | REV 01 | 740-031980 | AP21RLJ     | SFP+-10G-SR       |
| Xcvr 2     | REV 01 | 740-030658 | AD1148A0AYC | SFP+-10G-USR      |
| Xcvr 3     | REV 01 | 740-031980 | B11E02718   | SFP+-10G-SR       |
| FPC 4      | REV 10 | 750-056758 | CACW0706    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| FPC 7      | REV 10 | 750-056758 | CACS2725    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| FPC 8      | REV 11 | 750-043157 | CABN4955    | SRX5k IOC II      |
| CPU        | REV 04 | 711-043360 | CACT9926    | SRX5k MPC PMB     |
| MIC 0      | REV 19 | 750-049486 | CAAH0979    | 1x 100GE CFP      |
| PIC 0      |        | BUILTIN    | BUILTIN     | 1x 100GE CFP      |
| Xcvr 0     | REV 01 | 740-035329 | UP2077V     | CFP-100G-SR10     |
| FPC 9      | REV 10 | 750-056758 | CACW0755    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| FPC 10     | REV 07 | 750-044175 | CAAD0747    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| Fan Tray 0 | REV 04 | 740-035409 | ACAE2294    | Enhanced Fan Tray |
| Fan Tray 1 | REV 04 | 740-035409 | ACAE2099    | Enhanced Fan Tray |

node1:

-----  
Hardware inventory:

| Item             | Version | Part number | Serial number | Description               |
|------------------|---------|-------------|---------------|---------------------------|
| Chassis          |         |             | JN1235BC7AGA  | SRX5800                   |
| Midplane         | REV 01  | 710-024803  | ACRC3244      | SRX5800 Backplane         |
| FPM Board        | REV 01  | 710-024632  | CACA2108      | Front Panel Display       |
| PDM              | Rev 03  | 740-013110  | QCS1739519B   | Power Distribution Module |
| PEM 0            | Rev 04  | 740-034724  | QCS17230201Z  | PS 4.1kW; 200-240V AC     |
| in               |         |             |               |                           |
| PEM 1            | Rev 05  | 740-034724  | QCS174502014  | PS 4.1kW; 200-240V AC     |
| in               |         |             |               |                           |
| Routing Engine 0 | REV 01  | 740-056658  | 9009153221    | SRX5k RE-1800X4           |
| Routing Engine 1 |         |             |               |                           |
| CB 0             | REV 01  | 750-056587  | CACC9541      | SRX5k SCB II              |
| CB 1             | REV 01  | 750-056587  | CACG1447      | SRX5k SCB II              |
| CB 2             | REV 01  | 750-056587  | CACH9058      | SRX5k SCB II              |
| FPC 0            | REV 18  | 750-054877  | CACH4004      | SRX5k SPC II              |
| CPU              |         | BUILTIN     | BUILTIN       | SRX5k DPC PPC             |
| PIC 0            |         | BUILTIN     | BUILTIN       | SPU Cp                    |
| PIC 1            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| PIC 2            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| PIC 3            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| FPC 1            | REV 18  | 750-054877  | CACH4082      | SRX5k SPC II              |

|            |        |            |          |                   |
|------------|--------|------------|----------|-------------------|
| CPU        |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| FPC 2      | REV 10 | 750-056758 | CACW0713 | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| FPC 3      | REV 11 | 750-043157 | CACA8792 | SRX5k IOC II      |
| CPU        | REV 04 | 711-043360 | CACA8809 | SRX5k MPC PMB     |
| MIC 0      | REV 19 | 750-049486 | CAAH3485 | 1x 100GE CFP      |
| PIC 0      |        | BUILTIN    | BUILTIN  | 1x 100GE CFP      |
| Xcvr 0     | REV 01 | 740-035329 | UNMOG3C  | CFP-100G-SR10     |
| MIC 1      | REV 04 | 750-049488 | CABX0782 | 10x 10GE SFP+     |
| PIC 2      |        | BUILTIN    | BUILTIN  | 10x 10GE SFP+     |
| Xcvr 0     | REV 01 | 740-031980 | AMBOHX3  | SFP+-10G-SR       |
| Xcvr 1     | REV 01 | 740-031980 | ANT0E6V  | SFP+-10G-SR       |
| Xcvr 2     | REV 01 | 740-031980 | ANR0ZVY  | SFP+-10G-SR       |
| Xcvr 3     | REV 01 | 740-031980 | AP308ZU  | SFP+-10G-SR       |
| FPC 4      | REV 10 | 750-044175 | CAAS8024 | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 1      |        |            |          |                   |
| PIC 2      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| FPC 7      | REV 10 | 750-056758 | CACS5126 | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| FPC 8      | REV 11 | 750-043157 | CACA8798 | SRX5k IOC II      |
| CPU        | REV 04 | 711-043360 | CACA8826 | SRX5k MPC PMB     |
| MIC 0      | REV 19 | 750-049486 | CAAH0996 | 1x 100GE CFP      |
| PIC 0      |        | BUILTIN    | BUILTIN  | 1x 100GE CFP      |
| Xcvr 0     | REV 01 | 740-035329 | UP30A6N  | CFP-100G-SR10     |
| FPC 9      | REV 07 | 750-044175 | CAAD0745 | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| FPC 10     | REV 18 | 750-054877 | CACD2570 | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| Fan Tray 0 | REV 04 | 740-035409 | ACAE2122 | Enhanced Fan Tray |
| Fan Tray 1 | REV 04 | 740-035409 | ACAE2254 | Enhanced Fan Tray |

**show chassis hardware**

(SRX5400, SRX5600, and SRX5800 devices with SRX5000 line SRX5K-SCB3 (SCB3) with enhanced midplanes and SRX5K-MPC3-100G10G (IOC3) or SRX5K-MPC3-40G10G (IOC3))

```
user@host> show chassis hardware
node0:
```

```

Hardware inventory:
```

| Item     | Version | Part number | Serial number | Description               |
|----------|---------|-------------|---------------|---------------------------|
| Chassis  |         |             | JN1250870AGB  | SRX5600                   |
| Midplane | REV 01  | 760-063936  | ACRE2578      | Enhanced SRX5600 Midplane |



|                  |        |            |                |                         |
|------------------|--------|------------|----------------|-------------------------|
| FPM Board        | REV 02 | 710-017254 | KD9027         | Front Panel Display     |
| PEM 0            | Rev 03 | 740-034701 | QCS13090900T   | PS 1.4-2.6kW; 90-264V A |
| C in             |        |            |                |                         |
| PEM 1            | Rev 03 | 740-034701 | QCS13090904T   | PS 1.4-2.6kW; 90-264V A |
| C in             |        |            |                |                         |
| Routing Engine 0 | REV 01 | 740-056658 | 9009196496     | SRX5k RE-1800X4         |
| CB 0             | REV 01 | 750-062257 | CAEC2501       | SRX5k SCB3              |
| FPC 0            | REV 10 | 750-056758 | CADC8067       | SRX5k SPC II            |
| CPU              |        | BUILTIN    | BUILTIN        | SRX5k DPC PPC           |
| PIC 0            |        | BUILTIN    | BUILTIN        | SPU Cp                  |
| PIC 1            |        | BUILTIN    | BUILTIN        | SPU Flow                |
| PIC 2            |        | BUILTIN    | BUILTIN        | SPU Flow                |
| PIC 3            |        | BUILTIN    | BUILTIN        | SPU Flow                |
| FPC 2            | REV 01 | 750-062243 | CAEE5924       | SRX5k IOC3 24XGE+6XLG   |
| CPU              | REV 01 | 711-062244 | CAEB4890       | SRX5k IOC3 PMB          |
| PIC 0            |        | BUILTIN    | BUILTIN        | 12x 10GE SFP+           |
| PIC 1            |        | BUILTIN    | BUILTIN        | 12x 10GE SFP+           |
| PIC 2            |        | BUILTIN    | BUILTIN        | 3x 40GE QSFP+           |
| Xcvr 0           | REV 01 | 740-038623 | MOC13156230449 | QSFP+-40G-CU1M          |
| Xcvr 2           | REV 01 | 740-038623 | MOC13156230449 | QSFP+-40G-CU1M          |
| PIC 3            |        | BUILTIN    | BUILTIN        | 3x 40GE QSFP+           |
| WAN MEZZ         | REV 01 | 750-062682 | CAEE5817       | 24x 10GE SFP+ Mezz      |
| FPC 4            | REV 11 | 750-043157 | CACY1595       | SRX5k IOC II            |
| CPU              | REV 04 | 711-043360 | CACZ8879       | SRX5k MPC PMB           |
| MIC 1            | REV 04 | 750-049488 | CACM6062       | 10x 10GE SFP+           |
| PIC 2            |        | BUILTIN    | BUILTIN        | 10x 10GE SFP+           |
| Xcvr 7           | REV 01 | 740-021308 | AD1439301TU    | SFP+-10G-SR             |
| Xcvr 8           | REV 01 | 740-021308 | AD1439301SD    | SFP+-10G-SR             |
| Xcvr 9           | REV 01 | 740-021308 | AD1439301TS    | SFP+-10G-SR             |
| FPC 5            | REV 05 | 750-044175 | ZZ1371         | SRX5k SPC II            |
| CPU              |        | BUILTIN    | BUILTIN        | SRX5k DPC PPC           |
| PIC 0            |        | BUILTIN    | BUILTIN        | SPU Flow                |
| PIC 1            |        | BUILTIN    | BUILTIN        | SPU Flow                |
| PIC 2            |        | BUILTIN    | BUILTIN        | SPU Flow                |
| PIC 3            |        | BUILTIN    | BUILTIN        | SPU Flow                |
| Fan Tray         |        |            |                | Enhanced Fan Tray       |

node1:

-----  
Hardware inventory:

| Item             | Version | Part number | Serial number | Description               |
|------------------|---------|-------------|---------------|---------------------------|
| Chassis          |         |             | JN124FEC0AGB  | SRX5600                   |
| Midplane         | REV 01  | 760-063936  | ACRE2946      | Enhanced SRX5600 Midplane |
| FPM Board        | test    | 710-017254  | test          | Front Panel Display       |
| PEM 0            | Rev 01  | 740-038514  | QCS114111003  | DC 2.6kW Power Entry      |
| Module           |         |             |               |                           |
| PEM 1            | Rev 01  | 740-038514  | QCS12031100J  | DC 2.6kW Power Entry      |
| Module           |         |             |               |                           |
| Routing Engine 0 | REV 01  | 740-056658  | 9009186342    | SRX5k RE-1800X4           |
| CB 0             | REV 01  | 750-062257  | CAEB8178      | SRX5k SCB3                |
| FPC 0            | REV 07  | 750-044175  | CAAD0769      | SRX5k SPC II              |
| CPU              |         | BUILTIN     | BUILTIN       | SRX5k DPC PPC             |
| PIC 0            |         | BUILTIN     | BUILTIN       | SPU Cp                    |
| PIC 1            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| PIC 2            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| PIC 3            |         | BUILTIN     | BUILTIN       | SPU Flow                  |
| FPC 4            | REV 11  | 750-043157  | CACY1592      | SRX5k IOC II              |

|          |        |            |          |                   |
|----------|--------|------------|----------|-------------------|
| CPU      | REV 04 | 711-043360 | CACZ8831 | SRX5k MPC PMB     |
| MIC 1    | REV 04 | 750-049488 | CACN0239 | 10x 10GE SFP+     |
| PIC 2    |        | BUILTIN    | BUILTIN  | 10x 10GE SFP+     |
| Xcvr 7   | REV 01 | 740-031980 | ARN23HW  | SFP+-10G-SR       |
| Xcvr 8   | REV 01 | 740-031980 | ARN2FVW  | SFP+-10G-SR       |
| Xcvr 9   | REV 01 | 740-031980 | ARN2YVM  | SFP+-10G-SR       |
| FPC 5    | REV 10 | 750-056758 | CADA8736 | SRX5k SPC II      |
| CPU      |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| PIC 0    |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 1    |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 2    |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 3    |        | BUILTIN    | BUILTIN  | SPU Flow          |
| Fan Tray |        |            |          | Enhanced Fan Tray |

## show chassis hardware models

### show chassis hardware models (SRX1400 and SRX3000 line devices)

```

user@host> show chassis hardware models
Hardware inventory:
Item Version Part number Serial number FRU model number
Midplane REV 07 710-020310 VP8136 SRX3600-CHAS
PEM 0 rev 05 740-027644 G087E6003S05P AC Power Supply
PEM 1 rev 05 740-027644 G087E600AT05P AC Power Supply
CB 0 REV 11 750-021914 AAC9887 SRX3K-RE-12-10
Routing Engine
 CPP BUILTIN BUILTIN
FPC 0 REV 11 750-021882 AAAD9785 SRX3K-SFB-12GE
FPC 1 REV 10 750-016077 AAAE9989 SRX3K-SPC-1-10-40
FPC 2 REV 11 750-016077 AAAT8490 SRX3K-SPC-1-10-40
FPC 5 REV 15 750-020321 AAB83820 SRX3K-2XGE-XFP
FPC 10 REV 12 750-043828 AAAD9501 SRX1K3K-NP-2XGE-SFPP
Fan Tray 0 REV 06 750-021599 VR9734 SRX3600-FAN

```

## show chassis hardware models

### (SRX5600 and SRX5800 devices with SRX5000 line SRX5K-SCBE (SCB2) and SRX5K-RE-1800X4 (RE2))

```

user@host> show chassis hardware models
node0:

Hardware inventory:
Item Version Part number Serial number FRU model number
FPM Board REV 01 760-058099 CACA2100 SRX5800E-CRAFT
PEM 0 Rev 05 740-034724 QCS17460203K SRX5800-PWR-4100-AC
PEM 1 Rev 04 740-034724 QCS172302017 SRX5800-PWR-4100-AC
Routing Engine 0 REV 01 740-056658 9013040855 SRX5K-RE-1800X4
CB 0 REV 01 750-056587 CACG1424 SRX5K-SCBE
CB 1 REV 01 750-056587 CACC9307 SRX5K-SCBE
CB 2 REV 01 750-056587 CAAZ1128 SRX5K-SCBE
FPC 0 REV 10 750-056758 CACS2667 SRX5K-SPC-4-15-320
CPU BUILTIN BUILTIN
FPC 1 REV 18 750-054877 CACH4092 SRX5K-SPC-4-15-320
CPU BUILTIN BUILTIN
FPC 2 REV 10 750-056758 CACV0038 SRX5K-SPC-4-15-320
CPU BUILTIN BUILTIN
FPC 3 REV 10 750-043157 CACB6877 SRX5K-MPC
MIC 0 REV 19 750-049486 CAAH3504 SRX-MIC-1X100G-CFP
MIC 1 REV 04 750-049488 CACB6429 SRX-MIC-10XG-SFPP
FPC 4 REV 10 750-056758 CACW0706 SRX5K-SPC-4-15-320
CPU BUILTIN BUILTIN
FPC 7 REV 10 750-056758 CACS2725 SRX5K-SPC-4-15-320

```

|            |        |            |          |                    |
|------------|--------|------------|----------|--------------------|
| CPU        |        | BUILTIN    | BUILTIN  |                    |
| FPC 8      | REV 11 | 750-043157 | CABN4955 | SRX5K-MPC          |
| MIC 0      | REV 19 | 750-049486 | CAAH0979 | SRX-MIC-1X100G-CFP |
| FPC 9      | REV 10 | 750-056758 | CACW0755 | SRX5K-SPC-4-15-320 |
| CPU        |        | BUILTIN    | BUILTIN  |                    |
| FPC 10     | REV 07 | 750-044175 | CAAD0747 | 750-044175         |
| CPU        |        | BUILTIN    | BUILTIN  |                    |
| Fan Tray 0 | REV 04 | 740-035409 | ACAE2294 | SRX5800-HC-FAN     |
| Fan Tray 1 | REV 04 | 740-035409 | ACAE2099 | SRX5800-HC-FAN     |

node1:

-----  
Hardware inventory:

| Item             | Version | Part number | Serial number | FRU model number    |
|------------------|---------|-------------|---------------|---------------------|
| Midplane         | REV 01  | 710-024803  | ACRC3244      | SRX5800-BP-A        |
| FPM Board        | REV 01  | 710-024632  | CACA2108      | SRX5800-CRAFT-A     |
| PEM 0            | Rev 04  | 740-034724  | QCS17230201Z  | SRX5800-PWR-4100-AC |
| PEM 1            | Rev 05  | 740-034724  | QCS174502014  | SRX5800-PWR-4100-AC |
| Routing Engine 0 | REV 01  | 740-056658  | 9009153221    | SRX5K-RE-1800X4     |
| CB 0             | REV 01  | 750-056587  | CACC9541      | SRX5K-SCBE          |
| CB 1             | REV 01  | 750-056587  | CACG1447      | SRX5K-SCBE          |
| CB 2             | REV 01  | 750-056587  | CACH9058      | SRX5K-SCBE          |
| FPC 0            | REV 18  | 750-054877  | CACH4004      | SRX5K-SPC-4-15-320  |
| CPU              |         | BUILTIN     | BUILTIN       |                     |
| FPC 1            | REV 18  | 750-054877  | CACH4082      | SRX5K-SPC-4-15-320  |
| CPU              |         | BUILTIN     | BUILTIN       |                     |
| FPC 2            | REV 10  | 750-056758  | CACW0713      | SRX5K-SPC-4-15-320  |
| CPU              |         | BUILTIN     | BUILTIN       |                     |
| FPC 3            | REV 11  | 750-043157  | CACA8792      | SRX5K-MPC           |
| MIC 0            | REV 19  | 750-049486  | CAAH3485      | MIC3-3D-1X100GE-CFP |
| MIC 1            | REV 04  | 750-049488  | CABX0782      | SRX-MIC-10XG-SFPP   |
| FPC 4            | REV 10  | 750-044175  | CAAS8024      | SRX5K-SPC-4-15-320  |
| CPU              |         | BUILTIN     | BUILTIN       |                     |
| FPC 7            | REV 10  | 750-056758  | CACS5126      | SRX5K-SPC-4-15-320  |
| CPU              |         | BUILTIN     | BUILTIN       |                     |
| FPC 8            | REV 11  | 750-043157  | CACA8798      | SRX5K-MPC           |
| MIC 0            | REV 19  | 750-049486  | CAAH0996      | MIC3-3D-1X100GE-CFP |
| FPC 9            | REV 07  | 750-044175  | CAAD0745      | 750-044175          |
| CPU              |         | BUILTIN     | BUILTIN       |                     |
| FPC 10           | REV 18  | 750-054877  | CACD2570      | SRX5K-SPC-4-15-320  |
| CPU              |         | BUILTIN     | BUILTIN       |                     |
| Fan Tray 0       | REV 04  | 740-035409  | ACAE2122      | SRX5800-HC-FAN      |
| Fan Tray 1       | REV 04  | 740-035409  | ACAE2254      | SRX5800-HC-FAN      |

show chassis hardware models

(SRX5400, SRX5600, and SRX5800 devices with SRX5000 line SRX5K-SCB3 (SCB3) with enhanced midplanes and SRX5K-MPC3-100G10G (IOC3) or SRX5K-MPC3-40G10G (IOC3))

user@host> show chassis hardware models

node0:

-----  
Hardware inventory:

| Item             | Version | Part number | Serial number | FRU model number      |
|------------------|---------|-------------|---------------|-----------------------|
| Midplane         | REV 01  | 760-063936  | ACRE2578      | SRX5600X-CHAS         |
| FPM Board        | REV 02  | 710-017254  | KD9027        | CRAFT-MX480-S         |
| PEM 0            | Rev 03  | 740-034701  | QCS13090900T  | SRX5600-PWR-2520-AC-S |
| PEM 1            | Rev 03  | 740-034701  | QCS13090904T  | SRX5600-PWR-2520-AC-S |
| Routing Engine 0 | REV 01  | 740-056658  | 9009196496    | SRX5K-RE-1800X4       |
| CB 0             | REV 01  | 750-062257  | CAEC2501      | SRX5K-SCB3            |
| FPC 0            | REV 10  | 750-056758  | CADC8067      | SRX5K-SPC-4-15-320    |
| CPU              |         | BUILTIN     | BUILTIN       |                       |

```

FPC 2 REV 01 750-062243 CAEE5924
FPC 4 REV 11 750-043157 CACY1595 SRX5K-MPC
MIC 1 REV 04 750-049488 CACM6062 SRX-MIC-10XG-SFPP
FPC 5 REV 05 750-044175 ZZ1371 750-044175
CPU BUILTIN BUILTIN
Fan Tray SRX5600-HC-FAN

```

```
node1:
```

```

Hardware inventory:
```

| Item             | Version | Part number | Serial number | FRU model number      |
|------------------|---------|-------------|---------------|-----------------------|
| Midplane         | REV 01  | 760-063936  | ACRE2946      | SRX5600X-CHAS         |
| PEM 0            | Rev 01  | 740-038514  | QCS114111003  | SRX5600-PWR-2400-DC-S |
| PEM 1            | Rev 01  | 740-038514  | QCS12031100J  | SRX5600-PWR-2400-DC-S |
| Routing Engine 0 | REV 01  | 740-056658  | 9009186342    | SRX5K-RE-1800X4       |
| CB 0             | REV 01  | 750-062257  | CAEB8178      | SRX5K-SCB3            |
| FPC 0            | REV 07  | 750-044175  | CAAD0769      | SRX5K-SPC-4-15-320    |
| CPU              |         | BUILTIN     | BUILTIN       |                       |
| FPC 4            | REV 11  | 750-043157  | CACY1592      | SRX5K-MPC             |
| MIC 1            | REV 04  | 750-049488  | CACN0239      | SRX-MIC-10XG-SFPP     |
| FPC 5            | REV 10  | 750-056758  | CADA8736      | SRX5K-SPC-4-15-320    |
| CPU              |         | BUILTIN     | BUILTIN       |                       |
| Fan Tray         |         |             |               | SRX5600-HC-FAN        |

## show chassis hardware detail

### show chassis hardware detail

(SRX5600 and SRX5800 devices with SRX5000 line SRX5K-SCBE (SCB2) and (SRX5K-RE-1800X4 (RE2))

```
user@host> show chassis hardware detail
```

```
node0:
```

```

Hardware inventory:
```

| Item             | Version   | Part number                              | Serial number        | Description               |
|------------------|-----------|------------------------------------------|----------------------|---------------------------|
| Chassis          |           |                                          | JN122A040AGA         | SRX5800                   |
| Midplane         | REV 01    | 710-041799                               | ACRA7817             | SRX5800 Backplane         |
| FPM Board        | REV 01    | 760-058099                               | CACA2100             | Front Panel Display       |
| PDM              | Rev 03    | 740-013110                               | QCS1739517Z          | Power Distribution Module |
| PEM 0            | Rev 05    | 740-034724                               | QCS17460203K         | PS 4.1kW; 200-240V AC     |
| in               |           |                                          |                      |                           |
| PEM 1            | Rev 04    | 740-034724                               | QCS172302017         | PS 4.1kW; 200-240V AC     |
| in               |           |                                          |                      |                           |
| Routing Engine 0 | REV 01    | 740-056658                               | 9013040855           | SRX5k RE-1800X4           |
| ad0              | 3998 MB   | Virtium - TuffDrive                      | VCF P1T0200269450529 | 741 Compact Flash         |
| ad1              | 114304 MB | VSFA18PI128G-KC                          | 32779-073            | Disk 1                    |
| usb0 (addr 1)    |           | EHCI root hub 0                          | Intel                | uhub0                     |
| usb0 (addr 2)    |           | product 0x0020 32                        | vendor 0x8087        | uhub1                     |
| DIMM 0           |           | SGU04G72H1BD2SA-BB DIE REV-52 PCB REV-54 | MFR ID-ce80          |                           |
| DIMM 1           |           | SGU04G72H1BD2SA-BB DIE REV-52 PCB REV-54 | MFR ID-ce80          |                           |
| DIMM 2           |           | SGU04G72H1BD2SA-BB DIE REV-52 PCB REV-54 | MFR ID-ce80          |                           |
| DIMM 3           |           | SGU04G72H1BD2SA-BB DIE REV-52 PCB REV-54 | MFR ID-ce80          |                           |
| Routing Engine 1 |           |                                          |                      |                           |
| CB 0             | REV 01    | 750-056587                               | CACG1424             | SRX5k SCB II              |
| CB 1             | REV 01    | 750-056587                               | CACC9307             | SRX5k SCB II              |
| CB 2             | REV 01    | 750-056587                               | CAAZ1128             | SRX5k SCB II              |
| FPC 0            | REV 10    | 750-056758                               | CACS2667             | SRX5k SPC II              |
| CPU              |           | BUILTIN                                  | BUILTIN              | SRX5k DPC PPC             |
| PIC 0            |           | BUILTIN                                  | BUILTIN              | SPU Cp                    |
| PIC 1            |           | BUILTIN                                  | BUILTIN              | SPU Flow                  |
| PIC 2            |           | BUILTIN                                  | BUILTIN              | SPU Flow                  |
| PIC 3            |           | BUILTIN                                  | BUILTIN              | SPU Flow                  |

|            |        |            |             |                   |
|------------|--------|------------|-------------|-------------------|
| FPC 1      | REV 18 | 750-054877 | CACH4092    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| FPC 2      | REV 10 | 750-056758 | CACV0038    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| FPC 3      | REV 10 | 750-043157 | CACB6877    | SRX5k IOC II      |
| CPU        | REV 04 | 711-043360 | CACH6074    | SRX5k MPC PMB     |
| MIC 0      | REV 19 | 750-049486 | CAAH3504    | 1x 100GE CFP      |
| PIC 0      |        | BUILTIN    | BUILTIN     | 1x 100GE CFP      |
| Xcvr 0     | REV 01 | 740-035329 | UP1020Z     | CFP-100G-SR10     |
| MIC 1      | REV 04 | 750-049488 | CACB6429    | 10x 10GE SFP+     |
| PIC 2      |        | BUILTIN    | BUILTIN     | 10x 10GE SFP+     |
| Xcvr 0     | REV 01 | 740-031980 | AP21RJ5     | SFP+-10G-SR       |
| Xcvr 1     | REV 01 | 740-031980 | AP21RLJ     | SFP+-10G-SR       |
| Xcvr 2     | REV 01 | 740-030658 | AD1148A0AYC | SFP+-10G-USR      |
| Xcvr 3     | REV 01 | 740-031980 | B11E02718   | SFP+-10G-SR       |
| FPC 4      | REV 10 | 750-056758 | CACW0706    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| FPC 7      | REV 10 | 750-056758 | CACS2725    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| FPC 8      | REV 11 | 750-043157 | CABN4955    | SRX5k IOC II      |
| CPU        | REV 04 | 711-043360 | CACT9926    | SRX5k MPC PMB     |
| MIC 0      | REV 19 | 750-049486 | CAAH0979    | 1x 100GE CFP      |
| PIC 0      |        | BUILTIN    | BUILTIN     | 1x 100GE CFP      |
| Xcvr 0     | REV 01 | 740-035329 | UP2077V     | CFP-100G-SR10     |
| FPC 9      | REV 10 | 750-056758 | CACW0755    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN     | SPU Flow          |
| FPC 10     | REV 07 | 750-044175 | CAAD0747    | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN     | SRX5k DPC PPC     |
| Fan Tray 0 | REV 04 | 740-035409 | ACAE2294    | Enhanced Fan Tray |
| Fan Tray 1 | REV 04 | 740-035409 | ACAE2099    | Enhanced Fan Tray |

node1:

-----  
Hardware inventory:

| Item      | Version | Part number | Serial number | Description               |
|-----------|---------|-------------|---------------|---------------------------|
| Chassis   |         |             | JN1235BC7AGA  | SRX5800                   |
| Midplane  | REV 01  | 710-024803  | ACRC3244      | SRX5800 Backplane         |
| FPM Board | REV 01  | 710-024632  | CACA2108      | Front Panel Display       |
| PDM       | Rev 03  | 740-013110  | QCS1739519B   | Power Distribution Module |
| PEM 0     | Rev 04  | 740-034724  | QCS17230201Z  | PS 4.1kW; 200-240V AC     |
| in        |         |             |               |                           |

|                  |                     |                     |                      |                       |
|------------------|---------------------|---------------------|----------------------|-----------------------|
| PEM 1            | Rev 05              | 740-034724          | QCS174502014         | PS 4.1kW; 200-240V AC |
| in               |                     |                     |                      |                       |
| Routing Engine 0 | REV 01              | 740-056658          | 9009153221           | SRX5k RE-1800X4       |
| ad0              | 3998 MB             | Virtium - TuffDrive | VCF P1T0200298450703 | 72 Compact Flash      |
| ad1              | 114304 MB           | VSFA18PI128G-KC     | 32779-073            | Disk 1                |
| usb0 (addr 1)    | EHCI root hub 0     | Intel               |                      | uhub0                 |
| usb0 (addr 2)    | product 0x0020 32   | vendor 0x8087       |                      | uhub1                 |
| DIMM 0           | VL31B5263F-F8SD DIE | REV-0 PCB REV-0     |                      | MFR ID-ce80           |
| DIMM 1           | VL31B5263F-F8SD DIE | REV-0 PCB REV-0     |                      | MFR ID-ce80           |
| DIMM 2           | VL31B5263F-F8SD DIE | REV-0 PCB REV-0     |                      | MFR ID-ce80           |
| DIMM 3           | VL31B5263F-F8SD DIE | REV-0 PCB REV-0     |                      | MFR ID-ce80           |
| Routing Engine 1 |                     |                     |                      |                       |
| CB 0             | REV 01              | 750-056587          | CACC9541             | SRX5k SCB II          |
| CB 1             | REV 01              | 750-056587          | CACG1447             | SRX5k SCB II          |
| CB 2             | REV 01              | 750-056587          | CACH9058             | SRX5k SCB II          |
| FPC 0            | REV 18              | 750-054877          | CACH4004             | SRX5k SPC II          |
| CPU              |                     | BUILTIN             | BUILTIN              | SRX5k DPC PPC         |
| PIC 0            |                     | BUILTIN             | BUILTIN              | SPU Cp                |
| PIC 1            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 2            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 3            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| FPC 1            | REV 18              | 750-054877          | CACH4082             | SRX5k SPC II          |
| CPU              |                     | BUILTIN             | BUILTIN              | SRX5k DPC PPC         |
| PIC 0            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 1            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 2            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 3            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| FPC 2            | REV 10              | 750-056758          | CACW0713             | SRX5k SPC II          |
| CPU              |                     | BUILTIN             | BUILTIN              | SRX5k DPC PPC         |
| PIC 0            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 1            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 2            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 3            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| FPC 3            | REV 11              | 750-043157          | CACA8792             | SRX5k IOC II          |
| CPU              | REV 04              | 711-043360          | CACA8809             | SRX5k MPC PMB         |
| MIC 0            | REV 19              | 750-049486          | CAAH3485             | 1x 100GE CFP          |
| PIC 0            |                     | BUILTIN             | BUILTIN              | 1x 100GE CFP          |
| Xcvr 0           | REV 01              | 740-035329          | UNMOG3C              | CFP-100G-SR10         |
| MIC 1            | REV 04              | 750-049488          | CABX0782             | 10x 10GE SFP+         |
| PIC 2            |                     | BUILTIN             | BUILTIN              | 10x 10GE SFP+         |
| Xcvr 0           | REV 01              | 740-031980          | AMBOHX3              | SFP+-10G-SR           |
| Xcvr 1           | REV 01              | 740-031980          | ANTOE6V              | SFP+-10G-SR           |
| Xcvr 2           | REV 01              | 740-031980          | ANROZVY              | SFP+-10G-SR           |
| Xcvr 3           | REV 01              | 740-031980          | AP308ZU              | SFP+-10G-SR           |
| FPC 4            | REV 10              | 750-044175          | CAAS8024             | SRX5k SPC II          |
| CPU              |                     | BUILTIN             | BUILTIN              | SRX5k DPC PPC         |
| PIC 0            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 1            |                     |                     |                      |                       |
| PIC 2            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 3            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| FPC 7            | REV 10              | 750-056758          | CACS5126             | SRX5k SPC II          |
| CPU              |                     | BUILTIN             | BUILTIN              | SRX5k DPC PPC         |
| PIC 0            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 1            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 2            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| PIC 3            |                     | BUILTIN             | BUILTIN              | SPU Flow              |
| FPC 8            | REV 11              | 750-043157          | CACA8798             | SRX5k IOC II          |
| CPU              | REV 04              | 711-043360          | CACA8826             | SRX5k MPC PMB         |
| MIC 0            | REV 19              | 750-049486          | CAAH0996             | 1x 100GE CFP          |
| PIC 0            |                     | BUILTIN             | BUILTIN              | 1x 100GE CFP          |
| Xcvr 0           | REV 01              | 740-035329          | UP30A6N              | CFP-100G-SR10         |

|            |        |            |          |                   |
|------------|--------|------------|----------|-------------------|
| FPC 9      | REV 07 | 750-044175 | CAAD0745 | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| PIC 0      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 1      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 2      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| PIC 3      |        | BUILTIN    | BUILTIN  | SPU Flow          |
| FPC 10     | REV 18 | 750-054877 | CACD2570 | SRX5k SPC II      |
| CPU        |        | BUILTIN    | BUILTIN  | SRX5k DPC PPC     |
| Fan Tray 0 | REV 04 | 740-035409 | ACAE2122 | Enhanced Fan Tray |
| Fan Tray 1 | REV 04 | 740-035409 | ACAE2254 | Enhanced Fan Tray |

### show chassis hardware detail

(SRX5400, SRX5600, and SRX5800 devices with SRX5000 line SRX5K-SCB3 SCB3 with enhanced midplanes and (SRX5K-MPC3-100G10G (IOC3) or SRX5K-MPC3-40G10G (IOC3))

```
user@host> show chassis hardware detail
```

```
node0:
```

```

Hardware inventory:
```

| Item             | Version            | Part number           | Serial number      | Description               |
|------------------|--------------------|-----------------------|--------------------|---------------------------|
| Chassis          |                    |                       | JN1250870AGB       | SRX5600                   |
| Midplane         | REV 01             | 760-063936            | ACRE2578           | Enhanced SRX5600 Midplane |
| FPM Board        | REV 02             | 710-017254            | KD9027             | Front Panel Display       |
| PEM 0            | Rev 03             | 740-034701            | QCS13090900T       | PS 1.4-2.6kW; 90-264V     |
| AC in            |                    |                       |                    |                           |
| PEM 1            | Rev 03             | 740-034701            | QCS13090904T       | PS 1.4-2.6kW; 90-264V     |
| AC in            |                    |                       |                    |                           |
| Routing Engine 0 | REV 01             | 740-056658            | 9009196496         | SRX5k RE-1800X4           |
| ad0              | 3831 MB            | UGB30SFA4000T2        | SFA4000T2 000027A0 | Compact Flash             |
| ad1              | 114304 MB          | VSFA18PI128G-KC       | 32779-043          | Disk 1                    |
| usb0 (addr 1)    | product 0x0000 0   |                       | vendor 0x0000      | uhub0                     |
| usb0 (addr 2)    | product 0x0020 32  |                       | vendor 0x8087      | uhub1                     |
| DIMM 0           | SGU04G72H1BD2SA-BB | DIE REV-52 PCB REV-54 | MFR ID-ce80        |                           |
| DIMM 1           | SGU04G72H1BD2SA-BB | DIE REV-52 PCB REV-54 | MFR ID-ce80        |                           |
| DIMM 2           | SGU04G72H1BD2SA-BB | DIE REV-52 PCB REV-54 | MFR ID-ce80        |                           |
| DIMM 3           | SGU04G72H1BD2SA-BB | DIE REV-52 PCB REV-54 | MFR ID-ce80        |                           |
| CB 0             | REV 01             | 750-062257            | CAEC2501           | SRX5k SCB3                |
| FPC 0            | REV 10             | 750-056758            | CADC8067           | SRX5k SPC II              |
| CPU              |                    | BUILTIN               | BUILTIN            | SRX5k DPC PPC             |
| PIC 0            |                    | BUILTIN               | BUILTIN            | SPU Cp                    |
| PIC 1            |                    | BUILTIN               | BUILTIN            | SPU Flow                  |
| PIC 2            |                    | BUILTIN               | BUILTIN            | SPU Flow                  |
| PIC 3            |                    | BUILTIN               | BUILTIN            | SPU Flow                  |
| FPC 2            | REV 01             | 750-062243            | CAEE5924           | SRX5k IOC3 24XGE+6XLG     |
| CPU              | REV 01             | 711-062244            | CAEB4890           | SRX5k IOC3 PMB            |
| PIC 0            |                    | BUILTIN               | BUILTIN            | 12x 10GE SFP+             |
| PIC 1            |                    | BUILTIN               | BUILTIN            | 12x 10GE SFP+             |
| PIC 2            |                    | BUILTIN               | BUILTIN            | 3x 40GE QSFP+             |
| Xcvr 0           | REV 01             | 740-038623            | MOC13156230449     | QSFP+-40G-CU1M            |
| Xcvr 2           | REV 01             | 740-038623            | MOC13156230449     | QSFP+-40G-CU1M            |
| PIC 3            |                    | BUILTIN               | BUILTIN            | 3x 40GE QSFP+             |
| WAN MEZZ         | REV 01             | 750-062682            | CAEE5817           | 24x 10GE SFP+ Mezz        |
| FPC 4            | REV 11             | 750-043157            | CACY1595           | SRX5k IOC II              |
| CPU              | REV 04             | 711-043360            | CACZ8879           | SRX5k MPC PMB             |
| MIC 1            | REV 04             | 750-049488            | CACM6062           | 10x 10GE SFP+             |
| PIC 2            |                    | BUILTIN               | BUILTIN            | 10x 10GE SFP+             |
| Xcvr 7           | REV 01             | 740-021308            | AD1439301TU        | SFP+-10G-SR               |
| Xcvr 8           | REV 01             | 740-021308            | AD1439301SD        | SFP+-10G-SR               |
| Xcvr 9           | REV 01             | 740-021308            | AD1439301TS        | SFP+-10G-SR               |
| FPC 5            | REV 05             | 750-044175            | ZZ1371             | SRX5k SPC II              |
| CPU              |                    | BUILTIN               | BUILTIN            | SRX5k DPC PPC             |

|          |         |         |                   |
|----------|---------|---------|-------------------|
| PIC 0    | BUILTIN | BUILTIN | SPU Flow          |
| PIC 1    | BUILTIN | BUILTIN | SPU Flow          |
| PIC 2    | BUILTIN | BUILTIN | SPU Flow          |
| PIC 3    | BUILTIN | BUILTIN | SPU Flow          |
| Fan Tray |         |         | Enhanced Fan Tray |

node1:

-----  
Hardware inventory:

| Item             | Version            | Part number         | Serial number        | Description               |
|------------------|--------------------|---------------------|----------------------|---------------------------|
| Chassis          |                    |                     | JN124FEC0AGB         | SRX5600                   |
| Midplane         | REV 01             | 760-063936          | ACRE2946             | Enhanced SRX5600 Midplane |
| FPM Board        | test               | 710-017254          | test                 | Front Panel Display       |
| PEM 0            | Rev 01             | 740-038514          | QCS114111003         | DC 2.6kW Power Entry      |
| Module           |                    |                     |                      |                           |
| PEM 1            | Rev 01             | 740-038514          | QCS12031100J         | DC 2.6kW Power Entry      |
| Module           |                    |                     |                      |                           |
| Routing Engine 0 | REV 01             | 740-056658          | 9009186342           | SRX5k RE-1800X4           |
| ad0              | 3998 MB            | Virtium - TuffDrive | VCF P1T0200313161216 | 109 Compact Flash         |
| ad1              | 28843 MB           | UGB94BPH32H0S2-KCI  | 11000160387          | Disk 1                    |
| usb0 (addr 1)    | product            | 0x0000 0            | vendor 0x0000        | uhub0                     |
| usb0 (addr 2)    | product            | 0x0020 32           | vendor 0x8087        | uhub1                     |
| DIMM 0           | SGU04G72H1BD2SA-BB | DIE REV-52          | PCB REV-54           | MFR ID-ce80               |
| DIMM 1           | SGU04G72H1BD2SA-BB | DIE REV-52          | PCB REV-54           | MFR ID-ce80               |
| DIMM 2           | SGU04G72H1BD2SA-BB | DIE REV-52          | PCB REV-54           | MFR ID-ce80               |
| DIMM 3           | SGU04G72H1BD2SA-BB | DIE REV-52          | PCB REV-54           | MFR ID-ce80               |
| CB 0             | REV 01             | 750-062257          | CAEB8178             | SRX5k SCB3                |
| FPC 0            | REV 07             | 750-044175          | CAAD0769             | SRX5k SPC II              |
| CPU              |                    | BUILTIN             | BUILTIN              | SRX5k DPC PPC             |
| PIC 0            |                    | BUILTIN             | BUILTIN              | SPU Cp                    |
| PIC 1            |                    | BUILTIN             | BUILTIN              | SPU Flow                  |
| PIC 2            |                    | BUILTIN             | BUILTIN              | SPU Flow                  |
| PIC 3            |                    | BUILTIN             | BUILTIN              | SPU Flow                  |
| FPC 4            | REV 11             | 750-043157          | CACY1592             | SRX5k IOC II              |
| CPU              | REV 04             | 711-043360          | CACZ8831             | SRX5k MPC PMB             |
| MIC 1            | REV 04             | 750-049488          | CACN0239             | 10x 10GE SFP+             |
| PIC 2            |                    | BUILTIN             | BUILTIN              | 10x 10GE SFP+             |
| Xcvr 7           | REV 01             | 740-031980          | ARN23HW              | SFP+-10G-SR               |
| Xcvr 8           | REV 01             | 740-031980          | ARN2FVW              | SFP+-10G-SR               |
| Xcvr 9           | REV 01             | 740-031980          | ARN2YVM              | SFP+-10G-SR               |
| FPC 5            | REV 10             | 750-056758          | CADA8736             | SRX5k SPC II              |
| CPU              |                    | BUILTIN             | BUILTIN              | SRX5k DPC PPC             |
| PIC 0            |                    | BUILTIN             | BUILTIN              | SPU Flow                  |
| PIC 1            |                    | BUILTIN             | BUILTIN              | SPU Flow                  |
| PIC 2            |                    | BUILTIN             | BUILTIN              | SPU Flow                  |
| PIC 3            |                    | BUILTIN             | BUILTIN              | SPU Flow                  |
| Fan Tray         |                    |                     |                      | Enhanced Fan Tray         |

## show chassis hardware extensive node 1

### show chassis hardware extensive node 1

(SRX5600 and SRX5800 devices with SRX5000 line SRX5K-SCBE (SCB2) and SRX5K-RE-1800X4)

user@host> show chassis hardware extensive node 1

node1:

-----  
Hardware inventory:

| Item        | Version | Part number     | Serial number | Description |
|-------------|---------|-----------------|---------------|-------------|
| Chassis     |         |                 | JN1235BC7AGA  | SRX5800     |
| Jedec Code: | 0x7fb0  | EEPROM Version: | 0x02          |             |
|             |         | S/N:            | JN1235BC7AGA  |             |



```

Assembly ID: 0x051a Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00
ID: SRX5800
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 7f b0 02 ff 05 1a 00 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x20: 4a 4e 31 32 33 35 42 43 37 41 47 41 00 00 00 00
Address 0x30: 00 00 00 ff 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Midplane REV 01 710-024803 ACRC3244 SRX5800 Backplane
Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 710-024803 S/N: S/N ACRC3244
Assembly ID: 0x091a Assembly Version: 01.01
Date: 02-26-2014 Assembly Flags: 0x00
Version: REV 01
ID: SRX5800 Backplane FRU Model Number: SRX5800-BP-A
Board Information Record:
Address 0x00: ad 01 08 00 4c 96 14 d3 28 00 00 ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 01 ff 09 1a 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 31 30 2d 30 32 34 38 30 33 00 00
Address 0x20: 53 2f 4e 20 41 43 52 43 33 32 34 34 00 1a 02 07
Address 0x30: de ff ff ff ad 01 08 00 4c 96 14 d3 28 00 00 ff
Address 0x40: ff ff ff ff 01 00 00 00 00 00 00 00 00 00 00 53
Address 0x50: 52 58 35 38 30 30 2d 42 50 2d 41 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 ff ff ff ff ff ff ff ff ff ff
Address 0x70: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
FPM Board REV 01 710-024632 CACA2108 Front Panel Display
Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 710-024632 S/N: S/N CACA2108
Assembly ID: 0x096f Assembly Version: 01.01
Date: 02-05-2014 Assembly Flags: 0x00
Version: REV 01
ID: Front Panel Display FRU Model Number: SRX5800-CRAFT-A
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 01 ff 09 6f 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 31 30 2d 30 32 34 36 33 32 00 00
Address 0x20: 53 2f 4e 20 43 41 43 41 32 31 30 38 00 05 02 07
Address 0x30: de ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 01 00 00 00 00 00 00 00 00 00 00 53
Address 0x50: 52 58 35 38 30 30 2d 43 52 41 46 54 2d 41 00 00
Address 0x60: 00 00 00 00 00 00 ff ff ff ff ff ff ff ff ff ff
Address 0x70: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
PDM Rev 03 740-013110 QCS1739519B Power Distribution Module

Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 740-013110 S/N: QCS1739519B
Assembly ID: 0x0416 Assembly Version: 01.03
Date: 10-26-2013 Assembly Flags: 0x00
Version: Rev 03
ID: Power Distribution Module
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff 00 00 00
I2C Hex Data:

```

```

Address 0x00: 7f b0 01 ff 04 16 01 03 52 65 76 20 30 33 00 00
Address 0x10: 00 00 00 00 37 34 30 2d 30 31 33 31 31 30 00 00
Address 0x20: 51 43 53 31 37 33 39 35 31 39 42 00 00 1a 0a 07
Address 0x30: dd ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PEM 0 Rev 04 740-034724 QCS17230201Z PS 4.1kW; 200-240V AC
in
Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 740-034724 S/N: QCS17230201Z
Assembly ID: 0x044b Assembly Version: 01.04
Date: 06-04-2013 Assembly Flags: 0x00
Version: Rev 04
ID: PS 4.1kW; 200-240V AC in FRU Model Number: SRX5800-PWR-4100-AC
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff 00 00 00 00
I2C Hex Data:
Address 0x00: 7f b0 01 ff 04 4b 01 04 52 65 76 20 30 34 00 00
Address 0x10: 00 00 00 00 37 34 30 2d 30 33 34 37 32 34 00 00
Address 0x20: 51 43 53 31 37 32 33 30 32 30 31 5a 00 04 06 07
Address 0x30: dd ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: 00 00 00 00 01 00 00 00 00 00 00 00 00 00 00 53
Address 0x50: 52 58 35 38 30 30 2d 50 57 52 2d 34 31 30 30 2d
Address 0x60: 41 43 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PEM 1 Rev 05 740-034724 QCS174502014 PS 4.1kW; 200-240V AC
in
Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 740-034724 S/N: QCS174502014
Assembly ID: 0x044b Assembly Version: 01.05
Date: 11-06-2013 Assembly Flags: 0x00
Version: Rev 05
ID: PS 4.1kW; 200-240V AC in FRU Model Number: SRX5800-PWR-4100-AC
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff 00 00 00 00
I2C Hex Data:
Address 0x00: 7f b0 01 ff 04 4b 01 05 52 65 76 20 30 35 00 00
Address 0x10: 00 00 00 00 37 34 30 2d 30 33 34 37 32 34 00 00
Address 0x20: 51 43 53 31 37 34 35 30 32 30 31 34 00 06 0b 07
Address 0x30: dd ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: 00 00 00 00 01 00 00 00 00 00 00 00 00 00 00 53
Address 0x50: 52 58 35 38 30 30 2d 50 57 52 2d 34 31 30 30 2d
Address 0x60: 41 43 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Routing Engine 0 REV 01 740-056658 9009153221 SRX5k RE-1800X4
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 740-056658 S/N: 9009153221
Assembly ID: 0x0c1a Assembly Version: 01.01
Date: 07-22-2013 Assembly Flags: 0x00
Version: REV 01 CLEI Code: PROTOXCLEI
ID: SRX5k RE-1800X4 FRU Model Number: SRX5K-RE-1800X4
Board Information Record:
Address 0x00: 54 32 30 32 37 45 43 2d 34 34 47 42 00 00 00 00
I2C Hex Data:
Address 0x00: 7f b0 02 ff 0c 1a 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 34 30 2d 30 35 36 36 35 38 00 00
Address 0x20: 39 30 30 39 31 35 33 32 32 31 00 00 00 16 07 07
Address 0x30: dd ff ff ff 54 32 30 32 37 45 43 2d 34 34 47 42
Address 0x40: 00 00 00 00 01 50 52 4f 54 4f 58 43 4c 45 49 53

```

```

Address 0x50: 52 58 35 4b 2d 52 45 2d 31 38 30 30 58 34 00 00
Address 0x60: 00 00 00 00 00 00 41 30 30 ff ff ff ff ff ff ff
Address 0x70: ff ff ff 64 ff ff ff ff ff ff ff ff ff ff ff ff
ad0 3998 MB Virtium - TuffDrive VCF P1T0200298450703 72 Compact Flash
ad1 114304 MB VSFA18PI128G-KC 32779-073 Disk 1
usb0 (addr 1) EHCI root hub 0 Intel uhub0
usb0 (addr 2) product 0x0020 32 vendor 0x8087 uhub1
DIMM 0 VL31B5263F-F8SD DIE REV-0 PCB REV-0 MFR ID-ce80
DIMM 1 VL31B5263F-F8SD DIE REV-0 PCB REV-0 MFR ID-ce80
DIMM 2 VL31B5263F-F8SD DIE REV-0 PCB REV-0 MFR ID-ce80
DIMM 3 VL31B5263F-F8SD DIE REV-0 PCB REV-0 MFR ID-ce80
Routing Engine 1
CB 0 REV 01 750-056587 CACC9541 SRX5k SCB II
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 750-056587 S/N: S/N CACC9541
Assembly ID: 0x0c19 Assembly Version: 01.01
Date: 03-07-2014 Assembly Flags: 0x00
Version: REV 01 CLEI Code: PROTOXCLEI
ID: SRX5k SCB II FRU Model Number: SRX5K-SCBE
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 02 fe 0c 19 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 35 30 2d 30 35 36 35 38 37 00 00
Address 0x20: 53 2f 4e 20 43 41 43 43 39 35 34 31 00 07 03 07
Address 0x30: de ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 01 50 52 4f 54 4f 58 43 4c 45 49 53
Address 0x50: 52 58 35 4b 2d 53 43 42 45 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 41 00 00 ff ff ff ff ff ff ff
Address 0x70: ff ff ff 08 ff ff ff ff ff ff ff ff ff ff ff ff
CB 1 REV 01 750-056587 CACG1447 SRX5k SCB II
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 750-056587 S/N: S/N CACG1447
Assembly ID: 0x0c19 Assembly Version: 01.01
Date: 03-07-2014 Assembly Flags: 0x00
Version: REV 01 CLEI Code: PROTOXCLEI
ID: SRX5k SCB II FRU Model Number: SRX5K-SCBE
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 02 fe 0c 19 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 35 30 2d 30 35 36 35 38 37 00 00
Address 0x20: 53 2f 4e 20 43 41 43 47 31 34 34 37 00 07 03 07
Address 0x30: de ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 01 50 52 4f 54 4f 58 43 4c 45 49 53
Address 0x50: 52 58 35 4b 2d 53 43 42 45 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 41 00 00 ff ff ff ff ff ff ff
Address 0x70: ff ff ff 08 ff ff ff ff ff ff ff ff ff ff ff ff
CB 2 REV 01 750-056587 CACH9058 SRX5k SCB II
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 750-056587 S/N: S/N CACH9058
Assembly ID: 0x0c19 Assembly Version: 01.01
Date: 03-06-2014 Assembly Flags: 0x00
Version: REV 01 CLEI Code: PROTOXCLEI
ID: SRX5k SCB II FRU Model Number: SRX5K-SCBE
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 02 fe 0c 19 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 35 30 2d 30 35 36 35 38 37 00 00
Address 0x20: 53 2f 4e 20 43 41 43 48 39 30 35 38 00 06 03 07

```

```

Address 0x30: de ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 01 50 52 4f 54 4f 58 43 4c 45 49 53
Address 0x50: 52 58 35 4b 2d 53 43 42 45 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 41 00 00 ff ff ff ff ff ff
Address 0x70: ff ff ff 08 ff ff ff ff ff ff ff ff ff ff ff

```

### show chassis hardware extensive node 1

(SRX5400, SRX5600, and SRX5800 devices with SRX5000 line SRX5K-SCB3 (SCB3) with enhanced midplanes and SRX5K-MPC3-100G10G (IOC3) or SRX5K-MPC3-40G10G (IOC3))

```

user@host> show chassis hardware extensive node 1
node1:

Hardware inventory:
Item Version Part number Serial number Description
Chassis
Jedec Code: 0x7fb0 EEPROM Version: 0x02
S/N: JN124FEC0AGB
Assembly ID: 0x051b Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x08
ID: SRX5600
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 7f b0 02 ff 05 1b 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x20: 4a 4e 31 32 34 46 45 43 30 41 47 42 08 00 00
Address 0x30: 00 00 00 ff 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Midplane REV 01 760-063936 ACRE2946 Enhanced SRX5600 Midpla
ne
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 760-063936 S/N: ACRE2946
Assembly ID: 0x0914 Assembly Version: 01.01
Date: 03-19-2015 Assembly Flags: 0x08
Version: REV 01 CLEI Code: CLEI-CODE
ID: SRX5600 Midplane FRU Model Number: SRX5600X-CHAS
Board Information Record:
Address 0x00: ad 01 08 00 88 a2 5e 12 68 00 ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 02 ff 09 14 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 36 30 2d 30 36 33 39 33 36 00 00
Address 0x20: 53 2f 4e 20 41 43 52 45 32 39 34 36 08 13 03 07
Address 0x30: df ff ff ff ad 01 08 00 88 a2 5e 12 68 00 ff ff
Address 0x40: ff ff ff ff 01 43 4c 45 49 2d 43 4f 44 45 20 53
Address 0x50: 52 58 35 36 30 30 58 2d 43 48 41 53 20 20 20 20
Address 0x60: 20 20 20 20 20 20 31 30 31 ff ff ff ff ff ff ff
Address 0x70: ff ff ff ba ff ff ff ff ff ff ff ff ff ff ff ff
FPM Board test 710-017254 test Front Panel Display
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 710-017254 S/N: test
Assembly ID: 0x01ff Assembly Version: 01.00
Date: 06-18-2007 Assembly Flags: 0x00
Version: test
ID: Front Panel Display
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff

```

## I2C Hex Data:

```

Address 0x00: 7f b0 02 ff 01 ff 01 00 74 65 73 74 00 00 00 00
Address 0x10: 00 00 00 00 37 31 30 2d 30 31 37 32 35 34 00 00
Address 0x20: 74 65 73 74 00 00 00 00 00 00 00 00 12 06 07
Address 0x30: d7 ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 ff ff ff ff ff ff ff ff ff ff ff

```

PEM 0 Rev 01 740-038514 QCS114111003 DC 2.6kW Power Entry

## Module

```

Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 740-038514 S/N: QCS114111003
Assembly ID: 0x044c Assembly Version: 01.01
Date: 10-14-2011 Assembly Flags: 0x00
Version: Rev 01

```

ID: DC 2.6kW Power Entry Module FRU Model Number: SRX5600-PWR-2400-DC-S

## Board Information Record:

```

Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff 00 00 00 00

```

## I2C Hex Data:

```

Address 0x00: 7f b0 01 ff 04 4c 01 01 52 65 76 20 30 31 00 00
Address 0x10: 00 00 00 00 37 34 30 2d 30 33 38 35 31 34 00 00
Address 0x20: 51 43 53 31 31 34 31 31 30 30 33 00 0e 0a 07
Address 0x30: db ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: 00 00 00 00 01 00 00 00 00 00 00 00 00 00 00 53
Address 0x50: 52 58 35 36 30 30 2d 50 57 52 2d 32 34 30 30 2d
Address 0x60: 44 43 2d 53 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

```

PEM 1 Rev 01 740-038514 QCS12031100J DC 2.6kW Power Entry

## Module

```

Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 740-038514 S/N: QCS12031100J
Assembly ID: 0x044c Assembly Version: 01.01
Date: 01-17-2012 Assembly Flags: 0x00
Version: Rev 01

```

ID: DC 2.6kW Power Entry Module FRU Model Number: SRX5600-PWR-2400-DC-S

## Board Information Record:

```

Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff 00 00 00 00

```

## I2C Hex Data:

```

Address 0x00: 7f b0 01 ff 04 4c 01 01 52 65 76 20 30 31 00 00
Address 0x10: 00 00 00 00 37 34 30 2d 30 33 38 35 31 34 00 00
Address 0x20: 51 43 53 31 32 30 33 31 31 30 30 4a 00 11 01 07
Address 0x30: dc ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: 00 00 00 00 01 00 00 00 00 00 00 00 00 00 00 53
Address 0x50: 52 58 35 36 30 30 2d 50 57 52 2d 32 34 30 30 2d
Address 0x60: 44 43 2d 53 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

```

Routing Engine 0 REV 01 740-056658 9009186342 SRX5k RE-1800X4

```

Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 740-056658 S/N: 9009186342
Assembly ID: 0x0c1a Assembly Version: 01.01
Date: 02-05-2014 Assembly Flags: 0x00
Version: REV 01 CLEI Code: COUCATTBAA
ID: SRX5k RE-1800X4 FRU Model Number: SRX5K-RE-1800X4

```

## Board Information Record:

```

Address 0x00: 54 32 30 32 37 45 43 2d 34 34 47 42 00 00 00 00

```

## I2C Hex Data:

```

Address 0x00: 7f b0 02 ff 0c 1a 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 34 30 2d 30 35 36 36 35 38 00 00
Address 0x20: 39 30 30 39 31 38 36 33 34 32 00 00 00 05 02 07
Address 0x30: de ff ff ff 54 32 30 32 37 45 43 2d 34 34 47 42

```

```

Address 0x40: 00 00 00 00 01 43 4f 55 43 41 54 54 42 41 41 53
Address 0x50: 52 58 35 4b 2d 52 45 2d 31 38 30 30 58 34 00 00
Address 0x60: 00 00 00 00 00 00 41 30 30 ff ff ff ff ff ff ff
Address 0x70: ff ff ff 64 ff ff ff ff ff ff ff ff ff ff ff
ad0 3998 MB Virtium - TuffDrive VCF P1T0200313161216 109 Compact Flash
ad1 28843 MB UGB94BPH32H0S2-KCI 11000160387 Disk 1
usb0 (addr 1) product 0x0000 0 vendor 0x0000 uhub0
usb0 (addr 2) product 0x0020 32 vendor 0x8087 uhub1
DIMM 0 SGU04G72H1BD2SA-BB DIE REV-52 PCB REV-54 MFR ID-ce80
DIMM 1 SGU04G72H1BD2SA-BB DIE REV-52 PCB REV-54 MFR ID-ce80
DIMM 2 SGU04G72H1BD2SA-BB DIE REV-52 PCB REV-54 MFR ID-ce80
DIMM 3 SGU04G72H1BD2SA-BB DIE REV-52 PCB REV-54 MFR ID-ce80
CB 0 REV 01 750-062257 CAEB8178 SRX5k SCB3
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 750-062257 S/N: CAEB8178
Assembly ID: 0x0c59 Assembly Version: 01.01
Date: 03-19-2015 Assembly Flags: 0x00
Version: REV 01 CLEI Code: CLEI-CODE
ID: SRX5k SCB3 FRU Model Number: SRX5K-SCB3
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 02 ff 0c 59 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 35 30 2d 30 36 32 32 35 37 00 00
Address 0x20: 53 2f 4e 20 43 41 45 42 38 31 37 38 00 13 03 07
Address 0x30: df ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 01 43 4c 45 49 2d 43 4f 44 45 20 53
Address 0x50: 52 58 35 4b 2d 53 43 42 33 20 20 20 20 20 20
Address 0x60: 20 20 20 20 20 20 31 30 31 ff ff ff ff ff ff ff
Address 0x70: ff ff ff 63 ff ff ff ff ff ff ff ff ff ff ff
FPC 2 REV 01 750-062243 CAED0386 SRX5k IOC3 24XGE+6XLG
Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 750-062243 S/N: CAED0386
Assembly ID: 0x0c57 Assembly Version: 01.01
Date: 04-28-2015 Assembly Flags: 0x00
Version: REV 01
ID: SRX5k IOC3 24XGE+6XLG
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ae 01 f2 06 00 ff
I2C Hex Data:
Address 0x00: 7f b0 01 fe 0c 57 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 35 30 2d 30 36 32 32 34 33 00 00
Address 0x20: 53 2f 4e 20 43 41 45 44 30 33 38 36 00 1c 04 07
Address 0x30: df ff ff ff ff ff ff ff ff ff ff ff ff ff ae 01
Address 0x40: f2 06 00 ff 01 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 ff ff ff ff ff ff ff ff ff ff
Address 0x70: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
CPU REV 01 711-062244 CADX8554 SRX5k IOC3 PMB
Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 711-062244 S/N: CADX8554
Assembly ID: 0x0c5a Assembly Version: 01.01
Date: 04-28-2015 Assembly Flags: 0x00
Version: REV 01
ID: SRX5k IOC3 PMB
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 01 ff 0c 5a 01 01 52 45 56 20 30 31 00 00
Address 0x10: 00 00 00 00 37 31 31 2d 30 36 32 32 34 34 00 00
Address 0x20: 53 2f 4e 20 43 41 44 58 38 35 35 34 00 1c 04 07

```

```

Address 0x30: df ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 00 ff ff ff ff ff ff ff ff ff ff
Address 0x50: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x60: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x70: ff ff ff ff 00 00 00 00 2a 47 7e 50 10 05 76 5c
PIC 0 BUILTIN BUILTIN 12x 10GE SFP+
Jedec Code: 0x0000 EEPROM Version: 0x00
P/N: BUILTIN S/N: BUILTIN
Assembly ID: 0x0ab5 Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00
ID: 12x 10GE SFP+
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 00 00 00 00 0a b5 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 42 55 49 4c 54 49 4e 00 25 73 3a 20
Address 0x20: 42 55 49 4c 54 49 4e 00 25 73 3a 20 00 00 00 00
Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 c0 02 a9 3c 00 00 00 00 0a b6 00 00
PIC 1 BUILTIN BUILTIN 12x 10GE SFP+
Jedec Code: 0x0000 EEPROM Version: 0x00
P/N: BUILTIN S/N: BUILTIN
Assembly ID: 0x0ab5 Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00
ID: 12x 10GE SFP+
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 00 00 00 00 0a b5 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 42 55 49 4c 54 49 4e 00 25 73 3a 20
Address 0x20: 42 55 49 4c 54 49 4e 00 25 73 3a 20 00 00 00 00
Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 c0 02 e9 b4 00 00 00 00 0a b5 00 00
PIC 2 BUILTIN BUILTIN 3x 40GE QSFP+
Jedec Code: 0x0000 EEPROM Version: 0x00
P/N: BUILTIN S/N: BUILTIN
Assembly ID: 0x0ab6 Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00
ID: 3x 40GE QSFP+
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 00 00 00 00 0a b6 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 42 55 49 4c 54 49 4e 00 25 73 3a 20
Address 0x20: 42 55 49 4c 54 49 4e 00 25 73 3a 20 00 00 00 00
Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 c0 03 e8 c4 33 24 3a 38 00 00 00 02
PIC 3 BUILTIN BUILTIN 3x 40GE QSFP+
Jedec Code: 0x0000 EEPROM Version: 0x00
P/N: BUILTIN S/N: BUILTIN
Assembly ID: 0x0ab6 Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00

```

```

ID: 3x 40GE QSFP+
Board Information Record:
 Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
 Address 0x00: 00 00 00 00 0a b6 00 00 00 00 00 00 00 00 00 00
 Address 0x10: 00 00 00 00 42 55 49 4c 54 49 4e 00 25 73 3a 20
 Address 0x20: 42 55 49 4c 54 49 4e 00 25 73 3a 20 00 00 00 00
 Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
 Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
 Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
 Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
 Address 0x70: 00 00 00 00 c0 02 ab 1c 00 00 00 00 0a b5 00 00
WAN MEZZ REV 01 750-062682 CAEA4788 24x 10GE SFP+ Mezz
Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 750-062682 S/N: CAEA4788
Assembly ID: 0x0c76 Assembly Version: 01.01
Date: 04-28-2015 Assembly Flags: 0x00
Version: REV 01
ID: 24x 10GE SFP+ Mezz
Board Information Record:
 Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
 Address 0x00: 7f b0 01 ff 0c 76 01 01 52 45 56 20 30 31 00 00
 Address 0x10: 00 00 00 00 37 35 30 2d 30 36 32 36 38 32 00 00
 Address 0x20: 53 2f 4e 20 43 41 45 41 34 37 38 38 00 1c 04 07
 Address 0x30: df ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
 Address 0x40: ff ff ff ff 00 ff ff ff ff ff ff ff ff ff ff ff
 Address 0x50: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
 Address 0x60: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
 Address 0x70: ff ff ff ff 00 00 00 00 00 00 00 00 00 00 00 00
FPC 4 REV 11 750-043157 CACY1592 SRX5k IOC II
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 750-043157 S/N: CACY1592
Assembly ID: 0x0bd1 Assembly Version: 04.11
Date: 07-30-2014 Assembly Flags: 0x00
Version: REV 11 CLEI Code: COUIBCWBAA
ID: SRX5k IOC II FRU Model Number: SRX5K-MPC
Board Information Record:
 Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ae 01 f2 06 00 ff
I2C Hex Data:
 Address 0x00: 7f b0 02 ff 0b d1 04 0b 52 45 56 20 31 31 00 00
 Address 0x10: 00 00 00 00 37 35 30 2d 30 34 33 31 35 37 00 00
 Address 0x20: 53 2f 4e 20 43 41 43 59 31 35 39 32 00 1e 07 07
 Address 0x30: de ff ff ff ff ff ff ff ff ff ff ff ff ff ae 01
 Address 0x40: f2 06 00 ff 01 43 4f 55 49 42 43 57 42 41 41 53
 Address 0x50: 52 58 35 4b 2d 4d 50 43 00 00 00 00 00 00 00 00
 Address 0x60: 00 00 00 00 00 00 41 00 00 ff ff ff ff ff ff ff
 Address 0x70: ff ff ff 92 ff ff ff ff ff ff ff ff ff ff ff ff
CPU REV 04 711-043360 CACZ8831 SRX5k MPC PMB
Jedec Code: 0x7fb0 EEPROM Version: 0x01
P/N: 711-043360 S/N: CACZ8831
Assembly ID: 0x0bd2 Assembly Version: 01.04
Date: 07-28-2014 Assembly Flags: 0x00
Version: REV 04
ID: SRX5k MPC PMB
Board Information Record:
 Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
 Address 0x00: 7f b0 01 ff 0b d2 01 04 52 45 56 20 30 34 00 00
 Address 0x10: 00 00 00 00 37 31 31 2d 30 34 33 33 36 30 00 00
 Address 0x20: 53 2f 4e 20 43 41 43 5a 38 38 33 31 00 1c 07 07

```



```

Address 0x30: de ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 00 ff ff ff ff ff ff ff ff ff ff ff
Address 0x50: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x60: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x70: ff ff ff ff 00 00 00 00 49 fa 60 10 40 05 76 5c
MIC 1 REV 04 750-049488 CACN0239 10x 10GE SFP+
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 750-049488 S/N: CACN0239
Assembly ID: 0x0a88 Assembly Version: 02.04
Date: 02-26-2014 Assembly Flags: 0x00
Version: REV 04 CLEI Code: COUIBCXBAA
ID: 10x 10GE SFP+ FRU Model Number: SRX-MIC-10XG-SFPP
Board Information Record:
 Address 0x00: 34 01 03 03 ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
 Address 0x00: 7f b0 02 ff 0a 88 02 04 52 45 56 20 30 34 00 00
 Address 0x10: 00 00 00 00 37 35 30 2d 30 34 39 34 38 38 00 00
 Address 0x20: 53 2f 4e 20 43 41 43 4e 30 32 33 39 00 1a 02 07
 Address 0x30: de ff ff ff 34 01 03 03 ff ff ff ff ff ff ff ff
 Address 0x40: ff ff ff ff 01 43 4f 55 49 42 43 58 42 41 41 53
 Address 0x50: 52 58 2d 4d 49 43 2d 31 30 58 47 2d 53 46 50 50
 Address 0x60: 00 00 00 00 00 00 41 00 00 ff ff ff ff ff ff ff
 Address 0x70: ff ff ff 9f c0 03 e4 14 55 8a 95 a8 00 00 00 02
PIC 2 BUILTIN BUILTIN 10x 10GE SFP+
 Xcvr 7 REV 01 740-031980 ARN23HW SFP+-10G-SR
 Xcvr 8 REV 01 740-031980 ARN2FVW SFP+-10G-SR
 Xcvr 9 REV 01 740-031980 ARN2YVM SFP+-10G-SR
FPC 5 REV 10 750-056758 CADA8736 SRX5k SPC II
Jedec Code: 0x7fb0 EEPROM Version: 0x02
P/N: 750-056758 S/N: CADA8736
Assembly ID: 0x0b4f Assembly Version: 01.10
Date: 09-01-2014 Assembly Flags: 0x00
Version: REV 10 CLEI Code: COUCATLBAB
ID: SRX5k SPC II FRU Model Number: SRX5K-SPC-4-15-320
Board Information Record:
 Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ae 01 f2 06 00 ff
I2C Hex Data:
 Address 0x00: 7f b0 02 ff 0b 4f 01 0a 52 45 56 20 31 30 00 00
 Address 0x10: 00 00 00 00 37 35 30 2d 30 35 36 37 35 38 00 00
 Address 0x20: 53 2f 4e 20 43 41 44 41 38 37 33 36 00 01 09 07
 Address 0x30: de ff ff ff ff ff ff ff ff ff ff ff ff ff ae 01
 Address 0x40: f2 06 00 ff 01 43 4f 55 43 41 54 4c 42 41 42 53
 Address 0x50: 52 58 35 4b 2d 53 50 43 2d 34 2d 31 35 2d 33 32
 Address 0x60: 30 00 00 00 00 00 43 00 00 ff ff ff ff ff ff ff ff
 Address 0x70: ff ff ff 50 ff ff ff ff ff ff ff ff ff ff ff ff ff
CPU BUILTIN BUILTIN SRX5k DPC PPC
PIC 0 BUILTIN BUILTIN SPU Cp
Jedec Code: 0x0000 EEPROM Version: 0x00
P/N: BUILTIN S/N: BUILTIN
Assembly ID: 0x0a20 Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00
ID: SPU Cp
Board Information Record:
 Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
 Address 0x00: 00 00 00 00 0a 20 00 00 00 00 00 00 00 00 00 00
 Address 0x10: 00 00 00 00 42 55 49 4c 54 49 4e 00 41 73 73 65
 Address 0x20: 42 55 49 4c 54 49 4e 00 41 73 73 65 00 00 00 00
 Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
 Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
 Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

```

```

Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 de ad be ef 46 10 f0 d8 40 43 43 c0
PIC 1 BUILTIN BUILTIN SPU Flow
Jedec Code: 0x0000 EEPROM Version: 0x00
P/N: BUILTIN S/N: BUILTIN
Assembly ID: 0x0a21 Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00
ID: SPU Flow
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 00 00 00 00 0a 21 00 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 42 55 49 4c 54 49 4e 00 41 73 73 65
Address 0x20: 42 55 49 4c 54 49 4e 00 41 73 73 65 00 00 00 00
Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 de ad be ef 46 13 5b d0 40 43 43 c0
PIC 2 BUILTIN BUILTIN SPU Flow
Jedec Code: 0x0000 EEPROM Version: 0x00
P/N: BUILTIN S/N: BUILTIN
Assembly ID: 0x0a21 Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00
ID: SPU Flow
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 00 00 00 00 0a 21 00 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 42 55 49 4c 54 49 4e 00 41 73 73 65
Address 0x20: 42 55 49 4c 54 49 4e 00 41 73 73 65 00 00 00 00
Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 de ad be ef 46 0c 66 40 40 43 43 c0
PIC 3 BUILTIN BUILTIN SPU Flow
Jedec Code: 0x0000 EEPROM Version: 0x00
P/N: BUILTIN S/N: BUILTIN
Assembly ID: 0x0a21 Assembly Version: 00.00
Date: 00-00-0000 Assembly Flags: 0x00
ID: SPU Flow
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 00 00 00 00 0a 21 00 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 42 55 49 4c 54 49 4e 00 41 73 73 65
Address 0x20: 42 55 49 4c 54 49 4e 00 41 73 73 65 00 00 00 00
Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 de ad be ef 46 0e db 00 40 43 43 c0
Fan Tray Enhanced Fan Tray
FRU Model Number: SRX5600-HC-FAN

```

[show chassis hardware clei-models](#)

[show chassis hardware clei-models](#)

## (SRX5600 and SRX5800 devices with SRX5000 line SRX5K-SCBE (SCB2) and SRX5K-RE-1800X4 (RE2))

```

user@host> show chassis hardware clei-models node 1
node1:

Hardware inventory:
Item Version Part number CLEI code FRU model number
Midplane REV 01 710-024803
FPM Board REV 01 710-024632
PEM 0 Rev 04 740-034724
PEM 1 Rev 05 740-034724
Routing Engine 0 REV 01 740-056658 COUCATTBAA SRX5K-RE-1800X4
CB 0 REV 01 750-056587 COUCATSBAA SRX5K-SCBE
CB 1 REV 01 750-056587 COUCATSBAA SRX5K-SCBE
CB 2 REV 01 750-056587 COUCATSBAA SRX5K-SCBE
FPC 0 REV 18 750-054877 COUCATLBAA SRX5K-SPC-4-15-320
 CPU BUILTIN
FPC 1 REV 18 750-054877 COUCATLBAA SRX5K-SPC-4-15-320
 CPU BUILTIN
FPC 2 REV 18 750-054877 COUCATLBAA SRX5K-SPC-4-15-320
 CPU BUILTIN
FPC 3 REV 11 750-043157 COUIBCWBAA SRX5K-MPC
 MIC 0 REV 05 750-049486 COUIBCXBAA SRX-MIC-1X100G-CFP
 MIC 1 REV 04 750-049488 COUIBCXBAA SRX-MIC-10XG-SFPP
FPC 4 REV 18 750-054877 COUCATLBAA SRX5K-SPC-4-15-320
 CPU BUILTIN
FPC 7 REV 18 750-054877 COUCATLBAA SRX5K-SPC-4-15-320
 CPU BUILTIN
FPC 8 REV 11 750-043157 COUIBCWBAA SRX5K-MPC
 MIC 0 REV 05 750-049486 COUIBCXBAA SRX-MIC-1X100G-CFP
FPC 9 REV 18 750-054877 COUCATLBAA SRX5K-SPC-4-15-320
 CPU BUILTIN
FPC 10 REV 18 750-054877 COUCATLBAA SRX5K-SPC-4-15-320
 CPU BUILTIN
Fan Tray 0 REV 04 740-035409
Fan Tray 1 REV 04 740-035409

```

## show chassis hardware clei-models

(SRX5400, SRX5600, and SRX5800 devices with SRX5000 line SRX5K-SCB3 (SCB3) with enhanced midplanes and SRX5K-MPC3-100G10G (IOC3) or SRX5K-MPC3-40G10G (IOC3))

```

user@host> show chassis hardware clei-models
node0:

Hardware inventory:
Item Version Part number CLEI code FRU model number
Midplane REV 01 760-063936 CLEI-CODE SRX5600X-CHAS
FPM Board REV 02 710-017254 CLEI-CODE CRAFT-MX480-S
PEM 0 Rev 03 740-034701 CLEI-CODE SRX5600-PWR-2520-AC-S
PEM 1 Rev 03 740-034701 CLEI-CODE SRX5600-PWR-2520-AC-S
Routing Engine 0 REV 01 740-056658 COUCATTBAA SRX5K-RE-1800X4
CB 0 REV 01 750-062257 CLEI-CODE SRX5K-SCB3
FPC 0 REV 10 750-056758 COUCATLBAB SRX5K-SPC-4-15-320
 CPU BUILTIN
FPC 2 REV 01 750-062243
FPC 4 REV 11 750-043157 COUIBCWBAA SRX5K-MPC
 MIC 1 REV 04 750-049488 COUIBCXBAA SRX-MIC-10XG-SFPP
FPC 5 REV 05 750-044175 PROTOXCLEI 750-044175
 CPU BUILTIN
Fan Tray SRX5600-HC-FAN
node1:

```

-----  
Hardware inventory:

| Item             | Version | Part number | CLEI code  | FRU model number      |
|------------------|---------|-------------|------------|-----------------------|
| Midplane         | REV 01  | 760-063936  | CLEI-CODE  | SRX5600X-CHAS         |
| PEM 0            | Rev 01  | 740-038514  |            | SRX5600-PWR-2400-DC-S |
| PEM 1            | Rev 01  | 740-038514  |            | SRX5600-PWR-2400-DC-S |
| Routing Engine 0 | REV 01  | 740-056658  | COUCATTBAA | SRX5K-RE-1800X4       |
| CB 0             | REV 01  | 750-062257  | CLEI-CODE  | SRX5K-SCB3            |
| FPC 0            | REV 07  | 750-044175  | COUCASFBAA | SRX5K-SPC-4-15-320    |
| CPU              |         | BUILTIN     |            |                       |
| FPC 4            | REV 11  | 750-043157  | COUIBCWBAA | SRX5K-MPC             |
| MIC 1            | REV 04  | 750-049488  | COUIBCXBAA | SRX-MIC-10XG-SFPP     |
| FPC 5            | REV 10  | 750-056758  | COUCATLBAB | SRX5K-SPC-4-15-320    |
| CPU              |         | BUILTIN     |            |                       |
| Fan Tray         |         |             |            | SRX5600-HC-FAN        |

## show chassis pic (Security)

|                                 |                                                                                                                                                                                                   |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show chassis pic fpc-slot <i>slot-number</i> pic-slot <i>slot-number</i></code>                                                                                                             |
| <b>Release Information</b>      | Command introduced in Junos OS Release 9.2.                                                                                                                                                       |
| <b>Description</b>              | Display status information about the PIC installed in the specified Flexible PIC Concentrator (FPC) and PIC slot.                                                                                 |
| <b>Options</b>                  | <p><b>fpc-slot <i>slot-number</i></b>—Display information about the FPC in the slot.</p> <p><b>pic-slot <i>slot-number</i></b>—Display information about the PIC in this particular FPC slot.</p> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                              |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <i>Interfaces Feature Guide for Security Devices</i></li> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>        |
| <b>List of Sample Output</b>    | <a href="#">show chassis pic fpc-slot pic-slot on page 304</a>                                                                                                                                    |
| <b>Output Fields</b>            | <a href="#">Table 25 on page 303</a> lists the output fields for the <b>show chassis pic</b> command. Output fields are listed in the approximate order in which they appear.                     |

**Table 25: show chassis pic Output Fields**

| Field Name  | Field Description                                                                                                                                                                                                         |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type        | PIC type.                                                                                                                                                                                                                 |
| State       | <p>Status of the PIC. State is displayed only when a PIC is in the slot.</p> <ul style="list-style-type: none"> <li>• <b>Online</b>— PIC is online and running.</li> <li>• <b>Offline</b>—PIC is powered down.</li> </ul> |
| PIC version | PIC hardware version.                                                                                                                                                                                                     |
| Uptime      | How long the PIC has been online.                                                                                                                                                                                         |
| Port Number | Port number for the PIC.                                                                                                                                                                                                  |
| Cable Type  | Type of cable connected to the port: LH, LX, or SX.                                                                                                                                                                       |

Table 25: show chassis pic Output Fields (*continued*)

| Field Name                  | Field Description                                                                                                                                                                                                                                                                                                                                                                        |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PIC Port Information</b> | <p>Port-level information for the PIC.</p> <ul style="list-style-type: none"> <li>• Port—Port number</li> <li>• Cable type—Type of transceiver installed.</li> <li>• Fiber type—Type of fiber.</li> <li>• Xcvr vendor—Transceiver vendor name.</li> <li>• Xcvr vendor part number—Transceiver vendor part number.</li> <li>• Wavelength—Wavelength of the transmitted signal.</li> </ul> |

## Sample Output

### show chassis pic fpc-slot pic-slot

```

user@host> show chassis pic fpc-slot 10 pic-slot 0
FPC slot 10, PIC slot 0 information:
 Type 10x 10GE SFP+
 State Online
 PIC version 1.1
 Uptime 6 days, 7 hours, 29 minutes, 28 seconds

PIC port information:
 Port Cable type Fiber type Xcvr vendor Xcvr vendor Wavelength
 0 10GBASE SR MM FINISAR CORP. FTLX8571D3BNL-J1 850 nm

 Xcvr vendor
 firmware version
 0.0

PIC port information:
 Port Cable type Fiber type Xcvr vendor Xcvr vendor Wavelength
 1 10GBASE SR MM FINISAR CORP. FTLX8571D3BNL-J1 850 nm

 Xcvr vendor
 firmware version
 0.0

```

## show chassis power

|                                 |                                                                                                                                                                                               |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show chassis power                                                                                                                                                                            |
| <b>Release Information</b>      | Command modified in Junos OS Release 12.1X44-D10.                                                                                                                                             |
| <b>Description</b>              | Display power limits and usage information for the Power Entry Modules (PEMs).                                                                                                                |
| <b>Options</b>                  | This command has no options.                                                                                                                                                                  |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                          |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">show chassis power sequence on page 307</a></li> </ul> |
| <b>List of Sample Output</b>    | <a href="#">show chassis power on page 306</a>                                                                                                                                                |
| <b>Output Fields</b>            | <a href="#">Table 26 on page 305</a> lists the output fields for the <b>show chassis power</b> command. Output fields are listed in the approximate order in which they appear.               |

**Table 26: show chassis power Output Fields**

| Field Name        | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PEM number</b> | <p>AC or DC PEM number on the chassis. The following output fields are displayed for the PEM:</p> <ul style="list-style-type: none"> <li>• State—State of the PEM: <ul style="list-style-type: none"> <li>• Online—PEM is present in the slot and online.</li> <li>• Empty—PEM is not present in the slot.</li> <li>• Present—PEM is present in the slot, but not online.</li> </ul> </li> <li>• AC Input —State of the AC input power feed with the number of active and expected feeds (1 or 2).</li> <li>• Capacity—Actual power input capacity with maximum capacity displayed (in parentheses) in watts.</li> <li>• DC Output—DC power output, in watts, for the specified zone, at the specified amps and voltage (A @ V), and load and percentage utilization of the maximum capacity for the zone.</li> </ul> |
| <b>System</b>     | <p>Overall power statistics for the system zone:</p> <ul style="list-style-type: none"> <li>• Zone number: <ul style="list-style-type: none"> <li>• Capacity—Maximum power capacity available for the zone, in watts.</li> <li>• Allocated power—Actual capacity allocated for the zone, in watts, with remaining power displayed in parentheses.</li> <li>• Actual usage—Actual power usage for the zone, in watts.</li> </ul> </li> <li>• Total system capacity—Cumulative power capacity of all the zones, in watts.</li> <li>• Total remaining capacity—Difference between the total system capacity and cumulative allocated power of all zones, in watts.</li> </ul>                                                                                                                                            |

## Sample Output

### show chassis power

```
user@host> show chassis power

PEM 0:
 State: Present
 DC input: Out of range (1 feed expected, 0 feed connected)
 DC input: 48.0 V input (0 mV)
 Capacity: 0 W (maximum 4100 W)

PEM 1:
 State: Present
 DC input: Out of range (1 feed expected, 0 feed connected)
 DC input: 48.0 V input (0 mV)
 Capacity: 0 W (maximum 4100 W)

PEM 2:
 State: Online
 DC input: OK (2 feed expected, 2 feed connected)
 DC input: 48.0 V input (57500 mV)
 Capacity: 4100 W (maximum 4100 W)
 DC output: 1881 W (zone 0, 33 A at 57 V, 45% of capacity)

PEM 3:
 State: Online
 DC input: OK (2 feed expected, 2 feed connected)
 DC input: 48.0 V input (56500 mV)
 Capacity: 4100 W (maximum 4100 W)
 DC output: 2464 W (zone 1, 44 A at 56 V, 60% of capacity)

System:
 Zone 0:
 Capacity: 4100 W (maximum 4100 W)
 Allocated power: 2920 W (1180 W remaining)
 Actual usage: 1881 W
 Zone 1:
 Capacity: 4100 W (maximum 4100 W)
 Allocated power: 3875 W (225 W remaining)
 Actual usage: 2464 W
 Total system capacity: 8200 W (maximum 8200 W)
 Total remaining power: 1405 W
```



## show chassis power sequence

|                                 |                                                                                                                                                                                          |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show chassis power sequence                                                                                                                                                              |
| <b>Release Information</b>      | Command modified in Junos OS Release 12.1X44-D10.                                                                                                                                        |
| <b>Description</b>              | Display the power-on sequence for the FPCs in the chassis. The numbers indicate the slot number of the FPCs.                                                                             |
| <b>Options</b>                  | This command has no options.                                                                                                                                                             |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                     |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">fru-poweron-sequence on page 187</a></li> </ul>   |
| <b>List of Sample Output</b>    | <a href="#">show chassis power sequence on page 307</a>                                                                                                                                  |
| <b>Output Fields</b>            | <a href="#">Table 27 on page 307</a> lists the output fields for the <b>show chassis power sequence</b> command. Output fields are listed in the approximate order in which they appear. |

Table 27: show chassis power sequence Output Fields

| Field Name                 | Field Description                                                                                |
|----------------------------|--------------------------------------------------------------------------------------------------|
| Chassis FRU Power Sequence | Power-on sequence for the FPCs in the chassis. The numbers indicate the slot number of the FPCs. |

## Sample Output

### show chassis power sequence

```
user@host> show chassis power sequence
Chassis FRU Power On Sequence: 0 1 2 3 4 5 6 7 8 9 10 11
```

## show firewall (View)

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>show firewall &lt;filter <i>filter-name</i>&gt; &lt;counter <i>counter-name</i>&gt; &lt;log&gt; &lt;prefix-action-stats&gt; &lt;terse&gt;</pre>                                                                                                                                                                                                                                                                           |
| <b>Release Information</b>      | Command introduced before Junos OS Release 10.0 .                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Description</b>              | Display statistics about configured firewall filters.                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Options</b>                  | <p><b>none</b>—Display statistics about configured firewall filters.</p> <p><b>filter <i>filter-name</i></b>—Name of a configured filter.</p> <p><b>counter <i>counter-name</i></b>—Name of a filter counter.</p> <p><b>log</b>—Display log entries for firewall filters.</p> <p><b>prefix-action-stats</b>—Display prefix action statistics for firewall filters.</p> <p><b>terse</b>—Display firewall filter names only.</p> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><i>firewall</i></li> </ul>                                                                                                                                                                                                                                                                                                                                                              |
| <b>List of Sample Output</b>    | <a href="#">show firewall on page 309</a>                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Output Fields</b>            | <a href="#">Table 28 on page 308</a> lists the output fields for the <b>show firewall</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                     |

Table 28: show firewall Output Fields

| Field Name    | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Filter</b> | <p>Name of a filter that has been configured with the <b>filter</b> statement at the <b>[edit firewall]</b> hierarchy level.</p> <p>When an interface-specific filter is displayed, the name of the filter is followed by the full interface name and by either <b>-i</b> for an input filter or <b>-o</b> for an output filter.</p> <p>When dynamic filters are displayed, the name of the filter is followed by the full interface name and by either <b>-in</b> for an input filter or <b>-out</b> for an output filter. When a logical system-specific filter is displayed, the name of the filter is prefixed with two underscore (__) characters and the name of the logical system (for example, __ls1/filter1).</p> |

Table 28: show firewall Output Fields (*continued*)

| Field Name      | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Counters</b> | Display filter counter information: <ul style="list-style-type: none"> <li>• <b>Name</b>—Name of a filter counter that has been configured with the <b>counter</b> firewall filter action.</li> <li>• <b>Bytes</b>—Number of bytes that match the filter term under which the <b>counter</b> action is specified.</li> <li>• <b>Packets</b>—Number of packets that matched the filter term under which the <b>counter</b> action is specified.</li> </ul>                                                                                                                                                 |
| <b>Policers</b> | Display policer information: <ul style="list-style-type: none"> <li>• <b>Name</b>—Name of policer.</li> <li>• <b>Bytes</b>—Number of bytes that match the filter term under which the policer action is specified. This is only the number out-of-specification (out-of-spec) byte counts, not all the bytes in all packets policed by the policer.</li> <li>• <b>Packets</b>—Number of packets that matched the filter term under which the policer action is specified. This is only the number of out-of-specification (out-of-spec) packet counts, not all packets policed by the policer.</li> </ul> |

## Sample Output

### show firewall

```

user@host> show firewall
Filter: ef_path
Counters:
Name Bytes Packets
def-count 0 0
video-count 0 0
voice-count 0 0

Filter: __default_bpdu_filter__

Filter: deep
Counters:
Name Bytes Packets
deep2 302076 5031

Filter: deep-flood
Counters:
Name Bytes Packets
deep_flood_def 302136 5032
deep1 0 0
Policers:
Name Packets
deep-pol-op-first 0

```

## show interfaces (View Aggregated Ethernet)

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <pre>show interfaces &lt;aenumber   rethnumber &gt; &lt;brief   detail   extensive   terse&gt; &lt;descriptions&gt; &lt;media&gt; &lt;snmp-index snmp-index&gt; &lt;statistics&gt;</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Release Information</b>      | Command modified in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Description</b>              | Display status information about the specified aggregated Ethernet interface or redundant Ethernet interface. If you do not specify an interface name, status information for all interfaces is displayed.                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li><i>aenumber   rethnumber</i>—(Optional) Display standard information about the specified aggregated Ethernet interface or redundant Ethernet interface.</li> <li><i>brief   detail   extensive   terse</i>—(Optional) Display the specified level of output.</li> <li><i>descriptions</i>—(Optional) Display interface description strings.</li> <li><i>media</i>—(Optional) Display media-specific information.</li> <li><i>snmp-index snmp-index</i>—(Optional) Display information for the specified SNMP index of the interface.</li> <li><i>statistics</i>—(Optional) Display static interface statistics.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>List of Sample Output</b>    | <a href="#">show interfaces extensive (Aggregated Ethernet) on page 316</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Output Fields</b>            | <a href="#">Table 29 on page 310</a> lists the output fields for the <b>show interfaces</b> (Aggregated Ethernet) command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

Table 29: Aggregated Ethernet show interfaces Output Fields

| Field Name         | Field Description                                                                   | Level of Output       |
|--------------------|-------------------------------------------------------------------------------------|-----------------------|
| Physical Interface |                                                                                     |                       |
| Physical interface | Name of the physical interface and state of the interface.                          | All levels            |
| Enabled            | State of the physical interface.                                                    | All levels            |
| Interface index    | Index number of the physical interface, which reflects its initialization sequence. | All levels            |
| SNMP ifIndex       | SNMP index number for the physical interface.                                       | detail extensive none |

Table 29: Aggregated Ethernet show interfaces Output Fields (*continued*)

| Field Name                     | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                    | Level of Output         |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| <b>Generation</b>              | Unique number for use by Juniper Networks technical support only.                                                                                                                                                                                                                                                                                                                                                                                    | <b>detail extensive</b> |
| <b>Link-level type</b>         | Encapsulation being used on the physical interface.                                                                                                                                                                                                                                                                                                                                                                                                  | All levels              |
| <b>MTU</b>                     | Maximum transmission unit size on the physical interface.                                                                                                                                                                                                                                                                                                                                                                                            | All levels              |
| <b>Speed</b>                   | Speed at which the interface is running.                                                                                                                                                                                                                                                                                                                                                                                                             | All levels              |
| <b>Loopback</b>                | Loopback status: <b>Enabled</b> or <b>Disabled</b> . If loopback is enabled, type of loopback: <b>Local</b> or <b>Remote</b> .                                                                                                                                                                                                                                                                                                                       | All levels              |
| <b>Source filtering</b>        | Source filtering status: <b>Enabled</b> or <b>Disabled</b> .                                                                                                                                                                                                                                                                                                                                                                                         | All levels              |
| <b>Flow control</b>            | Flow control status: <b>Enabled</b> or <b>Disabled</b> .                                                                                                                                                                                                                                                                                                                                                                                             | All levels              |
| <b>Minimum links needed</b>    | Number of child links that must be operational for the aggregate interface to be operational.                                                                                                                                                                                                                                                                                                                                                        | All levels              |
| <b>Device flags</b>            | Information about the physical device.                                                                                                                                                                                                                                                                                                                                                                                                               | All levels              |
| <b>Interface flags</b>         | Information about the interface.                                                                                                                                                                                                                                                                                                                                                                                                                     | All levels              |
| <b>Current address</b>         | Configured MAC address.                                                                                                                                                                                                                                                                                                                                                                                                                              | <b>detail extensive</b> |
| <b>Hardware address</b>        | Hardware MAC address.                                                                                                                                                                                                                                                                                                                                                                                                                                | <b>detail extensive</b> |
| <b>Last flapped</b>            | Date, time, and how long ago the interface went from down to up or up to down. The format is <b>Last flapped: year-month-day hours:minutes:seconds timezone (hours:minutes:seconds ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .                                                                                                                                                                             | <b>detail extensive</b> |
| <b>Input Rate</b>              | Input rate in bits per second (bps) and packets per second (pps).                                                                                                                                                                                                                                                                                                                                                                                    | None specified          |
| <b>Output Rate</b>             | Output rate in bps and pps.                                                                                                                                                                                                                                                                                                                                                                                                                          | None specified          |
| <b>Statistics last cleared</b> | Time when the statistics for the interface were last set to zero.                                                                                                                                                                                                                                                                                                                                                                                    | <b>detail extensive</b> |
| <b>Traffic statistics</b>      | Number and rate of bytes and packets received and transmitted on the physical interface. <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul> | <b>detail extensive</b> |

Table 29: Aggregated Ethernet show interfaces Output Fields (*continued*)

| Field Name              | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Level of Output  |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| IPv6 transit statistics | <p>Number of IPv6 transit bytes and packets received and transmitted on the physical interface if IPv6 statistics tracking is enabled.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | detail extensive |
| Input errors            | <p>Input errors on the interface:</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of incoming frame aborts and frame check sequence (FCS) errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid FCS.</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Giants</b>—Number of frames received that are larger than the giant threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>                                                                                                 | detail extensive |
| Output errors           | <p>Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious:</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b> —Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul> | detail extensive |
| Egress queues           | Total number of egress queues supported on the specified interface                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | detail extensive |
| Queue counters          | <p>CoS queue number and its associated user-configured forwarding class name.</p> <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | detail extensive |
| Logical Interface       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                  |
| Logical interface       | Name of the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | All levels       |

Table 29: Aggregated Ethernet show interfaces Output Fields (*continued*)

| Field Name             | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Level of Output              |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>Index</b>           | Index number of the logical interface (which reflects its initialization sequence).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <b>detail extensive</b> none |
| <b>SNMP ifIndex</b>    | SNMP interface index number of the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <b>detail extensive</b> none |
| <b>Generation</b>      | Unique number for use by Juniper Networks technical support only.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | <b>detail extensive</b>      |
| <b>Flags</b>           | Information about the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | All levels                   |
| <b>VLAN-Tag</b>        | Tag Protocol Identifier (TPID) and VLAN identifier.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | All levels                   |
| <b>Demux</b>           | IP demultiplexing (demux) value that appears if this interface is used as the demux underlying interface. The output is one of the following: <ul style="list-style-type: none"> <li>Source Family Inet</li> <li>Destination Family Inet</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <b>detail extensive</b> none |
| <b>Encapsulation</b>   | Encapsulation on the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | All levels                   |
| <b>Statistics</b>      | Information about the number of packets, packets per second, number of bytes, and bytes per second on this aggregate interface. <ul style="list-style-type: none"> <li><b>Bundle</b>—Information about input and output bundle rates.</li> <li><b>Link</b>—(<b>detail</b> and <b>extensive</b> only) Information about specific links in the aggregate, including link state and input and output rates.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <b>detail extensive</b> none |
| <b>LACP info</b>       | Link Aggregation Control Protocol (LACP) information for each aggregated interface. <ul style="list-style-type: none"> <li><b>Role</b> can be one of the following: <ul style="list-style-type: none"> <li><b>Actor</b>—Local device participating in LACP negotiation.</li> <li><b>Partner</b>—Remote device participating in LACP negotiation.</li> </ul> </li> <li><b>System priority</b>—Priority assigned to the system (by management or administrative policy), encoded as an unsigned integer.</li> <li><b>System identifier</b>—Actor or partner system ID, encoded as a MAC address.</li> <li><b>Port priority</b>—Priority assigned to the port by the actor or partner (by management or administrative policy), encoded as an unsigned integer.</li> <li><b>Port number</b>—Port number assigned to the port by the actor or partner, encoded as an unsigned integer.</li> <li><b>Port key</b>—Operational key value assigned to the port by the actor or partner, encoded as an unsigned integer.</li> </ul> | <b>detail extensive</b> none |
| <b>LACP Statistics</b> | LACP statistics for each aggregated interface. <ul style="list-style-type: none"> <li><b>LACP Rx</b>—LACP received counter that increments for each normal hello.</li> <li><b>LACP Tx</b>—Number of LACP transmit packet errors logged.</li> <li><b>Unknown Rx</b>—Number of unrecognized packet errors logged.</li> <li><b>Illegal Rx</b>—Number of invalid packets received.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <b>detail extensive</b> none |

Table 29: Aggregated Ethernet show interfaces Output Fields (*continued*)

| Field Name                                            | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Level of Output              |
|-------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>Marker Statistic</b>                               | <p>(<b>detail</b> and <b>extensive</b> only) Information about 802.3ad marker protocol statistics on the specified links.</p> <ul style="list-style-type: none"> <li>• <b>Marker Rx</b>—Number of valid marker PDUs received on this aggregation port.</li> <li>• <b>Resp Tx</b>—Number of marker response PDUs transmitted on this aggregation port.</li> <li>• <b>Unknown Rx</b>—Number of frames received that either carry the slow protocols Ethernet type value (43B.4) but contain an unknown protocol data unit (PDU), or are addressed to the slow protocols group MAC address (43B.3) but do not carry the slow protocols Ethernet type.</li> <li>• <b>Illegal Rx</b>—Number of frames received that carry the slow protocols Ethernet type value (43B.4) but contain a badly formed PDU or an illegal value of protocol subtype (43B.4).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <b>detail extensive none</b> |
| <b>Flow Statistics</b>                                | Flow statistics for each aggregated interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <b>detail extensive none</b> |
| <b>Flow Input statistics</b>                          | Statistics for packets received by the flow module.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>detail extensive none</b> |
| <b>Flow Output statistics</b>                         | Statistics for packets sent by the flow module.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | <b>detail extensive none</b> |
| <b>Flow error statistics (Packets dropped due to)</b> | <p>Packet drop statistics for the flow module.</p> <ul style="list-style-type: none"> <li>• <b>Address spoofing</b>—Packet dropped when the screen module detected address spoofing.</li> <li>• <b>Authentication failed</b>—Packet dropped because the IPsec Encapsulating Security Payload (ESP) or Authentication Header (AH) authentication failed.</li> <li>• <b>Incoming NAT errors</b>—Packet dropped because the source NAT rule search failed, an invalid source NAT binding was found, or the NAT allocation failed.</li> <li>• <b>Invalid zone received packet</b>—This counter is not currently in use.</li> <li>• <b>Multiple user authentications</b>—Packet dropped if it matches more than one policy that specifies user authentication. (Sometimes packets are looped through the system more than once. Each time a packet passes through the system, that packet must be permitted by a policy.)</li> <li>• <b>Multiple incoming NAT</b>—Packet dropped if source NAT is specified more than once. (Sometimes packets are looped through the system more than once.)</li> <li>• <b>No parent for a gate</b>—This counter is not currently in use.</li> <li>• <b>No one interested in self packets</b>—This counter is incremented for one of the following reasons: <ul style="list-style-type: none"> <li>• The outbound interface is a self interface, but the packet is not marked as a to-self packet and the destination address is in a source NAT pool.</li> <li>• No service is interested in the to-self packet</li> <li>• When a zone has ident-reset service enabled, the TCP RST to IDENT request for port 113 is sent back and this counter is incremented.</li> </ul> </li> </ul> | <b>detail extensive none</b> |



Table 29: Aggregated Ethernet show interfaces Output Fields (*continued*)

| Field Name                                            | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Level of Output              |
|-------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>Flow error statistics (Packets dropped due to)</b> | Packet drop statistics for the flow module (continued). <ul style="list-style-type: none"> <li>• <b>No minor session</b>—Packet dropped because no minor sessions are available and a minor session was requested. Minor sessions are allocated for storing additional TCP state information.</li> <li>• <b>No more sessions</b>—Packet dropped because there were no more free sessions available.</li> <li>• <b>No NAT gate</b>—This counter is not currently in use.</li> <li>• <b>No route present</b>—Packet dropped because a valid route was not available to forward the packet.</li> <li>• <b>No SA for incoming SPI</b>—Packet dropped because the incoming IPsec packet's security parameter index (SPI) does not match any known SPI.</li> <li>• <b>No tunnel found</b>—Packet dropped because a valid tunnel could not be found.</li> <li>• <b>No session for a gate</b>—Packet dropped by an ALG.</li> <li>• <b>No zone or NULL zone binding</b>—Packet dropped because its incoming interface was not bound to any zone.</li> <li>• <b>Policy denied</b>—The error counter is incremented for one of the following reasons:               <ul style="list-style-type: none"> <li>• Source or destination NAT (or both) has occurred and policy says to drop the packet.</li> <li>• Policy specifies user authentication, which failed.</li> <li>• Policy was configured to deny this packet.</li> </ul> </li> <li>• <b>Security association not active</b>—Packet dropped because an IPsec packet was received for an inactive SA.</li> <li>• <b>TCP sequence number out of window</b>—TCP packet with a sequence number failed the TCP sequence number check that was received.</li> <li>• <b>Syn-attack protection</b>—Packet dropped because of SYN attack protection or SYN cookie protection.</li> <li>• <b>User authentication errors</b>—Packet dropped because policy requires authentication; however:               <ul style="list-style-type: none"> <li>• Only Telnet, FTP, and HTTP traffic can be authenticated.</li> <li>• The corresponding authentication entry could not be found, if web-auth is specified.</li> <li>• The maximum number of authenticated sessions per user was exceeded.</li> </ul> </li> </ul> | <b>detail extensive none</b> |
| <b>protocol-family</b>                                | Protocol family configured on the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>brief</b>                 |
| <b>Protocol</b>                                       | Protocol family configured on the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>detail extensive none</b> |
| <b>MTU</b>                                            | Maximum transmission unit size on the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <b>detail extensive none</b> |
| <b>Maximum labels</b>                                 | Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <b>detail extensive none</b> |
| <b>Generation</b>                                     | Unique number for use by Juniper Networks technical support only.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <b>detail extensive</b>      |
| <b>Route Table</b>                                    | Routing table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <b>detail extensive</b>      |

Table 29: Aggregated Ethernet show interfaces Output Fields (*continued*)

| Field Name                   | Field Description                                                                                                                                          | Level of Output              |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>Flags</b>                 | Information about protocol family flags.                                                                                                                   | <b>detail extensive none</b> |
| <b>Mac-Validate Failures</b> | Number of MAC address validation failures for packets and bytes. This field is displayed when MAC address validation is enabled for the logical interface. | <b>detail extensive none</b> |
| <b>Addresses, Flags</b>      | Information about address flags.                                                                                                                           | <b>detail extensive none</b> |
| <b>Destination</b>           | IP address of the remote side of the connection.                                                                                                           | <b>detail extensive none</b> |
| <b>Local</b>                 | IP address of the logical interface.                                                                                                                       | <b>detail extensive none</b> |
| <b>Broadcast</b>             | Broadcast address of the logical interface.                                                                                                                | <b>detail extensive none</b> |
| <b>Policer</b>               | Policer to be evaluated when packets are received or transmitted on the interface.                                                                         | <b>detail extensive none</b> |
| <b>Generation</b>            | Unique number for use by Juniper Networks technical support only.                                                                                          | <b>detail extensive</b>      |

## Sample Output

### show interfaces extensive (Aggregated Ethernet)

```
user@host> show interfaces ae0 extensive
```

```
Physical interface: ae0, Enabled, Physical link is Up
Interface index: 1973, SNMP ifIndex: 501, Generation: 2176
Link-level type: Ethernet, MTU: 1518, Speed: 3Gbps, BPDU Error: None, MAC-REWRITE
Error: None, Loopback: Disabled,
Source filtering: Disabled, Flow control: Disabled, Minimum links needed: 1,
Minimum bandwidth needed: 0
Device flags : Present Running
Interface flags: SNMP-Traps Internal: 0x4000
Current address: 00:1f:12:8c:af:c0, Hardware address: 00:1f:12:8c:af:c0
Last flapped : 2010-04-16 14:25:36 PDT (00:02:50 ago)
Statistics last cleared: Never
Traffic statistics:
Input bytes : 64 0 bps
Output bytes : 9816525824 463779840 bps
Input packets: 1 0 pps
Output packets: 38345804 226455 pps
IPv6 transit statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Dropped traffic statistics due to STP State:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Input errors:
Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0, Policed discards:
```

```

0, Resource errors: 0
Output errors:
 Carrier transitions: 0, Errors: 0, Drops: 0, MTU errors: 0, Resource errors:
0
Egress queues: 8 supported, 4 in use
Queue counters: Queued packets Transmitted packets Dropped packets

 0 best-effort 38270790 38270790 0

 1 expedited-fo 0 0 0

 2 assured-forw 0 0 0

 3 network-cont 526 526 0

Logical interface ae0.0 (Index 69) (SNMP ifIndex 502) (Generation 692)
Flags: SNMP-Traps 0x4000 VLAN-Tag [0x8100.11] Encapsulation: ENET2
Statistics Packets pps Bytes bps
Bundle:
 Input : 1 0 64 0
 Output: 38572259 226453 9874497884 463775744
Link:
 ge-5/0/1.0
 Input : 0 0 0 0
 Output: 12743866 75484 3262429696 154591232
 ge-5/2/0.0
 Input : 1 0 64 0
 Output: 13043256 75484 3339073116 154591232
 ge-5/2/1.0
 Input : 0 0 0 0
 Output: 12785137 75485 3272995072 154593280
Marker Statistics: Marker Rx Resp Tx Unknown Rx Illegal Rx
 ge-5/0/1.0 0 0 0 0
 ge-5/2/0.0 0 0 0 0
 ge-5/2/1.0 0 0 0 0
Security: Zone: HOST
Allowed host-inbound traffic : bootp bfd bgp dns dvmrp igmp ldp msdp nhrp
ospf pgm pim rip router-discovery rsvp sap vrrp dhcp
finger ftp tftp ident-reset http https ike netconf ping reverse-telnet
reverse-ssh rlogin rpm rsh snmp snmp-trap ssh telnet
traceroute xnm-clear-text xnm-ssl lsping ntp sip
Flow Statistics :
Flow Input statistics :
 Self packets : 0
 ICMP packets : 0
 VPN packets : 0
 Multicast packets : 0
 Bytes permitted by policy : 0
 Connections established : 0
Flow Output statistics:
 Multicast packets : 0
 Bytes permitted by policy : 8976842784
Flow error statistics (Packets dropped due to):
 Address spoofing: 0
 Authentication failed: 0
 Incoming NAT errors: 0
 Invalid zone received packet: 0
 Multiple user authentications: 0
 Multiple incoming NAT: 0
 No parent for a gate: 0
 No one interested in self packets: 0

```

```

No minor session: 0
No more sessions: 0
No NAT gate: 0
No route present: 0
No SA for incoming SPI: 0
No tunnel found: 0
No session for a gate: 0
No zone or NULL zone binding 0
Policy denied: 0
Security association not active: 0
TCP sequence number out of window: 0
Syn-attack protection: 0
User authentication errors: 0
Protocol inet, MTU: 1500, Generation: 841, Route table: 0
Flags: Sendbcast-pkt-to-re
Addresses, Flags: Is-Preferred Is-Primary
Destination: 100.1.1/24, Local: 100.1.1.2, Broadcast: 100.1.1.255,
Generation: 422
Protocol multiservice, MTU: Unlimited, Generation: 842, Route table: 0
Flags: Is-Primary
Policer: Input: __default_arp_policer__
Logical interface ae0.32767 (Index 83) (SNMP ifIndex 503) (Generation 693)
Flags: SNMP-Traps 0x4004000 VLAN-Tag [0x0000.0] Encapsulation: ENET2
Statistics Packets pps Bytes bps
Bundle:
Input : 0 0 0 0
Output: 0 0 0 0
Link:
ge-5/0/1.32767
Input : 0 0 0 0
Output: 0 0 0 0
ge-5/2/0.32767
Input : 0 0 0 0
Output: 0 0 0 0
ge-5/2/1.32767
Input : 0 0 0 0
Output: 0 0 0 0
LACP info: Role System System Port Port Port
priority identifier priority number key

ge-5/0/1.32767 Actor 127 00:1f:12:8c:af:c0 127 833 1
ge-5/0/1.32767 Partner 127 00:1f:12:8f:d7:c0 127 641 1
ge-5/2/0.32767 Actor 127 00:1f:12:8c:af:c0 127 848 1
ge-5/2/0.32767 Partner 127 00:1f:12:8f:d7:c0 127 656 1
ge-5/2/1.32767 Actor 127 00:1f:12:8c:af:c0 127 849 1
ge-5/2/1.32767 Partner 127 00:1f:12:8f:d7:c0 127 657 1

LACP Statistics: LACP Rx LACP Tx Unknown Rx Illegal Rx
ge-5/0/1.32767 342 511 0 0
ge-5/2/0.32767 344 498 0 0
ge-5/2/1.32767 344 500 0 0
Marker Statistics: Marker Rx Resp Tx Unknown Rx Illegal Rx
ge-5/0/1.32767 0 0 0 0
ge-5/2/0.32767 0 0 0 0
ge-5/2/1.32767 0 0 0 0

```

```

Security: Zone: HOST
Allowed host-inbound traffic : bootp bfd bgp dns dvmrp igmp ldp msdp nhrp
ospf pgm pim rip router-discovery rsvp sap vrrp dhcp
finger ftp tftp ident-reset http https ike netconf ping reverse-telnet
reverse-ssh rlogin rpm rsh snmp snmp-trap ssh telnet
traceroute xnm-clear-text xnm-ssl lsping ntp sip
Flow Statistics :
Flow Input statistics :
 Self packets : 0
 ICMP packets : 0
 VPN packets : 0
 Multicast packets : 0
 Bytes permitted by policy : 0
 Connections established : 0
Flow Output statistics:
 Multicast packets : 0
 Bytes permitted by policy : 0
Flow error statistics (Packets dropped due to):
 Address spoofing: 0
 Authentication failed: 0
 Incoming NAT errors: 0
 Invalid zone received packet: 0
 Multiple user authentications: 0
 Multiple incoming NAT: 0
 No parent for a gate: 0
 No one interested in self packets: 0
 No minor session: 0
 No more sessions: 0
 No NAT gate: 0
 No route present: 0
 No SA for incoming SPI: 0
 No tunnel found: 0
 No session for a gate: 0
 No zone or NULL zone binding 0
 Policy denied: 0
 Security association not active: 0
 TCP sequence number out of window: 0
 Syn-attack protection: 0
 User authentication errors: 0
Protocol multiservice, MTU: Unlimited, Generation: 843, Route table: 0
Flags: None
Policer: Input: __default_arp_policer__

```

## show interfaces (SRX Series)

---

**Syntax** `show interfaces`  
`< interface-name | brief | controller | descriptions | destination-class | detail | diagnostics |`  
`extensive | far-end-interval | filters | flow-statistics | interval | load-balancing |`  
`mac-database | mc-ae | media | policers | queue | redundancy | routing | routing-instance`  
`| snmp-index | source-class | statistics | switch-port | terse | transport | zone >`

**Release Information** Command modified in Junos OS Release 9.5.

**Description** Display status information and statistics about interfaces on SRX Series appliance running Junos OS.

On SRX Series appliance, on configuring identical IPs on a single interface, you will not see a warning message; instead, you will see a syslog message.

- Options**
- **interface-name**—(Optional) Display standard information about the specified interface. Following is a list of typical interface names. Replace *pim* with the PIM slot and port with the port number.
    - **at-*pim*/0/*port***—ATM-over-ADSL or ATM-over-SHDSL interface.
    - **ce1-*pim*/0/ *port***—Channelized E1 interface.
    - **cl-0/0/8**—3G wireless modem interface for SRX320 devices.
    - **ct1-*pim*/0/*port***—Channelized T1 interface.
    - **dl0**—Dialer Interface for initiating ISDN and USB modem connections.
    - **e1-*pim*/0/*port***—E1 interface.
    - **e3-*pim*/0/*port***—E3 interface.
    - **fe-*pim*/0/*port***—Fast Ethernet interface.
    - **ge-*pim*/0/*port***—Gigabit Ethernet interface.
    - **se-*pim*/0/*port***—Serial interface.
    - **t1-*pim*/0/*port***—T1 (also called DS1) interface.
    - **t3-*pim*/0/*port***—T3 (also called DS3) interface.
    - **wx-slot/0/0**—WAN acceleration interface, for the WXC Integrated Services Module (ISM 200).
  - **brief**—(Optional) Display brief output.
  - **controller**—(Optional) Show controller information.
  - **descriptions**—(Optional) Display interface description strings.
  - **destination-class**—(Optional) Show statistics for destination class.
  - **detail**—(Optional) Display detailed output.
  - **diagnostics**—(Optional) Show interface diagnostics information.

- **extensive**—(Optional) Display extensive output.
- **far-end-interval**—(Optional) Show far end interval statistics.
- **filters**—(Optional) Show interface filters information.
- **flow-statistics**—(Optional) Show security flow counters and errors.
- **interval**—(Optional) Show interval statistics.
- **load-balancing**—(Optional) Show load-balancing status.
- **mac-database**—(Optional) Show media access control database information.
- **mc-ae**—(Optional) Show MC-AE configured interface information.
- **media**—(Optional) Display media information.
- **policers**—(Optional) Show interface policers information.
- **queue**—(Optional) Show queue statistics for this interface.
- **redundancy**—(Optional) Show redundancy status.
- **routing**—(Optional) Show routing status.
- **routing-instance**—(Optional) Name of routing instance.
- **snmp-index**—(Optional) SNMP index of interface.
- **source-class**—(Optional) Show statistics for source class.
- **statistics**—(Optional) Display statistics and detailed output.
- **switch-port**—(Optional) Front end port number (0..15).
- **terse**—(Optional) Display terse output.
- **transport**—(Optional) Show interface transport information.
- **zone**—(Optional) Interface's zone.

**Required Privilege Level** view

**Related Documentation** [• Understanding Interfaces](#)

**List of Sample Output** [show interfaces Gigabit Ethernet on page 328](#)  
[show interfaces extensive \(Gigabit Ethernet\) on page 329](#)  
[show interfaces detail \(Gigabit Ethernet\) on page 331](#)  
[show interfaces terse on page 333](#)

**Output Fields** [Table 30 on page 322](#) lists the output fields for the **show interfaces** command. Output fields are listed in the approximate order in which they appear.

Table 30: show interfaces Output Fields

| Field Name                | Field Description                                                                                                                                                                                                                                   | Level of Output              |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>Physical Interface</b> |                                                                                                                                                                                                                                                     |                              |
| <b>Physical interface</b> | Name of the physical interface.                                                                                                                                                                                                                     | All levels                   |
| <b>Enabled</b>            | State of the interface.                                                                                                                                                                                                                             | All levels                   |
| <b>Interface index</b>    | Index number of the physical interface, which reflects its initialization sequence.                                                                                                                                                                 | <b>detail extensive none</b> |
| <b>SNMP ifIndex</b>       | SNMP index number for the physical interface.                                                                                                                                                                                                       | <b>detail extensive none</b> |
| <b>Link-level type</b>    | Encapsulation being used on the physical interface.                                                                                                                                                                                                 | All levels                   |
| <b>Generation</b>         | Unique number for use by Juniper Networks technical support only.                                                                                                                                                                                   | <b>detail extensive</b>      |
| <b>MTU</b>                | Maximum transmission unit size on the physical interface.                                                                                                                                                                                           | All levels                   |
| <b>Link mode</b>          | Link mode: Full-duplex or Half-duplex.                                                                                                                                                                                                              |                              |
| <b>Speed</b>              | Speed at which the interface is running.                                                                                                                                                                                                            | All levels                   |
| <b>BPDU error</b>         | Bridge protocol data unit (BPDU) error: Detected or None                                                                                                                                                                                            |                              |
| <b>Loopback</b>           | Loopback status: <b>Enabled</b> or <b>Disabled</b> . If loopback is enabled, type of loopback: <b>Local</b> or <b>Remote</b> .                                                                                                                      | All levels                   |
| <b>Source filtering</b>   | Source filtering status: <b>Enabled</b> or <b>Disabled</b> .                                                                                                                                                                                        | All levels                   |
| <b>Flow control</b>       | Flow control status: <b>Enabled</b> or <b>Disabled</b> .                                                                                                                                                                                            | All levels                   |
| <b>Auto-negotiation</b>   | (Gigabit Ethernet interfaces) Autonegotiation status: <b>Enabled</b> or <b>Disabled</b> .                                                                                                                                                           | All levels                   |
| <b>Remote-fault</b>       | (Gigabit Ethernet interfaces) Remote fault status: <ul style="list-style-type: none"> <li>• <b>Online</b>—Autonegotiation is manually configured as online.</li> <li>• <b>Offline</b>—Autonegotiation is manually configured as offline.</li> </ul> | All levels                   |
| <b>Device flags</b>       | Information about the physical device.                                                                                                                                                                                                              | All levels                   |
| <b>Interface flags</b>    | Information about the interface.                                                                                                                                                                                                                    | All levels                   |
| <b>Link flags</b>         | Information about the physical link.                                                                                                                                                                                                                | All levels                   |
| <b>CoS queues</b>         | Number of CoS queues configured.                                                                                                                                                                                                                    | <b>detail extensive none</b> |
| <b>Current address</b>    | Configured MAC address.                                                                                                                                                                                                                             | <b>detail extensive none</b> |



Table 30: show interfaces Output Fields (*continued*)

| Field Name                              | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Level of Output              |
|-----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>Last flapped</b>                     | Date, time, and how long ago the interface went from down to up. The format is <b>Last flapped: year-month-day hour:minute:second:timezone (hour:minute:second ago)</b> . For example, <b>Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)</b> .                                                                                                                                                                                                                                                                          | <b>detail extensive none</b> |
| <b>Input Rate</b>                       | Input rate in bits per second (bps) and packets per second (pps).                                                                                                                                                                                                                                                                                                                                                                                                                                                             | None                         |
| <b>Output Rate</b>                      | Output rate in bps and pps.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | None                         |
| <b>Active alarms and Active defects</b> | <p>Ethernet-specific defects that can prevent the interface from passing packets. When a defect persists for a certain amount of time, it is promoted to an alarm. These fields can contain the value <b>None</b> or <b>Link</b>.</p> <ul style="list-style-type: none"> <li>• <b>None</b>—There are no active defects or alarms.</li> <li>• <b>Link</b>—Interface has lost its link state, which usually means that the cable is unplugged, the far-end system has been turned off, or the PIC is malfunctioning.</li> </ul> | <b>detail extensive none</b> |
| <b>Statistics last cleared</b>          | Time when the statistics for the interface were last set to zero.                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <b>detail extensive</b>      |
| <b>Traffic statistics</b>               | <p>Number and rate of bytes and packets received and transmitted on the physical interface.</p> <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—Number of bytes received on the interface.</li> <li>• <b>Output bytes</b>—Number of bytes transmitted on the interface.</li> <li>• <b>Input packets</b>—Number of packets received on the interface.</li> <li>• <b>Output packets</b>—Number of packets transmitted on the interface.</li> </ul>                                                                  | <b>detail extensive</b>      |

Table 30: show interfaces Output Fields (*continued*)

| Field Name           | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Level of Output  |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Input errors</b>  | <p>Input errors on the interface.</p> <ul style="list-style-type: none"> <li>• <b>Errors</b>—Sum of the incoming frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Framing errors</b>—Number of packets received with an invalid frame checksum (FCS).</li> <li>• <b>Runts</b>—Number of frames received that are smaller than the runt threshold.</li> <li>• <b>Policed discards</b>—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that Junos OS does not handle.</li> <li>• <b>L3 incompletes</b>—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded. L3 incomplete errors can be ignored by configuring the <b>ignore-l3-incompletes</b> statement.</li> <li>• <b>L2 channel errors</b>—Number of times the software did not find a valid logical interface for an incoming frame.</li> <li>• <b>L2 mismatch timeouts</b>—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the receive direction that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul>                                                                                                                                                    | <b>extensive</b> |
| <b>Output errors</b> | <p>Output errors on the interface.</p> <ul style="list-style-type: none"> <li>• <b>Carrier transitions</b>—Number of times the interface has gone from <b>down</b> to <b>up</b>. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.</li> <li>• <b>Errors</b>—Sum of the outgoing frame aborts and FCS errors.</li> <li>• <b>Drops</b>—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.</li> <li>• <b>Collisions</b>—Number of Ethernet collisions. The Gigabit Ethernet PIC supports only full-duplex operation, so for Gigabit Ethernet PICs, this number should always remain 0. If it is nonzero, there is a software bug.</li> <li>• <b>Aged packets</b>—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.</li> <li>• <b>FIFO errors</b>—Number of FIFO errors in the send direction as reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.</li> <li>• <b>HS link CRC errors</b>—Number of errors on the high-speed links between the ASICs responsible for handling the interfaces.</li> <li>• <b>MTU errors</b>—Number of packets whose size exceeded the MTU of the interface.</li> <li>• <b>Resource errors</b>—Sum of transmit drops.</li> </ul> | <b>extensive</b> |

Table 30: show interfaces Output Fields (*continued*)

| Field Name                      | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Level of Output  |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| Ingress queues                  | Total number of ingress queues supported on the specified interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | extensive        |
| Queue counters and queue number | CoS queue number and its associated user-configured forwarding class name. <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | detail extensive |
| MAC statistics                  | Receive and Transmit statistics reported by the PIC's MAC subsystem, including the following: <ul style="list-style-type: none"> <li>• <b>Total octets and total packets</b>—Total number of octets and packets.</li> <li>• <b>Unicast packets, Broadcast packets, and Multicast packets</b>—Number of unicast, broadcast, and multicast packets.</li> <li>• <b>CRC/Align errors</b>—Total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error).</li> <li>• <b>FIFO error</b>—Number of FIFO errors that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC or a cable is probably malfunctioning.</li> <li>• <b>MAC control frames</b>—Number of MAC control frames.</li> <li>• <b>MAC pause frames</b>—Number of MAC control frames with <b>pause</b> operational code.</li> <li>• <b>Oversized frames</b>—There are two possible conditions regarding the number of oversized frames: <ul style="list-style-type: none"> <li>• Packet length exceeds 1518 octets, or</li> <li>• Packet length exceeds MRU</li> </ul> </li> <li>• <b>Jabber frames</b>—Number of frames that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is from 20 ms to 150 ms.</li> <li>• <b>Fragment frames</b>—Total number of packets that were less than 64 octets in length (excluding framing bits, but including FCS octets) and had either an FCS error or an alignment error. Fragment frames normally increment because both runts (which are normal occurrences caused by collisions) and noise hits are counted.</li> <li>• <b>VLAN tagged frames</b>—Number of frames that are VLAN tagged. The system uses the TPID of 0x8100 in the frame to determine whether a frame is tagged or not.</li> <li>• <b>Code violations</b>—Number of times an event caused the PHY to indicate "Data reception error" or "invalid data symbol error."</li> </ul> | extensive        |

Table 30: show interfaces Output Fields (*continued*)

| Field Name                             | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Level of Output |
|----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Filter statistics                      | <p>Receive and Transmit statistics reported by the PIC's MAC address filter subsystem. The filtering is done by the content-addressable memory (CAM) on the PIC. The filter examines a packet's source and destination MAC addresses to determine whether the packet should enter the system or be rejected.</p> <ul style="list-style-type: none"> <li>• <b>Input packet count</b>—Number of packets received from the MAC hardware that the filter processed.</li> <li>• <b>Input packet rejects</b>—Number of packets that the filter rejected because of either the source MAC address or the destination MAC address.</li> <li>• <b>Input DA rejects</b>—Number of packets that the filter rejected because the destination MAC address of the packet is not on the accept list. It is normal for this value to increment. When it increments very quickly and no traffic is entering the device from the far-end system, either there is a bad ARP entry on the far-end system, or multicast routing is not on and the far-end system is sending many multicast packets to the local device (which the router is rejecting).</li> <li>• <b>Input SA rejects</b>—Number of packets that the filter rejected because the source MAC address of the packet is not on the accept list. The value in this field should increment only if source MAC address filtering has been enabled. If filtering is enabled, if the value increments quickly, and if the system is not receiving traffic that it should from the far-end system, it means that the user-configured source MAC addresses for this interface are incorrect.</li> <li>• <b>Output packet count</b>—Number of packets that the filter has given to the MAC hardware.</li> <li>• <b>Output packet pad count</b>—Number of packets the filter padded to the minimum Ethernet size (60 bytes) before giving the packet to the MAC hardware. Usually, padding is done only on small ARP packets, but some very small IP packets can also require padding. If this value increments rapidly, either the system is trying to find an ARP entry for a far-end system that does not exist or it is misconfigured.</li> <li>• <b>Output packet error count</b>—Number of packets with an indicated error that the filter was given to transmit. These packets are usually aged packets or are the result of a bandwidth problem on the FPC hardware. On a normal system, the value of this field should not increment.</li> <li>• <b>CAM destination filters, CAM source filters</b>—Number of entries in the CAM dedicated to destination and source MAC address filters. There can only be up to 64 source entries. If source filtering is disabled, which is the default, the values for these fields should be 0.</li> </ul> | extensive       |
| Autonegotiation information            | <p>Information about link autonegotiation.</p> <ul style="list-style-type: none"> <li>• <b>Negotiation status:</b> <ul style="list-style-type: none"> <li>• <b>Incomplete</b>—Ethernet interface has the speed or link mode configured.</li> <li>• <b>No autonegotiation</b>—Remote Ethernet interface has the speed or link mode configured, or does not perform autonegotiation.</li> <li>• <b>Complete</b>—Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | extensive       |
| Packet Forwarding Engine configuration | <p>Information about the configuration of the Packet Forwarding Engine:</p> <ul style="list-style-type: none"> <li>• <b>Destination slot</b>—FPC slot number.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | extensive       |

Table 30: show interfaces Output Fields (*continued*)

| Field Name                           | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Level of Output              |
|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>CoS information</b>               | Information about the CoS queue for the physical interface. <ul style="list-style-type: none"> <li>• <b>CoS transmit queue</b>—Queue number and its associated user-configured forwarding class name.</li> <li>• <b>Bandwidth %</b>—Percentage of bandwidth allocated to the queue.</li> <li>• <b>Bandwidth bps</b>—Bandwidth allocated to the queue (in bps).</li> <li>• <b>Buffer %</b>—Percentage of buffer space allocated to the queue.</li> <li>• <b>Buffer usec</b>—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time.</li> <li>• <b>Priority</b>—Queue priority: <b>low</b> or <b>high</b>.</li> <li>• <b>Limit</b>—Displayed if rate limiting is configured for the queue. Possible values are <b>none</b> and <b>exact</b>. If <b>exact</b> is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If <b>none</b> is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.</li> </ul> | <b>extensive</b>             |
| <b>Interface transmit statistics</b> | Status of the <b>interface-transmit-statistics</b> configuration: Enabled or Disabled.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <b>detail extensive</b>      |
| <b>Queue counters (Egress)</b>       | CoS queue number and its associated user-configured forwarding class name. <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | <b>detail extensive</b>      |
| <b>Logical Interface</b>             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                              |
| <b>Logical interface</b>             | Name of the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | All levels                   |
| <b>Index</b>                         | Index number of the logical interface, which reflects its initialization sequence.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <b>detail extensive none</b> |
| <b>SNMP ifIndex</b>                  | SNMP interface index number for the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <b>detail extensive none</b> |
| <b>Generation</b>                    | Unique number for use by Juniper Networks technical support only.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <b>detail extensive</b>      |
| <b>Flags</b>                         | Information about the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | All levels                   |
| <b>Encapsulation</b>                 | Encapsulation on the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | All levels                   |
| <b>Traffic statistics</b>            | Number and rate of bytes and packets received and transmitted on the specified interface set. <ul style="list-style-type: none"> <li>• <b>Input bytes, Output bytes</b>—Number of bytes received and transmitted on the interface set. The value in this field also includes the Layer 2 overhead bytes for ingress or egress traffic on Ethernet interfaces if you enable accounting of Layer 2 overhead at the PIC level or the logical interface level.</li> <li>• <b>Input packets, Output packets</b>—Number of packets received and transmitted on the interface set.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <b>detail extensive</b>      |

Table 30: show interfaces Output Fields (*continued*)

| Field Name                                            | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Level of Output              |
|-------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| <b>Local statistics</b>                               | Number and rate of bytes and packets destined to the device.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | <b>extensive</b>             |
| <b>Transit statistics</b>                             | Number and rate of bytes and packets transiting the switch.<br><br><b>NOTE:</b> For Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces, the logical interface egress statistics might not accurately reflect the traffic on the wire when output shaping is applied. Traffic management output shaping might drop packets after they are tallied by the <b>Output bytes</b> and <b>Output packets</b> interface counters. However, correct values display for both of these egress statistics when per-unit scheduling is enabled for the Gigabit Ethernet IQ2 physical interface, or when a single logical interface is actively using a shared scheduler. | <b>extensive</b>             |
| <b>Security</b>                                       | Security zones that interface belongs to.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <b>extensive</b>             |
| <b>Flow Input statistics</b>                          | Statistics on packets received by flow module.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | <b>extensive</b>             |
| <b>Flow Output statistics</b>                         | Statistics on packets sent by flow module.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <b>extensive</b>             |
| <b>Flow error statistics (Packets dropped due to)</b> | Statistics on errors in the flow module.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <b>extensive</b>             |
| <b>Protocol</b>                                       | Protocol family.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>detail extensive none</b> |
| <b>MTU</b>                                            | Maximum transmission unit size on the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <b>detail extensive none</b> |
| <b>Generation</b>                                     | Unique number for use by Juniper Networks technical support only.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | <b>detail extensive</b>      |
| <b>Route Table</b>                                    | Route table in which the logical interface address is located. For example, 0 refers to the routing table inet.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | <b>detail extensive none</b> |
| <b>Flags</b>                                          | Information about protocol family flags. .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <b>detail extensive</b>      |
| <b>Addresses, Flags</b>                               | Information about the address flags..                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | <b>detail extensive none</b> |
| <b>Destination</b>                                    | IP address of the remote side of the connection.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>detail extensive none</b> |
| <b>Local</b>                                          | IP address of the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <b>detail extensive none</b> |
| <b>Broadcast</b>                                      | Broadcast address of the logical interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <b>detail extensive none</b> |
| <b>Generation</b>                                     | Unique number for use by Juniper Networks technical support only.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | <b>detail extensive</b>      |

## Sample Output

### show interfaces Gigabit Ethernet

```
user@host> show interfaces ge-0/0/1
```

```

Physical interface: ge-0/0/1, Enabled, Physical link is Down
 Interface index: 135, SNMP ifIndex: 510
 Link-level type: Ethernet, MTU: 1514, Link-mode: Full-duplex, Speed: 1000mbps,

 BPDU Error: None, MAC-REWRITE Error: None, Loopback: Disabled,
 Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
 Remote fault: Online
 Device flags : Present Running Down
 Interface flags: Hardware-Down SNMP-Traps Internal: 0x0
 Link flags : None
 CoS queues : 8 supported, 8 maximum usable queues
 Current address: 00:1f:12:e4:b1:01, Hardware address: 00:1f:12:e4:b1:01
 Last flapped : 2015-05-12 08:36:59 UTC (1w1d 22:42 ago)
 Input rate : 0 bps (0 pps)
 Output rate : 0 bps (0 pps)
 Active alarms : LINK
 Active defects : LINK
 Interface transmit statistics: Disabled

Logical interface ge-0/0/1.0 (Index 71) (SNMP ifIndex 514)
 Flags: Device-Down SNMP-Traps 0x0 Encapsulation: ENET2
 Input packets : 0
 Output packets: 0
 Security: Zone: public
 Protocol inet, MTU: 1500
 Flags: Sendbroadcast-pkt-to-re
 Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
 Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255

```

## Sample Output

### show interfaces extensive (Gigabit Ethernet)

```

user@host> show interfaces ge-0/0/1.0 extensive
Physical interface: ge-0/0/1, Enabled, Physical link is Down
 Interface index: 135, SNMP ifIndex: 510, Generation: 138
 Link-level type: Ethernet, MTU: 1514, Link-mode: Full-duplex, Speed: 1000mbps,

 BPDU Error: None, MAC-REWRITE Error: None, Loopback: Disabled,
 Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
 Remote fault: Online
 Device flags : Present Running Down
 Interface flags: Hardware-Down SNMP-Traps Internal: 0x0
 Link flags : None
 CoS queues : 8 supported, 8 maximum usable queues
 Hold-times : Up 0 ms, Down 0 ms
 Current address: 00:1f:12:e4:b1:01, Hardware address: 00:1f:12:e4:b1:01
 Last flapped : 2015-05-12 08:36:59 UTC (1w1d 22:57 ago)
 Statistics last cleared: Never
 Traffic statistics:
 Input bytes : 0 0 bps
 Output bytes: 0 0 bps
 Input packets: 0 0 pps
 Output packets: 0 0 pps
 Input errors:
 Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
 L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
 FIFO errors: 0, Resource errors: 0
 Output errors:
 Carrier transitions: 0, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,

```

```

FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Egress queues: 8 supported, 4 in use
Queue counters: Queued packets Transmitted packets Dropped packets

 0 best-effort 0 0 0
 1 expedited-fo 0 0 0
 2 assured-forw 0 0 0
 3 network-cont 0 0 0

Queue number: Mapped forwarding classes
 0 best-effort
 1 expedited-forwarding
 2 assured-forwarding
 3 network-control

Active alarms : LINK
Active defects : LINK
MAC statistics:
Total octets Receive Transmit
Total packets 0 0
Unicast packets 0 0
Broadcast packets 0 0
Multicast packets 0 0
CRC/Align errors 0 0
FIFO errors 0 0
MAC control frames 0 0
MAC pause frames 0 0
Oversized frames 0
Jabber frames 0
Fragment frames 0
VLAN tagged frames 0
Code violations 0

Filter statistics:
Input packet count 0
Input packet rejects 0
Input DA rejects 0
Input SA rejects 0
Output packet count 0
Output packet pad count 0
Output packet error count 0
CAM destination filters: 2, CAM source filters: 0
Autonegotiation information:
Negotiation status: Incomplete
Packet Forwarding Engine configuration:
Destination slot: 0
CoS information:
Direction : Output
CoS transmit queue Bandwidth Buffer Priority
Limit
 % bps % usec
 0 best-effort 95 950000000 95 0 low
none
 3 network-control 5 50000000 5 0 low
none
Interface transmit statistics: Disabled

Logical interface ge-0/0/1.0 (Index 71) (SNMP ifIndex 514) (Generation 136)
Flags: Device-Down SNMP-Traps 0x0 Encapsulation: ENET2
Traffic statistics:

```



```

Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Local statistics:
Input bytes : 0
Output bytes : 0
Input packets: 0
Output packets: 0
Transit statistics:
Input bytes : 0 0 bps
Output bytes : 0 0 bps
Input packets: 0 0 pps
Output packets: 0 0 pps
Security: Zone: public
Flow Statistics :
Flow Input statistics :
Self packets : 0
ICMP packets : 0
VPN packets : 0
Multicast packets : 0
Bytes permitted by policy : 0
Connections established : 0
Flow Output statistics:
Multicast packets : 0
Bytes permitted by policy : 0
Flow error statistics (Packets dropped due to):
Address spoofing: 0
Authentication failed: 0
Incoming NAT errors: 0
Invalid zone received packet: 0
Multiple user authentications: 0
Multiple incoming NAT: 0
No parent for a gate: 0
No one interested in self packets: 0
No minor session: 0
No more sessions: 0
No NAT gate: 0
No route present: 0
No SA for incoming SPI: 0
No tunnel found: 0
No session for a gate: 0
No zone or NULL zone binding 0
Policy denied: 0
Security association not active: 0
TCP sequence number out of window: 0
Syn-attack protection: 0
User authentication errors: 0
Protocol inet, MTU: 1500, Generation: 150, Route table: 0
Flags: Sendbroadcast-pkt-to-re
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255,
Generation: 150

```

## Sample Output

### show interfaces detail (Gigabit Ethernet)

```
user@host> show interfaces ge-0/0/1 detail
```

```

Physical interface: ge-0/0/1, Enabled, Physical link is Down
 Interface index: 135, SNMP ifIndex: 510, Generation: 138
 Link-level type: Ethernet, MTU: 1514, Link-mode: Full-duplex, Speed: 1000mbps,
 BPDU Error: None, MAC-REWRITE Error: None, Loopback: Disabled, Source filtering:
 Disabled,
 Flow control: Enabled, Auto-negotiation: Enabled, Remote fault: Online
 Device flags : Present Running Down
 Interface flags: Hardware-Down SNMP-Traps Internal: 0x0
 Link flags : None
 CoS queues : 8 supported, 8 maximum usable queues
 Hold-times : Up 0 ms, Down 0 ms
 Current address: 00:1f:12:e4:b1:01, Hardware address: 00:1f:12:e4:b1:01
 Last flapped : 2015-05-12 08:36:59 UTC (1w2d 00:00 ago)
 Statistics last cleared: Never
 Traffic statistics:
 Input bytes : 0 0 bps
 Output bytes : 0 0 bps
 Input packets: 0 0 pps
 Output packets: 0 0 pps
 Egress queues: 8 supported, 4 in use
 Queue counters:
 Queued packets Transmitted packets Dropped packets

 0 best-effort 0 0 0
 1 expedited-fo 0 0 0
 2 assured-forw 0 0 0
 3 network-cont 0 0 0

 Queue number: Mapped forwarding classes
 0 best-effort
 1 expedited-forwarding
 2 assured-forwarding
 3 network-control
 Active alarms : LINK
 Active defects : LINK
 Interface transmit statistics: Disabled

 Logical interface ge-0/0/1.0 (Index 71) (SNMP ifIndex 514) (Generation 136)
 Flags: Device-Down SNMP-Traps 0x0 Encapsulation: ENET2
 Traffic statistics:
 Input bytes : 0
 Output bytes : 0
 Input packets: 0
 Output packets: 0
 Local statistics:
 Input bytes : 0
 Output bytes : 0
 Input packets: 0
 Output packets: 0
 Transit statistics:
 Input bytes : 0 0 bps
 Output bytes : 0 0 bps
 Input packets: 0 0 pps
 Output packets: 0 0 pps
 Security: Zone: public
 Flow Statistics :
 Flow Input statistics :
 Self packets : 0
 ICMP packets : 0

```

```

VPN packets : 0
Multicast packets : 0
Bytes permitted by policy : 0
Connections established : 0
Flow Output statistics:
 Multicast packets : 0
 Bytes permitted by policy : 0
Flow error statistics (Packets dropped due to):
 Address spoofing: 0
 Authentication failed: 0
 Incoming NAT errors: 0
 Invalid zone received packet: 0
 Multiple user authentications: 0
 Multiple incoming NAT: 0
 No parent for a gate: 0
 No one interested in self packets: 0
 No minor session: 0
 No more sessions: 0
 No NAT gate: 0
 No route present: 0
 No SA for incoming SPI: 0
 No tunnel found: 0
 No session for a gate: 0
 No zone or NULL zone binding: 0
 Policy denied: 0
 Security association not active: 0
 TCP sequence number out of window: 0
 Syn-attack protection: 0
 User authentication errors: 0
Protocol inet, MTU: 1500, Generation: 150, Route table: 0
Flags: Sendbroadcast-pkt-to-re
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
 Destination: 1.1.1/24, Local: 1.1.1.1, Broadcast: 1.1.1.255, Generation:
150

```

## Sample Output

### show interfaces terse

```

user@host> show interfaces terse

```

| Interface      | Admin | Link  | Proto | Local          | Remote |
|----------------|-------|-------|-------|----------------|--------|
| ge-0/0/0       | up    | up    |       |                |        |
| ge-0/0/0.0     | up    | up    | inet  | 10.209.4.61/18 |        |
| gr-0/0/0       | up    | up    |       |                |        |
| ip-0/0/0       | up    | up    |       |                |        |
| st0            | up    | up    |       |                |        |
| st0.1          | up    | ready | inet  |                |        |
| ls-0/0/0       | up    | up    |       |                |        |
| lt-0/0/0       | up    | up    |       |                |        |
| mt-0/0/0       | up    | up    |       |                |        |
| pd-0/0/0       | up    | up    |       |                |        |
| pe-0/0/0       | up    | up    |       |                |        |
| e3-1/0/0       | up    | up    |       |                |        |
| t3-2/0/0       | up    | up    |       |                |        |
| e1-3/0/0       | up    | up    |       |                |        |
| se-4/0/0       | up    | down  |       |                |        |
| t1-5/0/0       | up    | up    |       |                |        |
| br-6/0/0       | up    | up    |       |                |        |
| dc-6/0/0       | up    | up    |       |                |        |
| dc-6/0/0.32767 | up    | up    |       |                |        |
| bc-6/0/0:1     | down  | up    |       |                |        |

|              |    |      |      |           |         |
|--------------|----|------|------|-----------|---------|
| bc-6/0/0:1.0 | up | down |      |           |         |
| d10          | up | up   |      |           |         |
| d10.0        | up | up   | inet |           |         |
| dsc          | up | up   |      |           |         |
| gre          | up | up   |      |           |         |
| ipip         | up | up   |      |           |         |
| lo0          | up | up   |      |           |         |
| lo0.16385    | up | up   | inet | 10.0.0.1  | --> 0/0 |
|              |    |      |      | 10.0.0.16 | --> 0/0 |
| lsi          | up | up   |      |           |         |
| mtun         | up | up   |      |           |         |
| pimd         | up | up   |      |           |         |
| pime         | up | up   |      |           |         |
| pp0          | up | up   |      |           |         |

## show interfaces diagnostics optics

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show interfaces diagnostics optics <i>interface-name</i></code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.1.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Description</b>              | <p>Display diagnostics data and alarms for Gigabit Ethernet optical transceivers (SFP) installed in SRX Series Services Gateways. The information provided by this command is known as digital optical monitoring (DOM) information.</p> <p>Thresholds that trigger a high alarm, low alarm, high warning, or low warning are set by the transponder vendors. Generally, a high alarm or low alarm indicates that the optics module is not operating properly. This information can be used to diagnose why a transceiver is not working.</p> |
| <b>Options</b>                  | <i>interface-name</i> —Name of the interface associated with the port in which the transceiver is installed: <code>ge-fpc/pic/port</code> .                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><i>Understanding Interfaces</i></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>List of Sample Output</b>    | <a href="#">show interfaces diagnostics optics on page 338</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Output Fields</b>            | <a href="#">Table 31 on page 335</a> lists the output fields for the show interfaces diagnostics optics command. Output fields are listed in the general order in which they appear.                                                                                                                                                                                                                                                                                                                                                          |

**Table 31: show interfaces diagnostics optics Output Fields**

| Field Name                            | Field Description                                                                                                                                                  |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Physical interface                    | Displays the name of the physical interface.                                                                                                                       |
| Laser bias current                    | Displays the magnitude of the laser bias power setting current, in milliamperes. The laser bias provides direct modulation of laser diodes and modulates currents. |
| Laser output power                    | Displays the laser output power, in milliwatts (mW) and decibels referred to 1.0 mW (dBm).                                                                         |
| Module temperature                    | Displays the temperature, in Celsius and Fahrenheit.                                                                                                               |
| Module voltage                        | Displays the voltage, in Volts.                                                                                                                                    |
| Receiver signal average optical power | Displays the receiver signal average optical power, in milliwatts (mW) and decibels referred to 1.0 mW (dBm).                                                      |
| Laser bias current high alarm         | Displays whether the laser bias power setting high alarm is <b>On</b> or <b>Off</b> .                                                                              |

Table 31: show interfaces diagnostics optics Output Fields (*continued*)

| Field Name                      | Field Description                                                                       |
|---------------------------------|-----------------------------------------------------------------------------------------|
| Laser bias current low alarm    | Displays whether the laser bias power setting low alarm is <b>On</b> or <b>Off</b> .    |
| Laser bias current high warning | Displays whether the laser bias power setting high warning is <b>On</b> or <b>Off</b> . |
| Laser bias current low warning  | Displays whether the laser bias power setting low warning is <b>On</b> or <b>Off</b> .  |
| Laser output power high alarm   | Displays whether the laser output power high alarm is <b>On</b> or <b>Off</b> .         |
| Laser output power low alarm    | Displays whether the laser output power low alarm is <b>On</b> or <b>Off</b> .          |
| Laser output power high warning | Displays whether the laser output power high warning is <b>On</b> or <b>Off</b> .       |
| Laser output power low warning  | Displays whether the laser output power low warning is <b>On</b> or <b>Off</b> .        |
| Module temperature high alarm   | Displays whether the module temperature high alarm is <b>On</b> or <b>Off</b> .         |
| Module temperature low alarm    | Displays whether the module temperature low alarm is <b>On</b> or <b>Off</b> .          |
| Module temperature high warning | Displays whether the module temperature high warning is <b>On</b> or <b>Off</b> .       |
| Module temperature low warning  | Displays whether the module temperature low warning is <b>On</b> or <b>Off</b> .        |
| Module voltage high alarm       | Displays whether the module voltage high alarm is <b>On</b> or <b>Off</b> .             |
| Module voltage low alarm        | Displays whether the module voltage low alarm is <b>On</b> or <b>Off</b> .              |
| Module voltage high warning     | Displays whether the module voltage high warning is <b>On</b> or <b>Off</b> .           |
| Module voltage low warning      | Displays whether the module voltage low warning is <b>On</b> or <b>Off</b> .            |
| Laser rx power high alarm       | Displays whether the receive laser power high alarm is <b>On</b> or <b>Off</b> .        |
| Laser rx power low alarm        | Displays whether the receive laser power low alarm is <b>On</b> or <b>Off</b> .         |

Table 31: show interfaces diagnostics optics Output Fields (*continued*)

| Field Name                                | Field Description                                                                  |
|-------------------------------------------|------------------------------------------------------------------------------------|
| Laser rx power high warning               | Displays whether the receive laser power high warning is <b>On</b> or <b>Off</b> . |
| Laser rx power low warning                | Displays whether the receive laser power low warning is <b>On</b> or <b>Off</b> .  |
| Laser bias current high alarm threshold   | Displays the vendor-specified threshold for the laser bias current high alarm.     |
| Laser bias current low alarm threshold    | Displays the vendor-specified threshold for the laser bias current low alarm.      |
| Laser bias current high warning threshold | Displays the vendor-specified threshold for the laser bias current high warning.   |
| Laser bias current low warning threshold  | Displays the vendor-specified threshold for the laser bias current low warning.    |
| Laser output power high alarm threshold   | Displays the vendor-specified threshold for the laser output power high alarm.     |
| Laser output power low alarm threshold    | Displays the vendor-specified threshold for the laser output power low alarm.      |
| Laser output power high warning threshold | Displays the vendor-specified threshold for the laser output power high warning.   |
| Laser output power low warning threshold  | Displays the vendor-specified threshold for the laser output power low warning.    |
| Module temperature high alarm threshold   | Displays the vendor-specified threshold for the module temperature high alarm.     |
| Module temperature low alarm threshold    | Displays the vendor-specified threshold for the module temperature low alarm.      |
| Module temperature high warning threshold | Displays the vendor-specified threshold for the module temperature high warning.   |
| Module temperature low warning threshold  | Displays the vendor-specified threshold for the module temperature low warning.    |
| Module voltage high alarm threshold       | Displays the vendor-specified threshold for the module voltage high alarm.         |
| Module voltage low alarm threshold        | Displays the vendor-specified threshold for the module voltage low alarm.          |
| Module voltage high warning threshold     | Displays the vendor-specified threshold for the module voltage high warning.       |

Table 31: show interfaces diagnostics optics Output Fields (*continued*)

| Field Name                                   | Field Description                                                            |
|----------------------------------------------|------------------------------------------------------------------------------|
| <b>Module voltage low warning threshold</b>  | Displays the vendor-specified threshold for the module voltage low warning.  |
| <b>Laser rx power high alarm threshold</b>   | Displays the vendor-specified threshold for the laser rx power high alarm.   |
| <b>Laser rx power low alarm threshold</b>    | Displays the vendor-specified threshold for the laser rx power low alarm.    |
| <b>Laser rx power high warning threshold</b> | Displays the vendor-specified threshold for the laser rx power high warning. |
| <b>Laser rx power low warning threshold</b>  | Displays the vendor-specified threshold for the laser rx power low warning.  |

## Sample Output

### show interfaces diagnostics optics

```

user@host> show interfaces diagnostics optics ge-2/0/0
Physical interface: ge-2/0/0
 Laser bias current : 7.408 mA
 Laser output power : 0.3500 mW / -4.56 dBm
 Module temperature : 23 degrees C / 73 degrees F
 Module voltage : 3.3450 V
 Receiver signal average optical power : 0.0002 mW / -36.99 dBm
 Laser bias current high alarm : Off
 Laser bias current low alarm : Off
 Laser bias current high warning : Off
 Laser bias current low warning : Off
 Laser output power high alarm : Off
 Laser output power low alarm : Off
 Laser output power high warning : Off
 Laser output power low warning : Off
 Module temperature high alarm : Off
 Module temperature low alarm : Off
 Module temperature high warning : Off
 Module temperature low warning : Off
 Module voltage high alarm : Off
 Module voltage low alarm : Off
 Module voltage high warning : Off
 Module voltage low warning : Off
 Laser rx power high alarm : Off
 Laser rx power low alarm : On
 Laser rx power high warning : Off
 Laser rx power low warning : On
 Laser bias current high alarm threshold : 17.000 mA
 Laser bias current low alarm threshold : 1.000 mA
 Laser bias current high warning threshold : 14.000 mA
 Laser bias current low warning threshold : 2.000 mA
 Laser output power high alarm threshold : 0.6310 mW / -2.00 dBm
 Laser output power low alarm threshold : 0.0670 mW / -11.74 dBm
 Laser output power high warning threshold : 0.6310 mW / -2.00 dBm
 Laser output power low warning threshold : 0.0790 mW / -11.02 dBm

```



```
Module temperature high alarm threshold : 95 degrees C / 203 degrees F
Module temperature low alarm threshold : -25 degrees C / -13 degrees F
Module temperature high warning threshold : 90 degrees C / 194 degrees F
Module temperature low warning threshold : -20 degrees C / -4 degrees F
Module voltage high alarm threshold : 3.900 V
Module voltage low alarm threshold : 2.700 V
Module voltage high warning threshold : 3.700 V
Module voltage low warning threshold : 2.900 V
Laser rx power high alarm threshold : 1.2590 mW / 1.00 dBm
Laser rx power low alarm threshold : 0.0100 mW / -20.00 dBm
Laser rx power high warning threshold : 0.7940 mW / -1.00 dBm
Laser rx power low warning threshold : 0.0158 mW / -18.01 dBm
```

## show interfaces flow-statistics

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show interfaces flow-statistics</b> < <i>interface-name</i> >                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Release Information</b>      | Command introduced in Junos OS Release 9.2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Description</b>              | Display interfaces flow statistics.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Options</b>                  | <p><b>Interface-name</b> — (Optional) Display flow statistics about the specified interface. Following is a list of typical interface names. Replace <i>pim</i> with the PIM slot and <i>port</i> with the port number. For a complete list, see the <i>Interface Naming Conventions</i>.</p> <ul style="list-style-type: none"> <li>• <b>at-<i>pim</i>/0/<i>port</i></b>—ATM-over-ADSL or ATM-over-SHDSL interface.</li> <li>• <b>br-<i>pim</i>/0/<i>port</i></b>—Basic Rate Interface for establishing ISDN connections.</li> <li>• <b>ce1-<i>pim</i>/0/<i>port</i></b>—Channelized E1 interface.</li> <li>• <b>ct1-<i>pim</i>/0/<i>port</i></b>—Channelized T1 interface.</li> <li>• <b>dl0</b>—Dialer Interface for initiating ISDN and USB modem connections.</li> <li>• <b>e1-<i>pim</i>/0/<i>port</i></b>—E1 interface.</li> <li>• <b>e3-<i>pim</i>/0/<i>port</i></b>—E3 interface.</li> <li>• <b>fe-<i>pim</i>/0/<i>port</i></b>—Fast Ethernet interface.</li> <li>• <b>ge-<i>pim</i>/0/<i>port</i></b>—Gigabit Ethernet interface.</li> <li>• <b>se-<i>pim</i>/0/<i>port</i></b>—Serial interface.</li> <li>• <b>t1-<i>pim</i>/0/<i>port</i></b>—T1 (also called DS1) interface.</li> <li>• <b>t3-<i>pim</i>/0/<i>port</i></b>—T3 (also called DS3) interface.</li> <li>• <b>wx-slot/0/0</b>—WAN acceleration interface, for the WXC Integrated Services Module (ISM 200).</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">Understanding Interfaces</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>List of Sample Output</b>    | <a href="#">show interfaces flow-statistics (Gigabit Ethernet) on page 343</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Output Fields</b>            | Table 32 on page 340 lists the output fields for the <b>show interfaces flow-statistics</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

Table 32: show interfaces flow-statistics Output Fields

| Field Name         | Field Description                                                               |
|--------------------|---------------------------------------------------------------------------------|
| Traffic statistics | Number of packets and bytes transmitted and received on the physical interface. |

Table 32: show interfaces flow-statistics Output Fields (*continued*)

| Field Name                    | Field Description                                                                                              |
|-------------------------------|----------------------------------------------------------------------------------------------------------------|
| <b>Local statistics</b>       | Number of packets and bytes transmitted and received on the physical interface.                                |
| <b>Transit statistics</b>     | Number of packets and bytes transiting the physical interface.                                                 |
| <b>Flow input statistics</b>  | Statistics on packets received by flow module.                                                                 |
| <b>Flow output statistics</b> | Statistics on packets sent by flow module.                                                                     |
| <b>Flow error statistics</b>  | Packet drop statistics for the flow module.<br>For further details, see <a href="#">Table 33 on page 341</a> . |

Table 33: Flow Error Statistics (Packet Drop Statistics for the Flow Module)

| Error                           | Error Description                                                                                                                                                                                                                                                                                                                                               |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Screen:</b>                  |                                                                                                                                                                                                                                                                                                                                                                 |
| Address spoofing                | The packet was dropped when the screen module detected address spoofing.                                                                                                                                                                                                                                                                                        |
| Syn-attack protection           | The packet was dropped because of SYN attack protection or SYN cookie protection.                                                                                                                                                                                                                                                                               |
| <b>VPN:</b>                     |                                                                                                                                                                                                                                                                                                                                                                 |
| Authentication failed           | The packet was dropped because the IPsec Encapsulating Security Payload (ESP) or Authentication Header (AH) authentication failed.                                                                                                                                                                                                                              |
| No SA for incoming SPI          | The packet was dropped because the incoming IPsec packet's security parameter index (SPI) does not match any known SPI.                                                                                                                                                                                                                                         |
| Security association not active | The packet was dropped because an IPsec packet was received for an inactive SA.                                                                                                                                                                                                                                                                                 |
| <b>NAT:</b>                     |                                                                                                                                                                                                                                                                                                                                                                 |
| Incoming NAT errors             | The source NAT rule search failed, an invalid source NAT binding was found, or the NAT allocation failed.                                                                                                                                                                                                                                                       |
| Multiple incoming NAT           | Sometimes packets are looped through the system more than once; if source NAT is specified more than once, the packet will be dropped.                                                                                                                                                                                                                          |
| <b>Auth:</b>                    |                                                                                                                                                                                                                                                                                                                                                                 |
| Multiple user authentications   | Sometimes packets are looped through the system more than once. Each time a packet passes through the system, that packet must be permitted by a policy. If the packet matches more than one policy that specifies user authentication, then it will be dropped.                                                                                                |
| User authentication errors      | Packet was dropped because policy requires authentication; however: <ul style="list-style-type: none"> <li>• Only Telnet, FTP, and HTTP traffic can be authenticated.</li> <li>• The corresponding authentication entry could not be found, if web-auth is specified.</li> <li>• The maximum number of authenticated sessions per user was exceeded.</li> </ul> |

Table 33: Flow Error Statistics (Packet Drop Statistics for the Flow Module) (*continued*)

|                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flow:                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| No one interested in self packets | <p>This counter is incremented for one of the following reasons:</p> <ul style="list-style-type: none"> <li>• The outbound interface is a self interface, but the packet is not marked as a to-self packet and the destination address is in a source NAT pool.</li> <li>• No service is interested in the to-self packet</li> <li>• When a zone has ident-reset service enabled, the TCP RST to IDENT request for port 113 is sent back and this counter is incremented.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| No minor session                  | The packet was dropped because no minor sessions are available and a minor session was requested. Minor sessions are allocated for storing additional TCP state information.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| No more sessions                  | The packet was dropped because there were no more free sessions available.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| No route present                  | <p>The packet was dropped because a valid route was not available to forward the packet.</p> <p>For new sessions, the counter is incremented for one of the following reasons:</p> <ul style="list-style-type: none"> <li>• No valid route was found to forward the packet.</li> <li>• A discard or reject route was found.</li> <li>• The route could not be added due to lack of memory.</li> <li>• The reverse path forwarding check failed for an incoming multicast packet.</li> </ul> <p>For existing sessions, the prior route was changed or deleted, or a more specific route was added. The session is rerouted, and this reroute could fail because:</p> <ul style="list-style-type: none"> <li>• A new route could not be found; either the previous route was removed, or the route was changed to discard or reject.</li> <li>• Multiple packets may concurrently force rerouting to occur, and only one packet can successfully complete the rerouting process. Other packets will be dropped.</li> <li>• The route table was locked for updates by the Routing Engine. Packets that match a new session are retried, whereas packets that match an existing session are not.</li> </ul> |
| No tunnel found                   | The packet was dropped because a valid tunnel could not be found                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| No session for a gate             | This counter is incremented when a packet is destined for an ALG, and the ALG decides to drop this packet.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| No zone or NULL zone binding      | The packet was dropped because its incoming interface was not bound to any zone.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Policy denied                     | <p>The error counter is incremented for one of the following reasons:</p> <ul style="list-style-type: none"> <li>• Source and/or destination NAT has occurred and policy says to drop the packet.</li> <li>• Policy specifies user authentication, which failed.</li> <li>• Policy was configured to deny this packet.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| TCP sequence number out of window | A TCP packet with a sequence number failed the TCP sequence number check that was received.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Counters Not Currently in Use     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| No parent for a gate              | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

Table 33: Flow Error Statistics (Packet Drop Statistics for the Flow Module) (*continued*)

|                              |   |
|------------------------------|---|
| Invalid zone received packet | - |
| No NAT gate                  | - |

## Sample Output

### show interfaces flow-statistics (Gigabit Ethernet)

```

user@host> show interfaces flow-statistics ge-0/0/1.0
Logical interface ge-0/0/1.0 (Index 70) (SNMP ifIndex 49)
 Flags: SNMP-Traps Encapsulation: ENET2
 Input packets : 5161
 Output packets: 83
 Security: Zone: zone2
 Allowed host-inbound traffic : bootp bfd bgp dns dvmrp igmp ldp msdp nhrp
ospf pgm
pim rip router-discovery rsvp sap vrrp dhcp finger ftp tftp ident-reset http
https ike
netconf ping rlogin rpm rsh snmp snmp-trap ssh telnet traceroute xnm-clear-text
xnm-ssl
lsping
Flow Statistics :
Flow Input statistics :
 Self packets : 0
 ICMP packets : 0
 VPN packets : 2564
 Bytes permitted by policy : 3478
 Connections established : 1
Flow Output statistics:
 Multicast packets : 0
 Bytes permitted by policy : 16994
Flow error statistics (Packets dropped due to):
 Address spoofing: 0
 Authentication failed: 0
 Incoming NAT errors: 0
 Invalid zone received packet: 0
 Multiple user authentications: 0
 Multiple incoming NAT: 0
 No parent for a gate: 0
 No one interested in self packets: 0
 No minor session: 0
 No more sessions: 0
 No NAT gate: 0
 No route present: 0
 No SA for incoming SPI: 0
 No tunnel found: 0
 No session for a gate: 0
 No zone or NULL zone binding: 0
 Policy denied: 0
 Security association not active: 0
 TCP sequence number out of window: 0
 Syn-attack protection: 0
 User authentication errors: 0
Protocol inet, MTU: 1500
 Flags: None
 Addresses, Flags: Is-Preferred Is-Primary
 Destination: 2.2.2/24, Local: 2.2.2.2, Broadcast: 2.2.2.255

```



## show interfaces statistics (View)

|                                 |                                                                                              |
|---------------------------------|----------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show interfaces statistics <i>interface-name</i></code>                                |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.1.                                                 |
| <b>Description</b>              | Displays the interface input and output statistics for physical and logical interface.       |
| <b>Required Privilege Level</b> | view                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Understanding Interfaces</a></li> </ul> |
| <b>List of Sample Output</b>    | <a href="#">show interfaces statistics on page 345</a>                                       |

### Sample Output

#### show interfaces statistics

```

user@host> show interfaces statistics st0.1
Logical interface st0.1 (Index 91) (SNMP ifIndex 268)
 Flags: Point-To-Point SNMP-Traps Encapsulation: Secure-Tunnel
 Input packets : 2743333
 Output packets: 6790470992
 Security: Zone: untrust
 Allowed host-inbound traffic : bootp bfd bgp dns dvmrp igmp ldp msdp nhrp
ospf pgm pim rip router-discovery rsvp sap vrrp dhcp finger ftp tftp ident-reset
http https ike netconf ping reverse-telnet
reverse-ssh rlogin rpm rsh snmp snmp-trap ssh telnet traceroute xnm-clear-text
xnm-ssl lsping ntp sip
 Protocol inet, MTU: 9192
 Addresses, Flags: Is-Preferred Is-Primary
 Destination: 192.167.1.0/30, Local: 192.167.1.1

```

## show interfaces swfabx

|                                 |                                                                                                                                                                                                      |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show interfaces <swfab0   swfab1>                                                                                                                                                                    |
| <b>Release Information</b>      | Command introduced in Junos OS Release 11.1.                                                                                                                                                         |
| <b>Description</b>              | List the configured interfaces for each swfab interface. The swfab interface can contain one or more members because it is an aggregated interface.                                                  |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                 |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><i>clear interfaces statistics swfabx</i></li> </ul>                                                                                                          |
| <b>List of Sample Output</b>    | <a href="#">show interfaces &lt;swfab0   swfab1&gt; on page 346</a>                                                                                                                                  |
| <b>Output Fields</b>            | <a href="#">Table 34 on page 346</a> lists the output fields for the <b>show interfaces &lt;swfab0   swfab1&gt;</b> command. Output fields are listed in the approximate order in which they appear. |

**Table 34: show interfaces <swfab0 | swfab1> Output Fields**

| Field Name               | Field Description                                                                                                                                                |
|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>fabric-options</b>    | The fabric-options hierarchy is made to be in sync with the fab interfaces.                                                                                      |
| <b>member-interfaces</b> | <p>Interfaces specified under member-interfaces are single logical aggregate-Ethernet interfaces.</p> <p>This interface carries internode switching traffic.</p> |

## Sample Output

**show interfaces <swfab0 | swfab1>**

```

user@host> show interfaces <swfab0 | swfab1>
fabric-options {
 member-interfaces {
 ge-0/0/6;
 ge-0/0/7;
 }
}
```



## show monitor security flow

|                                 |                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show monitor security flow                                                                                                                                                                                                                                                                                                                  |
| <b>Release Information</b>      | Command introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                                                                                                         |
| <b>Description</b>              | Display information about the security flow session monitoring.                                                                                                                                                                                                                                                                             |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                        |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Monitoring Security Flow Sessions Overview on page 117</a></li> <li>• <a href="#">monitor security flow filter on page 256</a></li> <li>• <a href="#">monitor security flow start on page 258</a></li> <li>• <a href="#">clear monitor security flow filter on page 231</a></li> </ul> |
| <b>List of Sample Output</b>    | <a href="#">show monitor security flow on page 347</a>                                                                                                                                                                                                                                                                                      |
| <b>Output Fields</b>            | Lists the output fields for the <b>show monitor security flow</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                          |

Table 35: show monitor security flow Output Fields

| Field Name                           | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Monitor security flow session status | State of the security flow session monitoring: <b>active</b> or <b>inactive</b> .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Monitor security flow trace file     | Name of the file for monitoring output.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Monitor security flow filters        | <ul style="list-style-type: none"> <li>• <b>Destination Address</b>—Address of the destination to be matched.</li> <li>• <b>Destination Port</b>—Name of the destination port to be matched.</li> <li>• <b>Interface Name</b>—Interface name to be matched.</li> <li>• <b>Logical System Name</b>—Logical system name to be matched.</li> <li>• <b>Name</b>—Name of the security flow filter.</li> <li>• <b>Protocol</b>—Name of the protocol to be matched.</li> <li>• <b>Source Address</b>—Address of the source to be matched.</li> <li>• <b>Source Port</b>—Name of the source port to be matched.</li> <li>• <b>Status</b>—State of the security flow filter: <b>active</b> or <b>inactive</b>.</li> </ul> |

## Sample Output

### show monitor security flow

```
user@host>show monitor security flow
```

```
Monitor security flow session status: Active
Monitor security flow trace file: flow
Monitor security flow filters:
 Name: server-sql
```

```
Status: Active
source: 10.2.2.1 (port *), destination: 10.20.30.40 (port 1433)
protocol: TCP
Name: internet-access
Status: Active
source: * (port *), destination: * (port 80)
protocol: TCP
```

## show security flow cp-session

|                                 |                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow cp-session</b><br>[<filter>] [summary   terse]                                                                                                                                                                                                                                                                                                                 |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                                                         |
| <b>Description</b>              | Display central point session-related flow information.                                                                                                                                                                                                                                                                                                                              |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• destination-port—Destination port</li> <li>• destination-prefix—Destination prefix</li> <li>• family—Display session by family.</li> <li>• protocol—IP protocol number</li> <li>• source-port—Source port</li> <li>• source-prefix—Source IP prefix or address</li> <li>• summary   terse—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                           |
| <b>List of Sample Output</b>    | <a href="#">show security flow cp-session on page 350</a><br><a href="#">show security flow cp-session summary on page 350</a><br><a href="#">show security flow cp-session terse on page 351</a>                                                                                                                                                                                    |
| <b>Output Fields</b>            | <a href="#">Table 36 on page 349</a> lists the output fields for the <b>show security flow cp-session</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                           |

**Table 36: show security flow cp-session Output Fields**

| Field Name             | Field Description                                 |
|------------------------|---------------------------------------------------|
| Valid gates            | Number of valid central point sessions.           |
| Pending gates          | Number of pending central point sessions.         |
| Invalidated gates      | Number of invalid central point sessions.         |
| Gates in other states  | Number of central point sessions in other states. |
| Total gates            | Number of central point sessions in total.        |
| Maximum sessions       | Number of maximum central point sessions.         |
| Maximum inet6 sessions | Number of maximum inet6 central point sessions.   |

Table 36: show security flow cp-session Output Fields (*continued*)

| Field Name | Field Description                                                                          |
|------------|--------------------------------------------------------------------------------------------|
| Session ID | Number that identifies the session. Use this ID to get more information about the session. |
| SPU        | Services Processing Unit.                                                                  |
| In         | Incoming flow (source and destination IP addresses).                                       |
| Out        | Reverse flow (source and destination IP addresses).                                        |

## Sample Output

### show security flow cp-session

```

root> show security flow cp-session
DCP Flow Sessions on FPC2 PIC0:
Total sessions: 0

DCP Flow Sessions on FPC2 PIC1:

Session ID: 90001929, SPU: 16, Valid
 In: 0.0.0.0/0 --> 0.0.0.0/0;0,
 Out: 2.2.2.2/5353 --> 1.1.1.2/31235;udp,
Total sessions: 1

DCP Flow Sessions on FPC4 PIC0:

Session ID: 160001607, SPU: 16, Valid
 In: 1.1.1.2/48614 --> 99.99.99.2/23;tcp,
 Out: 2.2.2.2/23 --> 1.1.1.2/48614;tcp,

Session ID: 160001610, SPU: 16, Valid
 In: 1.1.1.2/31235 --> 99.99.99.2/5353;udp,
 Out: 0.0.0.0/0 --> 0.0.0.0/0;0,
Total sessions: 2

DCP Flow Sessions on FPC4 PIC1:
Total sessions: 0

```

## Sample Output

### show security flow cp-session summary

```

root> show security flow cp-session summary
DCP Flow Sessions on FPC10 PIC0:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:

Valid sessions: 2
Pending sessions: 0

```

```

Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 2
Maximum sessions: 7549747
Maximum inet6 sessions: 7549747

```

DCP Flow Sessions on FPC10 PIC2:

```

Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 2
Maximum sessions: 7549747
Maximum inet6 sessions: 7549747

```

DCP Flow Sessions on FPC10 PIC3:

```

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1
Maximum sessions: 7549747
Maximum inet6 sessions: 7549747

```

#### show security flow cp-session terse

```
root> show security flow cp-session terse
```

```

DCP Flow Sessions on FPC10 PIC0:
Total sessions: 0

```

DCP Flow Sessions on FPC10 PIC1:

```

Session ID: 410003288, SPU: 41, Valid
 In: 200.0.0.10/7000 --> 60.0.0.3/8000;udp,
 Out: 60.0.0.3/8000 --> 200.0.0.10/7000;udp,

```

```

Session ID: 410003289, SPU: 41, Valid
 In: 200.0.0.10/7000 --> 60.0.0.5/8000;udp,
 Out: 60.0.0.5/8000 --> 200.0.0.10/7000;udp,
Total sessions: 2

```

DCP Flow Sessions on FPC10 PIC2:

```

Session ID: 420002637, SPU: 42, Valid
 In: 200.0.0.10/7000 --> 60.0.0.2/8000;udp,
 Out: 60.0.0.2/8000 --> 200.0.0.10/7000;udp,

```

```

Session ID: 420002638, SPU: 42, Valid
 In: 200.0.0.10/7000 --> 60.0.0.4/8000;udp,
 Out: 60.0.0.4/8000 --> 200.0.0.10/7000;udp,
Total sessions: 2

```

DCP Flow Sessions on FPC10 PIC3:

```

Session ID: 430001189, SPU: 43, Valid
 In: 200.0.0.10/7000 --> 60.0.0.6/8000;udp,
 Out: 60.0.0.6/8000 --> 200.0.0.10/7000;udp,
Total sessions: 1

```



## show security flow cp-session destination-port

|                                 |                                                                                                                                                                                                                                                                            |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show security flow cp-session destination-port <i>destination-port-number</i> [summary   terse]</code>                                                                                                                                                               |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                                                               |
| <b>Description</b>              | Display central point session-related flow information for the specified destination port.                                                                                                                                                                                 |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li><i>destination-port-number</i>—Number of the destination port for which to display central point session information.<br/><b>Range:</b> 1 through 65,535</li> <li>summary   terse—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><a href="#">show security flow cp-session on page 349</a></li> <li><a href="#">show security flow cp-session destination-prefix on page 355</a></li> </ul>                                                                          |
| <b>List of Sample Output</b>    | <a href="#">show security flow cp-session destination-port summary on page 354</a><br><a href="#">show security flow cp-session destination-port terse on page 354</a>                                                                                                     |
| <b>Output Fields</b>            | Table 37 on page 353 lists the output fields for the <b>show security flow cp-session destination-port</b> command. Output fields are listed in the approximate order in which they appear.                                                                                |

**Table 37: show security flow cp-session destination-port Output Fields**

| Field Name            | Field Description                                                                          |
|-----------------------|--------------------------------------------------------------------------------------------|
| Valid gates           | Number of valid central point sessions.                                                    |
| Pending gates         | Number of pending central point sessions.                                                  |
| Invalidated gates     | Number of invalid central point sessions.                                                  |
| Gates in other states | Number of central point sessions in other states.                                          |
| Total gates           | Number of central point sessions in total.                                                 |
| Session ID            | Number that identifies the session. Use this ID to get more information about the session. |
| SPU                   | Services Processing Unit.                                                                  |
| In                    | Incoming flow (source and destination IP addresses).                                       |
| Out                   | Reverse flow (source and destination IP addresses).                                        |

## Sample Output

### show security flow cp-session destination-port summary

```
root> show security flow cp-session destination-port 21 summary
DCP Flow Sessions on FPC10 PIC0:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

### show security flow cp-session destination-port terse

```
root> show security flow cp-session destination-port 21 terse
DCP Flow Sessions on FPC10 PIC0:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:

Session ID: 410003298, SPU: 41, Valid
 In: 200.0.0.10/26182 --> 60.0.0.1/21;tcp,
 Out: 60.0.0.1/21 --> 200.0.0.10/26182;tcp,
Total sessions: 1

DCP Flow Sessions on FPC10 PIC2:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC3:
Total sessions: 0
```



## show security flow cp-session destination-prefix

|                                 |                                                                                                                                                                                                                                                                                                |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show security flow cp-session destination-prefix <i>destination-IP-prefix</i> [summary   terse]</code>                                                                                                                                                                                   |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                                                                                   |
| <b>Description</b>              | Display central point session-related flow information for the specified destination prefix.                                                                                                                                                                                                   |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li><code>destination-IP-prefix</code>—Destination IP prefix or address for which to display central point session information.<br/><b>Range:</b> 1 through 65,535.</li> <li><code>summary   terse</code>—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                           |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><a href="#">show security flow cp-session on page 349</a></li> <li><a href="#">show security flow cp-session destination-port on page 353</a></li> </ul>                                                                                                |
| <b>List of Sample Output</b>    | <a href="#">show security flow cp-session destination-prefix summary on page 356</a><br><a href="#">show security flow cp-session destination-prefix terse on page 356</a>                                                                                                                     |
| <b>Output Fields</b>            | <a href="#">Table 38 on page 355</a> lists the output fields for the <b>show security flow cp-session destination-prefix</b> command. Output fields are listed in the approximate order in which they appear.                                                                                  |

**Table 38: show security flow cp-session destination-prefix Output Fields**

| Field Name            | Field Description                                                                          |
|-----------------------|--------------------------------------------------------------------------------------------|
| Valid gates           | Number of valid central point sessions.                                                    |
| Pending gates         | Number of pending central point sessions.                                                  |
| Invalidated gates     | Number of invalid central point sessions.                                                  |
| Gates in other states | Number of central point sessions in other states.                                          |
| Total gates           | Number of central point sessions in total.                                                 |
| Session ID            | Number that identifies the session. Use this ID to get more information about the session. |
| SPU                   | Services Processing Unit.                                                                  |
| In                    | Incoming flow (source and destination IP addresses).                                       |
| Out                   | Reverse flow (source and destination IP addresses).                                        |

## Sample Output

### show security flow cp-session destination-prefix summary

```
root> show security flow cp-session destination-prefix 60/8 summary
DCP Flow Sessions on FPC10 PIC0:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

### show security flow cp-session destination-prefix terse

```
root> show security flow cp-session destination-prefix 60/8 terse
DCP Flow Sessions on FPC10 PIC0:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Session ID: 420002660, SPU: 42, Valid
 In: 200.0.0.10/26183 --> 60.0.0.1/21;tcp,
 Out: 60.0.0.1/21 --> 200.0.0.10/26183;tcp,
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:
Total sessions: 0
```

## show security flow cp-session family

|                                 |                                                                                                                                                                                                                                                                                   |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow cp-session family <i>family</i> [summary   terse]</b>                                                                                                                                                                                                       |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                                                                      |
| <b>Description</b>              | Display central point session-related flow information for the specified family.                                                                                                                                                                                                  |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <i>family</i>—Display session by family.</li> <li>• <i>inet</i>—Display IPv4 sessions.</li> <li>• <i>inet6</i>—Display IPv6 and IPv6-NATPT sessions.</li> <li>• <i>summary   terse</i>—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                              |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow cp-session on page 349</a></li> </ul>                                                                                                                                                                     |
| <b>List of Sample Output</b>    | <a href="#">show security flow cp-session family summary on page 358</a><br><a href="#">show security flow cp-session family terse on page 358</a>                                                                                                                                |
| <b>Output Fields</b>            | <a href="#">Table 39 on page 357</a> lists the output fields for the <b>show security flow cp-session family</b> command. Output fields are listed in the approximate order in which they appear.                                                                                 |

**Table 39: show security flow cp-session family Output Fields**

| Field Name            | Field Description                                                                          |
|-----------------------|--------------------------------------------------------------------------------------------|
| Valid gates           | Number of valid central point sessions.                                                    |
| Pending gates         | Number of pending central point sessions.                                                  |
| Invalidated gates     | Number of invalid central point sessions.                                                  |
| Gates in other states | Number of central point sessions in other states.                                          |
| Total gates           | Number of central point sessions in total.                                                 |
| Session ID            | Number that identifies the session. Use this ID to get more information about the session. |
| SPU                   | Services Processing Unit.                                                                  |
| In                    | Incoming flow (source and destination IP addresses).                                       |
| Out                   | Reverse flow (source and destination IP addresses).                                        |

## Sample Output

### show security flow cp-session family summary

```
root> show security flow cp-session family inet summary
DCP Flow Sessions on FPC10 PIC0:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

### show security flow cp-session family terse

```
root> show security flow cp-session family inet terse
DCP Flow Sessions on FPC10 PIC0:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Session ID: 420002660, SPU: 42, Valid
 In: 200.0.0.10/26183 --> 60.0.0.1/21;tcp,
 Out: 60.0.0.1/21 --> 200.0.0.10/26183;tcp,
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:
Total sessions: 0
```

## show security flow cp-session protocol

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow cp-session protocol</b> <i>protocol-name</i> [ <b>summary</b>   <b>terse</b> ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Description</b>              | Display central point session-related flow information for the specified protocol.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <i>protocol-name</i> —Protocol to use as a central point session filter. Information about the central point session that uses this protocol is displayed.</li> </ul> <p>Possible protocols are:</p> <ul style="list-style-type: none"> <li>• ah—IP Security Authentication Header</li> <li>• egp—Exterior gateway protocol</li> <li>• esp—IPsec Encapsulating Security Payload</li> <li>• gre—Generic routing encapsulation</li> <li>• icmp—Internet Control Message Protocol</li> <li>• icmp6—Internet Control Message Protocol</li> <li>• igmp—Internet Group Management Protocol</li> <li>• ipip—IP over IP</li> <li>• ospf—Open Shortest Path First</li> <li>• pim—Protocol Independent Multicast</li> <li>• rsvp—Resource Reservation Protocol</li> <li>• sctp—Stream Control Transmission Protocol</li> <li>• tcp—Transmission Control Protocol</li> <li>• udp—User Datagram Protocol</li> <li>• <b>summary</b>   <b>terse</b>—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow cp-session on page 349</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>List of Sample Output</b>    | <a href="#">show security flow cp-session protocol summary on page 360</a><br><a href="#">show security flow cp-session protocol terse on page 361</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Output Fields</b>            | <a href="#">Table 40 on page 360</a> lists the output fields for the <b>show security flow cp-session</b> protocol command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

Table 40: show security flow cp-session protocol Output Fields

| Field Name            | Field Description                                                                          |
|-----------------------|--------------------------------------------------------------------------------------------|
| Valid gates           | Number of valid central point sessions.                                                    |
| Pending gates         | Number of pending central point sessions.                                                  |
| Invalidated gates     | Number of invalid central point sessions.                                                  |
| Gates in other states | Number of central point sessions in other states.                                          |
| Total gates           | Number of central point sessions in total.                                                 |
| Session ID            | Number that identifies the session. Use this ID to get more information about the session. |
| SPU                   | Services Processing Unit.                                                                  |
| In                    | Incoming flow (source and destination IP addresses).                                       |
| Out                   | Reverse flow (source and destination IP addresses).                                        |

## Sample Output

### show security flow cp-session protocol summary

```
root> show security flow cp-session protocol tcp summary
DCP Flow Sessions on FPC10 PIC0:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

```
DCP Flow Sessions on FPC10 PIC1:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

```
DCP Flow Sessions on FPC10 PIC2:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

```
DCP Flow Sessions on FPC10 PIC3:
```

```
Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
```

```
Sessions in other states: 0
Total sessions: 1
```

#### `show security flow cp-session protocol terse`

```
root> show security flow cp-session protocol tcp terse
Session ID: 160000015, SPU: 17, Valid
 In: 40.0.0.111/32838 --> 30.0.0.100/21;tcp,
 Out: 30.0.0.100/21 --> 40.0.0.111/32838;tcp,
Total sessions: 1
```

## show security flow cp-session source-port

|                                 |                                                                                                                                                                                                                                 |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow cp-session source-port</b> <i>source-port-number</i> [summary   terse]                                                                                                                                    |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                    |
| <b>Description</b>              | Display central point session-related flow information for the specified source-port.                                                                                                                                           |
| <b>Options</b>                  | <p><b>source-port-number</b>—Number of the source port about which to display central point session information.</p> <p><b>Range:</b> 1 through 65,535</p> <p><b>summary   terse</b>—Display the specified level of output.</p> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                            |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow cp-session on page 349</a></li> <li>• <a href="#">show security flow cp-session source-prefix on page 364</a></li> </ul>                                |
| <b>List of Sample Output</b>    | <p><a href="#">show security flow cp-session source-port summary on page 363</a></p> <p><a href="#">show security flow cp-session source-port terse on page 363</a></p>                                                         |
| <b>Output Fields</b>            | <a href="#">Table 41 on page 362</a> lists the output fields for the <b>show security flow cp-session source-port</b> command. Output fields are listed in the approximate order in which they appear.                          |

**Table 41: show security flow cp-session source-port Output Fields**

| Field Name            | Field Description                                                                          |
|-----------------------|--------------------------------------------------------------------------------------------|
| Valid gates           | Number of valid central point sessions.                                                    |
| Pending gates         | Number of pending central point sessions.                                                  |
| Invalidated gates     | Number of invalid central point sessions.                                                  |
| Gates in other states | Number of central point sessions in other states.                                          |
| Total gates           | Number of central point sessions in total.                                                 |
| Session ID            | Number that identifies the session. Use this ID to get more information about the session. |
| SPU                   | Services Processing Unit.                                                                  |
| In                    | Incoming flow (source and destination IP addresses).                                       |
| Out                   | Reverse flow (source and destination IP addresses).                                        |



## Sample Output

### show security flow cp-session source-port summary

```

root> show security flow cp-session source-port 7000 summary
DCP Flow Sessions on FPC10 PIC0:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

```

### show security flow cp-session source-port terse

```

root> show security flow cp-session source-port 7000 terse
DCP Flow Sessions on FPC10 PIC0:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Session ID: 420002661, SPU: 42, Valid
 In: 200.0.0.10/7000 --> 60.0.0.2/8000;udp,
 Out: 60.0.0.2/8000 --> 200.0.0.10/7000;udp,
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

## show security flow cp-session source-prefix

|                                 |                                                                                                                                                                                                                               |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow cp-session source-prefix</b> <i>source-IP-prefix</i> [summary   terse]                                                                                                                                  |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                  |
| <b>Description</b>              | Display central point session related flow information for the specified source-prefix.                                                                                                                                       |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li><i>source-IP-prefix</i>—Source IP prefix or address for which to display central point session information.</li> <li>summary   terse—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                          |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><a href="#">show security flow cp-session on page 349</a></li> <li><a href="#">show security flow cp-session source-port on page 362</a></li> </ul>                                    |
| <b>List of Sample Output</b>    | <a href="#">show security flow cp-session source-prefix summary on page 365</a><br><a href="#">show security flow cp-session source-prefix terse on page 365</a>                                                              |
| <b>Output Fields</b>            | Table 42 on page 364 lists the output fields for the <b>show security flow cp-session source-prefix</b> command. Output fields are listed in the approximate order in which they appear.                                      |

Table 42: show security flow cp-session source-prefix Output Fields

| Field Name            | Field Description                                                                          |
|-----------------------|--------------------------------------------------------------------------------------------|
| Valid gates           | Number of valid central point sessions.                                                    |
| Pending gates         | Number of pending central point sessions.                                                  |
| Invalidated gates     | Number of invalid central point sessions.                                                  |
| Gates in other states | Number of central point sessions in other states.                                          |
| Total gates           | Number of central point sessions in total.                                                 |
| Session ID            | Number that identifies the session. Use this ID to get more information about the session. |
| SPU                   | Services Processing Unit.                                                                  |
| In                    | Incoming flow (source and destination IP addresses).                                       |
| Out                   | Reverse flow (source and destination IP addresses).                                        |

## Sample Output

### show security flow cp-session source-prefix summary

```

root> show security flow cp-session source-prefix 200/8 summary
DCP Flow Sessions on FPC10 PIC0:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

```

### show security flow cp-session source-prefix terse

```

root> show security flow cp-session source-prefix 200/8 terse
DCP Flow Sessions on FPC10 PIC0:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC1:
Total sessions: 0

DCP Flow Sessions on FPC10 PIC2:

Session ID: 420002663, SPU: 42, Valid
 In: 200.0.0.10/7000 --> 60.0.0.2/8000;udp,
 Out: 60.0.0.2/8000 --> 200.0.0.10/7000;udp,
Total sessions: 1

DCP Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

## show security flow gate

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow gate</b><br>[<filter>] [brief   summary]                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; Filter and display options added in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                                                   |
| <b>Description</b>              | <p>Display information about temporary openings known as pinholes or gates in the security firewall.</p> <p>Pinholes are used by applications that commonly have both control and data sessions and must create openings in the firewall for the data sessions based on information from the parent sessions.</p>                                                                                                                        |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• destination-port—Destination port</li> <li>• destination-prefix—Destination IP prefix or address</li> <li>• protocol—IP protocol number</li> <li>• source-port—Source port</li> <li>• source-prefix—Source IP prefix or address</li> <li>• brief   summary—Display the specified level of output.</li> </ul>                                                                                    |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow gate brief node on page 378</a></li> <li>• <a href="#">show security flow gate destination-port on page 384</a></li> <li>• <a href="#">show security flow gate destination-prefix on page 387</a></li> <li>• <a href="#">show security flow gate protocol on page 390</a></li> <li>• <a href="#">show security flow gate summary node on page 393</a></li> </ul> |
| <b>List of Sample Output</b>    | <a href="#">show security flow gate on page 367</a><br><a href="#">show security flow gate brief on page 368</a><br><a href="#">show security flow gate summary on page 369</a>                                                                                                                                                                                                                                                          |
| <b>Output Fields</b>            | Table 43 on page 366 lists the output fields for the <b>show security flow gate</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                     |

Table 43: show security flow gate Output Fields

| Field Name | Field Description                        |
|------------|------------------------------------------|
| Hole       | Range of flows permitted by the pinhole. |

Table 43: show security flow gate Output Fields (*continued*)

| Field Name            | Field Description                                                                                                                                                            |
|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Translated            | Tuples used to create the session if it matches the pinhole. <ul style="list-style-type: none"> <li>Source address and port</li> <li>Destination address and port</li> </ul> |
| Protocol              | Application protocol, such as UDP or TCP.                                                                                                                                    |
| Application           | Name of the application.                                                                                                                                                     |
| Age                   | Idle timeout for the pinhole.                                                                                                                                                |
| Flags                 | Internal debug flags for the pinhole.                                                                                                                                        |
| Zone                  | Incoming zone.                                                                                                                                                               |
| Reference count       | Number of resource manager references to the pinhole.                                                                                                                        |
| Resource              | Resource manager information about the pinhole.                                                                                                                              |
| Valid gates           | Number of valid gates.                                                                                                                                                       |
| Pending gates         | Number of pending gates.                                                                                                                                                     |
| Invalidated gates     | Number of invalid gates.                                                                                                                                                     |
| Gates in other states | Number of gates in other states.                                                                                                                                             |
| Total gates           | Number of gates in total.                                                                                                                                                    |
| Maximum gates         | Number of maximum gates                                                                                                                                                      |

## Sample Output

### show security flow gate

```

user@host> show security flow gate
Ho1e: 0.0.0.0-0.0.0.0/0-0->40.1.1.252-40.1.1.252/64515-64515
Translated: 0.0.0.0/0->11.0.31.161/25415
Protocol: udp
Application: none/0
Age: 101 seconds
Flags: 0xe001
Zone: untrust
Reference count: 1
Resource: 5-1024-8185
Ho1e: 0.0.0.0-0.0.0.0/0-0->40.1.1.252-40.1.1.252/1046-1046
Translated: 40.1.1.250/36039->11.0.31.161/5060
Protocol: udp
Application: junos-sip/63
Age: 65535 seconds

```

```
Flags: 0xe200
Zone: untrust
Reference count: 1
Resource: 5-1024-8189
Hole: 0.0.0.0-0.0.0.0/0-0->40.1.1.5-40.1.1.5/24101-24101
Translated: 0.0.0.0/0->40.1.1.5/24101
Protocol: udp
Application: none/0
Age: 93 seconds
Flags: 0xe001
Zone: trust
Reference count: 1
Resource: 5-1024-8188
Hole: 0.0.0.0-0.0.0.0/0-0->40.1.1.5-40.1.1.5/24100-24100
Translated: 0.0.0.0/0->40.1.1.5/24100
Protocol: udp
Application: none/0
Age: 93 seconds
Flags: 0xe001
Zone: trust
Reference count: 1
Resource: 5-1024-8191
Hole: 0.0.0.0-0.0.0.0/0-0->40.1.1.250-40.1.1.250/5060-5060
Translated: 0.0.0.0/0->40.1.1.250/5060
Protocol: udp
Application: junos-sip/63
Age: 65535 seconds
Flags: 0xe200
Zone: trust
Reference count: 1
Resource: 5-1024-8190
```

#### show security flow gate brief

```
root> show security flow gate brief
Flow Gates on FPC4 PIC1:

Hole: 40.0.0.111-40.0.0.111/0-0->30.0.0.100-30.0.0.100/38143-38143
Translated: 40.0.0.111/0->30.0.0.100/38143
Protocol: tcp
Application: FTP ALG/79
Age: 65532 seconds
Flags: 0x0080
Zone: trust
Reference count: 1
Resource: 1-24576-86016

Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1

Flow Gates on FPC5 PIC0:

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

Flow Gates on FPC5 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0

#### show security flow gate summary

```
root> show security flow gate summary
```

Flow Gates on FPC4 PIC1:

Valid gates: 1  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 1  
Maximum gates: 131072

Flow Gates on FPC5 PIC0:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0  
Maximum gates: 131072

Flow Gates on FPC5 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0  
Maximum gates: 131072

## show security flow ip-action

---

**Syntax** `show security flow ip-action [ <filter> ] [ summary family (inet | inet6) ]`

**Release Information** Command introduced in Junos OS Release 10.1. Logical systems option added in Junos OS Release 11.2. Summary option introduced in Junos OS Release 12.1.

**Description** Display the current IP-action settings, based on filtered options, for IP sessions running on the device.

**Options** • *filter*—Filter the display based on the specified criteria.

The following filters display those sessions that match the criteria specified by the filter. Refer to the sample output for filtered output examples.

**all** | [*filter*]  
—All active sessions on the device.

**destination-port** *destination-port*  
—Destination port number of the traffic. Range is 1 through 65,535.

**destination-prefix** *destination-prefix*  
—Destination IP prefix or address.

**family** (inet | inet6) [*filter*]  
—IPv4 traffic or IPv6-NATPT traffic and filtered options.

**logical-system** *logical-system-name* | **all** [*filter*]  
—Specified logical system or all logical systems.

**protocol** *protocol-name* | *protocol-number* [*filter*]  
—Protocol name or number and filtered options.

- **ah** or 51
- **egp** or 8
- **esp** or 50
- **gre** or 47
- **icmp** or 1
- **icmp6** or 58
- **igmp** or 2
- **ipip** or 4
- **ospf** or 89
- **pim** or 103
- **rsvp** or 46
- **sctp** or 132
- **tcp** or 6
- **udp** or 17

**root-logical-system** [*filter*]  
—Default logical system information and filtered options.



**source-port** *source-port*—Source port number of the traffic. Range is 1 through 65,535.

**source-prefix** *source-prefix*—Source IP prefix or address of the traffic.

- **summary** —Summary information about IP-action entries.

**family**—Display summary of IP-action entries by family. This option is used to filter the output.

- **inet**—Display summary of IPv4 entries.
- **inet6**—Display summary of IPv6 entries.

**Required Privilege Level** view

- Related Documentation**
- [Juniper Networks Devices Processing Overview on page 3](#)
  - [clear security flow ip-action on page 232](#)
  - [clear security flow session destination-port on page 237](#)
  - [clear security flow ip-action on page 232](#)

**List of Sample Output**

[show security flow ip-action on page 372](#)  
[show security flow ip-action destination-port on page 373](#)  
[show security flow ip-action destination-prefix on page 374](#)  
[show security flow ip-action family inet protocol on page 374](#)  
[show security flow ip-action family inet logical-system all on page 375](#)  
[show security flow ip-action source-prefix on page 376](#)  
[show security flow ip-action summary on page 377](#)  
[show security flow ip-action summary family inet on page 377](#)  
[show security flow ip-action summary family inet6 on page 377](#)

**Output Fields** [Table 44 on page 371](#) lists the output fields for the **show security flow ip-action** command. Output fields are listed in the approximate order in which they appear.

**Table 44: show security flow ip-action Output Fields**

| Field Name     | Field Description                                                |
|----------------|------------------------------------------------------------------|
| Src-Addr       | Source address of outbound IP traffic.                           |
| Src-Port       | Source port number of outbound IP traffic.                       |
| Dst-Addr       | Destination address of inbound IP traffic.                       |
| Dst-Port/Proto | Destination port number and protocol type of inbound IP traffic. |
| Timeout (sec)  | Configured timeouts and time remaining for an IP session.        |
| Zone           | Security zone associated with an IP session.                     |
| Action         | Configured action type, for example, block, close, and notify.   |

Table 44: show security flow ip-action Output Fields (*continued*)

| Field Name        | Field Description                                                                   |
|-------------------|-------------------------------------------------------------------------------------|
| State             | The active mode and passive mode describe the states of the <b>ip-action</b> entry. |
| IPv4 action count | The total number of IPv4 entries.                                                   |
| IPv6 action count | The total number of IPv6 entries.                                                   |

## Sample Output

### show security flow ip-action

```

user@host> show security flow ip-action
Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 21/tcp 293/300 *
close Passive
IPv4 action count: 1 on FPC0.PIC1

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 21/tcp 293/300 *
close Passive
IPv4 action count: 1 on FPC0.PIC2

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 21/tcp 293/300 *
close Passive
IPv4 action count: 1 on FPC0.PIC3

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 21/tcp 293/300 *
close Passive
IPv4 action count: 1 on FPC1.PIC0

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 21/tcp 293/300 *
close Passive
IPv4 action count: 1 on FPC1.PIC1

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 21/tcp 292/300 *
close Passive
IPv4 action count: 1 on FPC1.PIC2

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 21/tcp 292/300 *
close Active
IPv4 action count: 1 on FPC1.PIC3
IPv4 action count: Active mode 1 on all PICs
IPv6 action count: 0 on FPC0.PIC1
IPv6 action count: 0 on FPC0.PIC2

```

```

IPv6 action count: 0 on FPC0.PIC3
IPv6 action count: 0 on FPC1.PIC0
IPv6 action count: 0 on FPC1.PIC1
IPv6 action count: 0 on FPC1.PIC2
IPv6 action count: 0 on FPC1.PIC3
IPv6 action count: Active mode 0 on all PICs

```

### show security flow ip-action destination-port

```
user@host> show security flow ip-action destination-port 21
```

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| Action                            | State    |          |                |              |      |
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 274/300      | *    |
| close                             | Passive  |          |                |              |      |
| IPv4 action count: 1 on FPC0.PIC1 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| Action                            | State    |          |                |              |      |
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 274/300      | *    |
| close                             | Passive  |          |                |              |      |
| IPv4 action count: 1 on FPC0.PIC2 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| Action                            | State    |          |                |              |      |
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 274/300      | *    |
| close                             | Passive  |          |                |              |      |
| IPv4 action count: 1 on FPC0.PIC3 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| Action                            | State    |          |                |              |      |
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 274/300      | *    |
| close                             | Passive  |          |                |              |      |
| IPv4 action count: 1 on FPC1.PIC0 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| Action                            | State    |          |                |              |      |
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 274/300      | *    |
| close                             | Passive  |          |                |              |      |
| IPv4 action count: 1 on FPC1.PIC1 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| Action                            | State    |          |                |              |      |
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 274/300      | *    |
| close                             | Passive  |          |                |              |      |
| IPv4 action count: 1 on FPC1.PIC2 |          |          |                |              |      |

| Src-Addr | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|----------|----------|----------|----------------|--------------|------|
| Action   | State    |          |                |              |      |
| 4.0.0.1  | *        | 5.0.0.1  | 21/tcp         | 273/300      | *    |
| close    | Active   |          |                |              |      |

```

IPv4 action count: 1 on FPC1.PIC3
IPv4 action count: Active mode 1 on all PICs
IPv6 action count: 0 on FPC0.PIC1
IPv6 action count: 0 on FPC0.PIC2
IPv6 action count: 0 on FPC0.PIC3
IPv6 action count: 0 on FPC1.PIC0
IPv6 action count: 0 on FPC1.PIC1
IPv6 action count: 0 on FPC1.PIC2
IPv6 action count: 0 on FPC1.PIC3
IPv6 action count: Active mode 0 on all PICs

```

**show security flow ip-action destination-prefix**

```
user@host> show security flow ip-action destination-prefix 5.0.0.0/8
```

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 245/300      | *    |
| close Passive                     |          |          |                |              |      |
| IPv4 action count: 1 on FPC0.PIC1 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 245/300      | *    |
| close Passive                     |          |          |                |              |      |
| IPv4 action count: 1 on FPC0.PIC2 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 245/300      | *    |
| close Passive                     |          |          |                |              |      |
| IPv4 action count: 1 on FPC0.PIC3 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 245/300      | *    |
| close Passive                     |          |          |                |              |      |
| IPv4 action count: 1 on FPC1.PIC0 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 245/300      | *    |
| close Passive                     |          |          |                |              |      |
| IPv4 action count: 1 on FPC1.PIC1 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                           | *        | 5.0.0.1  | 21/tcp         | 245/300      | *    |
| close Passive                     |          |          |                |              |      |
| IPv4 action count: 1 on FPC1.PIC2 |          |          |                |              |      |

| Src-Addr                                     | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|----------------------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                                      | *        | 5.0.0.1  | 21/tcp         | 245/300      | *    |
| close Active                                 |          |          |                |              |      |
| IPv4 action count: 1 on FPC1.PIC3            |          |          |                |              |      |
| IPv4 action count: Active mode 1 on all PICs |          |          |                |              |      |

**show security flow ip-action family inet protocol**

```
user@host> show security flow ip-action family inet protocoludp
```

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                           | *        | 5.0.0.1  | 69/udp         | 287/300      | *    |
| close Passive                     |          |          |                |              |      |
| IPv4 action count: 1 on FPC0.PIC1 |          |          |                |              |      |

| Src-Addr                          | Src-Port | Dst-Addr | Dst-Port/Proto | Timeout(sec) | Zone |
|-----------------------------------|----------|----------|----------------|--------------|------|
| 4.0.0.1                           | *        | 5.0.0.1  | 69/udp         | 287/300      | *    |
| close Passive                     |          |          |                |              |      |
| IPv4 action count: 1 on FPC0.PIC2 |          |          |                |              |      |

```

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 287/300 *
close Passive
IPv4 action count: 1 on FPC0.PIC3

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 287/300 *
close Active
IPv4 action count: 1 on FPC1.PIC0

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 287/300 *
close Passive
IPv4 action count: 1 on FPC1.PIC1

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 287/300 *
close Passive
IPv4 action count: 1 on FPC1.PIC2

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 287/300 *
close Passive
IPv4 action count: 1 on FPC1.PIC3
IPv4 action count: Active mode 1 on all PICs

```

#### show security flow ip-action family inet logical-system all

```
user@host> show security flow ip-action family inet logical-system all
```

```

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State Logical-System
4.0.0.1 * 5.0.0.1 69/udp 267/300 *
close Passive root-logical-system
IPv4 action count: 1 on FPC0.PIC1

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State Logical-System
4.0.0.1 * 5.0.0.1 69/udp 267/300 *
close Passive root-logical-system
IPv4 action count: 1 on FPC0.PIC2

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State Logical-System
4.0.0.1 * 5.0.0.1 69/udp 267/300 *
close Passive root-logical-system
IPv4 action count: 1 on FPC0.PIC3

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State Logical-System
4.0.0.1 * 5.0.0.1 69/udp 267/300 *
close Active root-logical-system
IPv4 action count: 1 on FPC1.PIC0

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone

```

```

Action State Logical-System
4.0.0.1 * 5.0.0.1 69/udp 267/300 *
close Passive root-logical-system
IPv4 action count: 1 on FPC1.PIC1

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State Logical-System
4.0.0.1 * 5.0.0.1 69/udp 266/300 *
close Passive root-logical-system
IPv4 action count: 1 on FPC1.PIC2

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State Logical-System
4.0.0.1 * 5.0.0.1 69/udp 266/300 *
close Passive root-logical-system
IPv4 action count: 1 on FPC1.PIC3
IPv4 action count: Active mode 1 on all PICs

```

### show security flow ip-action source-prefix

```

user@host> show security flow ip-action source-prefix 4.0.0.0/8

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 244/300 *
close Passive
IPv4 action count: 1 on FPC0.PIC1

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 244/300 *
close Passive
IPv4 action count: 1 on FPC0.PIC2

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 244/300 *
close Passive
IPv4 action count: 1 on FPC0.PIC3

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 244/300 *
close Active
IPv4 action count: 1 on FPC1.PIC0

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 244/300 *
close Passive
IPv4 action count: 1 on FPC1.PIC1

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 244/300 *
close Passive
IPv4 action count: 1 on FPC1.PIC2

Src-Addr Src-Port Dst-Addr Dst-Port/Proto Timeout(sec) Zone
Action State
4.0.0.1 * 5.0.0.1 69/udp 244/300 *

```

```

close Passive
IPv4 action count: 1 on FPC1.PIC3
IPv4 action count: Active mode 1 on all PICs

```

#### show security flow ip-action summary

```

user@host> show security flow ip-action summary

IPv4 action count: 1 on FPC0.PIC1
IPv4 action count: 1 on FPC0.PIC2
IPv4 action count: 1 on FPC0.PIC3
IPv4 action count: 1 on FPC1.PIC0
IPv4 action count: 1 on FPC1.PIC1
IPv4 action count: 1 on FPC1.PIC2
IPv4 action count: 1 on FPC1.PIC3
IPv4 action count: Active mode 1 on all PICs
IPv6 action count: 0 on FPC0.PIC1
IPv6 action count: 0 on FPC0.PIC2
IPv6 action count: 0 on FPC0.PIC3
IPv6 action count: 0 on FPC1.PIC0
IPv6 action count: 0 on FPC1.PIC1
IPv6 action count: 0 on FPC1.PIC2
IPv6 action count: 0 on FPC1.PIC3
IPv6 action count: Active mode 0 on all PICs

```

#### show security flow ip-action summary family inet

```

user@host> show security flow ip-action summary inet

IPv4 action count: 1 on FPC0.PIC1
IPv4 action count: 1 on FPC0.PIC2
IPv4 action count: 1 on FPC0.PIC3
IPv4 action count: 1 on FPC1.PIC0
IPv4 action count: 1 on FPC1.PIC1
IPv4 action count: 1 on FPC1.PIC2
IPv4 action count: 1 on FPC1.PIC3
IPv4 action count: Active mode 1 on all PICs

```

#### show security flow ip-action summary family inet6

```

user@host> show security flow ip-action summary family inet6

IPv6 action count: 1 on FPC0.PIC1
IPv6 action count: 1 on FPC0.PIC2
IPv6 action count: 1 on FPC0.PIC3
IPv6 action count: 1 on FPC1.PIC0
IPv6 action count: 1 on FPC1.PIC1
IPv6 action count: 1 on FPC1.PIC2
IPv6 action count: 1 on FPC1.PIC3
IPv6 action count: Active mode 1 on all PICs

```

## show security flow gate brief node

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow gate brief node</b> ( <i>node-id</i>   all   local   primary)                                                                                                                                                                                                                                                                                                                                                       |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; node options added in Junos OS Release 9.0. Filter options added in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                    |
| <b>Description</b>              | Display information about temporary openings known as pinholes or gates in the security firewall for the specified node options in brief mode.                                                                                                                                                                                                                                                                                            |
| <b>Options</b>                  | <p><b>node</b>—(Optional) For chassis cluster configurations, display gate information on a specific node.</p> <ul style="list-style-type: none"> <li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow gate on page 366</a></li> <li>• <a href="#">show security flow gate summary node on page 393</a></li> </ul>                                                                                                                                                                                                                                                       |
| <b>List of Sample Output</b>    | <a href="#">show security flow gate brief node 0 on page 379</a><br><a href="#">show security flow gate brief node 1 on page 380</a><br><a href="#">show security flow gate brief node all on page 380</a><br><a href="#">show security flow gate brief node local on page 382</a><br><a href="#">show security flow gate brief node primary on page 382</a>                                                                              |
| <b>Output Fields</b>            | <a href="#">Table 45 on page 378</a> lists the output fields for the <b>show security flow gate brief node</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                           |

**Table 45: show security flow gate brief node Output Fields**

| Field Name            | Field Description                        |
|-----------------------|------------------------------------------|
| Valid gates           | Number of valid gates.                   |
| Pending gates         | Number of pending gates.                 |
| Invalidated gates     | Number of invalid gates.                 |
| Gates in other states | Number of gates in other states.         |
| Total gates           | Number of gates in total.                |
| Hole                  | Range of flows permitted by the pinhole. |



Table 45: show security flow gate brief node Output Fields (*continued*)

| Field Name      | Field Description                                                                                                                                                                |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Translated      | Tuples used to create the session if it matches the pinhole. <ul style="list-style-type: none"> <li>• Source address and port</li> <li>• Destination address and port</li> </ul> |
| Protocol        | Application protocol, such as UDP or TCP.                                                                                                                                        |
| Application     | Name of the application.                                                                                                                                                         |
| Age             | Idle timeout for the pinhole.                                                                                                                                                    |
| Flags           | Internal debug flags for the pinhole.                                                                                                                                            |
| Zone            | Incoming zone.                                                                                                                                                                   |
| Reference count | Number of resource manager references to the pinhole.                                                                                                                            |
| Resource        | Resource manager information about the pinhole.                                                                                                                                  |

## Sample Output

### show security flow gate brief node 0

```

root@antbert> show security flow gate brief node 0
node0:

Flow Gates on FPC3 PIC1:

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0

Flow Gates on FPC4 PIC0:

Hole: 1.0.0.100-1.0.0.100/0-0->2.0.0.100-2.0.0.100/32707-32707
Translated: 1.0.0.100/0->2.0.0.100/32707
Protocol: tcp
Application: FTP ALG/79
Age: 65518 seconds
Flags: 0x0080
Zone: trust
Reference count: 1
Resource: 1-24576-86016

Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1

```

Flow Gates on FPC4 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0

#### show security flow gate brief node 1

```
root@antbert> show security flow gate brief node 1
node1:
```

-----

Flow Gates on FPC3 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0

Flow Gates on FPC4 PIC0:

Hole: 1.0.0.100-1.0.0.100/0-0->2.0.0.100-2.0.0.100/32707-32707  
Translated: 1.0.0.100/0->2.0.0.100/32707  
Protocol: tcp  
Application: FTP ALG/79  
Age: 65514 seconds  
Flags: 0x0080  
Zone: trust  
Reference count: 1  
Resource: 1-24576-86016

Valid gates: 1  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 1

Flow Gates on FPC4 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0

#### show security flow gate brief node all

```
root@antbert> show security flow gate brief node all
node0:
```

-----

Flow Gates on FPC3 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0

Total gates: 0

Flow Gates on FPC4 PIC0:

Hole: 1.0.0.100-1.0.0.100/0-0->2.0.0.100-2.0.0.100/32707-32707  
 Translated: 1.0.0.100/0->2.0.0.100/32707  
 Protocol: tcp  
 Application: FTP ALG/79  
 Age: 65512 seconds  
 Flags: 0x0080  
 Zone: trust  
 Reference count: 1  
 Resource: 1-24576-86016

Valid gates: 1  
 Pending gates: 0  
 Invalidated gates: 0  
 Gates in other states: 0  
 Total gates: 1

Flow Gates on FPC4 PIC1:

Valid gates: 0  
 Pending gates: 0  
 Invalidated gates: 0  
 Gates in other states: 0  
 Total gates: 0

node1:

Flow Gates on FPC3 PIC1:

Valid gates: 0  
 Pending gates: 0  
 Invalidated gates: 0  
 Gates in other states: 0  
 Total gates: 0

Flow Gates on FPC4 PIC0:

Hole: 1.0.0.100-1.0.0.100/0-0->2.0.0.100-2.0.0.100/32707-32707  
 Translated: 1.0.0.100/0->2.0.0.100/32707  
 Protocol: tcp  
 Application: FTP ALG/79  
 Age: 65510 seconds  
 Flags: 0x0080  
 Zone: trust  
 Reference count: 1  
 Resource: 1-24576-86016

Valid gates: 1  
 Pending gates: 0  
 Invalidated gates: 0  
 Gates in other states: 0  
 Total gates: 1

Flow Gates on FPC4 PIC1:

Valid gates: 0  
 Pending gates: 0

```
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

#### show security flow gate brief node local

```
root@antbert> show security flow gate brief node local
node0:
```

```

Flow Gates on FPC3 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

```
Flow Gates on FPC4 PIC0:
```

```
Ho1e: 1.0.0.100-1.0.0.100/0-0->2.0.0.100-2.0.0.100/32707-32707
Translated: 1.0.0.100/0->2.0.0.100/32707
Protocol: tcp
Application: FTP ALG/79
Age: 65504 seconds
Flags: 0x0080
Zone: trust
Reference count: 1
Resource: 1-24576-86016
```

```
Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1
```

```
Flow Gates on FPC4 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

#### show security flow gate brief node primary

```
root@antbert> show security flow gate brief node primary
node0:
```

```

Flow Gates on FPC3 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

```
Flow Gates on FPC4 PIC0:
```

```
Ho1e: 1.0.0.100-1.0.0.100/0-0->2.0.0.100-2.0.0.100/32707-32707
```

Translated: 1.0.0.100/0->2.0.0.100/32707  
Protocol: tcp  
Application: FTP ALG/79  
Age: 65500 seconds  
Flags: 0x0080  
Zone: trust  
Reference count: 1  
Resource: 1-24576-86016

Valid gates: 1  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 1

Flow Gates on FPC4 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0

## show security flow gate destination-port

|                                                                                                                                                                                                                                    |                                                                                                                                                                                                                                                           |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                                                                                                                                                                                                                      | <code>show security flow gate destination-port <i>destination-port-number</i> [brief   summary]</code>                                                                                                                                                    |
| <b>Release Information</b>                                                                                                                                                                                                         | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                                              |
| <b>Description</b>                                                                                                                                                                                                                 | Display information about temporary openings known as pinholes or gates in the security firewall that for the specified destination port.                                                                                                                 |
| <div>  <b>NOTE:</b> Destination port filter matches the gate only if the given port falls within the range of ports specified in the gate. </div> |                                                                                                                                                                                                                                                           |
| <b>Options</b>                                                                                                                                                                                                                     | <ul style="list-style-type: none"> <li><i>destination-port-number</i>—Number of the destination port for which to display gate information.<br/><b>Range:</b> 1 through 65,535</li> <li>brief   summary—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b>                                                                                                                                                                                                    | view                                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>                                                                                                                                                                                                       | <ul style="list-style-type: none"> <li><a href="#">show security flow gate on page 366</a></li> <li><a href="#">show security flow gate destination-prefix on page 387</a></li> </ul>                                                                     |
| <b>List of Sample Output</b>                                                                                                                                                                                                       | <a href="#">show security flow gate destination-port brief on page 385</a><br><a href="#">show security flow gate destination-port summary on page 386</a>                                                                                                |
| <b>Output Fields</b>                                                                                                                                                                                                               | <a href="#">Table 46 on page 384</a> lists the output fields for the <code>show security flow gate destination-port</code> command. Output fields are listed in the approximate order in which they appear.                                               |

**Table 46: show security flow gate destination-port Output Fields**

| Field Name  | Field Description                                                                                                                                                            |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hole        | Range of flows permitted by the pinhole.                                                                                                                                     |
| Translated  | Tuples used to create the session if it matches the pinhole. <ul style="list-style-type: none"> <li>Source address and port</li> <li>Destination address and port</li> </ul> |
| Protocol    | Application protocol, such as UDP or TCP.                                                                                                                                    |
| Application | Name of the application.                                                                                                                                                     |
| Age         | Idle timeout for the pinhole.                                                                                                                                                |

Table 46: show security flow gate destination-port Output Fields (*continued*)

| Field Name            | Field Description                                     |
|-----------------------|-------------------------------------------------------|
| Flags                 | Internal debug flags for the pinhole.                 |
| Zone                  | Incoming zone.                                        |
| Reference count       | Number of resource manager references to the pinhole. |
| Resource              | Resource manager information about the pinhole.       |
| Valid gates           | Number of valid gates.                                |
| Pending gates         | Number of pending gates.                              |
| Invalidated gates     | Number of invalid gates.                              |
| Gates in other states | Number of gates in other states.                      |
| Total gates           | Number of gates in total.                             |
| Maximum gates         | Number of maximum gates.                              |

## Sample Output

### show security flow gate destination-port brief

```

root> show security flow gate destination-port 33253 brief
Flow Gates on FPC4 PIC1:

Hole: 40.0.0.111-40.0.0.111/0-0->30.0.0.100-30.0.0.100/33253-33253
Translated: 40.0.0.111/0->30.0.0.100/33253
Protocol: tcp
Application: FTP ALG/79
Age: 65526 seconds
Flags: 0x0080
Zone: trust
Reference count: 1
Resource: 1-24576-86016

Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1

Flow Gates on FPC5 PIC0:

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0

Flow Gates on FPC5 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

#### show security flow gate destination-port summary

```
root> show security flow gate destination-port 33253 summary
Flow Gates on FPC4 PIC1:
```

```
Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1
Maximum gates: 131072
```

```
Flow Gates on FPC5 PIC0:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

```
Flow Gates on FPC5 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```



## show security flow gate destination-prefix

|                                 |                                                                                                                                                                                                                                           |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show security flow gate destination-prefix <i>destination-IP-prefix</i> [brief   summary]</code>                                                                                                                                    |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                              |
| <b>Description</b>              | Display information about temporary openings known as pinholes or gates in the security firewall for the specified destination prefix.                                                                                                    |
|                                 | <div>  <b>NOTE:</b> Destination prefix must match both the starting and ending address in the gate. </div>                                               |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li><code>destination-IP-prefix</code>—Destination IP prefix or address for which to display gate information.</li> <li><code>brief   summary</code>—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li><a href="#">show security flow gate on page 366</a></li> <li><a href="#">show security flow gate destination-port on page 384</a></li> </ul>                                                       |
| <b>List of Sample Output</b>    | <a href="#">show security flow gate destination-prefix brief on page 388</a><br><a href="#">show security flow gate destination-prefix summary on page 389</a>                                                                            |
| <b>Output Fields</b>            | Table 47 on page 387 lists the output fields for the <code>show security flow gate destination-prefix</code> command. Output fields are listed in the approximate order in which they appear.                                             |

**Table 47: show security flow gate destination-prefix Output Fields**

| Field Name  | Field Description                                                                                                                                                            |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hole        | Range of flows permitted by the pinhole.                                                                                                                                     |
| Translated  | Tuples used to create the session if it matches the pinhole. <ul style="list-style-type: none"> <li>Source address and port</li> <li>Destination address and port</li> </ul> |
| Protocol    | Application protocol, such as UDP or TCP.                                                                                                                                    |
| Application | Name of the application.                                                                                                                                                     |
| Age         | Idle timeout for the pinhole.                                                                                                                                                |
| Flags       | Internal debug flags for the pinhole.                                                                                                                                        |

Table 47: show security flow gate destination-prefix Output Fields (*continued*)

| Field Name            | Field Description                                     |
|-----------------------|-------------------------------------------------------|
| Zone                  | Incoming zone.                                        |
| Reference count       | Number of resource manager references to the pinhole. |
| Resource              | Resource manager information about the pinhole.       |
| Valid gates           | Number of valid gates.                                |
| Pending gates         | Number of pending gates.                              |
| Invalidated gates     | Number of invalid gates.                              |
| Gates in other states | Number of gates in other states.                      |
| Total gates           | Number of gates in total.                             |

## Sample Output

### show security flow gate destination-prefix brief

```

root> show security flow gate destination-prefix 30.0.0.100 brief
HoLe: 40.0.0.111-40.0.0.111/0-0->30.0.0.100-30.0.0.100/37308-37308
Translated: 40.0.0.111/0->30.0.0.100/37308
Protocol: tcp
Application: FTP ALG/79
Age: 65456 seconds
Flags: 0x0080
Zone: trust
Reference count: 1
Resource: 1-24575-86015

```

```

Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1

```

Flow Gates on FPC5 PIC0:

```

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0

```

Flow Gates on FPC5 PIC1:

```

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0

```

**show security flow gate destination-prefix summary**

```
root> show security flow gate destination-prefix 30.0.0.100 summary
Flow Gates on FPC4 PIC1:
```

```
Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1
```

```
Flow Gates on FPC5 PIC0:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

```
Flow Gates on FPC5 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

## show security flow gate protocol

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow gate protocol</b> <i>protocol-name</i> [brief   summary]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Description</b>              | Display information about temporary openings known as pinholes or gates in the security firewall for the specified protocol.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Options</b>                  | <ul style="list-style-type: none"><li>• <i>protocol-name</i> —Protocol to use as a gate filter. Information about gates that use this protocol is displayed.</li></ul> <p>Possible protocols are:</p> <ul style="list-style-type: none"><li>• ah—IP Security Authentication Header</li><li>• egp—Exterior gateway protocol</li><li>• esp—IPsec Encapsulating Security Payload</li><li>• gre—Generic routing encapsulation</li><li>• icmp—Internet Control Message Protocol</li><li>• icmp6—Internet Control Message Protocol</li><li>• igmp—Internet Group Management Protocol</li><li>• ipip—IP over IP</li><li>• ospf—Open Shortest Path First</li><li>• pim—Protocol Independent Multicast</li><li>• rsvp—Resource Reservation Protocol</li><li>• sctp—Stream Control Transmission Protocol</li><li>• tcp—Transmission Control Protocol</li><li>• udp—User Datagram Protocol</li><li>• brief   summary—Display the specified level of output.</li></ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <a href="#">show security flow gate on page 366</a></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>List of Sample Output</b>    | <a href="#">show security flow gate protocol brief on page 391</a><br><a href="#">show security flow gate protocol summary on page 392</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Output Fields</b>            | <a href="#">Table 48 on page 391</a> lists the output fields for the <b>show security flow gate protocol</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

Table 48: show security flow gate protocol Output Fields

| Field Name            | Field Description                                                                                                                                                                |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hole                  | Range of flows permitted by the pinhole.                                                                                                                                         |
| Translated            | Tuples used to create the session if it matches the pinhole. <ul style="list-style-type: none"> <li>• Source address and port</li> <li>• Destination address and port</li> </ul> |
| Protocol              | Application protocol, such as UDP or TCP.                                                                                                                                        |
| Application           | Name of the application.                                                                                                                                                         |
| Age                   | Idle timeout for the pinhole.                                                                                                                                                    |
| Flags                 | Internal debug flags for the pinhole.                                                                                                                                            |
| Zone                  | Incoming zone.                                                                                                                                                                   |
| Reference count       | Number of resource manager references to the pinhole.                                                                                                                            |
| Resource              | Resource manager information about the pinhole.                                                                                                                                  |
| Valid gates           | Number of valid gates.                                                                                                                                                           |
| Pending gates         | Number of pending gates.                                                                                                                                                         |
| Invalidated gates     | Number of invalid gates.                                                                                                                                                         |
| Gates in other states | Number of gates in other states.                                                                                                                                                 |
| Total gates           | Number of gates in total.                                                                                                                                                        |

## Sample Output

### show security flow gate protocol brief

```

root> root> show security flow gate protocol tcp brief
Hole: 40.0.0.111-40.0.0.111/0-0->30.0.0.100-30.0.0.100/37308-37308
Translated: 40.0.0.111/0->30.0.0.100/37308
Protocol: tcp
Application: FTP ALG/79
Age: 65414 seconds
Flags: 0x0080
Zone: trust
Reference count: 1
Resource: 1-24575-86015

Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0

```

```
Total gates: 1

Flow Gates on FPC5 PIC0:

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0

Flow Gates on FPC5 PIC1:

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

#### **show security flow gate protocol summary**

```
root> show security flow gate protocol tcp summary
Flow Gates on FPC4 PIC1:

Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1

Flow Gates on FPC5 PIC0:

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0

Flow Gates on FPC5 PIC1:

Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
```

## show security flow gate summary node

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow gate summary node</b> ( <i>node-id</i>   all   local   primary)                                                                                                                                                                                                                                                                                                                                                     |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; node options added in Junos OS Release 9.0. Filter options added in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                    |
| <b>Description</b>              | Display information about temporary openings known as pinholes or gates in the security firewall for the specified node options in summary mode.                                                                                                                                                                                                                                                                                          |
| <b>Options</b>                  | <p><b>node</b>—(Optional) For chassis cluster configurations, display gate information on a specific node.</p> <ul style="list-style-type: none"> <li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">show security flow gate</a></li> <li>• <a href="#">show security flow gate brief node on page 378</a></li> </ul>                                                                                                                                                                                                                                                                     |
| <b>List of Sample Output</b>    | <a href="#">show security flow gate summary node 0 on page 394</a><br><a href="#">show security flow gate summary node 1 on page 395</a><br><a href="#">show security flow gate summary node all on page 395</a><br><a href="#">show security flow gate summary node local on page 396</a><br><a href="#">show security flow gate summary node primary on page 397</a>                                                                    |
| <b>Output Fields</b>            | <a href="#">Table 49 on page 393</a> lists the output fields for the <b>show security flow gate summary node</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                         |

**Table 49: show security flow gate summary node Output Fields**

| Field Name            | Field Description                        |
|-----------------------|------------------------------------------|
| Valid gates           | Number of valid gates.                   |
| Pending gates         | Number of pending gates.                 |
| Invalidated gates     | Number of invalid gates.                 |
| Gates in other states | Number of gates in other states.         |
| Total gates           | Number of gates in total.                |
| Hole                  | Range of flows permitted by the pinhole. |

Table 49: show security flow gate summary node Output Fields (*continued*)

| Field Name      | Field Description                                                                                                                                                            |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Translated      | Tuples used to create the session if it matches the pinhole. <ul style="list-style-type: none"> <li>Source address and port</li> <li>Destination address and port</li> </ul> |
| Protocol        | Application protocol, such as UDP or TCP.                                                                                                                                    |
| Application     | Name of the application.                                                                                                                                                     |
| Age             | Idle timeout for the pinhole.                                                                                                                                                |
| Flags           | Internal debug flags for the pinhole.                                                                                                                                        |
| Zone            | Incoming zone.                                                                                                                                                               |
| Reference count | Number of resource manager references to the pinhole.                                                                                                                        |
| Resource        | Resource manager information about the pinhole.                                                                                                                              |

## Sample Output

### show security flow gate summary node 0

```
root@antbert> show security flow gate summary node 0
node0:
```

```

Flow Gates on FPC3 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC0:
```

```
Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
```



```
Total gates: 0
Maximum gates: 131072
```

#### show security flow gate summary node 1

```
root@antbert> show security flow gate summary node 1
node1:
```

```

Flow Gates on FPC3 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC0:
```

```
Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

#### show security flow gate summary node all

```
root@antbert> show security flow gate summary node all
node0:
```

```

Flow Gates on FPC3 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC0:
```

```
Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

```
node1:
```

```

Flow Gates on FPC3 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC0:
```

```
Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

#### show security flow gate summary node local

```
root@antbert> show security flow gate summary node local
node0:
```

```

Flow Gates on FPC3 PIC1:
```

```
Valid gates: 0
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 0
Maximum gates: 131072
```

```
Flow Gates on FPC4 PIC0:
```

```
Valid gates: 1
Pending gates: 0
Invalidated gates: 0
Gates in other states: 0
Total gates: 1
Maximum gates: 131072
```

Flow Gates on FPC4 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0  
Maximum gates: 131072

#### show security flow gate summary node primary

```
root@antbert> show security flow gate summary node primary
node0:
```

-----

Flow Gates on FPC3 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0  
Maximum gates: 131072

Flow Gates on FPC4 PIC0:

Valid gates: 1  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 1  
Maximum gates: 131072

Flow Gates on FPC4 PIC1:

Valid gates: 0  
Pending gates: 0  
Invalidated gates: 0  
Gates in other states: 0  
Total gates: 0  
Maximum gates: 131072

## show security flow session

---

**Syntax** `show security flow session`  
`[filter ] [brief | extensive | summary ]`

**Release Information** Command introduced in Junos OS Release 8.5. Support for filter and view options added in Junos OS Release 10.2. Application firewall, dynamic application, and logical system filters added in Junos OS Release 11.2. Policy ID filter added in Junos OS Release 12.3X48-D10.

**Description** Display information about all currently active security sessions on the device.

**Options** • *filter*—Filter the display by the specified criteria.

The following filters reduce the display to those sessions that match the criteria specified by the filter. Refer to the specific **show** command for examples of the filtered output.

**application**—Predefined application name

**application-firewall**—Application firewall enabled

**application-firewall-rule-set**—Application firewall enabled with the specified rule set

**application-traffic-control**—Application traffic control session

**application-traffic-control-rule-set**—Application traffic control rule set name and rule name

**destination-port**—Destination port

**destination-prefix**—Destination IP prefix or address

**dynamic-application**—Dynamic application

**dynamic-application-group**—Dynamic application

**encrypted**—Encrypted traffic

**extensive**—Display detailed output

**family**—Display session by family

**idp**—IDP enabled sessions

**interface**—Name of incoming or outgoing interface

**logical-system** (**all** | *logical-system-name*)—Name of a specific logical system or **all** to display all logical systems

**nat**—Display sessions with network address translation

**policy-id**—Display session information based on policy ID; the range is 1 through 4,294,967,295

**protocol**—IP protocol number

**resource-manager**—Resource manager

**root-logical-system**—Display root logical system as default

**security-intelligence**—Display security intelligence sessions

**services-offload**—Display services offload sessions

**session-identifier**—Display session with specified session identifier

**source-port**—Source port

**source-prefix**—Source IP prefix

**summary**—Display output summary

**tunnel**—Tunnel sessions

- **brief | extensive | summary**—Display the specified level of output.
- **none**—Display information about all active sessions.

**Required Privilege Level**

view

**Related Documentation**

- [Juniper Networks Devices Processing Overview on page 3](#)
- [clear security flow session all on page 234](#)

**List of Sample Output**

[show security flow session on page 401](#)  
[show security flow session brief on page 401](#)  
[show security flow session extensive on page 402](#)  
[show security flow session summary on page 402](#)

**Output Fields**

[Table 50 on page 399](#) lists the output fields for the **show security flow session** command. Output fields are listed in the approximate order in which they appear.

**Table 50: show security flow session Output Fields**

| Field Name    | Field Description                                                                                                      |
|---------------|------------------------------------------------------------------------------------------------------------------------|
| Session ID    | Number that identifies the session. Use this ID to get more information about the session.                             |
| CP Session ID | Number that identifies the central point session. Use this ID to get more information about the central point session. |
| Policy name   | Policy that permitted the traffic.                                                                                     |
| Timeout       | Idle timeout after which the session expires.                                                                          |

Table 50: show security flow session Output Fields (*continued*)

| Field Name                           | Field Description                                                                                                                                                                                                               |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| In                                   | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).                                         |
| Out                                  | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).                                          |
| Total sessions                       | Total number of sessions.                                                                                                                                                                                                       |
| Status                               | Session status.                                                                                                                                                                                                                 |
| Flag                                 | Internal flag depicting the state of the session, used for debugging purposes. The three available flags are: <ul style="list-style-type: none"> <li>• flag</li> <li>• natflag</li> <li>• natflag2</li> </ul>                   |
| Policy name                          | Name and ID of the policy that the first packet of the session matched.                                                                                                                                                         |
| Source NAT pool                      | The name of the source pool where NAT is used.                                                                                                                                                                                  |
| Dynamic application                  | Name of the application.                                                                                                                                                                                                        |
| Application traffic control rule-set | AppQoS rule set for this session.                                                                                                                                                                                               |
| Rule                                 | AppQoS rule for this session.                                                                                                                                                                                                   |
| Forwarding class                     | The AppQoS forwarding class name for this session that distinguishes the transmission priority                                                                                                                                  |
| DSCP code point                      | Differentiated Services (DiffServ) code point (DSCP) value remarked by the matching rule for this session.                                                                                                                      |
| Loss priority                        | One of four priority levels set by the matching rule to control discarding a packet during periods of congestion. A high loss priority means a high probability that the packet could be dropped during a period of congestion. |
| Rate limiter client to server        | The rate-limiter profile assigned to the client-to-server traffic defining a unique combination of <b>bandwidth-limit</b> and <b>burst-size-limit</b> specifications.                                                           |
| Rate limiter server to client        | The rate-limiter profile assigned to the server-to-client traffic defining a unique combination of <b>bandwidth-limit</b> and <b>burst-size-limit</b> specifications.                                                           |
| Maximum timeout                      | Maximum session timeout.                                                                                                                                                                                                        |
| Current timeout                      | Remaining time for the session unless traffic exists in the session.                                                                                                                                                            |

Table 50: show security flow session Output Fields (*continued*)

| Field Name         | Field Description                                                                                                                                                                     |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session State      | Session state.                                                                                                                                                                        |
| Start time         | Time when the session was created, offset from the system start time.                                                                                                                 |
| Unicast-sessions   | Number of unicast sessions.                                                                                                                                                           |
| Multicast-sessions | Number of multicast sessions.                                                                                                                                                         |
| Failed-sessions    | Number of failed sessions.                                                                                                                                                            |
| Sessions-in-use    | Number of sessions in use. <ul style="list-style-type: none"> <li>Valid sessions</li> <li>Pending sessions</li> <li>Invalidated sessions</li> <li>Sessions in other states</li> </ul> |
| Maximum-sessions   | Maximum number of sessions permitted.                                                                                                                                                 |

## Sample Output

### show security flow session

```

root> show security flow session
Flow Sessions on FPC10 PIC1:

Session ID: 410000086, Policy name: default-policy-00/2, Timeout: 1790, Valid
 In: 200.0.0.10/41041 --> 60.0.0.2/21;tcp, If: ge-7/1/0.0, Pkts: 6, Bytes: 288,
 CP Session ID: 410000206
 Out: 60.0.0.2/21 --> 200.0.0.10/41041;tcp, If: ge-7/1/1.0, Pkts: 5, Bytes: 291,
 CP Session ID: 410000206
Total sessions: 1

Flow Sessions on FPC10 PIC2:
Total sessions: 0

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

### show security flow session brief

```

root> show security flow session brief
Flow Sessions on FPC10 PIC1:

Session ID: 410000086, Policy name: default-policy-00/2, Timeout: 1774, Valid
 In: 200.0.0.10/41041 --> 60.0.0.2/21;tcp, If: ge-7/1/0.0, Pkts: 9, Bytes: 414,
 CP Session ID: 410000206
 Out: 60.0.0.2/21 --> 200.0.0.10/41041;tcp, If: ge-7/1/1.0, Pkts: 8, Bytes: 479,
 CP Session ID: 410000206
Total sessions: 1

Flow Sessions on FPC10 PIC2:

```

Total sessions: 0

Flow Sessions on FPC10 PIC3:

Total sessions: 0

### show security flow session extensive

```
root> show security flow session extensive
```

Flow Sessions on FPC10 PIC1:

Session ID: 410000086, Status: Normal  
Flags: 0x42/0x0/0x2010103  
Policy name: default-policy-00/2  
Source NAT pool: Null, Application: junos-ftp/1  
Dynamic application: junos:UNKNOWN,  
Encryption: Unknown  
Application traffic control rule-set: INVALID, Rule: INVALID  
Maximum timeout: 1800, Current timeout: 1718  
Session State: Valid  
Start time: 64760, Duration: 108  
In: 200.0.0.10/41041 --> 60.0.0.2/21;tcp,  
Interface: ge-7/1/0.0,  
Session token: 0x6, Flag: 0xc0002621  
Route: 0xa0010, Gateway: 200.0.0.10, Tunnel: 0  
Port sequence: 0, FIN sequence: 0,  
FIN state: 0,  
Pkts: 9, Bytes: 414  
CP Session ID: 410000206  
Out: 60.0.0.2/21 --> 200.0.0.10/41041;tcp,  
Interface: ge-7/1/1.0,  
Session token: 0x7, Flag: 0xc0002620  
Route: 0x80010, Gateway: 60.0.0.2, Tunnel: 0  
Port sequence: 0, FIN sequence: 0,  
FIN state: 0,  
Pkts: 8, Bytes: 479  
CP Session ID: 410000206  
Total sessions: 1

Flow Sessions on FPC10 PIC2:

Total sessions: 0

Flow Sessions on FPC10 PIC3:

Total sessions: 0

### show security flow session summary

```
root> show security flow session summary
```

Flow Sessions on FPC10 PIC1:

Unicast-sessions: 1  
Multicast-sessions: 0  
Services-offload-sessions: 0  
Failed-sessions: 0  
Sessions-in-use: 1  
Valid sessions: 1  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Maximum-sessions: 6291456

Flow Sessions on FPC10 PIC2:

Unicast-sessions: 0



```
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC10 PIC3:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

## show security flow session brief node

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session brief node</b> ( <i>node-id</i>   all   local   primary)                                                                                                                                                                                                                                                                                                                                                       |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; node options added in Junos OS Release 9.0. Filter options added in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                       |
| <b>Description</b>              | Display information about all currently active security sessions on the device for the specified node options in brief mode.                                                                                                                                                                                                                                                                                                                 |
| <b>Options</b>                  | <p><b>node</b>—(Optional) For chassis cluster configurations, display session information on a specific node.</p> <ul style="list-style-type: none"> <li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">show security flow session</a></li> </ul>                                                                                                                                                                                                                                                             |
| <b>List of Sample Output</b>    | <a href="#">show security flow session brief node 0 on page 405</a><br><a href="#">show security flow session brief node 1 on page 405</a><br><a href="#">show security flow session brief node all on page 406</a><br><a href="#">show security flow session brief node local on page 406</a><br><a href="#">show security flow session brief node primary on page 407</a>                                                                  |
| <b>Output Fields</b>            | <a href="#">Table 51 on page 404</a> lists the output fields for the <b>show security flow session brief node</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                           |

**Table 51: show security flow session brief node Output Fields**

| Field Name  | Field Description                                                                                                                                                                       |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID  | Number that identifies the session. Use this ID to get more information about the session.                                                                                              |
| Policy name | Policy that permitted the traffic.                                                                                                                                                      |
| State       | Session state.                                                                                                                                                                          |
| Timeout     | Idle timeout after which the session expires.                                                                                                                                           |
| In          | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |

Table 51: show security flow session brief node Output Fields (*continued*)

| Field Name     | Field Description                                                                                                                                                                      |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Out            | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| CP Session ID  | Number that identifies the central point session. Use this ID to get more information about the central point session.                                                                 |
| Total sessions | Total number of sessions.                                                                                                                                                              |

## Sample Output

### show security flow session brief node 0

```

root@host> show security flow session brief node 0
node0:

Flow Sessions on FPC0 PIC1:

Session ID: 10000001, Policy name: default-policy-00/2, State: Active, Timeout:
1696, Valid
Resource information : FTP ALG, 1, 0
 In: 100.0.0.2/60059 --> 120.0.0.2/21;tcp, If: reth0.0, Pkts: 14, Bytes: 626,
CP Session ID: 10000001
 Out: 120.0.0.2/21 --> 100.0.0.2/60059;tcp, If: reth1.0, Pkts: 13, Bytes: 744,
CP Session ID: 10000001

Total sessions: 1

Flow Sessions on FPC0 PIC2:
Total sessions: 0

Flow Sessions on FPC0 PIC3:
Total sessions: 0

```

### show security flow session brief node 1

```

root@host> show security flow session brief node 1
node1:

Flow Sessions on FPC0 PIC1:

Session ID: 10000001, Policy name: default-policy-00/2, State: Backup, Timeout:
12, Valid
Resource information : FTP ALG, 1, 0
 In: 100.0.0.2/60059 --> 120.0.0.2/21;tcp, If: reth0.0, Pkts: 0, Bytes: 0, CP
Session ID: 10000001
 Out: 120.0.0.2/21 --> 100.0.0.2/60059;tcp, If: reth1.0, Pkts: 0, Bytes: 0, CP
Session ID: 10000001
Total sessions: 1

Flow Sessions on FPC0 PIC2:
Total sessions: 0

```

```
Flow Sessions on FPC0 PIC3:
Total sessions: 0
```

#### show security flow session brief node all

```
root@host> show security flow session brief node all
node0:

Flow Sessions on FPC0 PIC1:

Session ID: 10000001, Policy name: default-policy-00/2, State: Active, Timeout:
1672, Valid
Resource information : FTP ALG, 1, 0
 In: 100.0.0.2/60059 --> 120.0.0.2/21;tcp, If: reth0.0, Pkts: 14, Bytes: 626,
CP Session ID: 10000001
 Out: 120.0.0.2/21 --> 100.0.0.2/60059;tcp, If: reth1.0, Pkts: 13, Bytes: 744,
CP Session ID: 10000001
Total sessions: 1

Flow Sessions on FPC0 PIC2:
Total sessions: 0

Flow Sessions on FPC0 PIC3:
Total sessions: 0

node1:

Flow Sessions on FPC0 PIC1:

Session ID: 10000001, Policy name: default-policy-00/2, State: Backup, Timeout:
50, Valid
Resource information : FTP ALG, 1, 0
 In: 100.0.0.2/60059 --> 120.0.0.2/21;tcp, If: reth0.0, Pkts: 0, Bytes: 0, CP
Session ID: 10000001
 Out: 120.0.0.2/21 --> 100.0.0.2/60059;tcp, If: reth1.0, Pkts: 0, Bytes: 0, CP
Session ID: 10000001
Total sessions: 1

Flow Sessions on FPC0 PIC2:
Total sessions: 0

Flow Sessions on FPC0 PIC3:
Total sessions: 0
```

#### show security flow session brief node local

```
root@host> show security flow session brief node local
node0:

Flow Sessions on FPC0 PIC1:

Session ID: 10000001, Policy name: default-policy-00/2, State: Active, Timeout:
1662, Valid
Resource information : FTP ALG, 1, 0
 In: 100.0.0.2/60059 --> 120.0.0.2/21;tcp, If: reth0.0, Pkts: 14, Bytes: 626,
CP Session ID: 10000001
 Out: 120.0.0.2/21 --> 100.0.0.2/60059;tcp, If: reth1.0, Pkts: 13, Bytes: 744,
```

```
CP Session ID: 10000001
Total sessions: 1
```

```
Flow Sessions on FPC0 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC0 PIC3:
Total sessions: 0
```

#### show security flow session brief node primary

```
root@host> show security flow session brief node primary
node0:
```

```

Flow Sessions on FPC0 PIC1:
```

```
Session ID: 10000001, Policy name: default-policy-00/2, State: Active, Timeout:
1650, Valid
Resource information : FTP ALG, 1, 0
 In: 100.0.0.2/60059 --> 120.0.0.2/21;tcp, If: reth0.0, Pkts: 14, Bytes: 626,
CP Session ID: 10000001
 Out: 120.0.0.2/21 --> 100.0.0.2/60059;tcp, If: reth1.0, Pkts: 13, Bytes: 744,
CP Session ID: 10000001
Total sessions: 1
```

```
Flow Sessions on FPC0 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC0 PIC3:
Total sessions: 0
```

## show security flow session destination-port

|                                 |                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session destination-port</b><br><i>destination-port-number</i> [brief   extensive   summary]                                                                                                                                                                                                                           |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; Filter and view options added in Junos OS Release 10.2.                                                                                                                                                                                                                                          |
| <b>Description</b>              | Display information about each session that uses the specified destination port.                                                                                                                                                                                                                                                             |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b><i>destination-port-number</i></b>—Number of the destination port for which to display sessions information.</li> <li>• <b>Range:</b> 1 through 65,535</li> <li>• <b>brief   extensive   summary</b>—Display the specified level of output.</li> </ul>                                           |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session destination-port on page 237</a></li> </ul>                                                                                                                               |
| <b>List of Sample Output</b>    | <a href="#">show security flow session destination-port 23 on page 409</a><br><a href="#">show security flow session destination-port 23 brief on page 410</a><br><a href="#">show security flow session destination-port 23 extensive on page 410</a><br><a href="#">show security flow session destination-port 23 summary on page 411</a> |
| <b>Output Fields</b>            | <a href="#">Table 52 on page 408</a> lists the output fields for the <b>show security flow session destination-port</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                     |

**Table 52: show security flow session destination-port Output Fields**

| Field Name         | Field Description                                                                                                                                                                       |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Session ID</b>  | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| <b>Policy name</b> | Policy that permitted the traffic.                                                                                                                                                      |
| <b>Timeout</b>     | Idle timeout after which the session expires.                                                                                                                                           |
| <b>In</b>          | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| <b>Out</b>         | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |

Table 52: show security flow session destination-port Output Fields (*continued*)

| Field Name         | Field Description                                                                                                                                                                     |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Total sessions     | Total number of sessions.                                                                                                                                                             |
| Status             | Session status.                                                                                                                                                                       |
| Flag               | Internal flag depicting the state of the session, used for debugging purposes.                                                                                                        |
| Policy name        | Name and ID of the policy that the first packet of the session matched.                                                                                                               |
| Source NAT pool    | The name of the source pool where NAT is used.                                                                                                                                        |
| Application        | Name of the application.                                                                                                                                                              |
| Maximum timeout    | Maximum session timeout.                                                                                                                                                              |
| Current timeout    | Remaining time for the session unless traffic exists in the session.                                                                                                                  |
| Session State      | Session state.                                                                                                                                                                        |
| Start time         | Time when the session was created, offset from the system start time.                                                                                                                 |
| Unicast-sessions   | Number of unicast sessions.                                                                                                                                                           |
| Multicast-sessions | Number of multicast sessions.                                                                                                                                                         |
| Failed-sessions    | Number of failed sessions.                                                                                                                                                            |
| Sessions-in-use    | Number of sessions in use. <ul style="list-style-type: none"> <li>Valid sessions</li> <li>Pending sessions</li> <li>Invalidated sessions</li> <li>Sessions in other states</li> </ul> |
| Maximum-sessions   | Number of maximum sessions.                                                                                                                                                           |

## Sample Output

### show security flow session destination-port 23

```

root> show security flow session destination-port 23
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:
Total sessions: 0

Flow Sessions on FPC10 PIC3:

Session ID: 430000098, Policy name: default-policy-00/2, Timeout: 1778, Valid

```

```
In: 200.0.0.10/15190 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 109, Bytes:
5874, CP Session ID: 430000093
Out: 60.0.0.2/23 --> 200.0.0.10/15190;tcp, If: ge-7/1/1.0, Pkts: 64, Bytes:
4015, CP Session ID: 430000093
Total sessions: 1
```

#### show security flow session destination-port 23 brief

```
root> show security flow session destination-port 23 brief
Flow Sessions on FPC10 PIC1:
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC3:
```

```
Session ID: 430000098, Policy name: default-policy-00/2, Timeout: 1696, Valid
In: 200.0.0.10/15190 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 109, Bytes:
5874, CP Session ID: 430000093
Out: 60.0.0.2/23 --> 200.0.0.10/15190;tcp, If: ge-7/1/1.0, Pkts: 64, Bytes:
4015, CP Session ID: 430000093
Total sessions: 1
```

#### show security flow session destination-port 23 extensive

```
root> show security flow session destination-port 23 extensive
Flow Sessions on FPC10 PIC1:
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC3:
```

```
Session ID: 430000098, Status: Normal
Flags: 0x40/0x0/0x2008003
Policy name: default-policy-00/2
Source NAT pool: Null, Application: junos-telnet/10
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 1630
Session State: Valid
Start time: 65490, Duration: 207
In: 200.0.0.10/15190 --> 60.0.0.2/23;tcp,
Interface: ge-7/1/0.0,
Session token: 0x6, Flag: 0xc0001021
Route: 0xa0010, Gateway: 200.0.0.10, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 109, Bytes: 5874
CP Session ID: 430000093
Out: 60.0.0.2/23 --> 200.0.0.10/15190;tcp,
Interface: ge-7/1/1.0,
Session token: 0x7, Flag: 0xc0001020
Route: 0x80010, Gateway: 60.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 64, Bytes: 4015
```



```
CP Session ID: 430000093
Total sessions: 1
```

#### show security flow session destination-port 23 summary

```
root> show security flow session destination-port 23 summary
Flow Sessions on FPC10 PIC1:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC2:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC3:
```

```
Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1
```

## show security flow session destination-prefix

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session destination-prefix</b><br><i>destination-IP-prefix</i> [brief   extensive   summary]                                                                                                                                                                                                                                                                                                                               |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5. Support for IPv6 addresses in active/active chassis cluster configurations (in addition to the existing support of active/passive chassis cluster configurations) added in Junos OS Release 10.4.<br>Support for IPv6 addresses added in Junos OS Release 10.2.<br>Filter and view options added in Junos OS Release 10.2.                                                                           |
| <b>Description</b>              | Display information about each session that matches the specified IP destination prefix.                                                                                                                                                                                                                                                                                                                                                         |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <i>destination-IP-prefix</i>—Destination IP prefix or address for which to display session information.</li> <li>• brief   extensive   summary—Display the specified level of output.</li> </ul>                                                                                                                                                                                                        |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session destination-port on page 237</a></li> </ul>                                                                                                                                                                                                                                   |
| <b>List of Sample Output</b>    | <a href="#">show security flow session destination-prefix 60/8 on page 413</a><br><a href="#">show security flow session destination-prefix 60/8 brief on page 414</a><br><a href="#">show security flow session destination-prefix 60/8 extensive on page 414</a><br><a href="#">show security flow session destination-prefix 60/8 summary on page 415</a><br><a href="#">show security flow session destination-prefix 10::10 on page 415</a> |
| <b>Output Fields</b>            | <a href="#">Table 53 on page 412</a> lists the output fields for the <b>show security flow session destination-prefix</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                       |

**Table 53: show security flow session destination-prefix Output Fields**

| Field Name  | Field Description                                                                                                                                                                       |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID  | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| Policy name | Policy that permitted the traffic.                                                                                                                                                      |
| Timeout     | Idle timeout after which the session expires.                                                                                                                                           |
| In          | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |

Table 53: show security flow session destination-prefix Output Fields (*continued*)

| Field Name         | Field Description                                                                                                                                                                             |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Out                | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).        |
| Total sessions     | Total number of sessions.                                                                                                                                                                     |
| Status             | Session status.                                                                                                                                                                               |
| Flag               | Internal flag depicting the state of the session, used for debugging purposes.                                                                                                                |
| Policy name        | Name and ID of the policy that the first packet of the session matched.                                                                                                                       |
| Source NAT pool    | The name of the source pool where NAT is used.                                                                                                                                                |
| Application        | Name of the application.                                                                                                                                                                      |
| Maximum timeout    | Maximum session timeout.                                                                                                                                                                      |
| Current timeout    | Remaining time for the session unless traffic exists in the session.                                                                                                                          |
| Session State      | Session state.                                                                                                                                                                                |
| Start time         | Time when the session was created, offset from the system start time.                                                                                                                         |
| Unicast-sessions   | Number of unicast sessions.                                                                                                                                                                   |
| Multicast-sessions | Number of multicast sessions.                                                                                                                                                                 |
| Failed-sessions    | Number of failed sessions.                                                                                                                                                                    |
| Sessions-in-use    | Number of sessions in use. <ul style="list-style-type: none"> <li>• Valid sessions</li> <li>• Pending sessions</li> <li>• Invalidated sessions</li> <li>• Sessions in other states</li> </ul> |
| Maximum-sessions   | Number of maximum sessions.                                                                                                                                                                   |

## Sample Output

### show security flow session destination-prefix 60/8

```

root> show security flow session destination-prefix 60/8
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

```

Total sessions: 0

Flow Sessions on FPC10 PIC3:

Session ID: 430000098, Policy name: default-policy-00/2, Timeout: 1450, Valid  
In: 200.0.0.10/15190 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 109, Bytes:  
5874, CP Session ID: 430000093  
Out: 60.0.0.2/23 --> 200.0.0.10/15190;tcp, If: ge-7/1/1.0, Pkts: 64, Bytes:  
4015, CP Session ID: 430000093  
Total sessions: 1

#### show security flow session destination-prefix 60/8 brief

root> show security flow session destination-prefix 60/8 brief

Flow Sessions on FPC10 PIC1:

Total sessions: 0

Flow Sessions on FPC10 PIC2:

Total sessions: 0

Flow Sessions on FPC10 PIC3:

Session ID: 430000098, Policy name: default-policy-00/2, Timeout: 1258, Valid  
In: 200.0.0.10/15190 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 109, Bytes:  
5874, CP Session ID: 430000093  
Out: 60.0.0.2/23 --> 200.0.0.10/15190;tcp, If: ge-7/1/1.0, Pkts: 64, Bytes:  
4015, CP Session ID: 430000093  
Total sessions: 1

#### show security flow session destination-prefix 60/8 extensive

root> show security flow session destination-prefix 60/8 extensive

Flow Sessions on FPC10 PIC1:

Total sessions: 0

Flow Sessions on FPC10 PIC2:

Total sessions: 0

Flow Sessions on FPC10 PIC3:

Session ID: 430000098, Status: Normal  
Flags: 0x40/0x0/0x2008003  
Policy name: default-policy-00/2  
Source NAT pool: Null, Application: junos-telnet/10  
Dynamic application: junos:UNKNOWN,  
Encryption: Unknown  
Application traffic control rule-set: INVALID, Rule: INVALID  
Maximum timeout: 1800, Current timeout: 1172  
Session State: Valid  
Start time: 65490, Duration: 666  
In: 200.0.0.10/15190 --> 60.0.0.2/23;tcp,  
Interface: ge-7/1/0.0,  
Session token: 0x6, Flag: 0xc0001021  
Route: 0xa0010, Gateway: 200.0.0.10, Tunnel: 0  
Port sequence: 0, FIN sequence: 0,  
FIN state: 0,  
Pkts: 109, Bytes: 5874  
CP Session ID: 430000093  
Out: 60.0.0.2/23 --> 200.0.0.10/15190;tcp,  
Interface: ge-7/1/1.0,  
Session token: 0x7, Flag: 0xc0001020

```

Route: 0x80010, Gateway: 60.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 64, Bytes: 4015
CP Session ID: 430000093
Total sessions: 1

```

#### show security flow session destination-prefix 60/8 summary

```

root> show security flow session destination-prefix 60/8 summary
Flow Sessions on FPC10 PIC1:

```

```

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

```

```

Flow Sessions on FPC10 PIC2:

```

```

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

```

```

Flow Sessions on FPC10 PIC3:

```

```

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

```

#### show security flow session destination-prefix 10::10

```

user@host> show security flow session destination-prefix 5001::2
Session ID: 50000004, Policy name: self-traffic-policy/1, Timeout: 2
In: 10::11/42756 --> 10::10/0;icmp, If: .local..0
Out: 10::10/0 --> 10::11/42756;icmp, If: ge-0/3/0.0

```

```

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

```

## show security flow session extensive node

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session extensive node</b> ( <i>node-id</i>   all   local   primary)                                                                                                                                                                                                                                                                                                                                                   |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; node options added in Junos OS Release 9.0. Filter options added in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                       |
| <b>Description</b>              | Display information about all currently active security sessions on the device for the specified node options in extensive mode.                                                                                                                                                                                                                                                                                                             |
| <b>Options</b>                  | <p><b>node</b>—(Optional) For chassis cluster configurations, display session information on a specific node.</p> <ul style="list-style-type: none"> <li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">show security flow session on page 398</a></li> </ul>                                                                                                                                                                                                                                                 |
| <b>List of Sample Output</b>    | <a href="#">show security flow session extensive node 0 on page 417</a><br><a href="#">show security flow session extensive node 1 on page 418</a><br><a href="#">show security flow session extensive node all on page 418</a><br><a href="#">show security flow session extensive node local on page 420</a><br><a href="#">show security flow session extensive node primary on page 421</a>                                              |
| <b>Output Fields</b>            | <a href="#">Table 54 on page 416</a> lists the output fields for the <b>show security flow session extensive node</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                       |

**Table 54: show security flow session extensive node Output Fields**

| Field Name  | Field Description                                                                                        |
|-------------|----------------------------------------------------------------------------------------------------------|
| Session ID  | Number that identifies the session. You can use this ID to get additional information about the session. |
| Status      | Session status.                                                                                          |
| State       | Session state.                                                                                           |
| Flag        | Internal flag depicting the state of the session, used for debugging purposes.                           |
| Policy name | Policy that permitted the traffic.                                                                       |

Table 54: show security flow session extensive node Output Fields (*continued*)

| Field Name      | Field Description                                                                                                                                                                             |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Source NAT pool | The name of the source pool where NAT is used.                                                                                                                                                |
| Maximum timeout | Maximum session timeout.                                                                                                                                                                      |
| Current timeout | Remaining time for the session unless traffic exists in the session.                                                                                                                          |
| Start time      | Time when the session was created, offset from the system start time.                                                                                                                         |
| Duration        | Length of time for which the session is active.                                                                                                                                               |
| In              | Incoming flow (source and destination IP addresses, application protocol, interface, session token, flag, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| Out             | Reverse flow (source and destination IP addresses, application protocol, interface, session token, flag, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |
| Total sessions  | Total number of sessions.                                                                                                                                                                     |
| CP Session ID   | Number that identifies the central point session. Use this ID to get more information about the central point session.                                                                        |

## Sample Output

### show security flow session extensive node 0

```

root@host> show security flow session extensive node 0
node0:

Flow Sessions on FPC0 PIC1:

Session ID: 10000003, Status: Normal, State: Active
Flags: 0x8000042/0x8000000/0x110103
Policy name: default-policy-00/2
Source NAT pool: Null, Application: junos-ftp/1
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 1778
Session State: Valid
Start time: 6466, Duration: 28
 In: 100.0.0.2/52080 --> 120.0.0.2/21;tcp,
 Interface: reth0.0,
 Session token: 0x6, Flag: 0x40002621
 Route: 0x86193c2, Gateway: 100.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 9, Bytes: 414
 CP Session ID: 10000004
 Out: 120.0.0.2/21 --> 100.0.0.2/52080;tcp,

```

```
Interface: reth1.0,
Session token: 0x6, Flag: 0x40002620
Route: 0x86033c2, Gateway: 120.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 8, Bytes: 420
CP Session ID: 10000004
Total sessions: 1
```

```
Flow Sessions on FPC0 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC0 PIC3:
Total sessions: 0
```

### show security flow session extensive node 1

```
root@host> show security flow session extensive node 1
node1:
```

```

Flow Sessions on FPC0 PIC1:
```

```
Session ID: 10000003, Status: Normal, State: Backup
Flags: 0x10000042/0x0/0x10103
Policy name: default-policy-00/2
Source NAT pool: Null, Application: junos-ftp/1
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 14324
Session State: Valid
Start time: 6248, Duration: 90
In: 100.0.0.2/52080 --> 120.0.0.2/21;tcp,
Interface: reth0.0,
Session token: 0x6, Flag: 0x60002621
Route: 0x86193c2, Gateway: 100.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 0, Bytes: 0
CP Session ID: 10000003
Out: 120.0.0.2/21 --> 100.0.0.2/52080;tcp,
Interface: reth1.0,
Session token: 0x6, Flag: 0x60002620
Route: 0x86033c2, Gateway: 120.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 0, Bytes: 0
CP Session ID: 10000003
Total sessions: 1
```

```
Flow Sessions on FPC0 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC0 PIC3:
Total sessions: 0
```

### show security flow session extensive node all

```
root@host> show security flow session extensive node all
```



node0:

-----

Flow Sessions on FPC0 PIC1:

Session ID: 10000003, Status: Normal, State: Active  
 Flags: 0x8000042/0x8000000/0x110103  
 Policy name: default-policy-00/2  
 Source NAT pool: Null, Application: junos-ftp/1  
 Dynamic application: junos:UNKNOWN,  
 Encryption: Unknown  
 Application traffic control rule-set: INVALID, Rule: INVALID  
 Maximum timeout: 1800, Current timeout: 1692  
 Session State: Valid  
 Start time: 6466, Duration: 113  
 In: 100.0.0.2/52080 --> 120.0.0.2/21;tcp,  
 Interface: reth0.0,  
 Session token: 0x6, Flag: 0x40002621  
 Route: 0x86193c2, Gateway: 100.0.0.2, Tunnel: 0  
 Port sequence: 0, FIN sequence: 0,  
 FIN state: 0,  
 Pkts: 9, Bytes: 414  
 CP Session ID: 10000004  
 Out: 120.0.0.2/21 --> 100.0.0.2/52080;tcp,  
 Interface: reth1.0,  
 Session token: 0x6, Flag: 0x40002620  
 Route: 0x86033c2, Gateway: 120.0.0.2, Tunnel: 0  
 Port sequence: 0, FIN sequence: 0,  
 FIN state: 0,  
 Pkts: 8, Bytes: 420  
 CP Session ID: 10000004  
 Total sessions: 1

Flow Sessions on FPC0 PIC2:

Total sessions: 0

Flow Sessions on FPC0 PIC3:

Total sessions: 0

node1:

-----

Flow Sessions on FPC0 PIC1:

Session ID: 10000003, Status: Normal, State: Backup  
 Flags: 0x10000042/0x0/0x10103  
 Policy name: default-policy-00/2  
 Source NAT pool: Null, Application: junos-ftp/1  
 Dynamic application: junos:UNKNOWN,  
 Encryption: Unknown  
 Application traffic control rule-set: INVALID, Rule: INVALID  
 Maximum timeout: 1800, Current timeout: 14298  
 Session State: Valid  
 Start time: 6248, Duration: 115  
 In: 100.0.0.2/52080 --> 120.0.0.2/21;tcp,  
 Interface: reth0.0,  
 Session token: 0x6, Flag: 0x60002621  
 Route: 0x86193c2, Gateway: 100.0.0.2, Tunnel: 0  
 Port sequence: 0, FIN sequence: 0,  
 FIN state: 0,  
 Pkts: 0, Bytes: 0

```

CP Session ID: 10000003
Out: 120.0.0.2/21 --> 100.0.0.2/52080;tcp,
Interface: reth1.0,
Session token: 0x6, Flag: 0x60002620
Route: 0x86033c2, Gateway: 120.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 0, Bytes: 0
CP Session ID: 10000003
Total sessions: 1

```

```

Flow Sessions on FPC0 PIC2:
Total sessions: 0

```

```

Flow Sessions on FPC0 PIC3:
Total sessions: 0

```

### show security flow session extensive node local

```

root@host> show security flow session extensive node local
node0:

```

```

Flow Sessions on FPC0 PIC1:

```

```

Session ID: 10000003, Status: Normal, State: Active
Flags: 0x8000042/0x8000000/0x110103
Policy name: default-policy-00/2
Source NAT pool: Null, Application: junos-ftp/1
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 1584
Session State: Valid
Start time: 6466, Duration: 221
In: 100.0.0.2/52080 --> 120.0.0.2/21;tcp,
Interface: reth0.0,
Session token: 0x6, Flag: 0x40002621
Route: 0x86193c2, Gateway: 100.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 9, Bytes: 414
CP Session ID: 10000004
Out: 120.0.0.2/21 --> 100.0.0.2/52080;tcp,
Interface: reth1.0,
Session token: 0x6, Flag: 0x40002620
Route: 0x86033c2, Gateway: 120.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 8, Bytes: 420
CP Session ID: 10000004
Total sessions: 1

```

```

Flow Sessions on FPC0 PIC2:
Total sessions: 0

```

```

Flow Sessions on FPC0 PIC3:
Total sessions: 0

```

**show security flow session extensive node primary**

```
root@host> show security flow session extensive node primary
node0:
```

-----  
**Flow Sessions on FPC0 PIC1:**

```
Session ID: 10000003, Status: Normal, State: Active
Flags: 0x8000042/0x8000000/0x110103
Policy name: default-policy-00/2
Source NAT pool: Null, Application: junos-ftp/1
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 1554
Session State: Valid
Start time: 6466, Duration: 252
 In: 100.0.0.2/52080 --> 120.0.0.2/21;tcp,
 Interface: reth0.0,
 Session token: 0x6, Flag: 0x40002621
 Route: 0x86193c2, Gateway: 100.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 9, Bytes: 414
 CP Session ID: 10000004
 Out: 120.0.0.2/21 --> 100.0.0.2/52080;tcp,
 Interface: reth1.0,
 Session token: 0x6, Flag: 0x40002620
 Route: 0x86033c2, Gateway: 120.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 8, Bytes: 420
 CP Session ID: 10000004
Total sessions: 1
```

```
Flow Sessions on FPC0 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC0 PIC3:
Total sessions: 0
```

## show security flow session family

|                                 |                                                                                                                                                                                                                                                                                                              |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security flow session family (inet   inet6)<br>[brief   extensive   summary]                                                                                                                                                                                                                            |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                                                                                                                 |
| <b>Description</b>              | Display filtered summary of information about existing sessions, including types of sessions, active and failed sessions, and the maximum allowed number of sessions.                                                                                                                                        |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>inet</b>—Display details summary of IPv4 sessions.</li> <li>• <b>inet6</b>—Display details summary of IPv6 sessions.</li> <li>• <b>brief   extensive   summary</b>—Display the specified level of output.</li> </ul>                                             |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session family on page 239</a></li> </ul>                                                                                                         |
| <b>List of Sample Output</b>    | <a href="#">show security flow session family inet on page 423</a><br><a href="#">show security flow session family inet brief on page 424</a><br><a href="#">show security flow session family inet extensive on page 424</a><br><a href="#">show security flow session family inet summary on page 426</a> |
| <b>Output Fields</b>            | <a href="#">Table 55 on page 422</a> lists the output fields for the <b>show security flow session family</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                               |

**Table 55: show security flow session family Output Fields**

| Field Name     | Field Description                                                                                                                                                                       |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID     | Number that identifies the session. Use this ID to get more information about the session.                                                                                              |
| Policy name    | Policy that permitted the traffic.                                                                                                                                                      |
| Timeout        | Idle timeout after which the session expires.                                                                                                                                           |
| In             | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| Out            | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |
| Total sessions | Total number of sessions.                                                                                                                                                               |
| Status         | Session status.                                                                                                                                                                         |

Table 55: show security flow session family Output Fields (*continued*)

| Field Name         | Field Description                                                                                                                                                                             |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flag               | Internal flag depicting the state of the session, used for debugging purposes.                                                                                                                |
| Policy name        | Name and ID of the policy that the first packet of the session matched.                                                                                                                       |
| Source NAT pool    | The name of the source pool where NAT is used.                                                                                                                                                |
| Application        | Name of the application.                                                                                                                                                                      |
| Maximum timeout    | Maximum session timeout.                                                                                                                                                                      |
| Current timeout    | Remaining time for the session unless traffic exists in the session.                                                                                                                          |
| Session State      | Session state.                                                                                                                                                                                |
| Start time         | Time when the session was created, offset from the system start time.                                                                                                                         |
| Unicast-sessions   | Number of unicast sessions.                                                                                                                                                                   |
| Multicast-sessions | Number of multicast sessions.                                                                                                                                                                 |
| Failed-sessions    | Number of failed sessions.                                                                                                                                                                    |
| Sessions-in-use    | Number of sessions in use. <ul style="list-style-type: none"> <li>• Valid sessions</li> <li>• Pending sessions</li> <li>• Invalidated sessions</li> <li>• Sessions in other states</li> </ul> |
| Maximum-sessions   | Number of maximum sessions.                                                                                                                                                                   |

## Sample Output

### show security flow session family inet

```

root> show security flow session family inet
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000107, Policy name: default-policy-00/2, Timeout: 4, Valid
 In: 200.0.0.10/3 --> 60.0.0.1/19001;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
 CP Session ID: 420000202
 Out: 60.0.0.1/19001 --> 200.0.0.10/3;icmp, If: .local..0, Pkts: 1, Bytes: 84,
 CP Session ID: 420000202
Total sessions: 1

Flow Sessions on FPC10 PIC3:
```

```

Session ID: 430000115, Policy name: default-policy-00/2, Timeout: 2, Valid
 In: 200.0.0.10/2 --> 60.0.0.1/19001;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 430000110
 Out: 60.0.0.1/19001 --> 200.0.0.10/2;icmp, If: .local..0, Pkts: 1, Bytes: 84,
CP Session ID: 430000110

```

```

Session ID: 430000117, Policy name: default-policy-00/2, Timeout: 4, Valid
 In: 200.0.0.10/4 --> 60.0.0.1/19001;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 430000111
 Out: 60.0.0.1/19001 --> 200.0.0.10/4;icmp, If: .local..0, Pkts: 1, Bytes: 84,
CP Session ID: 430000111
Total sessions: 2

```

### show security flow session family inet brief

```
root> show security flow session family inet brief
```

```
Flow Sessions on FPC10 PIC1:
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC2:
```

```

Session ID: 420000115, Policy name: default-policy-00/2, Timeout: 2, Valid
 In: 200.0.0.10/1 --> 60.0.0.1/19769;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 420000206
 Out: 60.0.0.1/19769 --> 200.0.0.10/1;icmp, If: .local..0, Pkts: 1, Bytes: 84,
CP Session ID: 420000206

```

```

Session ID: 420000117, Policy name: default-policy-00/2, Timeout: 2, Valid
 In: 200.0.0.10/2 --> 60.0.0.1/19769;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 420000207
 Out: 60.0.0.1/19769 --> 200.0.0.10/2;icmp, If: .local..0, Pkts: 1, Bytes: 84,
CP Session ID: 420000207
Total sessions: 2

```

```
Flow Sessions on FPC10 PIC3:
```

```

Session ID: 430000119, Policy name: default-policy-00/2, Timeout: 2, Valid
 In: 200.0.0.10/3 --> 60.0.0.1/19769;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 430000112
 Out: 60.0.0.1/19769 --> 200.0.0.10/3;icmp, If: .local..0, Pkts: 1, Bytes: 84,
CP Session ID: 430000112
Total sessions: 1

```

### show security flow session family inet extensive

```
root> show security flow session family inet extensive
```

```
Flow Sessions on FPC10 PIC1:
```

```

Session ID: 410000111, Status: Normal
Flags: 0x80400040/0x0/0x2800023
Policy name: default-policy-00/2
Source NAT pool: Null
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 4, Current timeout: 4
Session State: Valid
Start time: 76455, Duration: 0
 In: 200.0.0.10/4 --> 60.0.0.1/20537;icmp,
 Interface: ge-7/1/0.0,
 Session token: 0x6, Flag: 0xc0000021

```

```

Route: 0xa0010, Gateway: 200.0.0.10, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 1, Bytes: 84
CP Session ID: 410000242
Out: 60.0.0.1/20537 --> 200.0.0.10/4;icmp,
Interface: .local..0,
Session token: 0x2, Flag: 0x40000030
Route: 0xffffb0006, Gateway: 60.0.0.1, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 1, Bytes: 84
CP Session ID: 410000242
Total sessions: 1

```

#### Flow Sessions on FPC10 PIC2:

```

Session ID: 420000123, Status: Normal
Flags: 0x80400040/0x0/0x2800023
Policy name: default-policy-00/2
Source NAT pool: Null
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 4, Current timeout: 2
Session State: Valid
Start time: 76454, Duration: 2
In: 200.0.0.10/3 --> 60.0.0.1/20537;icmp,
Interface: ge-7/1/0.0,
Session token: 0x6, Flag: 0xc0000021
Route: 0xa0010, Gateway: 200.0.0.10, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 1, Bytes: 84
CP Session ID: 420000210
Out: 60.0.0.1/20537 --> 200.0.0.10/3;icmp,
Interface: .local..0,
Session token: 0x2, Flag: 0x40000030
Route: 0xffffb0006, Gateway: 60.0.0.1, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 1, Bytes: 84
CP Session ID: 420000210
Total sessions: 1

```

#### Flow Sessions on FPC10 PIC3:

```

Session ID: 430000131, Status: Normal
Flags: 0x80400040/0x0/0x2800023
Policy name: default-policy-00/2
Source NAT pool: Null
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 4, Current timeout: 4
Session State: Valid
Start time: 76421, Duration: 1
In: 200.0.0.10/5 --> 60.0.0.1/20537;icmp,
Interface: ge-7/1/0.0,
Session token: 0x6, Flag: 0xc0000021
Route: 0xa0010, Gateway: 200.0.0.10, Tunnel: 0

```

```
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 1, Bytes: 84
CP Session ID: 430000118
Out: 60.0.0.1/20537 --> 200.0.0.10/5;icmp,
Interface: .local..0,
Session token: 0x2, Flag: 0x40000030
Route: 0xffffb0006, Gateway: 60.0.0.1, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 1, Bytes: 84
CP Session ID: 430000118
Total sessions: 1
```

#### show security flow session family inet summary

```
root> show security flow session family inet summary
Flow Sessions on FPC10 PIC1:
```

```
Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 2
Sessions in other states: 0
Total sessions: 4
```

```
Flow Sessions on FPC10 PIC2:
```

```
Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 2
Sessions in other states: 0
Total sessions: 4
```

```
Flow Sessions on FPC10 PIC3:
```

```
Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 2
Sessions in other states: 0
Total sessions: 4
```



## show security flow session interface

|                                 |                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session interface</b><br><i>interface-name</i> [brief   extensive   summary]                                                                                                                                                                                                                                               |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; Filter and view options added in Junos OS Release 10.2.                                                                                                                                                                                                                                              |
| <b>Description</b>              | Display information about each session that uses the specified interface. The interface name can be a session's incoming or outgoing interface.                                                                                                                                                                                                  |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>interface-name</b>—Name of the interface on the device for which to display sessions information.</li> <li>• brief   extensive   summary—Display the specified level of output.</li> </ul>                                                                                                           |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session interface on page 240</a></li> </ul>                                                                                                                                          |
| <b>List of Sample Output</b>    | <a href="#">show security flow session interface ge-0/0/2.0 on page 428</a><br><a href="#">show security flow session interface ge-0/0/2.0 brief on page 429</a><br><a href="#">show security flow session interface ge-0/0/2.0 extensive on page 429</a><br><a href="#">show security flow session interface ge-7/1/1.0 summary on page 430</a> |
| <b>Output Fields</b>            | <a href="#">Table 56 on page 427</a> lists the output fields for the <b>show security flow session interface</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                |

**Table 56: show security flow session interface Output Fields**

| Field Name     | Field Description                                                                                                                                                                       |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID     | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| Policy name    | Policy that permitted the traffic.                                                                                                                                                      |
| Timeout        | Idle timeout after which the session expires.                                                                                                                                           |
| In             | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| Out            | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |
| Total sessions | Total number of sessions.                                                                                                                                                               |

Table 56: show security flow session interface Output Fields (*continued*)

| Field Name         | Field Description                                                                                                                                                                     |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Status             | Session status.                                                                                                                                                                       |
| Flag               | Internal flag depicting the state of the session, used for debugging purposes.                                                                                                        |
| Policy name        | Name and ID of the policy that the first packet of the session matched.                                                                                                               |
| Source NAT pool    | The name of the source pool where NAT is used.                                                                                                                                        |
| Application        | Name of the application.                                                                                                                                                              |
| Maximum timeout    | Maximum session timeout.                                                                                                                                                              |
| Current timeout    | Remaining time for the session unless traffic exists in the session.                                                                                                                  |
| Session State      | Session state.                                                                                                                                                                        |
| Start time         | Time when the session was created, offset from the system start time.                                                                                                                 |
| Unicast-sessions   | Number of unicast sessions.                                                                                                                                                           |
| Multicast-sessions | Number of multicast sessions.                                                                                                                                                         |
| Failed-sessions    | Number of failed sessions.                                                                                                                                                            |
| Sessions-in-use    | Number of sessions in use. <ul style="list-style-type: none"> <li>Valid sessions</li> <li>Pending sessions</li> <li>Invalidated sessions</li> <li>Sessions in other states</li> </ul> |
| Maximum-sessions   | Number of maximum sessions.                                                                                                                                                           |

## Sample Output

### show security flow session interface ge-0/0/2.0

```

root> show security flow session interface ge-7/1/1.0
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000146, Policy name: default-policy-00/2, Timeout: 58, Valid
 In: 200.0.0.10/9 --> 60.0.0.2/21562;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 420000247
 Out: 60.0.0.2/21562 --> 200.0.0.10/9;icmp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0,
CP Session ID: 420000247
Total sessions: 1

```

Flow Sessions on FPC10 PIC3:

```
Session ID: 430000146, Policy name: default-policy-00/2, Timeout: 56, Valid
 In: 200.0.0.10/8 --> 60.0.0.2/21562;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 430000131
 Out: 60.0.0.2/21562 --> 200.0.0.10/8;icmp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0,
CP Session ID: 430000131
Total sessions: 1
```

#### show security flow session interface ge-0/0/2.0 brief

```
root> show security flow session interface ge-7/1/1.0 brief
```

Flow Sessions on FPC10 PIC1:

```
Session ID: 410000137, Policy name: default-policy-00/2, Timeout: 2, Valid
 In: 200.0.0.10/5 --> 60.0.0.2/23354;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 410000269
 Out: 60.0.0.2/23354 --> 200.0.0.10/5;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 410000269
Total sessions: 1
```

Flow Sessions on FPC10 PIC2:

```
Session ID: 420000151, Policy name: default-policy-00/2, Timeout: 54, Valid
 In: 200.0.0.10/1 --> 60.0.0.2/23354;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 420000252
 Out: 60.0.0.2/23354 --> 200.0.0.10/1;icmp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0,
CP Session ID: 420000252
Total sessions: 1
```

Flow Sessions on FPC10 PIC3:

Total sessions: 0

#### show security flow session interface ge-0/0/2.0 extensive

```
root> show security flow session interface ge-7/1/1.0 extensive
```

Flow Sessions on FPC10 PIC1:

Total sessions: 0

Flow Sessions on FPC10 PIC2:

```
Session ID: 420000151, Status: Normal
Flags: 0x40/0x0/0x2000003
Policy name: default-policy-00/2
Source NAT pool: Null
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 60, Current timeout: 48
Session State: Valid
Start time: 83328, Duration: 12
 In: 200.0.0.10/1 --> 60.0.0.2/23354;icmp,
 Interface: ge-7/1/0.0,
 Session token: 0x6, Flag: 0xc0000021
 Route: 0xa0010, Gateway: 200.0.0.10, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 1, Bytes: 84
 CP Session ID: 420000252
 Out: 60.0.0.2/23354 --> 200.0.0.10/1;icmp,
```

```
Interface: ge-7/1/1.0,
Session token: 0x7, Flag: 0xc0000020
Route: 0x80010, Gateway: 60.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 0, Bytes: 0
CP Session ID: 420000252
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0
```

#### show security flow session interface ge-7/1/1.0 summary

```
root> show security flow session interface ge-7/1/1.0 summary
Flow Sessions on FPC10 PIC1:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

Flow Sessions on FPC10 PIC2:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

Flow Sessions on FPC10 PIC3:

Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 2
```

## show security flow session nat

|                                 |                                                                                                                                                                                                                |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show security flow session nat [brief   extensive   summary]</code>                                                                                                                                      |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.2.                                                                                                                                                                   |
| <b>Description</b>              | Display sessions with network address translation.                                                                                                                                                             |
| <b>Options</b>                  | <code>brief   extensive   summary</code> —Display the specified level of output.                                                                                                                               |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                           |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">show security flow session on page 398</a></li> </ul>                   |
| <b>List of Sample Output</b>    | <a href="#">show security flow session nat brief on page 432</a><br><a href="#">show security flow session nat extensive on page 432</a><br><a href="#">show security flow session nat summary on page 433</a> |
| <b>Output Fields</b>            | Table 57 on page 431 lists the output fields for the <code>show security flow session nat</code> command. Output fields are listed in the approximate order in which they appear.                              |

Table 57: show security flow session nat Output Fields

| Field Name           | Field Description                                                                                                                                                                       |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID           | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| Policy name          | Policy that permitted the traffic.                                                                                                                                                      |
| Timeout              | Idle timeout after which the session expires.                                                                                                                                           |
| Resource information | Information about the session particular to the resource manager, including the name of the ALG, the group ID, and the resource ID.                                                     |
| In                   | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| Out                  | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |
| Total sessions       | Total number of sessions.                                                                                                                                                               |
| Status               | Session status.                                                                                                                                                                         |
| Flag                 | Internal flag depicting the state of the session, used for debugging purposes.                                                                                                          |

Table 57: show security flow session nat Output Fields (*continued*)

| Field Name           | Field Description                                                       |
|----------------------|-------------------------------------------------------------------------|
| Policy name          | Name and ID of the policy that the first packet of the session matched. |
| Source NAT pool      | The name of the source pool where NAT is used.                          |
| Application          | Name of the application.                                                |
| Maximum timeout      | Maximum session timeout.                                                |
| Current timeout      | Remaining time for the session unless traffic exists in the session.    |
| Session State        | Session state.                                                          |
| Start time           | Time when the session was created, offset from the system start time.   |
| Valid sessions       | Number of valid sessions.                                               |
| Pending sessions     | Number of pending sessions.                                             |
| Invalidated sessions | Number of invalidated sessions.                                         |

## Sample Output

### show security flow session nat brief

```

root> show security flow session nat brief
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000390, Policy name: default-policy-00/2, Timeout: 1778, Valid
 In: 200.0.0.10/41043 --> 60.0.0.2/21;tcp, If: ge-7/1/0.0, Pkts: 9, Bytes: 414,
 CP Session ID: 420001090
 Out: 60.0.0.2/21 --> 60.0.0.1/19473;tcp, If: ge-7/1/1.0, Pkts: 8, Bytes: 479,
 CP Session ID: 430000964
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

### show security flow session nat extensive

```

root> show security flow session nat extensive
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000390, Status: Normal
Flags: 0x2/0x0/0x2010103
Policy name: default-policy-00/2
Source NAT pool: interface, Application: junos-ftp/1

```

```

Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 1770
Session State: Valid
Start time: 151971, Duration: 55
 In: 200.0.0.10/41043 --> 60.0.0.2/21;tcp,
 Interface: ge-7/1/0.0,
 Session token: 0x6, Flag: 0xc0002621
 Route: 0x70010, Gateway: 200.0.0.10, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 9, Bytes: 414
 CP Session ID: 420001090
 Out: 60.0.0.2/21 --> 60.0.0.1/19473;tcp,
 Interface: ge-7/1/1.0,
 Session token: 0x7, Flag: 0xe0002620
 Route: 0x80010, Gateway: 60.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 8, Bytes: 479
 CP Session ID: 430000964
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

#### show security flow session nat summary

```

root> show security flow session nat summary
Flow Sessions on FPC10 PIC1:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

Flow Sessions on FPC10 PIC3:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

```

## show security flow session policy-id

|                                 |                                                                                                                                                                                                                                                                      |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session policy-id</b> <i>policy-id-number</i> [brief   extensive   summary ]                                                                                                                                                                   |
| <b>Release Information</b>      | Command introduced in Junos OS Release 12.3X48-D10.                                                                                                                                                                                                                  |
| <b>Description</b>              | Display information about each session by using policy id of the session.                                                                                                                                                                                            |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>policy-id-number</b> —ID of the policy that the first packet of the session matches with.<br/><b>Range:</b> 1through 4294967295</li> <li>• brief   extensive   summary—Display the specified level of output.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                 |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session protocol on page 242</a></li> </ul>                                                               |
| <b>List of Sample Output</b>    | <a href="#">show security flow session policy-id 4 on page 435</a><br><a href="#">show security flow session policy-id 4 extensive on page 435</a>                                                                                                                   |
| <b>Output Fields</b>            | <a href="#">Table 58 on page 434</a> lists the output fields for the <b>show security flow session policy-id</b> command. Output fields are listed in the approximate order in which they appear.                                                                    |

**Table 58: show security flow session policy-id Output Fields**

| Field Name  | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID  | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Policy name | Policy that permitted the traffic.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Timeout     | Idle timeout after which the session expires.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| In          | For the input flow: <ul style="list-style-type: none"> <li>• Source and destination addresses and protocol tuple for the input flow.</li> <li>• <b>Interface:</b> Input flow interface.</li> <li>• <b>Session token:</b> Internal token derived from the virtual routing instance.</li> <li>• <b>Flag:</b> Internal debugging flags.</li> <li>• <b>Route:</b> Internal next hop of the route to be used by the flow.</li> <li>• <b>Gateway:</b> Next-hop gateway of the flow.</li> <li>• <b>Tunnel:</b> If the flow is going into a tunnel, the tunnel ID. Otherwise, 0 (zero).</li> <li>• <b>Port Sequence, FIN sequence, FIN state, Cookie:</b> Internal TCP state tracking information.</li> </ul> |



Table 58: show security flow session policy-id Output Fields (*continued*)

| Field Name          | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Out                 | <p>For the reverse flow:</p> <ul style="list-style-type: none"> <li>• Source and destination addresses, and protocol tuple for the reverse flow.</li> <li>• <b>Interface:</b> Reverse flow interface.</li> <li>• <b>Session token:</b> Internal token derived from the virtual routing instance.</li> <li>• <b>Flag:</b> Internal debugging flags.</li> <li>• <b>Route:</b> Internal next hop of the route to be used by the flow.</li> <li>• <b>Gateway:</b> Next-hop gateway of the flow.</li> <li>• <b>Tunnel:</b> If the flow is going into a tunnel, the tunnel ID. Otherwise, 0 (zero).</li> <li>• <b>Port Sequence, FIN sequence, FIN state, Cookie:</b> Internal TCP state tracking information.</li> </ul> |
| Total sessions      | Total number of sessions.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Status              | Session status.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Flag                | Internal flag depicting the state of the session, used for debugging purposes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Policy name         | Name and ID of the policy that the first packet of the session matched.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Source NAT pool     | The name of the source pool where NAT is used.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Dynamic application | Name of the application.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Maximum timeout     | Maximum session timeout.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Current timeout     | Remaining time for the session unless traffic exists in the session.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Session State       | Session state.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Start time          | Time when the session was created, offset from the system start time.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

## Sample Output

### show security flow session policy-id 4

```

root> show security flow session policy-id 4
Flow Sessions on FPC1 PIC0:

Session ID: 20093273, Policy name: p1/4, Timeout: 1784, Valid
 In: 101.0.0.2/1 --> 111.0.0.3/1;0, If: ge-0/0/0.0, Pkts: 1, Bytes: 84
 Out: 111.0.0.3/1 --> 201.0.0.1/22643;0, If: ge-0/0/1.0, Pkts: 0, Bytes: 0
Total sessions: 1

```

### show security flow session policy-id 4 extensive

```

root> show security flow session policy-id 4 extensive
Flow Sessions on FPC10 PIC1:
Total sessions: 0

```

## Flow Sessions on FPC10 PIC2:

Session ID: 420000428, Status: Normal  
Flags: 0x0/0x0/0x2008003  
Policy name: p1/4  
Source NAT pool: interface, Application: junos-telnet/10  
Dynamic application: junos:UNKNOWN,  
Encryption: Unknown  
Application traffic control rule-set: INVALID, Rule: INVALID  
Maximum timeout: 1800, Current timeout: 1740  
Session State: Valid  
Start time: 152305, Duration: 64  
In: 200.0.0.10/15192 --> 60.0.0.2/23;tcp,  
Interface: ge-7/1/0.0,  
Session token: 0x6, Flag: 0xc0001021  
Route: 0x70010, Gateway: 200.0.0.10, Tunnel: 0  
Port sequence: 0, FIN sequence: 0,  
FIN state: 0,  
Pkts: 40, Bytes: 2251  
CP Session ID: 420001128  
Out: 60.0.0.2/23 --> 60.0.0.1/8078;tcp,  
Interface: ge-7/1/1.0,  
Session token: 0x7, Flag: 0xe0001020  
Route: 0x80010, Gateway: 60.0.0.2, Tunnel: 0  
Port sequence: 0, FIN sequence: 0,  
FIN state: 0,  
Pkts: 28, Bytes: 1714  
CP Session ID: 430000965  
Total sessions: 1

## Flow Sessions on FPC10 PIC3:

Total sessions: 0

## show security flow session protocol

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session protocol</b> ( <i>protocol-name</i>   <i>protocol-number</i> )<br>[brief   extensive   summary]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; Filter and view options introduced in Junos OS Release 10.2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Description</b>              | Display information about each session that uses the specified protocol.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Options</b>                  | <p><b><i>protocol-name</i></b> —(Optional) Protocol to use as a sessions filter. Information about sessions that use this protocol is displayed. Possible protocols are:</p> <ul style="list-style-type: none"> <li>• <b>ah</b>—IP Security Authentication Header</li> <li>• <b>egp</b>—Exterior gateway protocol</li> <li>• <b>esp</b>—IPsec Encapsulating Security Payload</li> <li>• <b>gre</b>—Generic routing encapsulation</li> <li>• <b>icmp</b>—Internet Control Message Protocol</li> <li>• <b>igmp</b>—Internet Group Management Protocol</li> <li>• <b>ipip</b>—IP over IP</li> <li>• <b>ospf</b>—Open Shortest Path First</li> <li>• <b>pim</b>—Protocol Independent Multicast</li> <li>• <b>rsvp</b>—Resource Reservation Protocol</li> <li>• <b>sctp</b>—Stream Control Transmission Protocol</li> <li>• <b>tcp</b>—Transmission Control Protocol</li> <li>• <b>udp</b>—User Datagram Protocol</li> </ul> <p><b><i>protocol-number</i></b> —(Optional) Numeric protocol value. For a complete list of possible numeric values, see RFC 1700, <i>Assigned Numbers (for the Internet Protocol Suite)</i>.</p> <p><b>Range:</b> 0 through 255</p> <p><b>brief   extensive   summary</b>—Display the specified level of output.</p> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session protocol on page 242</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>List of Sample Output</b>    | <a href="#">show security flow session protocol icmp on page 439</a><br><a href="#">show security flow session protocol icmp brief on page 439</a><br><a href="#">show security flow session protocol icmp extensive on page 440</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

[show security flow session protocol icmp summary on page 440](#)

**Output Fields** [Table 59 on page 438](#) lists the output fields for the **show security flow session protocol** command. Output fields are listed in the approximate order in which they appear.

**Table 59: show security flow session protocol Output Fields**

| Field Name         | Field Description                                                                                                                                                                       |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID         | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| Policy name        | Policy that permitted the traffic.                                                                                                                                                      |
| Timeout            | Idle timeout after which the session expires.                                                                                                                                           |
| In                 | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| Out                | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |
| Total sessions     | Total number of sessions.                                                                                                                                                               |
| Status             | Session status.                                                                                                                                                                         |
| Flag               | Internal flag depicting the state of the session, used for debugging purposes.                                                                                                          |
| Policy name        | Name and ID of the policy that the first packet of the session matched.                                                                                                                 |
| Source NAT pool    | The name of the source pool where NAT is used.                                                                                                                                          |
| Application        | Name of the application.                                                                                                                                                                |
| Maximum timeout    | Maximum session timeout.                                                                                                                                                                |
| Current timeout    | Remaining time for the session unless traffic exists in the session.                                                                                                                    |
| Session State      | Session state.                                                                                                                                                                          |
| Start time         | Time when the session was created, offset from the system start time.                                                                                                                   |
| Unicast-sessions   | Number of unicast sessions.                                                                                                                                                             |
| Multicast-sessions | Number of multicast sessions.                                                                                                                                                           |
| Failed-sessions    | Number of failed sessions.                                                                                                                                                              |

Table 59: show security flow session protocol Output Fields (*continued*)

| Field Name       | Field Description                                                                                                                                                                            |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Sessions-in-use  | <p>Number of sessions in use.</p> <ul style="list-style-type: none"> <li>Valid sessions</li> <li>Pending sessions</li> <li>Invalidated sessions</li> <li>Sessions in other states</li> </ul> |
| Maximum-sessions | Number of maximum sessions.                                                                                                                                                                  |

## Sample Output

### show security flow session protocol icmp

```

root> show security flow session protocol icmp
Flow Sessions on FPC10 PIC1:

Session ID: 410000654, Policy name: p1/4, Timeout: 2, Valid
 In: 200.0.0.10/2 --> 60.0.0.2/15685;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 410001264
 Out: 60.0.0.2/15685 --> 200.0.0.10/2;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 410001264
Total sessions: 1

Flow Sessions on FPC10 PIC2:
Total sessions: 0

Flow Sessions on FPC10 PIC3:

Session ID: 430000399, Policy name: p1/4, Timeout: 2, Valid
 In: 200.0.0.10/3 --> 60.0.0.2/15685;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 430001053
 Out: 60.0.0.2/15685 --> 200.0.0.10/3;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 430001053
Total sessions: 1

```

### show security flow session protocol icmp brief

```

root> show security flow session protocol icmp brief
Flow Sessions on FPC10 PIC1:

Session ID: 410000658, Policy name: p1/4, Timeout: 4, Valid
 In: 200.0.0.10/4 --> 60.0.0.2/16453;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 410001268
 Out: 60.0.0.2/16453 --> 200.0.0.10/4;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 410001268
Total sessions: 1

Flow Sessions on FPC10 PIC2:

Session ID: 420000612, Policy name: p1/4, Timeout: 2, Valid
 In: 200.0.0.10/5 --> 60.0.0.2/16453;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
CP Session ID: 420001316
 Out: 60.0.0.2/16453 --> 200.0.0.10/5;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
CP Session ID: 420001316
Total sessions: 1

```

Flow Sessions on FPC10 PIC3:

```
Session ID: 430000405, Policy name: p1/4, Timeout: 2, Valid
 In: 200.0.0.10/6 --> 60.0.0.2/16453;icmp, If: ge-7/1/0.0, Pkts: 1, Bytes: 84,
 CP Session ID: 430001059
 Out: 60.0.0.2/16453 --> 200.0.0.10/6;icmp, If: ge-7/1/1.0, Pkts: 1, Bytes: 84,
 CP Session ID: 430001059
Total sessions: 1
```

#### show security flow session protocol icmp extensive

```
root> show security flow session protocol icmp extensive
```

Flow Sessions on FPC10 PIC1:

```
Session ID: 410000660, Status: Normal
Flags: 0x80000040/0x0/0x2800003
Policy name: p1/4
Source NAT pool: Null
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 4, Current timeout: 2
Session State: Valid
Start time: 153201, Duration: 3
 In: 200.0.0.10/8 --> 60.0.0.2/16453;icmp,
 Interface: ge-7/1/0.0,
 Session token: 0x6, Flag: 0xc0000021
 Route: 0x70010, Gateway: 200.0.0.10, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 1, Bytes: 84
 CP Session ID: 410001270
 Out: 60.0.0.2/16453 --> 200.0.0.10/8;icmp,
 Interface: ge-7/1/1.0,
 Session token: 0x7, Flag: 0xc0000020
 Route: 0x80010, Gateway: 60.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 1, Bytes: 84
 CP Session ID: 410001270
Total sessions: 1
```

Flow Sessions on FPC10 PIC2:

Total sessions: 0

Flow Sessions on FPC10 PIC3:

Total sessions: 0

#### show security flow session protocol icmp summary

```
root> show security flow session protocol icmp summary
```

Flow Sessions on FPC10 PIC1:

```
Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 1
Sessions in other states: 0
Total sessions: 3
```

Flow Sessions on FPC10 PIC2:

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

Flow Sessions on FPC10 PIC3:

```
Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 1
Sessions in other states: 0
Total sessions: 3
```

## show security flow session resource-manager

|                                 |                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session resource-manager</b><br>[brief   extensive   summary]                                                                                                                                                                                                                                              |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; Filter and view options introduced in Junos OS Release 10.2.                                                                                                                                                                                                                         |
| <b>Description</b>              | Display information about sessions created by the resource manager.                                                                                                                                                                                                                                                              |
| <b>Options</b>                  | none—Display all resource manager sessions.<br><br>brief   extensive   summary—Display the specified level of output.                                                                                                                                                                                                            |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session resource-manager on page 244</a></li> </ul>                                                                                                                   |
| <b>List of Sample Output</b>    | <a href="#">show security flow session resource-manager on page 443</a><br><a href="#">show security flow session resource-manager brief on page 444</a><br><a href="#">show security flow session resource-manager extensive on page 444</a><br><a href="#">show security flow session resource-manager summary on page 445</a> |
| <b>Output Fields</b>            | <a href="#">Table 60 on page 442</a> lists the output fields for the <b>show security flow session resource-manager</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                         |

Table 60: show security flow session resource-manager Output Fields

| Field Name           | Field Description                                                                                                                                                                       |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID           | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| Policy name          | Policy that permitted the traffic.                                                                                                                                                      |
| Timeout              | Idle timeout after which the session expires.                                                                                                                                           |
| Resource information | Information about the session particular to the resource manager, including the name of the ALG, the group ID, and the resource ID.                                                     |
| In                   | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| Out                  | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |



Table 60: show security flow session resource-manager Output Fields (*continued*)

| Field Name               | Field Description                                                                                                      |
|--------------------------|------------------------------------------------------------------------------------------------------------------------|
| Total sessions           | Total number of sessions.                                                                                              |
| Status                   | Session status.                                                                                                        |
| Flag                     | Internal flag depicting the state of the session, used for debugging purposes.                                         |
| Policy name              | Name and ID of the policy that the first packet of the session matched.                                                |
| Source NAT pool          | The name of the source pool where NAT is used.                                                                         |
| Application              | Name of the application.                                                                                               |
| Maximum timeout          | Maximum session timeout.                                                                                               |
| Current timeout          | Remaining time for the session unless traffic exists in the session.                                                   |
| Session State            | Session state.                                                                                                         |
| Start time               | Time when the session was created, offset from the system start time.                                                  |
| Valid sessions           | Number of valid sessions.                                                                                              |
| Pending sessions         | Number of pending sessions.                                                                                            |
| Invalidated sessions     | Number of invalidated sessions.                                                                                        |
| Sessions in other states | Number of sessions in other states.                                                                                    |
| CP Session ID            | Number that identifies the central point session. Use this ID to get more information about the central point session. |

## Sample Output

### show security flow session resource-manager

```
root> show security flow session resource-manager
Flow Sessions on FPC10 PIC1:
```

```
Session ID: 410000664, Policy name: p1/4, Timeout: 1734, Valid
Resource information : FTP ALG, 1, 0
 In: 200.0.0.10/41047 --> 60.0.0.2/21;tcp, If: ge-7/1/0.0, Pkts: 13, Bytes: 586,
 CP Session ID: 410001274
 Out: 60.0.0.2/21 --> 200.0.0.10/41047;tcp, If: ge-7/1/1.0, Pkts: 13, Bytes:
803, CP Session ID: 410001274
Total sessions: 1
```

```
Flow Sessions on FPC10 PIC2:
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC3:
Total sessions: 0
```

#### show security flow session resource-manager brief

```
root> show security flow session resource-manager brief
Flow Sessions on FPC10 PIC1:

Session ID: 410000664, Policy name: p1/4, Timeout: 1704, Valid
Resource information : FTP ALG, 1, 0
In: 200.0.0.10/41047 --> 60.0.0.2/21;tcp, If: ge-7/1/0.0, Pkts: 13, Bytes: 586,
CP Session ID: 410001274
Out: 60.0.0.2/21 --> 200.0.0.10/41047;tcp, If: ge-7/1/1.0, Pkts: 13, Bytes:
803, CP Session ID: 410001274
Total sessions: 1

Flow Sessions on FPC10 PIC2:
Total sessions: 0

Flow Sessions on FPC10 PIC3:
Total sessions: 0
```

#### show security flow session resource-manager extensive

```
root> show security flow session resource-manager extensive
Flow Sessions on FPC10 PIC1:

Session ID: 410000664, Status: Normal
Flags: 0x42/0x0/0x2010103
Policy name: p1/4
Source NAT pool: Null, Application: junos-ftp/1
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 1682
Session State: Valid
Start time: 160496, Duration: 153
Client: FTP ALG, Group: 1, Resource: 0
In: 200.0.0.10/41047 --> 60.0.0.2/21;tcp,
Interface: ge-7/1/0.0,
Session token: 0x6, Flag: 0xc0002621
Route: 0x70010, Gateway: 200.0.0.10, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 13, Bytes: 586
CP Session ID: 410001274
Out: 60.0.0.2/21 --> 200.0.0.10/41047;tcp,
Interface: ge-7/1/1.0,
Session token: 0x7, Flag: 0xc0002620
Route: 0x80010, Gateway: 60.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 13, Bytes: 803
CP Session ID: 410001274
Total sessions: 1

Flow Sessions on FPC10 PIC2:
Total sessions: 0

Flow Sessions on FPC10 PIC3:
Total sessions: 0
```

**show security flow session resource-manager summary**

```
root> show security flow session resource-manager summary
Flow Sessions on FPC10 PIC1:
```

```
Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1
```

```
Flow Sessions on FPC10 PIC2:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

```
Flow Sessions on FPC10 PIC3:
```

```
Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0
```

## show security flow session services-offload

---

|                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>              | <b>show security flow session services-offload</b><br>[ <i>filter</i> ] [ <i>brief</i>   <i>extensive</i>   <i>summary</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Release Information</b> | Command introduced in Junos OS Release 11.4. Low-latency option introduced in Junos OS Release 12.1X44-D10.<br>Starting with Junos OS Release 15.1X49-D10, the SRX5K-MPC3-100G10G (IOC3) and the SRX5K-MPC3-40G10G (IOC3) with Express Path (formerly known as <i>services offloading</i> ) support are introduced for SRX5400, SRX5600, and SRX5800 devices.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Description</b>         | Display information about all currently active services-offload security sessions on the device.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Options</b>             | <ul style="list-style-type: none"><li>• <i>filter</i>—Filter the display by the specified criteria.<br/><br/>The following filters reduce the display to those sessions that match the criteria specified by the filter:<br/><br/><b>application</b> —Application name.<br/><br/><b>application-firewall-rule-set</b>—Application firewall enabled with the specified rule set.<br/><br/><b>application-traffic-control-rule-set</b>—Application traffic control enabled with the specified rule set.<br/><br/><b>destination-port</b>—Destination port.<br/><br/><b>destination-prefix</b>—Destination IP prefix or address.<br/><br/><b>dynamic-application</b>—Dynamic application name.<br/><br/><b>dynamic-application-group</b>—Dynamic application group name.<br/><br/><b>encrypted</b>—Show encrypted traffic.<br/><br/><b>family</b>—Protocol family.<br/><br/><b>interface</b>—Name of incoming or outgoing interface.<br/><br/><b>logical-system</b>—Logical system name.<br/><br/><b>protocol</b>—IP protocol number.<br/><br/><b>root-logical-system</b>—Root logical system name.<br/><br/><b>source-port</b>—Source port.<br/><br/><b>source-prefix</b>—Source IP prefix or address.</li><li>• <i>brief</i>   <i>extensive</i>   <i>summary</i>—Display the specified level of output.</li></ul> |

**Required Privilege Level** view

**Related Documentation**

- [Juniper Networks Devices Processing Overview on page 3](#)
- [clear security flow session services-offload on page 245](#)

**List of Sample Output**

- [show security flow session services-offload on page 448](#)
- [show security flow session services-offload brief on page 448](#)
- [show security flow session services-offload extensive on page 449](#)
- [show security flow session services-offload summary on page 449](#)

**Output Fields** Table 61 on page 447 lists the output fields for the **show security flow session services-offload** command. Output fields are listed in the approximate order in which they appear.

**Table 61: show security flow session services-offload Output Fields**

| Field Name          | Field Description                                                                                                                                                                        |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID          | Number that identifies the services-offload session. Use this ID to get more information about the session.                                                                              |
| Policy name         | Policy that permits the services-offload traffic.                                                                                                                                        |
| Timeout             | Idle timeout period after which the services-offload session expires.                                                                                                                    |
| In                  | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets, and bytes). |
| Out                 | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets, and bytes).  |
| Total sessions      | Total number of services-offload sessions.                                                                                                                                               |
| Status              | Services-offload session status.                                                                                                                                                         |
| Flag                | Internal flag depicting the state of the services-offload session, used for debugging purposes.                                                                                          |
| Policy name         | Name and ID of the policy that the first packet of the services-offload session matched.                                                                                                 |
| Source NAT pool     | The name of the source pool where NAT is used.                                                                                                                                           |
| Application         | Name of the application.                                                                                                                                                                 |
| Dynamic application | Name of the dynamic application.                                                                                                                                                         |
| Maximum timeout     | Maximum amount of idle time allowed for the services-offload session.                                                                                                                    |
| Current timeout     | Number of seconds that the current services-offload session has been idle.                                                                                                               |

Table 61: show security flow session services-offload Output Fields (*continued*)

| Field Name               | Field Description                                                                      |
|--------------------------|----------------------------------------------------------------------------------------|
| Session State            | Services-offload session state.                                                        |
| Start time               | Time when the services-offload session was created, offset from the system start time. |
| Duration                 | Duration of the services-offload session.                                              |
| Valid sessions           | Number of valid services-offload sessions.                                             |
| Pending sessions         | Number of pending services-offload sessions.                                           |
| Invalidated sessions     | Number of invalidated services-offload sessions.                                       |
| Sessions in other states | Number of services-offload sessions in other states.                                   |
| Total sessions           | Total number of services-offload sessions.                                             |

## Sample Output

### show security flow session services-offload

```

user@host>show security flow session services-offload
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Policy name: p1/4, Timeout: 1788, Valid
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 9, Bytes: 507,
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp, If: ge-7/1/1.0, Pkts: 8, Bytes: 462,
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

### show security flow session services-offload brief

```

user@host>show security flow session services-offload brief
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Policy name: p1/4, Timeout: 1748, Valid
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 9, Bytes: 507,
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp, If: ge-7/1/1.0, Pkts: 8, Bytes: 462,
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

**show security flow session services-offload extensive**

```

user@host>show security flow session services-offload extensive
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Status: Normal
Flags: 0x40/0x0/0x2408003, services-offload
Policy name: p1/4
Source NAT pool: Null, Application: junos-telnet/10
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 1718
Session State: Valid
Start time: 165, Duration: 89
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp,
 Interface: ge-7/1/0.0,
 Session token: 0x6, Flag: 0x42001021
 Route: 0x80010, Gateway: 200.0.0.10, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 9, Bytes: 507
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp,
 Interface: ge-7/1/1.0,
 Session token: 0x7, Flag: 0x42001020
 Route: 0x70010, Gateway: 60.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 8, Bytes: 462
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

**show security flow session services-offload summary**

```

user@host>show security flow session services-offload summary
Flow Sessions on FPC10 PIC1:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

Flow Sessions on FPC10 PIC3:

Valid sessions: 1

```

```
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1
```



## show security flow session session-identifier

|                                 |                                                                                                                                                                                                                                                       |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session session-identifier <i>session-identifier</i></b>                                                                                                                                                                        |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5. Output changed to support natflag2 and flag in Junos OS Release 12.3X48-D10.                                                                                                                              |
| <b>Description</b>              | Display detailed information for the session with this identifier.                                                                                                                                                                                    |
| <b>Options</b>                  | <b><i>session-identifier</i></b> —Identifier of the session about which to display information.                                                                                                                                                       |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                  |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session session-identifier on page 248</a></li> </ul>                                      |
| <b>List of Sample Output</b>    | <a href="#">show security flow session session-identifier 420000002 on page 452</a><br><a href="#">show security flow session session-identifier 2218 on page 453</a><br><a href="#">show security flow session session-identifier 33 on page 453</a> |
| <b>Output Fields</b>            | <a href="#">Table 62 on page 451</a> lists the output fields for the <b>show security flow session session-identifier</b> command. Output fields are listed in the approximate order in which they appear.                                            |

**Table 62: show security flow session session-identifier Output Fields**

| Field Name      | Field Description                                                                                                                                                                                             |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID      | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                                      |
| Status          | Session status.                                                                                                                                                                                               |
| Flag            | Internal flag depicting the state of the session, used for debugging purposes. The three available flags are: <ul style="list-style-type: none"> <li>• flag</li> <li>• natflag</li> <li>• natflag2</li> </ul> |
| Virtual system  | Virtual system to which the session belongs.                                                                                                                                                                  |
| Policy name     | Name and ID of the policy that the first packet of the session matched.                                                                                                                                       |
| Maximum timeout | Maximum session timeout.                                                                                                                                                                                      |
| Current timeout | Remaining time for the session unless traffic exists in the session.                                                                                                                                          |
| Start time      | Time when the session was created, offset from the system start time.                                                                                                                                         |

Table 62: show security flow session session-identifier Output Fields (*continued*)

| Field Name      | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Duration</b> | Length of time for which the session is active.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>In</b>       | <p>For the input flow:</p> <ul style="list-style-type: none"> <li>Source and destination addresses and protocol tuple for the input flow.</li> <li><b>Interface:</b> Input flow interface.</li> <li><b>Session token:</b> Internal token derived from the virtual routing instance.</li> <li><b>Flag:</b> Internal debugging flags.</li> <li><b>Route:</b> Internal next hop of the route to be used by the flow.</li> <li><b>Gateway:</b> Next-hop gateway of the flow.</li> <li><b>Tunnel:</b> If the flow is going into a tunnel, the tunnel ID. Otherwise, 0 (zero).</li> <li><b>Port Sequence, FIN sequence, FIN state, Cookie:</b> Internal TCP state tracking information.</li> </ul>        |
| <b>Out</b>      | <p>For the reverse flow:</p> <ul style="list-style-type: none"> <li>Source and destination addresses, and protocol tuple for the reverse flow.</li> <li><b>Interface:</b> Reverse flow interface.</li> <li><b>Session token:</b> Internal token derived from the virtual routing instance.</li> <li><b>Flag:</b> Internal debugging flags.</li> <li><b>Route:</b> Internal next hop of the route to be used by the flow.</li> <li><b>Gateway:</b> Next-hop gateway of the flow.</li> <li><b>Tunnel:</b> If the flow is going into a tunnel, the tunnel ID. Otherwise, 0 (zero).</li> <li><b>Port Sequence, FIN sequence, FIN state, Cookie:</b> Internal TCP state tracking information.</li> </ul> |

## Sample Output

### show security flow session session-identifier 420000002

```

root> show security flow session session-identifier 420000002
Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Status: Normal
Flags: 0x40/0x0/0x2408003, services-offload
Policy name: p1/4
Source NAT pool: Null, Application: junos-telnet/10
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 1586
Session State: Valid
Start time: 165, Duration: 220
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp,
 Interface: ge-7/1/0.0,
 Session token: 0x6, Flag: 0x42001021
 Route: 0x80010, Gateway: 200.0.0.10, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 9, Bytes: 507
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp,
 Interface: ge-7/1/1.0,

```

```

Session token: 0x7, Flag: 0x42001020
Route: 0x70010, Gateway: 60.0.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0,
Pkts: 8, Bytes: 462
CP Session ID: 420000002
Total sessions: 1

```

## Sample Output

### show security flow session session-identifier 2218

```

user@host> show security flow session session-identifier 2218
Flow Sessions on FPC4 PIC1:

Session ID: 2218, Status: Normal,
Flags: 0x80000040, 0xffffffff, 0xffffffff
Virtual system: Root VSYS(I), Policy name: foo/4
Maximum timeout: 60, Current timeout: 60
Start time: 0, Duration: 0
Client: MGCP ALG, Group: 2047, Resource: 8188
In: 12.0.102.26/28072 --> 11.0.101.236/23252;udp,
Interface: ge-0/0/2.0,
Session token: 0xa, Flag: 0x8094740
Route: 0xb0010, Gateway: 12.0.102.26, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0, Cookie: 0,
Out: 11.0.101.236/23252 --> 12.0.102.26/28072;udp,
Interface: ge-0/0/1.0,
Session token: 0x8, Flag: 0x8094740
Route: 0xa0010, Gateway: 11.0.101.236, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0, Cookie: 0,
Total sessions: 1

```

## Sample Output

### show security flow session session-identifier 33

```

user@host> show security flow session session-identifier 33
Flow Sessions on FPC4 PIC1:

Session ID: 33, Status: Normal,
Flags: 0x80000040, 0xffffffff, 0xffffffff
Virtual system: Root VSYS(I), Policy name: default-policy/2
Application: junos-ftp/1
Maximum timeout: 1800, Current timeout: 1492
Start time: 31128, Duration: 121
In: 10.10.10.1/2851 --> 192.168.0.2/21;tcp,
Interface: tl-1/0/0.0,
Session token: 0x6, Flag: 0x80a15e0
Route: 0x60010, Gateway: 10.10.10.0, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0, Cookie: 0,
Out: 192.168.0.2/21 --> 10.10.10.1/2851;tcp,
Interface: ge-0/0/1.0,
Session token: 0x6, Flag: 0x80a15e0
Route: 0x90010, Gateway: 192.168.0.2, Tunnel: 0
Port sequence: 0, FIN sequence: 0,
FIN state: 0, Cookie: 0,
Total sessions: 1

```



## show security flow session source-port

|                                 |                                                                                                                                                                                                                                                                                                                                      |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session source-port</b><br>source-port-number<br>[brief   extensive   summary]                                                                                                                                                                                                                                 |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; Filter and view options introduced in Junos OS Release 10.2.                                                                                                                                                                                                                             |
| <b>Description</b>              | Display information about each session that uses the specified source port.                                                                                                                                                                                                                                                          |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>source-port-number</b>—Number of the source port about which to display sessions information.</li> <li>• brief   extensive   summary—Display the specified level of output.</li> </ul>                                                                                                   |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                 |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session source-port on page 249</a></li> </ul>                                                                                                                            |
| <b>List of Sample Output</b>    | <a href="#">show security flow session source-port 15198 on page 456</a><br><a href="#">show security flow session source-port 15198 brief on page 457</a><br><a href="#">show security flow session source-port 15198 extensive on page 457</a><br><a href="#">show security flow session source-port 15198 summary on page 457</a> |
| <b>Output Fields</b>            | <a href="#">Table 63 on page 455</a> lists the output fields for the <b>show security flow session source-port</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                  |

Table 63: show security flow session source-port Output Fields

| Field Name           | Field Description                                                                                                                                                                       |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session ID           | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| Policy name          | Policy that permitted the traffic.                                                                                                                                                      |
| Timeout              | Idle timeout after which the session expires.                                                                                                                                           |
| Resource information | Information about the session particular to the resource manager, including the name of the ALG, the group ID, and the resource ID.                                                     |
| In                   | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| Out                  | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |

Table 63: show security flow session source-port Output Fields (*continued*)

| Field Name               | Field Description                                                              |
|--------------------------|--------------------------------------------------------------------------------|
| Total sessions           | Total number of sessions.                                                      |
| Status                   | Session status.                                                                |
| Flag                     | Internal flag depicting the state of the session, used for debugging purposes. |
| Policy name              | Name and ID of the policy that the first packet of the session matched.        |
| Source NAT pool          | The name of the source pool where NAT is used.                                 |
| Application              | Name of the application.                                                       |
| Maximum timeout          | Maximum session timeout.                                                       |
| Current timeout          | Remaining time for the session unless traffic exists in the session.           |
| Session State            | Session state.                                                                 |
| Start time               | Time when the session was created, offset from the system start time.          |
| Valid sessions           | Number of valid sessions.                                                      |
| Pending sessions         | Number of pending sessions.                                                    |
| Invalidated sessions     | Number of invalidated sessions.                                                |
| Sessions in other states | Number of sessions in other states.                                            |

## Sample Output

### show security flow session source-port 15198

```

root> show security flow session source-port 15198
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Policy name: p1/4, Timeout: 770, Valid
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 9, Bytes: 507,
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp, If: ge-7/1/1.0, Pkts: 8, Bytes: 462,
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

**show security flow session source-port 15198 brief**

```

root> show security flow session source-port 15198 brief
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Policy name: p1/4, Timeout: 740, Valid
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 9, Bytes: 507,
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp, If: ge-7/1/1.0, Pkts: 8, Bytes: 462,
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

**show security flow session source-port 15198 extensive**

```

root> show security flow session source-port 15198 extensive
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Status: Normal
Flags: 0x40/0x0/0x2408003, services-offload
Policy name: p1/4
Source NAT pool: Null, Application: junos-telnet/10
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 750
Session State: Valid
Start time: 165, Duration: 1056
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp,
 Interface: ge-7/1/0.0,
 Session token: 0x6, Flag: 0x42001021
 Route: 0x80010, Gateway: 200.0.0.10, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 9, Bytes: 507
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp,
 Interface: ge-7/1/1.0,
 Session token: 0x7, Flag: 0x42001020
 Route: 0x70010, Gateway: 60.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 8, Bytes: 462
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

**show security flow session source-port 15198 summary**

```

root> show security flow session source-port 15198 summary

```

Flow Sessions on FPC10 PIC1:

Valid sessions: 0  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Valid sessions: 1  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 1

Flow Sessions on FPC10 PIC3:

Valid sessions: 0  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 0



## show security flow session source-prefix

|                                 |                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session source-prefix</b><br><b>source-prefix-number</b><br>[brief   extensive   summary]                                                                                                                                                                                                                                                             |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5.<br>Support for IPv6 addresses added in Junos OS Release 10.2. Support for IPv6 addresses in active/active chassis cluster configurations (in addition to the existing support of active/passive chassis cluster configurations) added in Junos OS Release 10.4.<br>Filter and view options introduced in Junos OS Release 10.2. |
| <b>Description</b>              | Display information about each session that uses the specified source prefix.                                                                                                                                                                                                                                                                                               |
| <b>Options</b>                  | <b>source-prefix-number</b> —Source IP prefix or address for which to display sessions information.<br><br><b>brief   extensive   summary</b> —Display the specified level of output.                                                                                                                                                                                       |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session source-prefix on page 251</a></li> </ul>                                                                                                                                                                 |
| <b>List of Sample Output</b>    | <a href="#">show security flow session source-prefix 200.0.0.10 on page 460</a><br><a href="#">show security flow session source-prefix 200.0.0.10 brief on page 461</a><br><a href="#">show security flow session source-prefix 200.0.0.10 extensive on page 461</a><br><a href="#">show security flow session source-prefix 200.0.0.10 summary on page 461</a>            |
| <b>Output Fields</b>            | <a href="#">Table 64 on page 459</a> lists the output fields for the <b>show security flow session source-prefix</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                       |

**Table 64: show security flow session source-prefix Output Fields**

| Field Name         | Field Description                                                                                                                                                                       |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Session ID</b>  | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| <b>Policy name</b> | Policy that permitted the traffic.                                                                                                                                                      |
| <b>Timeout</b>     | Idle timeout after which the session expires.                                                                                                                                           |
| <b>In</b>          | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| <b>Out</b>         | Reverse flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes).  |

Table 64: show security flow session source-prefix Output Fields (*continued*)

| Field Name               | Field Description                                                              |
|--------------------------|--------------------------------------------------------------------------------|
| Total sessions           | Total number of sessions.                                                      |
| Status                   | Session status.                                                                |
| Flag                     | Internal flag depicting the state of the session, used for debugging purposes. |
| Policy name              | Name and ID of the policy that the first packet of the session matched.        |
| Source NAT pool          | The name of the source pool where NAT is used.                                 |
| Application              | Name of the application.                                                       |
| Maximum timeout          | Maximum session timeout.                                                       |
| Current timeout          | Remaining time for the session unless traffic exists in the session.           |
| Session State            | Session state.                                                                 |
| Start time               | Time when the session was created, offset from the system start time.          |
| Valid sessions           | Number of valid sessions.                                                      |
| Pending sessions         | Number of pending sessions.                                                    |
| Invalidated sessions     | Number of invalidated sessions.                                                |
| Sessions in other states | Number of sessions in other states.                                            |

## Sample Output

### show security flow session source-prefix 200.0.0.10

```

root> show security flow session source-prefix 200.0.0.10
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Policy name: p1/4, Timeout: 488, Valid
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 9, Bytes: 507,
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp, If: ge-7/1/1.0, Pkts: 8, Bytes: 462,
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

**show security flow session source-prefix 200.0.0.10 brief**

```

root> show security flow session source-prefix 200.0.0.10 brief
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Policy name: p1/4, Timeout: 482, Valid
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 9, Bytes: 507,
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp, If: ge-7/1/1.0, Pkts: 8, Bytes: 462,
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

**show security flow session source-prefix 200.0.0.10 extensive**

```

root> show security flow session source-prefix 200.0.0.10 extensive
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Session ID: 420000002, Status: Normal
Flags: 0x40/0x0/0x2408003, services-offload
Policy name: p1/4
Source NAT pool: Null, Application: junos-telnet/10
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: 1800, Current timeout: 436
Session State: Valid
Start time: 165, Duration: 1370
 In: 200.0.0.10/15198 --> 60.0.0.2/23;tcp,
 Interface: ge-7/1/0.0,
 Session token: 0x6, Flag: 0x42001021
 Route: 0x80010, Gateway: 200.0.0.10, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 9, Bytes: 507
 CP Session ID: 420000002
 Out: 60.0.0.2/23 --> 200.0.0.10/15198;tcp,
 Interface: ge-7/1/1.0,
 Session token: 0x7, Flag: 0x42001020
 Route: 0x70010, Gateway: 60.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 8, Bytes: 462
 CP Session ID: 420000002
Total sessions: 1

Flow Sessions on FPC10 PIC3:
Total sessions: 0

```

**show security flow session source-prefix 200.0.0.10 summary**

```

root> show security flow session source-prefix 200.0.0.10 summary

```

Flow Sessions on FPC10 PIC1:

Valid sessions: 0  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Valid sessions: 1  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 1

Flow Sessions on FPC10 PIC3:

Valid sessions: 0  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 0

## show security flow session summary family

|                                 |                                                                                                                                                                                                                                                                                                                                                                        |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security flow session summary family (inet   inet6)                                                                                                                                                                                                                                                                                                               |
| <b>Release Information</b>      | <p>Command introduced in Junos OS Release 10.2.</p> <p>Support on SRX Series devices for flow-based mode for family inet6 added in Junos OS Release 10.2.</p> <p>Support for IPv6 addresses in active/active chassis cluster configurations (in addition to the existing support of active/passive chassis cluster configurations) added in Junos OS Release 10.4.</p> |
| <b>Description</b>              | Display filtered summary of information about existing sessions, including types of sessions, active and failed sessions, and the maximum allowed number of sessions.                                                                                                                                                                                                  |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>inet</b>—Display details summary of IPv4 sessions.</li> <li>• <b>inet6</b>—Display details summary of IPv6 sessions.</li> </ul>                                                                                                                                                                                            |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session all on page 234</a></li> </ul>                                                                                                                                                                      |
| <b>List of Sample Output</b>    | <p><a href="#">show security flow session summary family inet on page 463</a></p> <p><a href="#">show security flow session summary family inet6 on page 464</a></p>                                                                                                                                                                                                   |
| <b>Output Fields</b>            | <a href="#">Table 65 on page 463</a> lists the output fields for the <b>show security flow session summary family</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                 |

**Table 65: show security flow session summary Output Fields**

| Field Name               | Field Description                                                   |
|--------------------------|---------------------------------------------------------------------|
| Valid sessions           | Count of valid sessions.                                            |
| Pending sessions         | Count of pending sessions.                                          |
| Invalidated sessions     | Count of sessions the security device has determined to be invalid. |
| Sessions in other states | Count of sessions not in valid, pending, or invalidated state.      |
| Total sessions           | Total of the above counts.                                          |

## Sample Output

### show security flow session summary family inet

```
user@host> show security flow session summary family inet
```

Flow Sessions on FPC10 PIC1:

Valid sessions: 0  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Valid sessions: 1  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 1

Flow Sessions on FPC10 PIC3:

Valid sessions: 0  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 0

#### **show security flow session summary family inet6**

user@host> **show security flow session summary family inet6**

Flow Sessions on FPC10 PIC1:

Valid sessions: 0  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Valid sessions: 0  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 0

Flow Sessions on FPC10 PIC3:

Valid sessions: 1  
Pending sessions: 0  
Invalidated sessions: 0  
Sessions in other states: 0  
Total sessions: 1

## show security flow session summary node

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session summary node</b> ( <i>node-id</i>   all   local   primary)                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Release Information</b>      | <p>Command introduced in Junos OS Release 8.5; node options added in Junos OS Release 9.0. Filter options added in Junos OS Release 10.2.</p> <p>Support on SRX Series devices for flow-based mode for family inet6 added in Junos OS Release 10.2.</p> <p>Support for IPv6 addresses in active/active chassis cluster configurations (in addition to the existing support of active/passive chassis cluster configurations) added in Junos OS Release 10.4.</p> |
| <b>Description</b>              | Display information about all currently active security sessions on the device for the specified node options in summary mode.                                                                                                                                                                                                                                                                                                                                   |
| <b>Options</b>                  | <p><b>node</b>—(Optional) For chassis cluster configurations, display session information on a specific node.</p> <ul style="list-style-type: none"> <li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul>                     |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">show security flow session on page 398</a></li> </ul>                                                                                                                                                                                                                                                                     |
| <b>List of Sample Output</b>    | <p><a href="#">show security flow session summary node 0 on page 466</a></p> <p><a href="#">show security flow session summary node 1 on page 467</a></p> <p><a href="#">show security flow session summary node all on page 467</a></p> <p><a href="#">show security flow session summary node local on page 469</a></p> <p><a href="#">show security flow session summary node primary on page 469</a></p>                                                     |
| <b>Output Fields</b>            | <a href="#">Table 66 on page 465</a> lists the output fields for the <b>show security flow session summary node</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                             |

**Table 66: show security flow session summary node Output Fields**

| Field Name         | Field Description             |
|--------------------|-------------------------------|
| Unicast-sessions   | Number of unicast sessions.   |
| Multicast-sessions | Number of multicast sessions. |
| Failed-sessions    | Number of failed sessions.    |

Table 66: show security flow session summary node Output Fields (*continued*)

| Field Name       | Field Description                                                                                                                                                                     |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Sessions-in-use  | Number of sessions in use. <ul style="list-style-type: none"> <li>Valid sessions</li> <li>Pending sessions</li> <li>Invalidated sessions</li> <li>Sessions in other states</li> </ul> |
| Maximum-sessions | Number of maximum sessions.                                                                                                                                                           |

## Sample Output

### show security flow session summary node 0

```
root@host> show security flow session summary node 0
node0:
```

```

Flow Sessions on FPC0 PIC1:
Unicast-sessions: 1
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 1
 Valid sessions: 1
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC2:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC3:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```



**show security flow session summary node 1**

```
root@host> show security flow session summary node 1
node1:
```

```

Flow Sessions on FPC0 PIC1:
Unicast-sessions: 1
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 1
 Valid sessions: 1
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC2:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC3:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

**show security flow session summary node all**

```
root@host> show security flow session summary node all
node0:
```

```

Flow Sessions on FPC0 PIC1:
Unicast-sessions: 1
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 1
 Valid sessions: 1
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC2:
```

```
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC3:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
node1:
```

```

Flow Sessions on FPC0 PIC1:
Unicast-sessions: 1
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 1
 Valid sessions: 1
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC2:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC3:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

**show security flow session summary node local**

```
root@host> show security flow session summary node local
node0:
```

```

Flow Sessions on FPC0 PIC1:
Unicast-sessions: 1
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 1
 Valid sessions: 1
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC2:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC3:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

**show security flow session summary node primary**

```
root@host> show security flow session summary node primary
node0:
```

```

Flow Sessions on FPC0 PIC1:
Unicast-sessions: 1
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 1
 Valid sessions: 1
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC2:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

```
Flow Sessions on FPC0 PIC3:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 6291456
```

## show security flow session summary services-offload

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session summary services-offload</b> [ <i>filter</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Release Information</b>      | <p>Command introduced in Junos OS Release 11.4.</p> <p>Starting with Junos OS Release 15.1X49-D10, the SRX5K-MPC3-100G10G (IOC3) and the SRX5K-MPC3-40G10G (IOC3) with Express Path (formerly known as <i>services offloading</i>) support are introduced for SRX5400, SRX5600, and SRX5800 devices.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Description</b>              | Display information about all currently active services-offload security sessions on the device in summary mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <i>filter</i>—Filter the display by the specified criteria.</li> </ul> <p>The following filters reduce the display to those sessions that match the criteria specified by the filter:</p> <p><b>application</b>—Application name.</p> <p><b>application-firewall-rule-set</b>—Application firewall enabled with the specified rule set.</p> <p><b>application-traffic-control-rule-set</b>—Application traffic control enabled with the specified rule set.</p> <p><b>destination-port</b>—Destination port.</p> <p><b>destination-prefix</b>—Destination IP prefix or address.</p> <p><b>dynamic-application</b>—Dynamic application name.</p> <p><b>dynamic-application-group</b>—Dynamic application group name.</p> <p><b>family</b>—Protocol family.</p> <p><b>interface</b>—Name of incoming or outgoing interface.</p> <p><b>logical-system</b>—Logical system name.</p> <p><b>protocol</b>—IP protocol number.</p> <p><b>root-logical-system</b>—Root logical system name.</p> <p><b>source-port</b>—Source port.</p> <p><b>source-prefix</b>—Source IP prefix or address.</p> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> <li>• <a href="#">clear security flow session services-offload on page 245</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

**List of Sample Output** [show security flow session summary services-offload on page 472](#)  
[show security flow session summary services-offload application on page 473](#)  
[show security flow session summary services-offload destination-port on page 473](#)

**Output Fields** [Table 67 on page 472](#) lists the output fields for the **show security flow session summary services-offload** command. Output fields are listed in the approximate order in which they appear.

**Table 67: show security flow session summary services-offload Output Fields**

| Field Name                | Field Description                                                                                                                                          |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unicast-sessions          | Number of unicast sessions.                                                                                                                                |
| Multicast-sessions        | Number of multicast sessions.                                                                                                                              |
| Services-offload-sessions | Number of services-offload sessions.                                                                                                                       |
| Failed-sessions           | Number of failed sessions.                                                                                                                                 |
| Sessions-in-use           | Number of sessions in use: <ul style="list-style-type: none"> <li>Valid</li> <li>Pending</li> <li>Invalidated</li> <li>Sessions in other states</li> </ul> |
| Maximum-sessions          | Maximum number of sessions.                                                                                                                                |

## Sample Output

### show security flow session summary services-offload

```

user@host> show security flow session summary services-offload
Flow Sessions on FPC1 PIC0:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 409600

Flow Sessions on FPC2 PIC0:
Unicast-sessions: 1
Multicast-sessions: 0
Services-offload-sessions: 1
Failed-sessions: 0
Sessions-in-use: 1
 Valid sessions: 1
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0

```

```

Maximum-sessions: 819200

Flow Sessions on FPC3 PIC0:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 819200

Flow Sessions on FPC5 PIC0:
Unicast-sessions: 0
Multicast-sessions: 0
Services-offload-sessions: 0
Failed-sessions: 0
Sessions-in-use: 0
 Valid sessions: 0
 Pending sessions: 0
 Invalidated sessions: 0
 Sessions in other states: 0
Maximum-sessions: 819200

```

#### show security flow session summary services-offload application

```

user@host> show security flow session summary services-offload application telnet
Flow Sessions on FPC10 PIC1:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

Flow Sessions on FPC10 PIC2:

Valid sessions: 0
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 0

Flow Sessions on FPC10 PIC3:

Valid sessions: 1
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 1

```

#### show security flow session summary services-offload destination-port

```

user@host> show security flow session summary services-offload destination-port 23
Flow Sessions on FPC10 PIC1:
Total sessions: 0

Flow Sessions on FPC10 PIC2:

```

Total sessions: 0

Flow Sessions on FPC10 PIC3:

Session ID: 430000004, Policy name: p1/4, Timeout: 1500, Valid

In: 200.0.0.10/15200 --> 60.0.0.2/23;tcp, If: ge-7/1/0.0, Pkts: 13, Bytes: 718,  
CP Session ID: 430000003

Out: 60.0.0.2/23 --> 200.0.0.10/15200;tcp, If: ge-7/1/1.0, Pkts: 12, Bytes:  
677, CP Session ID: 430000003

Total sessions: 1



## show security flow session tunnel

|                                 |                                                                                                                                                                                                                                                                                         |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow session tunnel</b><br>[brief   extensive   summary]                                                                                                                                                                                                               |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; Filter and view options introduced in Junos OS Release 10.2.                                                                                                                                                                                |
| <b>Description</b>              | Display information about all tunnel sessions.                                                                                                                                                                                                                                          |
| <b>Options</b>                  | none—Display all tunnel sessions.<br><br>brief   extensive   summary—Display the specified level of output.                                                                                                                                                                             |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                    |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                              |
| <b>List of Sample Output</b>    | <a href="#">show security flow session tunnel on page 476</a><br><a href="#">show security flow session tunnel brief on page 477</a><br><a href="#">show security flow session tunnel extensive on page 477</a><br><a href="#">show security flow session tunnel summar on page 479</a> |
| <b>Output Fields</b>            | <a href="#">Table 68 on page 475</a> lists the output fields for the <b>show security flow session tunnel</b> command. Output fields are listed in the approximate order in which they appear.                                                                                          |

**Table 68: show security flow session tunnel Output Fields**

| Field Name             | Field Description                                                                                                                                                                       |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Session ID</b>      | Number that identifies the session. You can use this ID to get additional information about the session.                                                                                |
| <b>Policy name</b>     | Policy that permitted the traffic. NA (Not Applicable) for a tunnel session.                                                                                                            |
| <b>Timeout</b>         | Idle timeout after which the session expires. NA (Not Applicable) for a tunnel session.                                                                                                 |
| <b>In</b>              | Incoming flow (source and destination IP addresses, application protocol, interface, session token, route, gateway, tunnel, port sequence, FIN sequence, FIN state, packets and bytes). |
| <b>Total sessions</b>  | Total number of sessions.                                                                                                                                                               |
| <b>Status</b>          | Session status.                                                                                                                                                                         |
| <b>Flag</b>            | Internal flag depicting the state of the session, used for debugging purposes.                                                                                                          |
| <b>Policy name</b>     | Name and ID of the policy that the first packet of the session matched.                                                                                                                 |
| <b>Source NAT pool</b> | The name of the source pool where NAT is used.                                                                                                                                          |

Table 68: show security flow session tunnel Output Fields (*continued*)

| Field Name               | Field Description                                                     |
|--------------------------|-----------------------------------------------------------------------|
| Application              | Name of the application.                                              |
| Maximum timeout          | Maximum session timeout.                                              |
| Current timeout          | Remaining time for the session unless traffic exists in the session.  |
| Session State            | Session state.                                                        |
| Start time               | Time when the session was created, offset from the system start time. |
| Valid sessions           | Number of valid sessions.                                             |
| Pending sessions         | Number of pending sessions.                                           |
| Invalidated sessions     | Number of invalidated sessions.                                       |
| Sessions in other states | Number of sessions in other states.                                   |

## Sample Output

### show security flow session tunnel

```

root> show security flow session tunnel
Flow Sessions on FPC10 PIC1:

Session ID: 410000001, Policy name: N/A, Timeout: N/A, Valid
 In: 60.0.0.2/43405 --> 60.0.0.3/494;esp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
 ID: 420000000

Session ID: 410000002, Policy name: N/A, Timeout: N/A, Valid
 In: 60.0.0.2/0 --> 60.0.0.3/0;esp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
 ID: 420000000
Total sessions: 2

Flow Sessions on FPC10 PIC2:

Session ID: 420000003, Policy name: N/A, Timeout: N/A, Valid
 In: 60.0.0.2/0 --> 60.0.0.3/0;esp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
 ID: 420000000

Session ID: 420000004, Policy name: N/A, Timeout: N/A, Valid
 In: 60.0.0.2/0 --> 60.0.0.3/0;ah, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
 ID: 420000000
Total sessions: 2

Flow Sessions on FPC10 PIC3:

Session ID: 430000005, Policy name: N/A, Timeout: N/A, Valid
 In: 60.0.0.2/0 --> 60.0.0.3/0;esp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
 ID: 420000000

Session ID: 430000006, Policy name: N/A, Timeout: N/A, Valid

```

```
In: 60.0.0.2/0 --> 60.0.0.3/0;ah, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
ID: 420000000
Total sessions: 2
```

### show security flow session tunnel brief

```
root> show security flow session tunnel brief
```

```
Flow Sessions on FPC10 PIC1:
```

```
Session ID: 410000001, Policy name: N/A, Timeout: N/A, Valid
```

```
In: 60.0.0.2/43405 --> 60.0.0.3/494;esp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
ID: 420000000
```

```
Session ID: 410000002, Policy name: N/A, Timeout: N/A, Valid
```

```
In: 60.0.0.2/0 --> 60.0.0.3/0;esp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
ID: 420000000
```

```
Total sessions: 2
```

```
Flow Sessions on FPC10 PIC2:
```

```
Session ID: 420000003, Policy name: N/A, Timeout: N/A, Valid
```

```
In: 60.0.0.2/0 --> 60.0.0.3/0;esp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
ID: 420000000
```

```
Session ID: 420000004, Policy name: N/A, Timeout: N/A, Valid
```

```
In: 60.0.0.2/0 --> 60.0.0.3/0;ah, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
ID: 420000000
```

```
Total sessions: 2
```

```
Flow Sessions on FPC10 PIC3:
```

```
Session ID: 430000005, Policy name: N/A, Timeout: N/A, Valid
```

```
In: 60.0.0.2/0 --> 60.0.0.3/0;esp, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
ID: 420000000
```

```
Session ID: 430000006, Policy name: N/A, Timeout: N/A, Valid
```

```
In: 60.0.0.2/0 --> 60.0.0.3/0;ah, If: ge-7/1/1.0, Pkts: 0, Bytes: 0, CP Session
ID: 420000000
```

```
Total sessions: 2
```

### show security flow session tunnel extensive

```
root> show security flow session tunnel extensive
```

```
Flow Sessions on FPC10 PIC1:
```

```
Session ID: 410000001, Status: Normal
```

```
Flags: 0x10000/0x0/0x1
```

```
Policy name: N/A
```

```
Source NAT pool: Null
```

```
Dynamic application: junos:UNKNOWN,
```

```
Encryption: Unknown
```

```
Application traffic control rule-set: INVALID, Rule: INVALID
```

```
Maximum timeout: N/A, Current timeout: N/A
```

```
Session State: Valid
```

```
Start time: 3548, Duration: 797
```

```
In: 60.0.0.2/43405 --> 60.0.0.3/494;esp,
```

```
Interface: ge-7/1/1.0,
```

```
Session token: 0x7, Flag: 0x80100621
```

```
Route: 0x60010, Gateway: 60.0.0.2, Tunnel: 0
```

```
Port sequence: 0, FIN sequence: 0,
```

```
FIN state: 0,
```

Pkts: 0, Bytes: 0  
CP Session ID: 420000000

Session ID: 410000002, Status: Normal  
Flags: 0x10000/0x0/0x1  
Policy name: N/A  
Source NAT pool: Null  
Dynamic application: junos:UNKNOWN,  
Encryption: Unknown  
Application traffic control rule-set: INVALID, Rule: INVALID  
Maximum timeout: N/A, Current timeout: N/A  
Session State: Valid  
Start time: 3548, Duration: 797  
In: 60.0.0.2/0 --> 60.0.0.3/0;esp,  
Interface: ge-7/1/1.0,  
Session token: 0x7, Flag: 0x621  
Route: 0x60010, Gateway: 60.0.0.2, Tunnel: 0  
Port sequence: 0, FIN sequence: 0,  
FIN state: 0,  
Pkts: 0, Bytes: 0  
CP Session ID: 420000000  
Total sessions: 2

Flow Sessions on FPC10 PIC2:

Session ID: 420000003, Status: Normal  
Flags: 0x10000/0x0/0x1  
Policy name: N/A  
Source NAT pool: Null  
Dynamic application: junos:UNKNOWN,  
Encryption: Unknown  
Application traffic control rule-set: INVALID, Rule: INVALID  
Maximum timeout: N/A, Current timeout: N/A  
Session State: Valid  
Start time: 3513, Duration: 798  
In: 60.0.0.2/0 --> 60.0.0.3/0;esp,  
Interface: ge-7/1/1.0,  
Session token: 0x7, Flag: 0x621  
Route: 0x0, Gateway: 60.0.0.2, Tunnel: 0  
Port sequence: 0, FIN sequence: 0,  
FIN state: 0,  
Pkts: 0, Bytes: 0  
CP Session ID: 420000000

Session ID: 420000004, Status: Normal  
Flags: 0x10000/0x0/0x1  
Policy name: N/A  
Source NAT pool: Null  
Dynamic application: junos:UNKNOWN,  
Encryption: Unknown  
Application traffic control rule-set: INVALID, Rule: INVALID  
Maximum timeout: N/A, Current timeout: N/A  
Session State: Valid  
Start time: 3513, Duration: 798  
In: 60.0.0.2/0 --> 60.0.0.3/0;ah,  
Interface: ge-7/1/1.0,  
Session token: 0x7, Flag: 0x621  
Route: 0x0, Gateway: 60.0.0.2, Tunnel: 0  
Port sequence: 0, FIN sequence: 0,  
FIN state: 0,  
Pkts: 0, Bytes: 0

```

CP Session ID: 420000000
Total sessions: 2

Flow Sessions on FPC10 PIC3:

Session ID: 430000005, Status: Normal
Flags: 0x10000/0x0/0x1
Policy name: N/A
Source NAT pool: Null
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: N/A, Current timeout: N/A
Session State: Valid
Start time: 3513, Duration: 799
 In: 60.0.0.2/0 --> 60.0.0.3/0;esp,
 Interface: ge-7/1/1.0,
 Session token: 0x7, Flag: 0x621
 Route: 0x0, Gateway: 60.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 0, Bytes: 0
 CP Session ID: 420000000

Session ID: 430000006, Status: Normal
Flags: 0x10000/0x0/0x1
Policy name: N/A
Source NAT pool: Null
Dynamic application: junos:UNKNOWN,
Encryption: Unknown
Application traffic control rule-set: INVALID, Rule: INVALID
Maximum timeout: N/A, Current timeout: N/A
Session State: Valid
Start time: 3513, Duration: 799
 In: 60.0.0.2/0 --> 60.0.0.3/0;ah,
 Interface: ge-7/1/1.0,
 Session token: 0x7, Flag: 0x621
 Route: 0x0, Gateway: 60.0.0.2, Tunnel: 0
 Port sequence: 0, FIN sequence: 0,
 FIN state: 0,
 Pkts: 0, Bytes: 0
 CP Session ID: 420000000
Total sessions: 2

```

#### show security flow session tunnel summar

```

root> show security flow session tunnel summary
Flow Sessions on FPC10 PIC1:

Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0
Total sessions: 2

Flow Sessions on FPC10 PIC2:

Valid sessions: 2
Pending sessions: 0
Invalidated sessions: 0
Sessions in other states: 0

```

Total sessions: 2

Flow Sessions on FPC10 PIC3:

Valid sessions: 2

Pending sessions: 0

Invalidated sessions: 0

Sessions in other states: 0

Total sessions: 2

## show security flow statistics

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow statistics</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Release Information</b>      | <p>Command introduced in Junos OS Release 10.2.</p> <p>Starting with Junos OS Release 15.1X49-D10, SRX5K-MPC3-100G10G (IOC3) and SRX5K-MPC3-40G10G (IOC3) are introduced for SRX5400, SRX5600, and SRX5800 devices that perform hash-based datapath packet forwarding to interconnect with all existing IOC and SPC cards using the XL chip (packet-processing chip). The IOC3 XL chip uses a hash-based method to distribute ingress traffic to a pool of SPUs by default. Selection of hash keys depends on application protocols.</p> |
| <b>Description</b>              | Display flow-related system statistics.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>List of Sample Output</b>    | <p><a href="#">show security flow statistics on page 481</a></p> <p><a href="#">show security flow statistics (for hash-based datapath forwarding using SRX5K-MPC3-40G10G (IOC3) and SRX5K-MPC3-100G10G (IOC3) on page 482</a></p>                                                                                                                                                                                                                                                                                                       |
| <b>Output Fields</b>            | <p><a href="#">Table 69 on page 481</a> lists the output fields for the <b>show security flow statistics</b> command. Output fields are listed in the approximate order in which they appear.</p>                                                                                                                                                                                                                                                                                                                                        |

**Table 69: show security flow statistics Output Fields**

| Field Name        | Field Description            |
|-------------------|------------------------------|
| Current sessions  | Number of current sessions.  |
| Packets forwarded | Number of packets forwarded. |
| Packets dropped   | Number of Packets dropped.   |
| Fragment packets  | Number of fragment packets.  |

## Sample Output

### show security flow statistics

```

root> show security flow statistics
Flow Statistics of FPC4 PIC1:
 Current sessions: 63
 Packets forwarded: 3001
 Packets dropped: 1281
 Fragment packets: 0

Flow Statistics of FPC5 PIC0:
 Current sessions: 22
 Packets forwarded: 859

```

```
Packets dropped: 0
Fragment packets: 0
```

Flow Statistics of FPC5 PIC1:

```
Current sessions: 22
Packets forwarded: 858
Packets dropped: 0
Fragment packets: 0
```

Flow Statistics Summary:

```
System total valid sessions: 107
Packets forwarded: 4718
Packets dropped: 1281
Fragment packets: 0
```

**show security flow statistics (for hash-based datapath forwarding using SRX5K-MPC3-40G10G (IOC3) and SRX5K-MPC3-100G10G (IOC3))**

```
root> show security flow statistics
```

Flow Statistics of FPC0 PIC1:

```
Current sessions: 0
Packets forwarded: 0
Packets dropped: 0
Fragment packets: 0
```

Flow Statistics of FPC0 PIC2:

```
Current sessions: 0
Packets forwarded: 0
Packets dropped: 0
Fragment packets: 0
```

Flow Statistics of FPC0 PIC3:

```
Current sessions: 0
Packets forwarded: 0
Packets dropped: 0
Fragment packets: 0
```

Flow Statistics Summary:

```
System total valid sessions: 0
Packets forwarded: 0
Packets dropped: 0
Fragment packets: 0
```



## show security flow status

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security flow status</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Release Information</b>      | <p>Command introduced in Junos OS Release 10.2 ; session distribution mode option added in Junos OS Release 12.1X44-D10; enhanced route scaling mode option added in Junos OS Release 12.1X45-D10.</p> <p>Starting with Junos OS Release 15.1X49-D10, SRX5K-MPC3-100G10G (IOC3) and SRX5K-MPC3-40G10G (IOC3) are introduced for SRX5400, SRX5600, and SRX5800 devices that perform hash-based data path packet forwarding to interconnect with all existing IOC and SPC cards using the XL chip (packet-processing chip).</p> <p>The IOC3 XL chip uses a hash-based method to distribute ingress traffic to a pool of SPUs by default. Selection of hash keys depends on application protocols.</p> |
| <b>Description</b>              | Display the flow processing modes and logging status.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>List of Sample Output</b>    | <p><a href="#">show security flow status on page 484</a></p> <p><a href="#">show security flow status (IPsec Performance Acceleration) on page 484</a></p> <p><a href="#">show security flow status (for hash-based datapath forwarding using SRX5K-MPC3-40G10G (IOC3) and SRX5K-MPC3-100G10G (IOC3) on page 484</a></p>                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Output Fields</b>            | <p><a href="#">Table 70 on page 483</a> lists the output fields for the <b>show security flow status</b> command. Output fields are listed in the approximate order in which they appear.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

**Table 70: show security flow status Output Fields**

| Field Name                | Field Description                                                                                                                                                                                                                                                                 |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flow forwarding mode      | <p>Flow processing mode.</p> <ul style="list-style-type: none"> <li>• Inet forwarding mode</li> <li>• Inet6 forwarding mode</li> <li>• MPLS forwarding mode</li> <li>• ISO forwarding mode</li> <li>• Session distribution mode</li> <li>• Enhanced route scaling mode</li> </ul> |
| Flow trace status         | <p>Flow logging status.</p> <ul style="list-style-type: none"> <li>• Flow tracing status</li> <li>• Flow tracing options</li> </ul>                                                                                                                                               |
| flow session distribution | <p>SPU load distribution mode.</p> <ul style="list-style-type: none"> <li>• RR-based</li> <li>• Hash-based</li> </ul>                                                                                                                                                             |

Table 70: show security flow status Output Fields (*continued*)

| Field Name                          | Field Description                                                                                      |
|-------------------------------------|--------------------------------------------------------------------------------------------------------|
| Flow packet ordering                | packet-ordering mode. <ul style="list-style-type: none"> <li>• Hardware</li> <li>• Software</li> </ul> |
| Flow ipsec performance acceleration | IPsec VPN performance acceleration status.                                                             |

## Sample Output

### show security flow status

```

root> show security flow status
 Flow forwarding mode:
Inet forwarding mode: flow based
Inet6 forwarding mode: flow based
MPLS forwarding mode: drop
ISO forwarding mode: drop
+Enhanced route scaling mode: Enabled (reboot needed to disable)
Flow trace status
Flow tracing status: on
Flow tracing options: all
Flow session distribution
Distribution mode: Hash-based
Flow packet ordering
Ordering mode: Software (reboot needed to change to software)

```

### show security flow status (IPsec Performance Acceleration)

```

root> show security flow status
Flow forwarding mode:
 Inet forwarding mode: flow based
 Inet6 forwarding mode: drop
 MPLS forwarding mode: drop
 ISO forwarding mode: drop
Flow trace status
 Flow tracing status: off
Flow session distribution
 Distribution mode: RR-based
Flow packet ordering
Ordering mode: Software (reboot needed to change to software)
Flow ipsec performance acceleration: on

```

### show security flow status (for hash-based datapath forwarding using SRX5K-MPC3-40G10G (IOC3) and SRX5K-MPC3-100G10G (IOC3))

```

root> show security flow status
node0:

Flow forwarding mode:
 Inet forwarding mode: flow based
 Inet6 forwarding mode: drop
 MPLS forwarding mode: drop
 ISO forwarding mode: drop
Flow trace status
 Flow tracing status: off

```

```
Flow session distribution
 Distribution mode: Hash-based
Flow ipsec performance acceleration: off
Flow packet ordering
 Ordering mode: Hardware
```

```
node1:
```

```

Flow forwarding mode:
 Inet forwarding mode: flow based
 Inet6 forwarding mode: drop
 MPLS forwarding mode: drop
 ISO forwarding mode: drop
Flow trace status
 Flow tracing status: off
Flow session distribution
 Distribution mode: Hash-based
Flow ipsec performance acceleration: off
Flow packet ordering
 Ordering mode: Hardware
```

## show security forward-options mirror-filter

|                                 |                                                                                                                                                                                                                 |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security forward-options mirror-filter (all   <i>filter-name</i> )                                                                                                                                         |
| <b>Release Information</b>      | Command introduced in Junos OS Release 12.1X46-D10.                                                                                                                                                             |
| <b>Description</b>              | Display information about the status of the mirror filters.                                                                                                                                                     |
| <b>Options</b>                  | <p><b>all</b>—Display counters for all mirror filters.</p> <p><b><i>filter-name</i></b>—Name of the mirror filter for which the counter is displayed.</p>                                                       |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                            |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">mirror-filter (Security Forwarding Options) on page 197</a></li> <li>• <a href="#">clear security forward-options mirror filter on page 253</a></li> </ul> |
| <b>List of Sample Output</b>    | <a href="#">show security forward-options mirror-filter on page 486</a>                                                                                                                                         |
| <b>Output Fields</b>            | Lists the output fields for the <b>show security forward-options mirror-filter</b> command. Output fields are listed in the approximate order in which they appear in the output.                               |

Table 71: show security forward-options mirror-filter

| Field Name                | Field Description                                                               |
|---------------------------|---------------------------------------------------------------------------------|
| <b>mirror-filter-name</b> | Name of the mirror filter configured on the device.                             |
| <b>interface-in</b>       | Display the name of the incoming logical interface to be matched for mirroring. |
| <b>interface-out</b>      | Display the outgoing logical interface to be matched for mirroring.             |
| <b>protocol</b>           | Display the networking protocol name or number to be matched for mirroring.     |
| <b>source-prefix</b>      | Display the source IP prefix or address to be matched for mirroring.            |
| <b>destination-prefix</b> | Display the destination IP prefix or address to be matched for mirroring.       |
| <b>filter-counters</b>    | Display the number of packets matched for mirroring.                            |
| <b>output-counter</b>     | Display the number of packets sent to the sniffing device.                      |

## Sample Output

### show security forward-options mirror-filter

```
user@host> show security forward-options mirror-filter m10
node0:
```

---

Security mirror status

mirror-filter-name: m10  
interface-in: reth0.0  
interface-out: reth1.0  
protocol: 132  
source-prefix: 11.1.1.0  
destination-prefix: 41.1.1.0  
filter-counters: 143  
output-counters: 143

node1:

---

Security mirror status

mirror-filter-name: m10  
interface-in: reth0.0  
interface-out: reth1.0  
protocol: 132  
source-prefix: 11.1.1.0  
destination-prefix: 41.1.1.0  
filter-counters: 0  
output-counters: 0

## show security monitoring

**Syntax** show security monitoring

**Release Information** Command introduced in Junos OS Release 10.2.

**Description** Displays a count of security flow and central point (CP) sessions, CPU utilization (as a percentage of maximum), and memory in use (also as a percentage of maximum) at the moment the command is run.

**Required Privilege Level** View

**Related Documentation**

- *show security monitoring fpc fpc-number*
- *show security monitoring performance session*
- *show security monitoring performance spu*

## show security monitoring

```
user@host>show security monitoring
```

```
user@host> show security monitoring
```

| FPC   | PIC       | CPU | Mem | Flow session<br>current | Flow session<br>maximum | CP session<br>current | CP session<br>maximum |
|-------|-----------|-----|-----|-------------------------|-------------------------|-----------------------|-----------------------|
| 1     | 0         | 0   | 11  | 0                       | 0                       | 0                     | 0                     |
| 1     | 1         | 0   | 5   | 3                       | 6291456                 | 1                     | 7549747               |
| 1     | 2         | 0   | 5   | 2                       | 6291456                 | 0                     | 7549747               |
| 1     | 3         | 0   | 5   | 3                       | 6291456                 | 1                     | 7549747               |
| 8     | 0         | 0   | 65  | 4                       | 6963                    | 2                     | 8355                  |
| 8     | 1         | 0   | 65  | 2                       | 6963                    | 0                     | 8355                  |
| Total | Sessions: |     |     | 14                      | 18888294                | 4                     | 22665951              |

## show security monitoring (vSRX)

```
user@host>show security monitoring
```

```
user@host> show security monitoring
```

| FPC | PIC | CPU | Mem | Flow session<br>current | Flow session<br>maximum | CP session<br>current | CP session<br>maximum |
|-----|-----|-----|-----|-------------------------|-------------------------|-----------------------|-----------------------|
| 0   | 0   | 0   | 68  | 2                       | 524288                  | N/A                   | N/A                   |

## show security monitoring (vSRX in a Chassis Cluster)

```
user@host>show security monitoring
```

```
node0:
```

| FPC | PIC | CPU | Mem | Flow session<br>current | Flow session<br>maximum | CP session<br>current | CP session<br>maximum |
|-----|-----|-----|-----|-------------------------|-------------------------|-----------------------|-----------------------|
|-----|-----|-----|-----|-------------------------|-------------------------|-----------------------|-----------------------|

```

0 0 0 67 0 524288 N/A N/A
```

node1:

```

FPC PIC CPU Mem Flow session Flow session CP session CP session
current maximum current maximum

0 0 0 67 0 524288 N/A N/A
```

## show security policies

---

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show security policies</code><br><code>&lt;detail&gt;</code><br><code>&lt;none&gt;</code><br><code>policy-name <i>policy-name</i></code><br><code>&lt;detail&gt;</code><br><code>&lt;global&gt;</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Release Information</b>      | Command modified in Junos OS Release 9.2. Support for IPv6 addresses added in Junos OS Release 10.2. Support for IPv6 addresses in active/active chassis cluster configurations in addition to the existing support of active/passive chassis cluster configurations added in Junos OS Release 10.4. Support for wildcard addresses added in Junos OS Release 11.1. Support for global policy added in Junos OS Release 11.4. Support for services offloading added in Junos OS Release 11.4. Support for source-identities added in Junos OS Release 12.1. The <b>Description</b> output field added in Junos OS Release 12.1. Support for negated address added in Junos OS Release 12.1X45-D10. The output fields for Policy Statistics expanded, and the output fields for the <b>global</b> and <b>policy-name</b> options expanded to include from-zone and to-zone global match criteria in Junos OS Release 12.1X47-D10. Support for the <b>initial-tcp-mss</b> and <b>reverse-tcp-mss</b> options added in Junos OS Release 12.3X48-D20. |
| <b>Description</b>              | Display a summary of all security policies configured on the device. If a particular policy is specified, display information particular to that policy.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Options</b>                  | <ul style="list-style-type: none"><li>• <b>none</b>—Display basic information about all configured policies.</li><li>• <b>detail</b>—(Optional) Display a detailed view of all of the policies configured on the device.</li><li>• <b>policy-name <i>policy-name</i></b>—(Optional) Display information about the specified policy.</li><li>• <b>global</b>—Display information about global policies.</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"><li>• <i>Security Policies Overview</i></li><li>• <i>Understanding Security Policy Rules</i></li><li>• <i>Understanding Security Policy Elements</i></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>List of Sample Output</b>    | <a href="#">show security policies on page 493</a><br><a href="#">show security policies policy-name p1 detail on page 494</a><br><a href="#">show security policies (services-offload) on page 495</a><br><a href="#">show security policies detail on page 495</a><br><a href="#">show security policies detail (TCP Options) on page 496</a><br><a href="#">show security policies policy-name p1 (Negated Address) on page 496</a><br><a href="#">show security policies policy-name p1 detail (Negated Address) on page 497</a><br><a href="#">show security policies global on page 497</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                 |



**Output Fields** Table 72 on page 491 lists the output fields for the **show security policies** command. Output fields are listed in the approximate order in which they appear.

**Table 72: show security policies Output Fields**

| Field Name                       | Field Description                                                                                                                                                                                                                                                                                                                                                          |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| From zone                        | Name of the source zone.                                                                                                                                                                                                                                                                                                                                                   |
| To zone                          | Name of the destination zone.                                                                                                                                                                                                                                                                                                                                              |
| Policy                           | Name of the applicable policy.                                                                                                                                                                                                                                                                                                                                             |
| Description                      | Description of the applicable policy.                                                                                                                                                                                                                                                                                                                                      |
| State                            | Status of the policy: <ul style="list-style-type: none"> <li>• <b>enabled:</b> The policy can be used in the policy lookup process, which determines access rights for a packet and the action taken in regard to it.</li> <li>• <b>disabled:</b> The policy cannot be used in the policy lookup process, and therefore it is not available for access control.</li> </ul> |
| Index                            | Internal number associated with the policy.                                                                                                                                                                                                                                                                                                                                |
| Sequence number                  | Number of the policy within a given context. For example, three policies that are applicable in a from-zoneA-to-zoneB context might be ordered with sequence numbers 1, 2, 3. Also, in a from-zoneC-to-zoneD context, four policies might have sequence numbers 1, 2, 3, 4.                                                                                                |
| Source addresses                 | For standard display mode, the names of the source addresses for a policy. Address sets are resolved to their individual names.<br><br>For detail display mode, the names and corresponding IP addresses of the source addresses for a policy. Address sets are resolved to their individual address name-IP address pairs.                                                |
| Destination addresses            | Name of the destination address (or address set) as it was entered in the destination zone's address book. A packet's destination address must match this value for the policy to apply to it.                                                                                                                                                                             |
| Source addresses (excluded)      | Name of the source address excluded from the policy.                                                                                                                                                                                                                                                                                                                       |
| Destination addresses (excluded) | Name of the destination address excluded from the policy.                                                                                                                                                                                                                                                                                                                  |
| Source identities                | One or more user roles specified for a policy.                                                                                                                                                                                                                                                                                                                             |

Table 72: show security policies Output Fields (*continued*)

| Field Name                      | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Applications                    | <p>Name of a preconfigured or custom application whose type the packet matches, as specified at configuration time.</p> <ul style="list-style-type: none"> <li>• <b>IP protocol</b>: The Internet protocol used by the application—for example, TCP, UDP, ICMP.</li> <li>• <b>ALG</b>: If an ALG is explicitly associated with the policy, the name of the ALG is displayed. If <b>application-protocol ignore</b> is configured, ignore is displayed. Otherwise, 0 is displayed. However, even if this command shows ALG: 0, ALGs might be triggered for packets destined to well-known ports on which ALGs are listening, unless ALGs are explicitly disabled or when <b>application-protocol ignore</b> is not configured for custom applications.</li> <li>• <b>Inactivity timeout</b>: Elapsed time without activity after which the application is terminated.</li> <li>• <b>Source port range</b>: The low-high source port range for the session application.</li> </ul> |
| Destination Address Translation | <p>Status of the destination address translation traffic:</p> <ul style="list-style-type: none"> <li>• <b>drop translated</b>—Drop the packets with translated destination addresses.</li> <li>• <b>drop untranslated</b>—Drop the packets without translated destination addresses.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Application Firewall            | <p>An application firewall includes the following:</p> <ul style="list-style-type: none"> <li>• <b>Rule-set</b>—Name of the rule set.</li> <li>• <b>Rule</b>—Name of the rule. <ul style="list-style-type: none"> <li>• <b>Dynamic applications</b>—Name of the applications.</li> <li>• <b>Dynamic application groups</b>—Name of the application groups.</li> <li>• <b>Action</b>—The action taken with respect to a packet that matches the application firewall rule set. Actions include the following: <ul style="list-style-type: none"> <li>• <b>permit</b></li> <li>• <b>deny</b></li> </ul> </li> </ul> </li> <li>• <b>Default rule</b>—The default rule applied when the identified application is not specified in any rules of the rule set.</li> </ul>                                                                                                                                                                                                             |
| Action or Action-type           | <ul style="list-style-type: none"> <li>• The action taken in regard to a packet that matches the policy's tuples. Actions include the following: <ul style="list-style-type: none"> <li>• <b>permit</b></li> <li>• <b>firewall-authentication</b></li> <li>• <b>tunnel ipsec-vpn <i>vpn-name</i></b></li> <li>• <b>pair-policy <i>pair-policy-name</i></b></li> <li>• <b>source-nat pool <i>pool-name</i></b></li> <li>• <b>pool-set <i>pool-set-name</i></b></li> <li>• <b>interface</b></li> <li>• <b>destination-nat <i>name</i></b></li> <li>• <b>deny</b></li> <li>• <b>reject</b></li> <li>• <b>services-offload</b></li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                |
| Session log                     | <p>Session log entry that indicates whether the <b>at-create</b> and <b>at-close</b> flags were set at configuration time to log session information.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

Table 72: show security policies Output Fields (*continued*)

| Field Name                    | Field Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Scheduler name</b>         | Name of a preconfigured scheduler whose schedule determines when the policy is active and can be used as a possible match for traffic.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Policy statistics</b>      | <ul style="list-style-type: none"> <li>• <b>Input bytes</b>—The total number of bytes presented for processing by the device. <ul style="list-style-type: none"> <li>• <b>Initial direction</b>—The number of bytes presented for processing by the device from the initial direction.</li> <li>• <b>Reply direction</b>—The number of bytes presented for processing by the device from the reply direction.</li> </ul> </li> <li>• <b>Output bytes</b>—The total number of bytes actually processed by the device. <ul style="list-style-type: none"> <li>• <b>Initial direction</b>—The number of bytes from the initial direction actually processed by the device.</li> <li>• <b>Reply direction</b>—The number of bytes from the reply direction actually processed by the device.</li> </ul> </li> <li>• <b>Input packets</b>—The total number of packets presented for processing by the device. <ul style="list-style-type: none"> <li>• <b>Initial direction</b>—The number of packets presented for processing by the device from the initial direction.</li> <li>• <b>Reply direction</b>—The number of packets presented for processing by the device from the reply direction.</li> </ul> </li> <li>• <b>Output packets</b>—The total number of packets actually processed by the device. <ul style="list-style-type: none"> <li>• <b>Initial direction</b>—The number of packets actually processed by the device from the initial direction.</li> <li>• <b>Reply direction</b>—The number of packets actually processed by the device from the reply direction.</li> </ul> </li> <li>• <b>Session rate</b>—The total number of active and deleted sessions.</li> <li>• <b>Active sessions</b>—The number of sessions currently present because of access control lookups that used this policy.</li> <li>• <b>Session deletions</b>—The number of sessions deleted since system startup.</li> <li>• <b>Policy lookups</b>—The number of times the policy was accessed to check for a match.</li> </ul> <p><b>NOTE:</b> Configure the Policy P1 with the <b>count</b> option to display policy statistics.</p> |
| <b>Per policy TCP Options</b> | Configured sync and sequence checks, and the configured TCP MSS value for the initial direction and /or the reverse direction.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

## Sample Output

### show security policies

```

user@host> show security policies
From zone: trust, To zone: untrust
Policy: p1, State: enabled, Index: 4, Sequence number: 1
Source addresses:
sa-1-ipv4: 2.2.2.0/24
sa-2-ipv6: 2001:0db8::/32
sa-3-ipv6: 2001:0db6/24
sa-4-wc: 192.168.0.11/255.255.0.255
Destination addresses:
da-1-ipv4: 2.2.2.0/24
da-2-ipv6: 2400:0af8::/32

```

```

da-3-ipv6: 2400:0d78:0/24
da-4-wc: 192.168.22.11/255.255.0.255
Source identities: role1, role2, role4
Applications: any
Action: permit, application services, log, scheduled
Application firewall : my_ruleset1
Policy: p2, State: enabled, Index: 5, Sequence number: 2
Source addresses:
sa-1-ipv4: 2.2.2.0/24
sa-2-ipv6: 2001:0db8::/32
sa-3-ipv6: 2001:0db6/24
Destination addresses:
da-1-ipv4: 2.2.2.0/24
da-2-ipv6: 2400:0af8::/32
da-3-ipv6: 2400:0d78:0/24
Source identities: role1, role4
Applications: any
Action: deny, scheduled

```

#### show security policies policy-name p1 detail

```

user@host> show security policies policy-name p1 detail
Policy: p1, action-type: permit, State: enabled, Index: 4
Description: The policy p1 is for the sales team
Sequence number: 1
From zone: trust, To zone: untrust
Source addresses:
sa-1-ipv4: 2.2.2.0/24
sa-2-ipv6: 2001:0db8::/32
sa-3-ipv6: 2001:0db6/24
sa-4-wc: 192.168.0.11/255.255.0.255
Destination addresses:
da-1-ipv4: 2.2.2.0/24
da-2-ipv6: 2400:0af8::/32
da-3-ipv6: 2400:0d78:0/24
da-4-wc: 192.168.22.11/255.255.0.255
Source identities:
role1
role2
role4
Application: any
IP protocol: 0, ALG: 0, Inactivity timeout: 0
Source port range: [0-0]
Destination port range: [0-0]
Destination Address Translation: drop translated
Application firewall :
Rule-set: my_ruleset1
Rule: rule1
Dynamic Applications: junos:FACEBOOK, junos:YMSG
Dynamic Application groups: junos:web, junos:chat
Action: deny
Default rule: permit
Session log: at-create, at-close
Scheduler name: sch20
Per policy TCP Options: SYN check: No, SEQ check: No
Policy statistics:
Input bytes : 18144 545 bps
Initial direction: 9072 272 bps
Reply direction : 9072 272 bps
Output bytes : 18144 545 bps
Initial direction: 9072 272 bps

```

|                     |      |         |
|---------------------|------|---------|
| Reply direction :   | 9072 | 272 bps |
| Input packets :     | 216  | 6 pps   |
| Initial direction:  | 108  | 3 bps   |
| Reply direction :   | 108  | 3 bps   |
| Output packets :    | 216  | 6 pps   |
| Initial direction:  | 108  | 3 bps   |
| Reply direction :   | 108  | 3 bps   |
| Session rate :      | 108  | 3 sps   |
| Active sessions :   | 93   |         |
| Session deletions : | 15   |         |
| Policy lookups :    | 108  |         |

### show security policies (services-offload)

```

user@host> show security policies
Default policy: deny-all
From zone: trust, To zone: untrust
 Policy: p1, State: enabled, Index: 4, Scope Policy: 0, Sequence number: 1
 Source addresses: any
 Destination addresses: any
 Source identities: role1, role2, role4
 Applications: any
 Action: permit, services-offload, count
From zone: untrust, To zone: trust
 Policy: p2, State: enabled, Index: 5, Scope Policy: 0, Sequence number: 1
 Source addresses: any
 Destination addresses: any
 Source identities: role1, role2, role4
 Applications: any
 Action: permit, services-offload

```

### show security policies detail

```

user@host> show security policies detail
Default policy: deny-all
Policy: p1, action-type: permit, services-offload:enabled , State: enabled, Index:
4, Scope Policy: 0
Policy Type: Configured
Description: The policy p1 is for the sales team
Sequence number: 1
From zone: trust, To zone: untrust
Source addresses:
 any-ipv4(global): 0.0.0.0/0
 any-ipv6(global): ::/0
Destination addresses:
 any-ipv4(global): 0.0.0.0/0
 any-ipv6(global): ::/0
Source identities:
 role1
 role2
 role4
Application: any
 IP protocol: 0, ALG: 0, Inactivity timeout: 0
 Source port range: [0-0]
 Destination port range: [0-0]
Per policy TCP Options: SYN check: No, SEQ check: No
Policy statistics:
 Input bytes : 18144 545 bps
 Initial direction: 9072 272 bps
 Reply direction : 9072 272 bps
 Output bytes : 18144 545 bps

```

```

Initial direction: 9072 272 bps
Reply direction : 9072 272 bps
Input packets : 216 6 pps
Initial direction: 108 3 bps
Reply direction : 108 3 bps
Output packets : 216 6 pps
Initial direction: 108 3 bps
Reply direction : 108 3 bps
Session rate : 108 3 sps
Active sessions : 93
Session deletions : 15
Policy lookups : 108

Policy: p2, action-type: permit, services-offload:enabled , State: enabled, Index:
5, Scope Policy: 0
Policy Type: Configured
Description: The policy p2 is for the sales team
Sequence number: 1
From zone: untrust, To zone: trust
Source addresses:
 any-ipv4(global): 0.0.0.0/0
 any-ipv6(global): ::/0
Destination addresses:
 any-ipv4(global): 0.0.0.0/0
 any-ipv6(global): ::/0
Source identities:
 role1
 role2
 role4
Application: any
 IP protocol: 0, ALG: 0, Inactivity timeout: 0
 Source port range: [0-0]
 Destination port range: [0-0]
Per policy TCP Options: SYN check: No, SEQ check: No

```

#### show security policies detail (TCP Options)

```

user@host> show security policies policy-name policy1 detail
node0:

Policy: policy1, action-type: permit, State: enabled, Index: 7, Scope Policy: 0
Policy Type: Configured
Sequence number: 2
From zone: trust, To zone: untrust
Source addresses:
 any-ipv4(global): 0.0.0.0/0
 any-ipv6(global): ::/0
Destination addresses:
 any-ipv4(global): 0.0.0.0/0
 any-ipv6(global): ::/0
Application: any
 IP protocol: 0, ALG: 0, Inactivity timeout: 0
 Source port range: [0-0]
 Destination port range: [0-0]
Per policy TCP Options: SYN check: No, SEQ check: No
Per policy TCP MSS: initial: 800, reverse: 900

```

#### show security policies policy-name p1 (Negated Address)

```

user@host> show security policies policy-name p1
node0:

```

```

From zone: trust, To zone: untrust
Policy: p1, State: enabled, Index: 4, Scope Policy: 0, Sequence number: 1
Source addresses(excluded): as1
Destination addresses(excluded): as2
Applications: any
Action: permit

```

#### show security policies policy-name p1 detail (Negated Address)

```

user@host>show security policies policy-name p1 detail
node0:

Policy: p1, action-type: permit, State: enabled, Index: 4, Scope Policy: 0
Policy Type: Configured
Sequence number: 1
From zone: trust, To zone: untrust
Source addresses(excluded):
 ad1(ad): 255.255.255.255/32
 ad2(ad): 1.1.1.1/32
 ad3(ad): 15.100.199.56 ~ 15.200.100.16
 ad4(ad): 15.100.196.0/22
 ad5(ad): 15.1.7.199 ~ 15.1.8.19
 ad6(ad): 15.1.8.0/21
 ad7(ad): 15.1.7.0/24
Destination addresses(excluded):
 ad13(ad2): 20.1.7.0/24
 ad12(ad2): 20.1.4.1/32
 ad11(ad2): 20.1.7.199 ~ 20.1.8.19
 ad10(ad2): 50.1.4.0/22
 ad9(ad2): 20.1.1.11 ~ 50.1.5.199
 ad8(ad2): 2.1.1.1/32
Application: any
IP protocol: 0, ALG: 0, Inactivity timeout: 0
Source port range: [0-0]
Destination port range: [0-0]
Per policy TCP Options: SYN check: No, SEQ check: No

```

#### show security policies global

```

user@host>show security policies global policy-name Pa
node0:

Global policies:
Policy: Pa, State: enabled, Index: 5, Scope Policy: 0, Sequence number: 1
From zones: zone1, zone2
To zones: zone3, zone4
Source addresses: any
Destination addresses: any
Applications: any
Action: permit

```

## show security policies hit-count

---

**Syntax**    show security policies hit-count  
              <ascending | descending>  
              <from-zone *zone-name*>  
              <greater-than *count*>  
              <less-than *count*>  
              <to-zone *zone-name*>

**Release Information**    Command introduced in Junos OS Release 12.1.

**Description**    Display the utility rate of security policies according to the number of hits they receive. The number of hits can be listed without an order or sorted in either ascending or descending order, and they can be restricted to the number of hits that fall above or below a specific count or within a range. Data is shown for all zones associated with the policies or named zones.

Use this command without options to display the number of hits in random order for all security policies and for all zones.

- Options**
- **ascending | descending**—(Optional) Display the number of hits for security policies in ascending or descending order.
  - **from-zone *zone-name***—(Optional) Display the number of hits for security policies associated with the named source zone.
  - **greater-than *count***—(Optional) Display security policies for which the number of hits is greater than the specified number.  
**Range:** 0 through 4,294,967,295
  - **less-than *count***—(Optional) Display security policies for which the number of hits is less than the specified number.  
**Range:** 0 through 4,294,967,295
  - **to-zone *zone-name***—(Optional) Display the number of hits for security policies associated with the named destination zone.

**Required Privilege Level**    view

**Related Documentation**

- *clear security policies hit-count*
- *Security Policies Overview*

**List of Sample Output**    [show security policies hit-count on page 499](#)  
                                  [show security policies hit-count ascending on page 499](#)  
                                  [show security policies hit-count descending greater-than 70 less-than 100 on page 499](#)  
                                  [show security policies hit-count from-zone untrust to-zone trust on page 499](#)

**Output Fields**    [Table 73 on page 499](#) lists the output fields for the **show security policies hit-count** command. Output fields are listed in the approximate order in which they appear.



Table 73: show security policies hit-count Output Fields

| Field Name       | Field Description                                               |
|------------------|-----------------------------------------------------------------|
| from-zone        | Name of the source zone.                                        |
| to-zone          | Name of the destination zone.                                   |
| policy           | Name of the security policy.                                    |
| hit-count        | Number of hits for each security policy.                        |
| Number of policy | Number of security policies for which hit counts are displayed. |

### Sample Output

#### show security policies hit-count

```

user@host> show security policies hit-count
from-zone to-zone policy hit-count
untrust vrtrust u2t1 40
untrust trust u2t2 20
untrust trust u2t3 80

Number of policy: 3

```

### Sample Output

#### show security policies hit-count ascending

```

user@host> show security policies hit-count ascending
from-zone to-zone policy hit-count
untrust trust u2t2 20
untrust vrtrust u2t1 40
untrust trust u2t3 80

Number of policy: 3

```

### Sample Output

#### show security policies hit-count descending greater-than 70 less-than 100

```

user@host> show security policies hit-count descending greater-than 70 less-than 100
from-zone to-zone policy hit-count
untrust trust u2t2 100
untrust vrtrust u2t1 90
untrust vrtrust u2t3 80

Number of policy: 3

```

### Sample Output

#### show security policies hit-count from-zone untrust to-zone trust

```

user@host> show security policies hit-count from-zone untrust to-zone trust
from-zone to-zone policy hit-count
untrust trust u2t2 20

```

untrust trust u2t3 80

Number of policy: 2

## show security resource-manager group active

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security resource-manager group active<br><group-number><br><node ( node-id   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Description</b>              | Display security information about active groups created through the resource manager.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>none</b>—Display resource manager group service information for all active groups.</li> <li>• <b>group-number</b> —(Optional) Display resource manager group service information for a specific group identification number.</li> <li>• <b>node</b>—(Optional) For chassis cluster configurations, display active resource manager group service information on a specific node. <ul style="list-style-type: none"> <li>• <b>node-id</b> —Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> </li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>List of Sample Output</b>    | <a href="#">show security resource-manager group active on page 502</a><br><a href="#">show security resource-manager group active 2048 on page 502</a><br><a href="#">show security resource-manager group active node primary on page 502</a><br><a href="#">show security resource-manager group active node all on page 502</a><br><a href="#">show security resource-manager group active 1024 node all on page 502</a>                                                                                                                                                                                                                                                                                                                                         |
| <b>Output Fields</b>            | <a href="#">Table 74 on page 501</a> lists the output fields for the <b>show security resource-manager group</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

**Table 74: show security resource-manager group Output Fields**

| Field Name           | Field Description                                           |
|----------------------|-------------------------------------------------------------|
| <b>Total groups</b>  | Total number of groups in the system.                       |
| <b>active groups</b> | Number of active groups.                                    |
| <b>Group ID</b>      | Identification number whose group information is displayed. |

## Sample Output

### show security resource-manager group active

```
user@host> show security resource-manager group active
Total groups 32, active groups 0
```

## Sample Output

### show security resource-manager group active 2048

```
user@host> show security resource-manager group active 2048
Total groups 2048, active groups 1
Group ID 2048: state - Active
 : Virtual System - root
 : Application - SIP ALG
 : Group Timeout - 65535
 : Number of resources - 3
 Resource ID - 8190
 Resource ID - 8188
 Resource ID - 8187
```

## Sample Output

### show security resource-manager group active node primary

```
user@host> show security resource-manager group active node primary
node0:

Group ID 1024: Application - SIP ALG
Total groups 1024, active groups 1
```

## Sample Output

### show security resource-manager group active node all

```
user@host> show security resource-manager group active node all
node0:

Group ID 1024: Application - SIP ALG
Total groups 1024, active groups 1
node1:

Group ID 1024: Application - SIP ALG
Total groups 1024, active groups 1
```

## Sample Output

### show security resource-manager group active 1024 node all

```
user@host> show security resource-manager group active 1024 node all
node0:

Group ID 1024: state - Active
 : Application - SIP ALG
 : Group Timeout - 65535
 : Number of resources - 3
 Resource ID - 8192
 Resource ID - 8188
 Resource ID - 8187
```

node1:

-----  
Group ID 1024: state - Active  
: Application - SIP ALG  
: Group Timeout - 65535  
: Number of resources - 3  
Resource ID - 8187  
Resource ID - 8186  
Resource ID - 8190

## show security resource-manager resource active

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security resource-manager resource active<br><resource-id ><br><node ( node-id   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Description</b>              | Display security information about active resources created through the resource manager.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• none—Display information for all active resources.</li> <li>• resource-id —(Optional) Display information for a resource with a specific identification number.</li> <li>• node—(Optional) For chassis cluster configurations, display active resource manager information on a specific node. <ul style="list-style-type: none"> <li>• node-id —Identification number of the node. It can be 0 or 1.</li> <li>• all—Display information about all nodes.</li> <li>• local—Display information about the local node.</li> <li>• primary—Display information about the primary node.</li> </ul> </li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>List of Sample Output</b>    | <a href="#">show security resource-manager resource active on page 505</a><br><a href="#">show security resource-manager resource active 5 on page 505</a><br><a href="#">show security resource-manager resource active node local on page 505</a><br><a href="#">show security resource-manager resource active node primary on page 505</a>                                                                                                                                                                                                                                                                                                      |
| <b>Output Fields</b>            | Table 75 on page 504 lists the output fields for the <b>show security resource-manager resource</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

Table 75: show security resource-manager resource Output Fields

| Field Name       | Field Description                                              |
|------------------|----------------------------------------------------------------|
| Total resources  | Total number of resources in the system.                       |
| active resources | Number of active resources.                                    |
| Resource ID      | Identification number whose resource information is displayed. |

## Sample Output

### show security resource-manager resource active

```
user@host> show security resource-manager resource active
Resource ID 7: Group ID - 2, Application - JSF_sip

Resource ID 6: Group ID - 2, Application - JSF_sip

Resource ID 5: Group ID - 2, Application - JSF_sip

Resource ID 4: Group ID - 2, Application - JSF_sip

Resource ID 3: Group ID - 2, Application - JSF_sip

Resource ID 1: Group ID - 2, Application - JSF_sip

Resource ID 2: Group ID - 2, Application - JSF_sip
Total Resources 4326, active resources 7
```

## Sample Output

### show security resource-manager resource active 5

```
user@host> show security resource-manager resource active 5
Resource ID 5: state - Active
 Application - asl_client
 Parent group - 2
 Policy - 5
 From zone - untrust
 To zone - trust
 Resource timeout - 0
 Number of sessions - 0
 Number of Holes - 1
 Source IP range - {0.0.0.0, 0.0.0.0}
 Source port range - {0, 0}
 Destination IP range - {33.1.0.200, 33.1.0.200}
 Destination port range - {5060, 5060}
 Translated - {0.0.0.0/0 -> 33.1.0.200/5060}
 Protocol - 17
 Reference count - 1
```

## Sample Output

### show security resource-manager resource active node local

```
user@host> show security resource-manager resource active node local
node0:

Resource ID 8192: Group ID - 1024, Application - SIP ALG
Resource ID 8188: Group ID - 1024, Application - SIP ALG
Resource ID 8187: Group ID - 1024, Application - SIP ALG
Total Resources 8192, active resources 3
```

## Sample Output

### show security resource-manager resource active node primary

```
user@host> show security resource-manager resource active node primary
node0:

```

Resource ID 8192: Group ID - 1024, Application - SIP ALG  
Resource ID 8188: Group ID - 1024, Application - SIP ALG  
Resource ID 8187: Group ID - 1024, Application - SIP ALG  
Total Resources 8192, active resources 3



## show security resource-manager settings

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security resource-manager settings<br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                 |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5; <b>node</b> options added in Junos OS Release 9.0.                                                                                                                                                                                                                                                                                                                                               |
| <b>Description</b>              | Display resource manager settings.                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Options</b>                  | <b>node</b> —(Optional) For chassis cluster configurations, display resource manager settings on a specific node. <ul style="list-style-type: none"> <li>• <b>node-id</b>—Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                                                                                                                                   |
| <b>List of Sample Output</b>    | <a href="#">show security resource-manager settings on page 507</a><br><a href="#">show security resource-manager settings node primary on page 508</a><br><a href="#">show security resource-manager settings node all on page 508</a>                                                                                                                                                                                                      |
| <b>Output Fields</b>            | <a href="#">Table 76 on page 507</a> lists the output fields for the <b>show security resource-manager settings</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                         |

Table 76: show security resource-manager settings Output Fields

| Field Name       | Field Description                                                                                                                                                                                     |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Client Heartbeat | Time after which idle an resource manager client is timed out.                                                                                                                                        |
| Count            | Number of active clients.                                                                                                                                                                             |
| Pinhole age      | Duration for which the temporary opening in the security firewall (pinhole) is open for specified traffic. If the specified traffic does not exist during this time period, the pinhole is timed out. |

## Sample Output

### show security resource-manager settings

```
user@host> show security resource-manager settings
Client Heartbeat: timeout 600 seconds, count 5
Pinhole age: 32 seconds
```

## Sample Output

### show security resource-manager settings node primary

```
user@host> show security resource-manager settings node primary
node0:

Client heartbeat: timeout 600 seconds, count 5
Pinhole age: 120 seconds
```

## Sample Output

### show security resource-manager settings node all

```
user@host> show security resource-manager settings node all
node0:

Client heartbeat: timeout 600 seconds, count 5
Pinhole age: 120 seconds
node1:

Client heartbeat: timeout 600 seconds, count 5
Pinhole age: 120 seconds
```

## show security resource-manager summary

|                                 |                                                                                                                                                                                                     |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security resource-manager summary                                                                                                                                                              |
| <b>Release Information</b>      | Command introduced in Junos OS Release 11.4.                                                                                                                                                        |
| <b>Description</b>              | Display summary information about active resources, clients, groups, and sessions created through the resource manager.                                                                             |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                          |
| <b>List of Sample Output</b>    | <a href="#">show security resource-manager summary on page 509</a>                                                                                                                                  |
| <b>Output Fields</b>            | <a href="#">Table 77 on page 509</a> lists the output fields for the <b>show security resource-manager summary</b> command. Output fields are listed in the approximate order in which they appear. |

**Table 77: show security resource-manager summary Output Fields**

| Field Name                        | Field Description                            |
|-----------------------------------|----------------------------------------------|
| Active resource-manager clients   | Number of active resource manager clients.   |
| Active resource-manager groups    | Number of active resource manager groups.    |
| Active resource-manager resources | Number of active resource manager resources. |
| Active resource-manager sessions  | Number of active resource manager sessions.  |

## Sample Output

### show security resource-manager summary

```

user@host> show security resource-manager summary

Active resource-manager clients : 15
Active resource-manager groups : 1
Active resource-manager resources : 1
Active resource-manager sessions : 0

```

## show security screen ids-option

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security screen ids-option<br>screen-name<br><node ( <i>node-id</i>   all   local   primary )>                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5. Support for <b>node</b> options added in Junos OS Release 9.0. Support for IPv6 extension header screens added in Junos OS Release 12.1X46-D10. Support for UDP <b>port scan</b> added in Junos OS Release 12.1X47-D10.                                                                                                                                                                                                                                                                                                        |
| <b>Description</b>              | Display configuration information about the specified security screen.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>screen-name</b> —Name of the screen.</li> <li>• <b>node</b>—(Optional) For chassis cluster configurations, display the configuration status of the security screen on a specific node. <ul style="list-style-type: none"> <li>• <b>node-id</b> —Identification number of the node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> </li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <i>ids-option</i></li> <li>• <i>Example: Configuring Multiple Screening Options</i></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>List of Sample Output</b>    | <a href="#">show security screen ids-option jscreen on page 512</a><br><a href="#">show security screen ids-option jscreen (IPv6) on page 513</a><br><a href="#">show security screen ids-option jscreen1 node all on page 513</a>                                                                                                                                                                                                                                                                                                                                         |
| <b>Output Fields</b>            | <a href="#">Table 78 on page 510</a> lists the output fields for the <b>show security screen ids-option</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                                                                                                                                                                                                                                                                                               |

**Table 78: show security screen ids-option Output Fields**

| Field Name                   | Field Description                                                                                                                  |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| TCP address sweep threshold  | Number of microseconds for which the device accepts 10 TCP packets from the same remote source to different destination addresses. |
| TCP port scan threshold      | Number of microseconds during which the device accepts packets from the same remote source with up to 10 different port numbers.   |
| ICMP address sweep threshold | Maximum number of microseconds during which up to 10 ICMP echo requests from the same host are allowed into the device.            |

Table 78: show security screen ids-option Output Fields (*continued*)

| Field Name                          | Field Description                                                                                                                               |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| UDP flood threshold                 | Number of UDP packets per second allowed to ping the same destination address before the device rejects further UDP packets.                    |
| UDP port scan threshold             | Number of microseconds during which the device accepts packets from the same remote source IP with up to 10 different destination port numbers. |
| TCP winnuke                         | Enable or disable the detection of TCP WinNuke attacks.                                                                                         |
| TCP SYN flood attack threshold      | Number of SYN packets per second required to trigger the SYN proxy response.                                                                    |
| TCP SYN flood alarm threshold       | Number of half-complete proxy connections per second at which the device makes entries in the event alarm log.                                  |
| TCP SYN flood source threshold      | Number of SYN segments to be received per second before the device begins dropping connection requests.                                         |
| TCP SYN flood destination threshold | Number of SYN segments received per second before the device begins dropping connection requests.                                               |
| TCP SYN flood timeout               | Maximum length of time before a half-completed connection is dropped from the queue.                                                            |
| TCP SYN flood queue size            | Number of proxy connection requests that can be held in the proxy connection queue before the device begins rejecting new connection requests.  |
| ICMP large packet                   | Enable or disable the detection of any ICMP frame with an IP length greater than 1024 bytes.                                                    |
| UDP address sweep threshold         | Number of microseconds for which the device accepts 10 UDP packets from the same remote source to different destination addresses.              |
| IPv6 extension routing              | Enable or disable the IPv6 extension routing screen option.                                                                                     |
| IPv6 extension shim6                | Enable or disable the IPv6 extension shim6 screen option.                                                                                       |
| IPv6 extension fragment             | Enable or disable the IPv6 extension fragment screen option.                                                                                    |
| IPv6 extension AH                   | Enable or disable the IPv6 extension Authentication Header Protocol screen option.                                                              |
| IPv6 extension ESP                  | Enable or disable the IPv6 extension Encapsulating Security Payload screen option.                                                              |
| IPv6 extension mobility             | Enable or disable the IPv6 extension mobility screen option.                                                                                    |
| IPv6 extension HIP                  | Enable or disable the IPv6 extension Host Identify Protocol screen option.                                                                      |
| IPv6 extension no next              | Enable or disable the IPv6 extension no-next screen option.                                                                                     |
| IPv6 extension user-defined         | Enable or disable the IPv6 extension user-defined screen option.                                                                                |

Table 78: show security screen ids-option Output Fields (*continued*)

| Field Name                             | Field Description                                                                                                        |
|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| IPv6 extension HbyH jumbo              | Enable or disable the IPv6 extension HbyH jumbo screen option.                                                           |
| IPv6 extension HbyH RPL                | Enable or disable the IPv6 extension HbyH RPL screen option.                                                             |
| IPv6 extension HbyH router alert       | Enable or disable the IPv6 extension HbyH router screen option.                                                          |
| IPv6 extension HbyH quick start        | Enable or disable the IPv6 extension HbyH quick-start screen option.                                                     |
| IPv6 extension HbyH CALIPSO            | Enable or disable the IPv6 extension HbyH Common Architecture Label IPv6 Security Screen option.                         |
| IPv6 extension HbyH SMF DPD            | Enable or disable the IPv6 extension HbyH Simplified Multicast Forwarding IPv6 Duplicate Packet Detection screen option. |
| IPv6 extension HbyH user-defined       | Enable or disable the IPv6 extension HbyH user-defined screen option.                                                    |
| IPv6 extension Dst tunnel encaps limit | Enable or disable the IPv6 extension distributed (network) storage tunnel encapsulation limit screen option.             |
| IPv6 extension Dst home address        | Enable or disable the IPv6 extension DST home address screen option.                                                     |
| IPv6 extension Dst ILNP nonce          | Enable or disable the IPv6 extension DST Identifier-Locator Network Protocol nonce screen option.                        |
| IPv6 extension Dst line-id             | Enable or disable the IPv6 extension DST line-ID screen option.                                                          |
| IPv6 extension Dst user-defined        | Enable or disable the IPv6 extension DST user-defined screen option.                                                     |
| IPv6 extension header limit            | Threshold for the number of IPv6 extension headers that can pass through the screen.                                     |
| IPv6 malformed header                  | Enable or disable the IPv6 malformed header screen option.                                                               |
| ICMPv6 malformed header                | Enable or disable the ICMPv6 malformed packet screen option.                                                             |

## Sample Output

show security screen ids-option jscreen

```

user@host> show security screen ids-option jscreen
Screen object status:
Name Value
TCP port scan threshold 5000
UDP port scan threshold 10000
ICMP address sweep threshold 5000

```

## Sample Output

### show security screen ids-option jscreen (IPv6)

```
user@host> show security screen ids-option jscreen
```

Screen object status:

| Name                                  | Value   |
|---------------------------------------|---------|
| ICMP ping of death                    | enabled |
| .....                                 |         |
| IPv6 extension routing                | enabled |
| IPv6 extension shim6                  | enabled |
| IPv6 extension fragment               | enabled |
| IPv6 extension AH                     | enabled |
| IPv6 extension ESP                    | enabled |
| IPv6 extension mobility               | enabled |
| IPv6 extension HIP                    | enabled |
| IPv6 extension no next                | enabled |
| IPv6 extension user-defined           | enabled |
| IPv6 extension HbyH jumbo             | enabled |
| IPv6 extension HbyH RPL               | enabled |
| IPv6 extension HbyH router alert      | enabled |
| IPv6 extension HbyH quick start       | enabled |
| IPv6 extension HbyH CALIPSO           | enabled |
| IPv6 extension HbyH SMF DPD           | enabled |
| IPv6 extension HbyH user-defined      | enabled |
| IPv6 extension Dst tunnel encap limit | enabled |
| IPv6 extension Dst home address       | enabled |
| IPv6 extension Dst ILNP nonce         | enabled |
| IPv6 extension Dst line-id            | enabled |
| IPv6 extension Dst user-defined       | enabled |
| IPv6 extension header limit           | 20      |
| IPv6 Malformed header                 | enabled |
| ICMPv6 malformed packet               | enabled |

## Sample Output

### show security screen ids-option jscreen1 node all

```
user@host> show security screen ids-option jscreen1 node all
```

node0:

Screen object status:

| Name                                | Value   |
|-------------------------------------|---------|
| UDP flood threshold                 | 1000    |
| TCP winnuke                         | enabled |
| TCP SYN flood attack threshold      | 200     |
| TCP SYN flood alarm threshold       | 512     |
| TCP SYN flood source threshold      | 4000    |
| TCP SYN flood destination threshold | 4000    |
| TCP SYN flood timeout               | 20      |
| TCP SYN flood queue size            | 1024    |
| ICMP large packet                   | enabled |

node1:

Screen object status:

| Name                | Value |
|---------------------|-------|
| UDP flood threshold | 1000  |

|                                     |         |
|-------------------------------------|---------|
| TCP winnuke                         | enabled |
| TCP SYN flood attack threshold      | 200     |
| TCP SYN flood alarm threshold       | 512     |
| TCP SYN flood source threshold      | 4000    |
| TCP SYN flood destination threshold | 4000    |
| TCP SYN flood timeout               | 20      |
| TCP SYN flood queue size            | 1024    |
| ICMP large packet                   | enabled |



## show security screen statistics

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | show security screen statistics (zone <i>zone-name</i>   interface <i>interface-name</i> )<br><logical-system ( <i>logical-system-name</i>   all)><br><node ( <i>node-id</i>   all   local   primary)><br><root-logical-system>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5. <b>node</b> options added in Junos OS Release 9.0. <b>logical-system all</b> option added in Junos OS Release 11.2R6. Support for IPv6 extension header screens added in Junos OS Release 12.1X46-D10.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Description</b>              | Display intrusion detection service (IDS) security screen statistics.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>zone <i>zone-name</i></b>—Display screen statistics for this security zone.</li> <li>• <b>interface <i>interface-name</i></b>—Display screen statistics for this interface.</li> <li>• <b>logical-system</b>—(Optional) Display screen statistics for configured logical systems. <ul style="list-style-type: none"> <li>• <b><i>logical-system-name</i></b>—Display screen statistics for the named logical system.</li> <li>• <b>all</b>—Display screen statistics for all logical systems, including the master (root) logical system.</li> </ul> </li> <li>• <b>node</b>—(Optional) For chassis cluster configurations, display screen statistics on a specific node. <ul style="list-style-type: none"> <li>• <b><i>node-id</i></b>—Identification number of a node. It can be 0 or 1.</li> <li>• <b>all</b>—Display information about all nodes.</li> <li>• <b>local</b>—Display information about the local node.</li> <li>• <b>primary</b>—Display information about the primary node.</li> </ul> </li> <li>• <b>root-logical-system</b>—(Optional) Display screen statistics for the master logical system only.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <i>clear security screen statistics</i></li> <li>• <i>clear security screen statistics interface</i></li> <li>• <i>clear security screen statistics zone</i></li> <li>• <i>Example: Configuring Multiple Screening Options</i></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>List of Sample Output</b>    | <a href="#">show security screen statistics zone scrzone on page 518</a><br><a href="#">show security screen statistics zone untrust (IPv6) on page 518</a><br><a href="#">show security screen statistics interface ge-0/0/3 on page 519</a><br><a href="#">show security screen statistics interface ge-0/0/1 (IPv6) on page 519</a><br><a href="#">show security screen statistics interface ge-0/0/1 node primary on page 520</a><br><a href="#">show security screen statistics zone trust logical-system all on page 520</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

**Output Fields** Table 79 on page 516 lists the output fields for the **show security screen statistics** command. Output fields are listed in the approximate order in which they appear.

**Table 79: show security screen statistics Output Fields**

| Field Name             | Field Description                                                                                                                                                                                                                |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ICMP flood             | Internet Control Message Protocol (ICMP) flood counter. An ICMP flood typically occurs when ICMP echo requests use all resources in responding, such that valid network traffic can no longer be processed.                      |
| UDP flood              | User Datagram Protocol (UDP) flood counter. UDP flooding occurs when an attacker sends IP packets containing UDP datagrams with the purpose of slowing down the resources, such that valid connections can no longer be handled. |
| TCP winnuke            | Number of Transport Control Protocol (TCP) WinNuke attacks. WinNuke is a denial-of-service (DoS) attack targeting any computer on the Internet running Windows.                                                                  |
| TCP port scan          | Number of TCP port scans. The purpose of this attack is to scan the available services in the hopes that at least one port will respond, thus identifying a service to target.                                                   |
| ICMP address sweep     | Number of ICMP address sweeps. An IP address sweep can occur with the intent of triggering responses from active hosts.                                                                                                          |
| IP tear drop           | Number of teardrop attacks. Teardrop attacks exploit the reassembly of fragmented IP packets.                                                                                                                                    |
| TCP SYN flood          | Number of TCP SYN attacks.                                                                                                                                                                                                       |
| IP spoofing            | Number of IP spoofs. IP spoofing occurs when an invalid source address is inserted in the packet header to make the packet appear to come from a trusted source.                                                                 |
| ICMP ping of death     | ICMP ping of death counter. Ping of death occurs when IP packets are sent that exceed the maximum legal length (65,535 bytes).                                                                                                   |
| IP source route option | Number of IP source route attacks.                                                                                                                                                                                               |
| TCP address sweep      | Number of TCP address sweeps.                                                                                                                                                                                                    |
| TCP land attack        | Number of land attacks. Land attacks occur when an attacker sends spoofed SYN packets containing the IP address of the victim as both the destination and source IP address.                                                     |
| TCP SYN fragment       | Number of TCP SYN fragments.                                                                                                                                                                                                     |
| TCP no flag            | Number of TCP headers without flags set. A normal TCP segment header has at least one control flag set.                                                                                                                          |
| IP unknown protocol    | Number of IPs.                                                                                                                                                                                                                   |
| IP bad options         | Number of invalid options.                                                                                                                                                                                                       |
| IP record route option | Number of packets with the IP record route option enabled. This option records the IP addresses of the network devices along the path that the IP packet travels.                                                                |

Table 79: show security screen statistics Output Fields (*continued*)

| Field Name                        | Field Description                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| IP timestamp option               | Number of IP timestamp option attacks. This option records the time (in Universal Time) when each network device receives the packet during its trip from the point of origin to its destination.                                                                                                                                                             |
| IP security option                | Number of IP security option attacks.                                                                                                                                                                                                                                                                                                                         |
| IP loose source route option      | Number of IP loose source route option attacks. This option specifies a partial route list for a packet to take on its journey from source to destination.                                                                                                                                                                                                    |
| IP strict source route option     | Number of IP strict source route option attacks. This option specifies the complete route list for a packet to take on its journey from source to destination.                                                                                                                                                                                                |
| IP stream option                  | Number of stream option attacks. This option provides a way for the 16-bit SATNET stream identifier to be carried through networks that do not support streams.                                                                                                                                                                                               |
| ICMP fragment                     | Number of ICMP fragments. Because ICMP packets contain very short messages, there is no legitimate reason for ICMP packets to be fragmented. If an ICMP packet is so large that it must be fragmented, something is amiss.                                                                                                                                    |
| ICMP large packet                 | Number of large ICMP packets.                                                                                                                                                                                                                                                                                                                                 |
| TCP SYN FIN                       | Number of TCP SYN FIN packets.                                                                                                                                                                                                                                                                                                                                |
| TCP FIN no ACK                    | Number of TCP FIN flags without the acknowledge (ACK) flag.                                                                                                                                                                                                                                                                                                   |
| Source session limit              | Number of concurrent sessions that can be initiated from a source IP address.                                                                                                                                                                                                                                                                                 |
| TCP SYN-ACK-ACK proxy             | Number of TCP flags enabled with SYN-ACK-ACK. To prevent flooding with SYN-ACK-ACK sessions, you can enable the SYN-ACK-ACK proxy protection screen option. After the number of connections from the same IP address reaches the SYN-ACK-ACK proxy threshold and SRX Series devices running Junos OS reject further connection requests from that IP address. |
| IP block fragment                 | Number of IP block fragments.                                                                                                                                                                                                                                                                                                                                 |
| Destination session limit         | Number of concurrent sessions that can be directed to a single destination IP address.                                                                                                                                                                                                                                                                        |
| UDP address sweep                 | Number of UDP address sweeps.                                                                                                                                                                                                                                                                                                                                 |
| IPv6 extension header             | Number of packets filtered for the defined IPv6 extension headers.                                                                                                                                                                                                                                                                                            |
| IPv6 extension hop by hop option  | Number of packets filtered for the defined IPv6 hop-by-hop option types.                                                                                                                                                                                                                                                                                      |
| IPv6 extension destination option | Number of packets filtered for the defined IPv6 destination option types.                                                                                                                                                                                                                                                                                     |
| IPv6 extension header limit       | Number of packets filtered for crossing the defined IPv6 extension header limit.                                                                                                                                                                                                                                                                              |
| IPv6 malformed header             | Number of IPv6 malformed headers defined for the intrusion detection service (IDS).                                                                                                                                                                                                                                                                           |

Table 79: show security screen statistics Output Fields (*continued*)

|                         |                                                                 |
|-------------------------|-----------------------------------------------------------------|
| ICMPv6 malformed packet | Number of ICMPv6 malformed packets defined for the IDS options. |
|-------------------------|-----------------------------------------------------------------|

## Sample Output

show security screen statistics zone scrzone

```

user@host> show security screen statistics zone scrzone
Screen statistics:
IDS attack type Statistics
ICMP flood 0
UDP flood 0
TCP winnuke 0
TCP port scan 91
ICMP address sweep 0
TCP sweep 0
UDP sweep 0
IP tear drop 0
TCP SYN flood 0
IP spoofing 0
ICMP ping of death 0
IP source route option 0
TCP land attack 0
TCP SYN fragment 0
TCP no flag 0
IP unknown protocol 0
IP bad options 0
IP record route option 0
IP timestamp option 0
IP security option 0
IP loose source route option 0
IP strict source route option 0
IP stream option 0
ICMP fragment 0
ICMP large packet 0
TCP SYN FIN 0
TCP FIN no ACK 0
Source session limit 0
TCP SYN-ACK-ACK proxy 0
IP block fragment 0
Destination session limit 0

```

## Sample Output

show security screen statistics zone untrust (IPv6)

```

user@host> show security screen statistics zone untrust
Screen statistics:
IDS attack type Statistics
ICMP flood 0
UDP flood 0
TCP winnuke 0
.....
IPv6 extension header 0
IPv6 extension hop by hop option 0
IPv6 extension destination option 0
IPv6 extension header limit 0
IPv6 malformed header 0

```

|                         |   |
|-------------------------|---|
| ICMPv6 malformed packet | 0 |
|-------------------------|---|

## Sample Output

show security screen statistics interface ge-0/0/3

```
user@host> show security screen statistics interface ge-0/0/3
Screen statistics:
IDS attack type Statistics
ICMP flood 0
UDP flood 0
TCP winnuke 0
TCP port scan 91
ICMP address sweep 0
TCP sweep 0
UDP sweep 0
IP tear drop 0
TCP SYN flood 0
IP spoofing 0
ICMP ping of death 0
IP source route option 0
TCP land attack 0
TCP SYN fragment 0
TCP no flag 0
IP unknown protocol 0
IP bad options 0
IP record route option 0
IP timestamp option 0
IP security option 0
IP loose source route option 0
IP strict source route option 0
IP stream option 0
ICMP fragment 0
ICMP large packet 0
TCP SYN FIN 0
TCP FIN no ACK 0
Source session limit 0
TCP SYN-ACK-ACK proxy 0
IP block fragment 0
Destination session limit 0
```

## Sample Output

show security screen statistics interface ge-0/0/1 (IPv6)

```
user@host> show security screen statistics interface ge-0/0/1
Screen statistics:
IDS attack type Statistics
ICMP flood 0
UDP flood 0
.....
IPv6 extension header 0
IPv6 extension hop by hop option 0
IPv6 extension destination option 0
IPv6 extension header limit 0
IPv6 malformed header 0
ICMPv6 malformed packet 0
```

## Sample Output

### show security screen statistics interface ge-0/0/1 node primary

```
user@host> show security screen statistics interface ge-0/0/1 node primary
node0:
```

```

Screen statistics:
IDS attack type Statistics
ICMP flood 1
UDP flood 1
TCP winnuke 1
TCP port scan 1
ICMP address sweep 1
TCP sweep 1
UDP sweep 1
IP tear drop 1
TCP SYN flood 1
IP spoofing 1
ICMP ping of death 1
IP source route option 1
TCP land attack 1
TCP SYN fragment 1
TCP no flag 1
IP unknown protocol 1
IP bad options 1
IP record route option 1
IP timestamp option 1
IP security option 1
IP loose source route option 1
IP strict source route option 1
IP stream option 1
ICMP fragment 1
ICMP large packet 1
TCP SYN FIN 1
TCP FIN no ACK 1
Source session limit 1
TCP SYN-ACK-ACK proxy 1
IP block fragment 1
Destination session limit 1
```

## Sample Output

### show security screen statistics zone trust logical-system all

```
user@host> show security screen statistics zone trust logical-system all
Logical system: root-logical-system
Screen statistics:
```

```
IDS attack type Statistics
ICMP flood 0
UDP flood 0
TCP winnuke 0
TCP port scan 0
ICMP address sweep 0
TCP sweep 0
UDP sweep 0
IP tear drop 0
TCP SYN flood 0
IP spoofing 0
ICMP ping of death 0
```

|                               |   |
|-------------------------------|---|
| IP source route option        | 0 |
| TCP land attack               | 0 |
| TCP SYN fragment              | 0 |
| TCP no flag                   | 0 |
| IP unknown protocol           | 0 |
| IP bad options                | 0 |
| IP record route option        | 0 |
| IP timestamp option           | 0 |
| IP security option            | 0 |
| IP loose source route option  | 0 |
| IP strict source route option | 0 |
| IP stream option              | 0 |
| ICMP fragment                 | 0 |
| ICMP large packet             | 0 |
| TCP SYN FIN                   | 0 |
| TCP FIN no ACK                | 0 |
| Source session limit          | 0 |
| TCP SYN-ACK-ACK proxy         | 0 |
| IP block fragment             | 0 |
| Destination session limit     | 0 |

Logical system: ls1

Screen statistics:

| IDS attack type               | Statistics |
|-------------------------------|------------|
| ICMP flood                    | 0          |
| UDP flood                     | 0          |
| TCP winnuke                   | 0          |
| TCP port scan                 | 0          |
| ICMP address sweep            | 0          |
| TCP sweep                     | 0          |
| UDP sweep                     | 0          |
| IP tear drop                  | 0          |
| TCP SYN flood                 | 0          |
| IP spoofing                   | 0          |
| ICMP ping of death            | 0          |
| IP source route option        | 0          |
| TCP land attack               | 0          |
| TCP SYN fragment              | 0          |
| TCP no flag                   | 0          |
| IP unknown protocol           | 0          |
| IP bad options                | 0          |
| IP record route option        | 0          |
| IP timestamp option           | 0          |
| IP security option            | 0          |
| IP loose source route option  | 0          |
| IP strict source route option | 0          |
| IP stream option              | 0          |
| ICMP fragment                 | 0          |
| ICMP large packet             | 0          |
| TCP SYN FIN                   | 0          |
| TCP FIN no ACK                | 0          |
| Source session limit          | 0          |
| TCP SYN-ACK-ACK proxy         | 0          |
| IP block fragment             | 0          |
| Destination session limit     | 0          |

Logical system: ls2

Screen statistics:

| IDS attack type | Statistics |
|-----------------|------------|
|-----------------|------------|

|                               |   |
|-------------------------------|---|
| ICMP flood                    | 0 |
| UDP flood                     | 0 |
| TCP winnuke                   | 0 |
| TCP port scan                 | 0 |
| ICMP address sweep            | 0 |
| TCP sweep                     | 0 |
| UDP sweep                     | 0 |
| IP tear drop                  | 0 |
| TCP SYN flood                 | 0 |
| IP spoofing                   | 0 |
| ICMP ping of death            | 0 |
| IP source route option        | 0 |
| TCP land attack               | 0 |
| TCP SYN fragment              | 0 |
| TCP no flag                   | 0 |
| IP unknown protocol           | 0 |
| IP bad options                | 0 |
| IP record route option        | 0 |
| IP timestamp option           | 0 |
| IP security option            | 0 |
| IP loose source route option  | 0 |
| IP strict source route option | 0 |
| IP stream option              | 0 |
| ICMP fragment                 | 0 |
| ICMP large packet             | 0 |
| TCP SYN FIN                   | 0 |
| TCP FIN no ACK                | 0 |
| Source session limit          | 0 |
| TCP SYN-ACK-ACK proxy         | 0 |
| IP block fragment             | 0 |
| Destination session limit     | 0 |



## show security softwares

|                                 |                                                                                                                                                                                                                                                                                                                                 |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <code>show security softwares &lt;software-name <i>software-name</i>&gt;<br/>&lt;logical-system (all   <i>logical-system-name</i>)&gt;</code>                                                                                                                                                                                   |
| <b>Release Information</b>      | Command introduced in Junos OS Release 10.4. The <b>logical-system</b> option introduced in Junos OS Release 12.1.                                                                                                                                                                                                              |
| <b>Description</b>              | Display a summary of information of all the software concentrators and details on concentrators with specified name.                                                                                                                                                                                                            |
| <b>Options</b>                  | <p><b>software-name <i>software-name</i></b>—Display the details of the specified software concentrator.</p> <p><b>logical-system (all   <i>logical-system-name</i>)</b>—Display software information for all logical systems or for a specified logical system. This option is only available to the master administrator.</p> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                                                                            |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <a href="#">Juniper Networks Devices Processing Overview on page 3</a></li> </ul>                                                                                                                                                                                                      |

## Sample Output

```

user@host> show security softwares
Software Name SC Address Status Number of SI connected
SC-CSSI-1 3001::1 Connected 2
SC-CSSI-str00 3100::1 Active 0
SC-CSSI-str01 3101::1 Inactive 0
SC-CSSI-str02 3001::1 Connected 2520

user@host> show security softwares software-name SC-CSSI-1
Name of software: SC-CSSI-1
 SC status: Connected
 SC address: 3001::1
 Zone: trust
 VR ID: 0
 SI Address SI Status SPU
3001::2 Active spu-1
3001::2 Active spu-21
SI number: 2

user@host> show security softwares logical-system ls-product-design
Software Name SC Address Status Number of SI connected
sc_1 3000::1 Connected 1

```

## show security zones

|                                 |                                                                                                                                                                                                                                                                               |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security zones</b><br><b>&lt;detail   terse&gt;</b><br><b>&lt; zone-name &gt;</b>                                                                                                                                                                                     |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5. The <b>Description</b> output field added in Junos OS Release 12.1.                                                                                                                                                               |
| <b>Description</b>              | Display information about security zones.                                                                                                                                                                                                                                     |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>none</b>—Display information about all zones.</li> <li>• <b>detail   terse</b>—(Optional) Display the specified level of output.</li> <li>• <b>zone-name</b> —(Optional) Display information about the specified zone.</li> </ul> |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                          |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <i>Security Zones and Interfaces Overview</i></li> <li>• <i>Supported System Services for Host Inbound Traffic</i></li> <li>• <i>security-zone</i></li> </ul>                                                                        |
| <b>List of Sample Output</b>    | <a href="#">show security zones on page 525</a><br><a href="#">show security zones abc on page 525</a><br><a href="#">show security zones abc detail on page 525</a><br><a href="#">show security zones terse on page 526</a>                                                 |
| <b>Output Fields</b>            | <a href="#">Table 80 on page 524</a> lists the output fields for the <b>show security zones</b> command. Output fields are listed in the approximate order in which they appear.                                                                                              |

**Table 80: show security zones Output Fields**

| Field Name          | Field Description                            |
|---------------------|----------------------------------------------|
| Security zone       | Name of the security zone.                   |
| Description         | Description of the security zone.            |
| Policy configurable | Whether the policy can be configured or not. |
| Interfaces bound    | Number of interfaces in the zone.            |
| Interfaces          | List of the interfaces in the zone.          |
| Zone                | Name of the zone.                            |
| Type                | Type of the zone.                            |

## Sample Output

show security zones

```
user@host> show security zones
Functional zone: management
 Description: This is the management zone.
 Policy configurable: No
 Interfaces bound: 1
 Interfaces:
 ge-0/0/0.0
Security zone: Host
 Description: This is the host zone.
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 1
 Interfaces:
 fxp0.0
Security zone: abc
 Description: This is the abc zone.
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 1
 Interfaces:
 ge-0/0/1.0
Security zone: def
 Description: This is the def zone.
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 1
 Interfaces:
 ge-0/0/2.0
```

## Sample Output

show security zones abc

```
user@host> show security zones abc
Security zone: abc
 Description: This is the abc zone.
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 1
 Interfaces:
 ge-0/0/1.0
```

## Sample Output

show security zones abc detail

```
user@host> show security zones abc detail
Security zone: abc
 Description: This is the abc zone.
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 1
 Interfaces:
 ge-0/0/1.0
```

## Sample Output

show security zones terse

```
user@host> show security zones terse
Zone Type
my-internal Security
my-external Security
dmz Security
```

## show security zones type

|                                 |                                                                                                                                                                                                                                                                                 |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>                   | <b>show security zones type</b><br>(functional   security)<br><detail   terse>                                                                                                                                                                                                  |
| <b>Release Information</b>      | Command introduced in Junos OS Release 8.5. The <b>Description</b> output field added in Junos OS Release 12.1.                                                                                                                                                                 |
| <b>Description</b>              | Display information about security zones of the specified type.                                                                                                                                                                                                                 |
| <b>Options</b>                  | <ul style="list-style-type: none"> <li>• <b>functional</b>—Display functional zones.</li> <li>• <b>security</b>—Display security zones.</li> <li>• <b>detail   terse</b>—(Optional) Display the specified level of output.</li> </ul>                                           |
| <b>Required Privilege Level</b> | view                                                                                                                                                                                                                                                                            |
| <b>Related Documentation</b>    | <ul style="list-style-type: none"> <li>• <i>Security Zones and Interfaces Overview</i></li> <li>• <i>Supported System Services for Host Inbound Traffic</i></li> <li>• <i>security-zone</i></li> </ul>                                                                          |
| <b>List of Sample Output</b>    | <a href="#">show security zones type functional on page 528</a><br><a href="#">show security zones type security on page 528</a><br><a href="#">show security zones type security terse on page 528</a><br><a href="#">show security zones type security detail on page 528</a> |
| <b>Output Fields</b>            | Table 81 on page 527 lists the output fields for the <b>show security zones type</b> command. Output fields are listed in the approximate order in which they appear.                                                                                                           |

Table 81: show security zones type Output Fields

| Field Name          | Field Description                            |
|---------------------|----------------------------------------------|
| Security zone       | Zone name.                                   |
| Description         | Description of the security zone.            |
| Policy configurable | Whether the policy can be configured or not. |
| Interfaces bound    | Number of interfaces in the zone.            |
| Interfaces          | List of the interfaces in the zone.          |
| Zone                | Name of the zone.                            |
| Type                | Type of the zone.                            |

## Sample Output

### show security zones type functional

```
user@host> show security zones type functional
Functional zone: management
 Description: management zone
 Policy configurable: No
 Interfaces bound: 0
 Interfaces:
```

## Sample Output

### show security zones type security

```
user@host> show security zones type security
Security zone: trust
 Description: trust zone
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 1
 Interfaces:
 ge-0/0/0.0
Security zone: untrust
 Description: untrust zone
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 1
 Interfaces:
 ge-0/0/1.0
Security zone: junos-host
 Description: junos-host zone
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 0
 Interfaces:
```

## Sample Output

### show security zones type security terse

```
user@host> show security zones type security terse
Zone Type
trust Security
untrust Security
junos-host Security
```

## Sample Output

### show security zones type security detail

```
user@host> show security zones type security detail
Security zone: trust
 Description: trust zone
 Send reset for non-SYN session TCP packets: Off
 Policy configurable: Yes
 Interfaces bound: 1
 Interfaces:
 ge-0/0/0.0
```

```
Security zone: untrust
Description: untrust zone
Send reset for non-SYN session TCP packets: Off
Policy configurable: Yes
Interfaces bound: 1
Interfaces:
ge-0/0/1.0
Security zone: junos-host
Description: junos-host zone
Send reset for non-SYN session TCP packets: Off
Policy configurable: Yes
Interfaces bound: 0
Interfaces:
```





## PART 8

# Index

- [Index on page 533](#)



# Index

## Symbols

|                                              |    |
|----------------------------------------------|----|
| #, comments in configuration statements..... | xx |
| ( ), in syntax descriptions.....             | xx |
| < >, in syntax descriptions.....             | xx |
| [ ], in configuration statements.....        | xx |
| { }, in configuration statements.....        | xx |
| (pipe), in syntax descriptions.....          | xx |

## A

|                                          |     |
|------------------------------------------|-----|
| action modifier                          |     |
| packet-mode.....                         | 142 |
| aging statement.....                     | 173 |
| all-tcp statement.....                   | 174 |
| allow-dns-reply statement.....           | 174 |
| allow-embedded-icmp statement.....       | 175 |
| application-services.....                | 176 |
| apply-to-half-close-state statement..... | 177 |

## B

|                                          |     |
|------------------------------------------|-----|
| braces, in configuration statements..... | xx  |
| brackets                                 |     |
| angle, in syntax descriptions.....       | xx  |
| square, in configuration statements..... | xx  |
| bypassing flow-based forwarding.....     | 139 |

## C

|                                                 |     |
|-------------------------------------------------|-----|
| changing session characteristics.....           | 29  |
| chassis                                         |     |
| environmental information, displaying.....      | 260 |
| Chassis Configuration Statement Hierarchy.....  | 167 |
| clear firewall command.....                     | 230 |
| clear monitor security flow filter command..... | 231 |
| clear security flow ip-action command.....      | 232 |
| clear security flow session all command.....    | 234 |
| clear security flow session application         |     |
| command.....                                    | 235 |
| clear security flow session destination-port    |     |
| command.....                                    | 237 |
| clear security flow session family .....        | 239 |
| clear security flow session interface           |     |
| command.....                                    | 240 |

|                                                   |     |
|---------------------------------------------------|-----|
| clear security flow session protocol              |     |
| command.....                                      | 242 |
| clear security flow session resource-manager      |     |
| command.....                                      | 244 |
| clear security flow session session-identifier    |     |
| command.....                                      | 248 |
| clear security flow session source-port           |     |
| command.....                                      | 249 |
| clear security flow session source-prefix         |     |
| command.....                                      | 251 |
| clear security forward-options mirror-filter      |     |
| command.....                                      | 253 |
| clear services application-identification counter |     |
| command.....                                      | 245 |
| comments, in configuration statements.....        | xx  |
| configuring dual-stack lite.....                  | 112 |
| configuring np-ioc.....                           | 77  |
| conventions                                       |     |
| text and syntax.....                              | xix |
| CoS features.....                                 | 6   |
| cross-network traffic in Express Path mode.....   | 64  |
| curly braces, in configuration statements.....    | xx  |
| customer support.....                             | xxi |
| contacting JTAC.....                              | xxi |

## D

|                                              |          |
|----------------------------------------------|----------|
| data processing, stateful and stateless..... | 3        |
| debugging                                    |          |
| end-to-end.....                              | 66       |
| destination-header statement.....            | 179      |
| destination-port statement.....              | 180      |
| destination-prefix statement.....            | 184      |
| diagnosis                                    |          |
| displaying selective stateless packet-based  |          |
| services configuration.....                  | 151, 160 |
| documentation                                |          |
| comments on.....                             | xxi      |
| ds-lite                                      |          |
| software concentrator.....                   | 109      |
| dual-stack lite.....                         | 109      |
| configuring.....                             | 112      |

## E

|                                    |     |
|------------------------------------|-----|
| early-ageout statement.....        | 184 |
| end-to-end debugging.....          | 66  |
| environmental information          |     |
| chassis, displaying.....           | 260 |
| ethernet-switching statement.....  | 178 |
| expansion of session capacity..... | 43  |

|                                    |     |                                            |          |
|------------------------------------|-----|--------------------------------------------|----------|
| Express Path.....                  | 57  | flow module sanity checks.....             | 105      |
| cross-network traffic.....         | 64  | ICMP overview.....                         | 107      |
| LAG.....                           | 57  | packet fragmentation.....                  | 107      |
| np-ioc card.....                   | 59  | packet header extension fields.....        | 103      |
| per session statistics.....        | 67  | packet header overview.....                | 101      |
| session scale up.....              | 64  | Path MTU.....                              | 105      |
| SRX5K-MPC.....                     | 78  | sessions.....                              | 90       |
| SRX5K-MPC3                         |     | SRX Series high-end devices.....           | 91       |
| IOC3.....                          | 81  |                                            |          |
| wing statistics counter.....       | 63  | ipv6                                       |          |
|                                    |     | configuring dual-stack lite.....           | 112      |
| <b>F</b>                           |     | ipv6-extension-header statement.....       | 193      |
| filters, stateless firewall.....   | 6   | ipv6-extension-header-limit statement..... | 194      |
| fin-invalidate-session.....        | 185 | ipv6-malformed-header statement.....       | 194      |
| firewall filters                   |     |                                            |          |
| statistics                         |     | <b>L</b>                                   |          |
| displaying.....                    | 524 | LAG                                        |          |
| flow session monitoring.....       | 117 | Express Path.....                          | 57       |
| flow-based packet processing       |     | low latency.....                           | 446      |
| defined.....                       | 3   | low-latency.....                           | 195      |
| flow-based processing              |     | low-watermark statement.....               | 196      |
| enabling.....                      | 94  |                                            |          |
| font conventions.....              | xix | <b>M</b>                                   |          |
| force-ip-reassembly statement..... | 185 | manuals                                    |          |
| forwarding-process.....            | 186 | comments on.....                           | xxi      |
| FPC                                |     | maximize-alg-sessions.....                 | 176      |
| status, displaying.....            | 264 | maximize-idp-sessions.....                 | 176, 196 |
| fru-poweron-sequence.....          | 187 | mirror filter.....                         | 132      |
|                                    |     | mirror-filter statement.....               | 197      |
| <b>G</b>                           |     | mode statement                             |          |
| gre-in statement.....              | 188 | (Forwarding Options).....                  | 198      |
| gre-out statement.....             | 189 | monitor security flow file command.....    | 254      |
|                                    |     | monitor security flow filter command.....  | 256      |
| <b>H</b>                           |     | monitor security flow start command.....   | 258      |
| high-watermark statement.....      | 189 | monitor security flow stop command.....    | 259      |
| hop-by-hop-header statement.....   | 190 | monitoring                                 |          |
|                                    |     | x2 traffic.....                            | 132      |
| <b>I</b>                           |     | monitoring security flow sessions.....     | 117      |
| ICMP                               |     |                                            |          |
| IPv6.....                          | 107 | <b>N</b>                                   |          |
| Path MTU.....                      | 105 | no-sequence-check statement.....           | 199      |
| icmpv6-malformed statement.....    | 191 | np-cache statement.....                    | 209      |
| inline-tap.....                    | 191 | np-ioc configuring.....                    | 77       |
| interface-in statement.....        | 192 |                                            |          |
| interface-out statement.....       | 192 | <b>O</b>                                   |          |
| IPv6                               |     | output statement.....                      | 200      |
| advanced flow.....                 | 89  |                                            |          |
| basic packet header fields.....    | 102 | <b>P</b>                                   |          |
| enabling.....                      | 94  | packet filtering.....                      | 3        |

|                                                 |          |                                                  |               |
|-------------------------------------------------|----------|--------------------------------------------------|---------------|
| packet fragmentation                            |          | session                                          |               |
| IPv6.....                                       | 107      | changing characteristics.....                    | 29            |
| packet ordering engine.....                     | 49, 50   | session capacity expansion.....                  | 43            |
| packet processing.....                          | 3        | session scale up for np-ioc card.....            | 64            |
| stateful.....                                   | 3        | show chassis environment command.....            | 260           |
| stateless.....                                  | 3        | show chassis fpc command.....                    | 264           |
| packet-based forwarding                         |          | show chassis hardware command.....               | 274           |
| selective stateless.....                        | 139      | show chassis pic command.....                    | 303           |
| packet-based processing.....                    | 5, 6     | show chassis power.....                          | 305           |
| packet-filter statement                         |          | show chassis power sequence.....                 | 307           |
| security.....                                   | 201      | show firewall command.....                       | 151, 160, 308 |
| packet-mode.....                                | 142      | show interfaces (Aggregated Ethernet)            |               |
| packet-ordering mode.....                       | 49, 50   | command.....                                     | 310           |
| parentheses, in syntax descriptions.....        | xx       | show interfaces command.....                     | 320           |
| Path MTU                                        |          | show interfaces diagnostics optics command.....  | 335           |
| Path MTU.....                                   | 105      | show interfaces flow-statistics command.....     | 340           |
| pending-sess-queue-length statement.....        | 203      | show interfaces statistics st0.1 command.....    | 345           |
| PICs                                            |          | show interfaces swfabx command.....              | 346           |
| status                                          |          | show monitor security flow command.....          | 347           |
| displaying for a specific PIC.....              | 303      | show security flow cp-session command.....       | 349           |
| policers, displaying.....                       | 490      | show security flow cp-session destination-port   |               |
| processing                                      |          | command.....                                     | 353           |
| data.....                                       | 3        | show security flow cp-session destination-prefix |               |
| flow-based.....                                 | 4        | command.....                                     | 355           |
| packet-based.....                               | 5, 6     | show security flow cp-session family             |               |
| propagate-settings statement.....               | 203      | command.....                                     | 357           |
| protocol statement.....                         | 204      | show security flow cp-session protocol           |               |
|                                                 |          | command.....                                     | 359           |
| <b>R</b>                                        |          | show security flow cp-session source-port        |               |
| resource-manager statement.....                 | 205      | command.....                                     | 362           |
| route-change-timeout statement.....             | 205      | show security flow cp-session source-prefix      |               |
| rst-invalidate-session statement.....           | 206      | command.....                                     | 364           |
| rst-sequence-check statement.....               | 206      | show security flow gate brief node command.....  | 378           |
|                                                 |          | show security flow gate command.....             | 366           |
| <b>S</b>                                        |          | show security flow gate destination-port         |               |
| sample configurations                           |          | command.....                                     | 384           |
| firewall filter configurations.....             | 151, 160 | show security flow gate destination-prefix       |               |
| Security Configuration Statement Hierarchy..... | 170      | command.....                                     | 387           |
| selective stateless packet-based services.....  | 139      | show security flow gate protocol command.....    | 390           |
| configuring.....                                | 142      | show security flow gate summary node             |               |
| end-to-end packet-based example.....            | 144      | command.....                                     | 393           |
| limitations.....                                | 142      | show security flow ip-action.....                | 370           |
| overview.....                                   | 140      | show security flow session brief node            |               |
| packet-based to flow-based example.....         | 154      | command.....                                     | 404           |
| verifying configuration.....                    | 151, 160 | show security flow session command.....          | 398           |
| sequence-check-required .....                   | 36       | show security flow session destination-port      |               |
| services-offload low-latency statement.....     | 195      | command.....                                     | 408           |
| services-offload statement.....                 | 208      | show security flow session destination-prefix    |               |
|                                                 |          | command.....                                     | 412           |

|                                                                 |     |                                           |          |
|-----------------------------------------------------------------|-----|-------------------------------------------|----------|
| show security flow session extensive node<br>command.....       | 416 | syn-check-required .....                  | 36       |
| show security flow session fast-forward<br>command.....         | 446 | syn-flood-protection-mode statement.....  | 214      |
| show security flow session interface<br>command.....            | 427 | syntax conventions.....                   | xix      |
| show security flow session policy-id<br>command.....            | 434 | <b>T</b>                                  |          |
| show security flow session protocol<br>command.....             | 437 | tcp-initial-timeout statement.....        | 215      |
| show security flow session resource-manager<br>command.....     | 442 | tcp-mss statement.....                    | 216      |
| show security flow session session-identifier<br>command.....   | 451 | tcp-session statement.....                | 217      |
| show security flow session source-port<br>command.....          | 455 | technical support                         |          |
| show security flow session source-prefix<br>command.....        | 459 | contacting JTAC.....                      | xxi      |
| show security flow session summary family<br>command.....       | 463 | time-wait-state statement.....            | 218      |
| show security flow session summary fast-forward<br>command..... | 471 | traceoptions statement                    |          |
| show security flow session summary node<br>command.....         | 465 | (Security Flow).....                      | 221      |
| show security flow session tunnel command.....                  | 475 | (Security).....                           | 219      |
| show security forward-options mirror-filter<br>command.....     | 486 | transport                                 |          |
| show security policies command.....                             | 490 | security log.....                         | 224      |
| show security policies hit-count command.....                   | 498 | <b>V</b>                                  |          |
| show security resource-manager group active<br>command.....     | 501 | verification                              |          |
| show security resource-manager resource active<br>command.....  | 504 | selective stateless packet-based services |          |
| show security resource-manager settings<br>command.....         | 507 | .....                                     | 151, 160 |
| show security resource-manager summary<br>command.....          | 509 | <b>W</b>                                  |          |
| show security screen ids-option command.....                    | 510 | weighted round-robin (WRR)                |          |
| show security screen statistics command.....                    | 515 | session distribution.....                 | 47       |
| show security softwires .....                                   | 523 | wing statistics counter.....              | 63       |
| show security zones command.....                                | 524 | <b>X</b>                                  |          |
| show security zones type command.....                           | 527 | x2 traffic monitoring.....                | 132      |
| source-port statement.....                                      | 210 |                                           |          |
| source-prefix statement.....                                    | 214 |                                           |          |
| stateful and stateless data processing.....                     | 3   |                                           |          |
| stateful packet processing .....                                | 3   |                                           |          |
| stateless firewall filters.....                                 | 6   |                                           |          |
| stateless packet processing.....                                | 3   |                                           |          |
| support, technical See technical support                        |     |                                           |          |