



CFS Commands

NX-1# show cfs application

NX-1# show cfs status

NX-1# show cfs peers

NX-1# show vpc consistency-parameters global

NX-1(config)# cfs ipv4 distribute